

41X Pattern Sewing Machine



Forewords

Thank you for using our Computerized Control System for Special Sewing Machine.

It is appreciated that you do read this manual carefully in order to operate the machine correctly and effectively. If the user operates the machine contrary to regulations herein, we will not take responsibility for any loss caused thereby to the user or any third party. Besides, you should keep this manual safely for future use. For any fault or problem of machine, please ask the professionals or the technicians authorized by our company for repair service

Safety Matters for Attention

1 ․ Signs & Definitions of Safety Marks

This User's Manual and the Safety Marks printed on the products are for you to use this product correctly so as to be away from personal injury. The signs and definitions of Marks are as follows:

 Danger	The incorrect operation due to negligence of this Mark will cause the serious personal injury or even death.
 Caution	The incorrect operation due to negligence of this Mark will cause the personal injury and the damage to mechanism.
	This symbol means "things to be noted". The pattern in the triangle indicates what must be paid attention to. (for example, the pattern on the left says, "beware of injuries")
	This kind of marks means "Forbidden".
	This kind of marks means "Must". The figure in the circle refers to the thing that has to be done. (E.g. The left figure is "Grounding!")

2 ․ Safety Matters for Attention

 Danger	
	For opening the control box, please turn off the power and pull out the plug from the socket first, and then wait for at least 5 minutes before opening the control box. Touching the part with high voltage will cause personal injury.
 Caution	
Using Environment	
	Try not to use this sewing machine near the sources of strong electric disturbance like high-frequency welding machine. The source of strong electric disturbance may affect the normal operation of the sewing machine.
	The voltage fluctuation shall be within $\pm 10\%$ of the rated voltage. Large-scaled voltage fluctuation will affect the normal operation of the sewing machine, where a voltage regulator is necessary.
	Working temperature: $0^{\circ}\text{C}\sim 45^{\circ}\text{C}$. The operation of the sewing machine will be affected in environment with temperature beyond the above range.
	Relative Humidity: 35%~85% (No dew inside the machine). Otherwise, the operation of the sewing machine will be affected.
	The supply of compressed gas shall be over the consumption required by the sewing machine. The insufficient supply of compressed gas will lead to the abnormal action of the sewing machine.
	In case of thunder, lightning or storm, please turn off the power and pull out the plug from the socket, for the operation of sewing machine may be affected.
Installation	
	Please ask the trained technicians to install the sewing machine.
	Don't connect the machine to power supply until the installation is finished. Otherwise the action of the sewing machine may cause personal injury once the start switch is pressed by mistake.
	When you tilt or erect the head of sewing machine, please use both of your hands in that operation. And never press the sewing machine with strength. If the sewing machine loses its balance, it will fall into floor thus causes the personal injury or

	mechanical damage.
	Grounding is a must. If the grounding cable is not fixed, it may cause the electric-shock and mis-operation of the machine.
	All the cables shall be fixed at least 25mm away from the moving components. By the way, don't excessively bend or over-tightly fix the cable with nails or clamps, or it may cause the fire or electric shock.
	Please add security cover on the machine head.

Sewing	
	This sewing machine can only be used by the trained staff.
	This sewing machine has no other usages but the sewing.
	When operating the sewing machine, do put on the protection glasses. Otherwise, the broken needle will cause personal injury if it hurts the eyes.
	Under following circumstances, please cut off the power at once so as to avoid the personal injury caused by the mis-operation of start switch: 1. Threading on needles; 2. Replacement of needles; 3. The sewing machine is not at work or beyond supervision.
	During working, don't touch or lean anything on the moving components, which will cause personal injury or damage the sewing machine.
	During working, in case of mis-operation, or abnormal noise or smell, user shall cut off the power at once, and then contact the trained technicians or the supplier of that machine for solution.
	For any trouble, please contact the trained technicians or the supplier of that machine.
Maintenance & Inspection	
	Only the trained technicians can perform the repair, maintenance and inspection of this sewing machine.
	For the repair, maintenance and inspection of electrical components, please contact the professionals at the manufacturer of control system in time.
	Under following circumstances, please cut off the power and pull out the plug at once so as to avoid personal injury caused by the mis-operation of start switch: 1. Repair, adjustment and inspection ; 2. Replacement of components like curve needle, cutter and so on.
	Before the inspection, adjustment or repair of any gas-driven devices, user shall cut off the gas supply till the pressure indicator falls to 0.
	When adjusting the devices with the power supply and gas supply on, users can't be too careful at following the entire Safety Matters for Attention.
	In case of damages of the sewing machine caused due to unauthorized modifications, our company will not be responsible for the repair.

1 General Information.....	119
1.1 General Introduction	119
1.2 Functions and Parameters	121
1.3 Matters for Safe Using.....	123
1.4 The Preventive Measures in Use	125
1.5 Standardization	127
1.6 Operation Method.....	127
2 Operation Instructions	128
2.1 Basic Operation	128
2.2 Instructions on Interface Display Status	130
2.2.1 Interface 1 (Main Interface P1: Standard Display Status)	130
2.2.2 Interface 2 (Display Status after Users Press NEXT in Main Interface P1)	130
2.2.3 Interface 3 (Catalogue Mode in Main Interface P1)	131
2.3 Instructions on Main Interface P1.....	132
2.3.1 Pattern Stitch Number Display	134
2.3.2 Speed Adjustment.....	135
2.3.3 Operation of Pattern Number Hot key	136
2.3.4 Pattern Display.....	137
2.3.5 Sewing Fabric Thickness Setting.....	138
2.3.6 Add counter setup	139
2.4 Main Interface P2	140
2.4.1 Winding Mode.....	142
2.5 Load Pattern.....	145
2.5.1 Operation Instructions:	146
1、Open the Interface to Load Pattern	146
2.5.2 Direct Load Mode.....	147
2.5.3 Delete Pattern.....	148
2.5.4 Supported Data Format.....	148
2.6 Save Pattern	149
2.7 Figure play version	151
2.8 Operation Setting	154
2.8.1 Setting Method.....	154
2.8.2 Types of Parameter Setting.....	157
2.8.3 Parameter Encryption	158
2.8.4 Recovery and Back-up of Parameters.....	160
2.8.5 Default Parameter Recovery	161
2.8.6 Parameter List.....	164
2.9 Test Mode	188
2.9.1 LCD Test	190
2.9.2 Touching Screen Correction	190
2.9.3 Input Signal Test.....	191
2.9.4 Main Shaft Speed Test.....	193
2.9.5 Output Signal Test	193
2.9.6 Continuous Running	196
2.9.7 XY Motor Origin Test	196
2.9.8 Main Motor Installation Angle Adjustment.....	197

2.9.9 Intermediate Presser Test.....	197
2.10 Function Setting.....	198
2.10.1 Version Inquiry Mode.....	200
2.10.2 Pattern Connection Mode	201
2.10.3 Version Inquiry Mode.....	204
2.10.4 Hotkey Setting	205
2.10.5 Data Transfer Mode	206
2.10.5.1 Data Transfer Mode	207
2.10.5.2 Formatting Mode	209
2.10.5.3 Pattern Transformation in Batch.....	210
2.10.6 Back-up Recovery Mode	210
2.10.7 Default Parameter Mode.....	210
2.10.8 Encrypt.....	211
2.10.9 Password Mode.....	212
2.10.10 Date and Time Setting	217
2.10.11 Alarm Record Mode	219
2.10.11.1 Error Note	219
2.10.11.2 Run Note.....	220
2.10.12 Update Mode	221
2.10.13 System Para	222
2.11 Letter Sewing Edition	223
2.11.1 Parameters of Letter Sewing.....	224
2.11.2 Adjustment of Letter Sewing Pattern.....	228
3 Appendix 1.....	231
3.1 Warning Information List	231
3.2 Hint Information List.....	244
4. Appendix 2	252
4.1 Operating box mounting dimensions	252
4.2 Control box mounting dimensions.....	253
4.3 Diagram and Cable Connection.....	254

1 General Information

1.1 General Introduction

Mitsubishi series computerized control system for industrial sewing machine: 1) Adoption of the world leading AC servo control technology on main shaft motor provides large torque, high efficiency, stable speed and low noise; 2) Diversified design of control panel can meet the special requirements of users on attachment; 3) System adopts German style structure, which greatly facilitates the installation and maintenance.

1.2 Functions and Parameters

NO.	Type of Controller	Computerized Control System for Pattern-sewing Machine
1	Sewing Area	X(Lateral) Direction Y(Longitudinal) Direction 600(mm) x 400(mm)
2	Max. Sewing Speed	3000rpm (with stitch interval below 3mm)
3	Stitch Length	0.1~12.7mm (Min Resolution: 0.10mm)
4	Feed Motion of Frame	Intermittent feeding (2-shaft driven by pulse motor)
5	Needle Bar Stroke	41.2mm
6	Needles	DP×5、 DP×17
7	Lift of Frame	Standard 18mm to Max. 22mm (Pneumatic type: Max. 25mm)
8	Intermediate Presser	Stepping Driving (Range: 0~8mm)
9	Lift of Intermediate Presser	20mm
10	Memory of Pattern Data	Memory/U Disk
11	Pause function	Stop the machine during the sewing
12	Scaling Up/Down Function	Allows a pattern to be scaled up/down on the X axis and Y axis independently when user sews a pattern. Ratio: 1% to 400% (0.1% per step)
13	Scaling Up/Down Method	Increasing / decreasing stitch length & Increasing / decreasing stitch number
14	Sewing Speed Limitation	200~3000rpm (100rpm per step)
15	Pattern Selection Function	Pattern No. selection method
16	Up counter	No Count/Count of Pattern /Count of Cycle (0~99999)
17	Down Counter	No Count/Count of Pattern /Count of Cycle (0~99999)
18	Sewing Machine Motor	Servo Motor
19	Stop Needle at Highest Position Function	After the completion of sewing, the needle can return to its highest position.
20	Rated Power	600W
21	Operation Temperature Range	0℃~45℃
22	Operation Humidity Range	35%~85% (No Dew Condensation)
23	Line Voltage	AC 220V ± 10%; 50/60Hz

※ Effective standard for product: QCYXDK0004—2020 Computerized Control System for Industrial Sewing Machine.

1.3 Matters for Safe Using

● Installation

- Control Box
 - ◆ Please install the control box according to the instructions
- Attachments
 - ◆ If other attachments are needed, please turn off the power and pull out the power plug.
- Power Cable
 - ◆ Do not press power cables forcefully or twist power cable excessively.
 - ◆ The power cables shall be fixed at least 25mm away from the rotating component.
 - ◆ Before powering the control box, user shall carefully check the voltage of power supply and the position of power input on the control box. If the power transformer is used, user should also check it before powering the machine. The power switch of the sewing machine must be set as “Off”.
- Grounding
 - ◆ In order to avoid the noise disturbance and electric shock caused by electric leakage, user should ground the grounding cable.
- Attachments
 - ◆ If any electric attachments are needed, please connect them to proper positions.
- Disassemble
 - ◆ When removing the control box, user must turn off the power and pull out the power plug.
 - ◆ When pulling out the power plug, user should hold the plug and remove it, instead of pulling the power cable only.
 - ◆ The control box contains the dangerous high voltage power. For opening the control box, please turn off the power and pull out the plug from socket first, and then wait for at least 5 minutes before opening the control box.

● Maintenance, Inspection and Repair

- Only trained technicians can perform the repair and maintenance of this machine.
- When replacing the needles and shuttles, user should turn off the power.
- Please use the spare parts from the authorized manufacturers.

● Others

- Do not touch the rotating or moving parts of the machine, especially the needle and belt, when the machine is working. User should also keep his/her hair away from those moving parts, so as to avoid the danger.
- Do not drop the control device on the floor, nor insert any stuff into the slots on the control box.
- Do not run the machine without the cover shells.
- If this control device is damaged or unable to work normally, please ask the technicians to adjust or repair it. Do not run the machine when the problem is not solved.
- Please do not change or modify this control device without authorization.

● Abandonment

- Dispose it as common industrial trash.

● Warning and Danger

- The mistake operation may cause danger. For the serious level, please refer to the figure below:

 Warning	The wrong operation may cause serious injury or death.	 Caution	The wrong operation may cause personal injury or loss of property.
--	--	--	--

- The meanings of the marks are shown below:

	Please operate machine according to instruction		Caution:High Voltage
	Caution:High Temperature		Grounding is a must
	Never do this		

1.4 The Preventive Measures in Use




Warning


1. When you press the switch [ON], please do not step the pedal.




2. When you leave the machine, please turn it off.




3. If user needs to tilt the head or replace the needle or thread the upper thread, please turn off the power.




4. Ground well the grounding cable.



5. Do not use the household terminal block to let machines to share one power supply.




6. For opening the control box, please turn off the power and pull out the plug from socket firstly, and then wait for at least 5 minutes before opening the control box.




7. After replacing the motor, user has to adjust the main motor installation angle according to this manual.

8. Please keep it away from the disturbance of high frequency machines.




9. If user needs the external signal socket to connect the attachments, the connecting wire shall be as short as possible. The long cable may cause mistake operations. And the connection cable shall be the shielded.



10. If the fuse is burnt, please solve the problem before replacing a new one with same capacity.

1.5 Standardization

The function keys use figures commonly recognized within the industry. Figures, as international language, are recognizable to users in every country.



1.6 Operation Method

The Mitsubishi type touching panel adopts the advanced touching operation technology, whose user-friendly interface and easy control bring the revolutionary changes to the daily usage of the users. For performing relevant operations, user can use his fingers or other objects to touch the screen.



Warning


Don't use sharp objects to touch the screen so as to avoid causing permanent damage to the touch panel.

2 Operation Instructions

2.1 Basic Operation

1、 Turn on Power Switch

After user turns on the power, the main interface P1 will be displayed.



2、 Pattern for Sewing

Display the selected pattern in the current interface. If user wants to change the pattern, he should refer to section [2.5 Load Pattern].


3、 Start Sewing

① Before the actual sewing, user need confirm the settings of the sewing conditions again, especially the setting of the speed (Range: 0~9).

② The speed of sewing machine is determined by the speed value and stitch interval. The speed value will determine the max speed of sewing machine, while the stitch interval will limit the speed of sewing machine.

[Note]: Do not change the speed value during the sewing, except the condition of pause, otherwise it may cause influence on the thread-withdrawing condition.

③ Put the sewing material to the appointed position, step the frame switch (black one) to lower the frame and step the running switch (grey one) to start the actual sewing. Once the sewing starts, user will not need to continue stepping on the running switch. When the sewing machine finishes the work, the frame will go up automatically.




4、 Pause

If user wants to stop the machine during the sewing, please press the emergency stop button on the head (Please refer to the following figure for details). After user presses that key, the sewing machine will stop at the

upper position (default setting) and enter the pause status. For releasing the pause status, please press that emergency stop button again. Then user can continue to perform the following operation:

- ① Step on the running switch to continue the sewing;
- ② Press Forward Moving/ Backward Moving to change the sewing start position;
- ③ Step on the frame switch to lift frame;
- ④ Change the speed value of sewing machine; and/or
- ⑤ Move the intermediate presser.



5、 Method for Mending the Sewing


User can use the pause function to perform the mending sewing. If user presses emergency stop key in case of thread-breakage, the needle will stop at the upper position. Press backward moving key to move the frame to the position that is two or three stitches before the thread-breakage point, finish threading and step the running switch to continue the sewing.




Note: never use your foot to step on the running switch when threading. It is very dangerous to run the sewing machine when threading, so be sure to remove your foot from the running switch when threading.

2.2 Instructions on Interface Display Status


2.2.1 Interface 1 (Main Interface P1: Standard Display Status)



2.2.2 Interface 2 (Display Status after Users Press NEXT in Main Interface P1)




2.2.3 Interface 3 (Catalogue Mode in Main Interface P1)



Functions:

No.	Function	Content
A	MENU Function Interface Title	The displayed content is the interface title of the MENU. When user press the button, the displayed content in the title bar will become the functional description of the corresponding key.
B	Pattern management (adding, deleting, checking and saving graphic data)	After entering the interface, execute the corresponding functions to search, sort, delete, save, read and other related operations for patterns.
C	Save Pattern (Save Pattern Data)	Save the pattern to memory or U disk
D	Edit Pattern (Pattern Design Mode)	Edit the pattern
E	Modify Pattern (Modification Mode)	Modify the pattern
F	Data Transformation (File Transformation Mode)	Transform the data
G	Operation Setting	Set the operation parameters
H	Test Mode	Test the external devices, LCD screen and so on.
I	Function Setting	Perform the function operations
J	Letter Sewing Edition	Perform letter sewing edition. [Note]: User can close letter sewing edition function via Parameter “Special” -> “Enable Letter Sewing”. The figure will disappear when it is deactivated.
K	Quit	Quit the current interface, and return to the upper interface.

2.3 Instructions on Main Interface P1




Functions:

No.	Functions	Content
A	Up-counter	Display the current value/set value of the Up-counter .
B	Down- counter	Display the current value/set value of the Down- counter .
C	The robbin counter's alarms number of stitches	Perform data setup operations
D	Date/Clock	Show time
E	Pattern Name	Display the name of current pattern
F	Pattern Shape	Display the shape of the current pattern [Note]:  is the position of origin.
G	Pattern Number Hot Key	Display the recently used pattern numbers, at most 40 numbers can be saved. Pressing the pattern number will activate that pattern for sewing. [Note]: In combined pattern sewing mode, the displayed content is the sub-pattern numbers and their number.
H	Pattern Selection Function	Pattern No. selection method
I	Speed Adjustment Area	Adjust and display the sewing speed of the current pattern
J	MENU	Display the catalogue (refer to [2.2.3 Interface 2])
K	Enter Main Interface P2	Press it to enter Main Interface P2.
L	Herringbone sewing template pattern setting key	Press this button to enter,parameters of herringbone seam can be set
M	Forward key	Press this key,X-Y (frame) will move forward on the pattern
N	Display the data	Displays the current pattern data
O	Copy pattern key	Press this button to enter, you can choose the pattern you need
P	Threading key	Press this key to thread
Q	Intermittent presser foot setting	Adjust the intermittent presser foot height
R	Trial sewing key	Trial sewing operation
S	Template lock key	Lock the pattern template used

No.	Functions	Content
T	The winding key	You can set whether to winding
U	Forward key	Move forward moves the sewing needle forward
V	Convert / zoom key	Press this key to enter and select the pattern you need


2.3.1 Pattern Stitch Number Display



Functions:

No.	Descriptions
A	Display the current frame position and sewing data type. (Sewing “SEW”, Feed “FEED”, Sub-origin “2HP”, Upper Stop “USTP”, Down Stop “DSTP”, Thread-trimming “TRIM”, Feed Speed “FEDS”, Restart “ASRT”, Board Heavy “HEVI”, Fabric Thick “ATUM”, Jump Sewing “BAT”, Function 1 “FUN1”~Function 7 “FUN7”, Reverse Presser Feet “REPF”, End “END”)
B	Display the stitch number at current position
C	Display the total stitch number of the current pattern (Including Feed, Thread-trimming, End, Code, etc.)
D	The distance that X/Y has traveled
E	Size of Pattern in X Direction
F	Size of Pattern in Y Direction
G	The time when the pattern was created


2.3.2 Speed Adjustment



Functions:

No.	Description
A	Increase the speed
B	Current sewing speed (200~2700) Display as speed value, if click this icon, you can jump to the standard parameter setting interface -- shortcut operation
C	Reduce the speed


2.3.3 Operation of Pattern Number Hot key




Functions:

No.	Description
A	Pattern number hot key (Current pattern: Displayed in white figure on blue background), select other number to shift the pattern.
B	Pattern number display page turn key

Example:




As shown in the figure, the shortcut key list in this example contains 2 pattern numbers. The current pattern number is 001. If we select pattern No. 002, the current pattern will be shifted to pattern No.002



As shown in the figure, This example selects the number 002 pattern, the current pattern will be shifted to pattern No.002

2.3.4 Pattern Display

In the Main interface P1, click the pattern display area to enter the pattern preview interface



Functions:

No.	Description
A	Pattern Name
B	Pattern Number
C	Size of Pattern in X Direction
D	Size of Pattern in Y Direction
E	Display Total Stitch Number of Pattern (Including Feed, Trimming, End, Code and so on).
F	Displays the current pattern type
G	Pattern Display.
H	Quit current interface and return to the previous interface.
I	Free space in memory display
J	The pattern display interface is cyclically enlarged


2.3.5 Sewing Fabric Thickness Setting

The lowest position of the intermediate presser is changeable. If the lowest position of intermediate presser in the default setting is lower than the thickness of the used fabric, user can use this function to change it.

[Note]: If users enter this interface when the intermediate presser is at down position, the system will hint “Lift Intermediate Presser”.

[Note]: After entering the interface for setting the fabric thickness: only when the intermediate presser goes down, can user set this parameter.

[Note]: The range of this parameter is 0.0~8.0mm.



Functions:


No.	Description
A	Current Height of Intermediate Presser
B	Target Height of Intermediate Presser
C	Increase Height The intermediate presser goes up by 0.1mm at each pressing
D	Decrease Height The intermediate presser goes down by 0.1mm at each pressing
E	Quit the current interface and return to the previous interface.
F	Move needle vertically.  : Needle down  : Needle up
G	Press it to move the intermediate presser in the arrow direction  : Intermediate presser up  : Intermediate presser down

H	Save and Quit
I	Height setting of presser foot
G	Two - stage presser foot setting

2.3.6 Add counter setup

Push down **00000/99999** in P1 to enter the setting interface of adding counter.

[Note] Counting mode of add/subtract counter is determined by the "counter" parameter in operation setting mode (refer to parameter description in [2.8.6 parameter setting table]).




Functions:

No.	Content
A	Shift the input between the set value and the current value (The button in shadow is the selected one).
B	Display the set value and current value (User can input the value in the dotted frame)
C	Up Counter Switch
D	Clear current value.
E	Quit counter setting mode and return to previous interface.
F	Clear the value inputted currently
G	Number keyboard, used to input set value and current value
H	Confirm the setting

[Note] The subtraction counter setting operation is the same as the addition counter operation.

2.4 Main Interface P2



Functions:



No.	Functions	Content
A	Main motor Angle setting	Set the Angle of main motor. The following number represents the Angle of the current angle.
B	wiper	Thread wiping output detection.
C	Trimming	Thread Trimming output detection.
D	Presser	Presser foot output detection.
E	Middle-presser foot	M-presser foot output detection.
F	Release	Thread release output detection.
G	Reverse Presser	Reverse Presser foot output detection
H	Auxiliary valve 1	Auxiliary valve 1 output detection
I	IO configuration	IO configuration parameters
J	Input signal	Input signal test
K	Reverse Pressers foot	Reverse presser output detection
L	Auxiliary valve 2	Auxiliary valve 2
M	Auxiliary valve 3	Auxiliary valve 3
N	MENU key	Display the catalogue
O	Reset button	The sewing needle goes back to its original point
P	Winding pattern	Can be set whether winding
Q	Thread Looser current	Set the current of Thread loosening device when threading
R	Needle Positin Setup	: The needle down  : The needle up
S	X lock shaft	X axis lock /release
T	Y lock shaft	Y axis lock /release
U	Trimming	Thread Trimming output detection.

V	Return key	Press it to return to the main interface 1
W	Coordinate values	Displays X/Y coordinate values

2.4.1 Winding Mode

For winding, user has to activate this interface . Step the frame switch to lower the frame and then step the running switch to run the sewing machine at the set speed. But the X & Y axis will not move. Step on the pedal again and the machine will stop in the up position.


[Note]: The winding action is determined by the parameter “Winding” set in the Operation Setting Mode. (Please refer to [2.8.6 Parameter List])



Functions:

No.	Description
A	Whether winding is allowed before origin detection
B	Actual winding speed setting. [Note] Decided by the parameter "winding core" -> "winding speed setting".
C	Winding stop mode setting. [Note] Decided by the parameter "winding core" -> "winding stop-mode setting".
D	Timed stop winding time setting. [Note] Decided by the parameter "winding core" -> "timing stop winding time setting".

2.5 Load Pattern



Functions:

No.	Functions	Content
A	Pattern preview list	Display the list of the saved pattern (Both number and name will be displayed). [Note 1]: If user selects pattern in VDT format, system will ask user to transform the pattern format. [Note 2]: If the stitch number of the selected pattern is over range or the data is damaged, the system will hint that the pattern is unable to be selected.
B	Pattern No List	Display the list of the saved pattern number.
C	Return to Main Interface	Return to main interface directly
D	Find patterns	Find patterns
E	Sequencing	Sequence the patterns according to their modification time or number.
F	Delete Pattern	Delete the selected pattern. [Note]: The currently sewing pattern cannot be deleted.
G	The save button	You can save the specified pattern
H	Access key	Select a pattern from memory or USB drive as the current sewing pattern.
I	Select Memory/ U Disk	Load pattern from memory or U disk Shift between U Disk and Memory
J	Enter	Confirm the operation. After the operation, the sewing pattern will turn to the newly selected pattern.
K	Page down	Page down to look up interface
L	Page	Display current page number/ total page number
M	Page up	to look up interface
N	Pattern Display	Can preview patterns

2.5.1 Operation Instructions:




1、 Open the Interface to Load Pattern

In main interface P1 (or P2), press  to activate the catalogue mode, and then press .

[Note]: If the moving frame is not at the origin, the system will be unable to load pattern. Therefore, please perform the operation for returning to origin first.

2、 Select the Object for Loading (Memory/ U Disk)

The default setting in this interface is the Memory Load Mode. You can press  to shift to U Disk Load Mode, which is shown at below.



[Note]: If user performs the above operation without inserting the U disk, the system will display “U Disk Is Pulled Out”.




3、 Select and Confirm Pattern Number

Select the pattern number for sewing and then press . After the selection, the system will return to the main interface directly.

[Note]: If the pattern with the same number exists in the memory when user loads pattern from U disk, the system will display “Replace Pattern in Memory?”. At this moment, user need follow the given instructions.

4、 Other Operations

If there are many patterns, user can use  for page turning and press  to view the pattern list more directly. If user knows the pattern number, he can use  to load the pattern directly.

2.5.2 Direct Load Mode



1、 Select Direct Load Mode

Press  in pattern loading interface to enter the Direct Load Mode.

[Note]: To load pattern by directly inputting the pattern number is limited to the memory load mode.




2、 Input the First Number

(E.g. Load pattern No.01)

- ① Input “1”.
- ② The patterns saved in the memory whose first number is 1 will be displayed on the bottom keyboard as below:

- ③ Press  to clear the inputted number and re-input them.

- ④ At this moment, press  to activate the pattern and then the system will return to the main interface and display the selected pattern.



3、 Switch English to Chinese

- ⑤ pattern search, you can input Chinese, switch to the Chinese input method mode to enter the search pattern.

2.5.3 Delete Pattern




User can press  to delete a pattern. At this moment, the system will display “Delete Pattern from Memory?” (If the system is at U Disk Load Mode, the system will display “Delete the Selected File?”). User need follow the given instructions, but the pattern being sewn cannot be deleted.

2.5.4 Supported Data Format

At present, the supported formats by the system are: NSP format, B format, BA format, VDT format, EMB format, DST format, DSB format, DSZ format, SEW format.


2.6 Save Pattern



Function:

No.	Functions	Content
A	Input Pattern Name	Display the pattern name
B	Input Pattern Number	Display the pattern number
C	Memory surplus function	Look at the amount of memory left
D	Display storage location	 : The storage location is memory  : The storage location is a usb flash drive
E	Keyboard	Input name or number
F	Return key	Return to the previous screen
G	Clear All Characters	Press it to clear all the inputted characters
H	Keep Pattern with Same Number	<input checked="" type="checkbox"/> keep the same number pat: Choose to keep the same number pattern, save the same pattern, pattern number is different <input type="checkbox"/> keep the same number pat: not to keep the pattern with the same number
I	Select Memory/ U Disk	Select read memory or U disk pattern, toggle to select U disk or memory
J	Identify key	Save the current Settings and exit to the previous screen

Operation Instructions:



1、Enter the pattern save interface

In main interface P1 (or P2), press  to activate the catalogue mode, and then press .

[Note]: If the moving frame is not at the origin, the system will be unable to save pattern. Therefore, please perform the operation for returning to origin first.

2、Set Name and Number

The default setting in this interface is the Memory Save Mode (you can see  at the upper left of the screen). You can press  to shift to U Disk Save Mode.

Press or to input the name or number.

Pressing **Backspace** is to delete the first character at the left of the cursor, while pressing  is to clear all the characters.

If user need shift between capital and small letters, please press **Caps**.


[Note]: User can decide the number for a pattern before saving; the filename of a pattern consists of “Pattern Name” + “@Pattern Number” + “Format Type.nsp”.

3、Save Pattern



After the input, press  to return to the main interface directly

[Note]: If the memory contains the pattern with the number same to that of the inputted one, the system will display “Replace Pattern in Memory?”

Press  to cancel the replacement; press  to perform the replacement.



2.7 Figure play version



Under the main interface P1 interface, click the menu key  → pattern typesetting key  to enter the pattern typesetting interface.

(1) Whether to re-enter

If you want to replace the entered data with a new one, press  (clear the last copy, reprint).

If you want to continue with the data you have entered, press  (continue with the last version).

(2) Set Speed

Click four speed buttons in the interface to select different speeds: 

(3) Set the pitch

Through the  ~  digital key and  ~  key, you can enter the pitch, ranging from 0.1 mm to 12.7 mm.


(4) Graphical parameter modification

There are parameter keys  in the interface for printing, modifying, and converting, and the related parameters are concentrated to facilitate user settings.

(5) Determine input

After the above data setting is completed, press the key  to enter the cursor input interface.

Supplementary Instructions



No.	function	content
A	X relative coordinates	Displays the relative coordinate X value of the current move. (In parentheses is the difference between the position of the cross cursor and the pattern)
B	Y relative coordinates	Displays the relative coordinate Y value of the current move. (In parentheses is the difference between the position of the cross cursor and the pattern)
C	X absolute coordinates	Displays the X value of the current coordinates.
D	Y absolute coordinates	Displays the Y value of the current coordinates.
E	Stitch length	Displays the set stitching distance. [Note] Air feeding needle distance is 12.0mm
F	Speed	Displays the current needle speed.
G	Code	Displays the current input code.
H	Needle count	Display the number of pins/total number of pins in the current machine needle position.
I	Number of shape points	The number of shapes entered during the current editing process.
J	Relative value of intermediate presser height	Displays the current intermediate presser height relative value
K	Absolute value of intermediate presser height	Displays the current intermediate presser height absolute value
L	Typesetting	Various typing functions.
M	Amplification	The pattern can be enlarged
N	Cancel last input	Press this key to cancel the last determined input point and return to the previous input point.
O	Change sewing machine speed	Press this button to switch sewing machine speed successively: low

No.	function	content
		speed, high speed, medium high speed, medium low speed.
P	Direction key	Move the frame in all directions.
Q	Table move speed set	The range is 1~3
R	Enter	Confirm the current edit shape.
S	Second origin	After the transfer, a second origin can be inserted at the current position.
T	Close	Closing function.
U	Needle position setting key	Raise or lower the needle position
V	Machine needle position setting key	Make the needle position rise or fall
W	Intermediate presser up	Adjust the intermediate presser to rise
X	Return to origin	Press and then execute the return to origin command.
Y	Quit	Return to the previous screen.
Z	Menu	Go into directory mode.
AA	Inching Movement(Click Move button)	 : make inching movement forward/backward on generated pattern.  : make fast inching movement forward/backward on generated pattern.
AB	Pattern screen display	Display the current printing pattern

2.8 Operation Setting

It is to set each parameter. For the description of each parameter, please refer to [2.8.6 Parameter List].

2.8.1 Setting Method



1、 Enter Operation Setting:

In main interface P1 (or P2), press  to activate the catalogue mode, and then press  .

2、 Interfaces at Setting Mode

After entering the operation setting interface, There are many parameters can be chose , user can use   to turn the pages for selecting parameters.




3、 Example :

① Mode Selection


Select the parameter for setting to activate the “Internal Parameter Setting Interface”. Here, we press “Presser foot”





② Internal Parameter Setting Interface


Select the parameter for setting to activate the “interface for changing the set value”. (We press “E-9” here.)



③ Change Set Value of Parameter


Press parameter to change the set value (here, we press “ON”). Then, press  to confirm it.

[Note]: Pressing  is to display the descriptions of that parameter and its value.



④ Check the Changed Parameter Set Value

Return to the “Internal Parameter Setting Interface”, where user can check the set value after change. Press  to quit.



⑤ Return to Mode Selection Interface

Return to “Mode Selection” interface. Because the set value is changed, the button “Modified” is displayed.

For returning to main interface P1 (or P2), please press .

For checking the modified content, please press the “Modified” key.



⑥ **View the modified parameters**

a) Enter password input mode

In the "Mode Selection" screen, press the "Modified Settings" button. After the password is entered correctly, the modified parameter setting mode will be entered. (See [2.8.3 Parameter Mode Encryption Instructions] for more information on password setting.)



b) Enter Modified Parameter Setting Mode


In this interface, the modified content of the parameter will be displayed. User can modify it again in this interface (Here, press "E-9").

If user wants to restore the modified parameters, he should press the button with the name of that parameter (Here, he can press "Pedal Operation Method") and then click "Restore". After that user only needs to follow the instruction of the system.


If user wants to restore the entire setting to their default values, he can press "Restore All". After that user only needs to follow the instruction of the system.

2.8.2 Types of Parameter Setting

There are two ways for setting parameter: selection type and input type, as shown below:



Selection Type



Input Type

2.8.3 Parameter Encryption


In the parameter mode, each operation entrance can be attached a password, so as to avoid the mistake operation.



1、Enter Parameter Encryption Interface:

In main interface P1 (or P2), press  to activate the catalogue mode, and then press  to Enter the interface for setting functions.

In the function setting interface, press .



2、Select Parameter for Encryption:

As shown in the picture, user can select one or many parameters for encryption. (Here, we select “Bobbin Winding”.)


Bobbin Winding: Selected

Bobbin Winding: Unselected

After selecting the parameter for encryption, user can press .

From then on, user has to input password when setting the parameter that was encrypted.

For changing password, please press .





3、Change Password

In the interface of setting new password,

press **Cur-Password:**

New-Password: &

Confirm: in

order and input the current password, new password, new password confirmation respectively. At last

press .

[Note]: The original password is the manufacturer ID. After setting the password, the current password is the password set last time.

2.8.4 Recovery and Back-up of Parameters


User can save the changed parameter into U disk for the recovery operation in future.



1、Enter Interface of Parameter Recovery and Back-up:

In main interface P1 (or P2), press  to activate the catalogue mode, and then press  to Enter the interface for setting functions.

In the function setting interface, press  to




2、Back up Parameters

Enter the restore backup parameters interface. By default, backup user parameters.

After inserting the usb flash drive, press . Once the operation is successful, a "bakParam" directory will be automatically created on the usb flash drive. The "backup.param" file in this directory is the parameter backup file.


[Note] if there is a file with the same name, it will be stamped with new data and the original data will disappear.



3、Restore parameters


Click the "restore mode" key to select the parameters that are not restored on the left side of the interface, and

then press the "ok" key  to perform the parameter restore operation, and return to the previous screen after the operation is successful.



4、Save user defaults

Select the "write user default value" key, press the "ok" key , the system will prompt for the input of permission 2 password, after the successful input will directly perform this operation.



5、Clear user defaults

After successfully writing the user default value, the "clear user default value" key is optional, and the user default value can be cleared by pressing .


2.8.5 Default Parameter Recovery

User can restore the parameters to their default values. Additionally, user can also save the set parameters for the usage in future.



1、Enter Default Parameter Recovery:

In main interface P1 (or P2), press  to activate the catalogue mode, and then press  to enter the interface for setting functions.



In Function Setting Interface, press  and then input the password (the original password is the manufacturer ID). With the correct password, user can enter Default Parameter Mode




2、 Use the Default Parameter

Click the corresponding default parameter and then press “System Default” to reload that value

After the reloading, the system will return to the upper interface automatically.

[Note] Some important parameter, like “Spindle Motor Stop Angle” cannot be restored in this operation.



3、 Save Customized Parameter

Press “Custom” to enter the interface of Customized parameter setting interface, where user can save the parameter set value.

Click  ~
 to confirm the position for saving, and then click  to save it.

After the saving, the system will return to the upper interface automatically

[Note] After saving, it will exit automatically and return to the previous screen.



4、 Load Parameter Saved by User

The method to enter the interface is the same as above, Check the content on button “Customized Parameter xx (Y/N)”. If it is Y in the bracket, it means there is saved customized parameter.

Click that key and press  to reload the corresponding parameter. After the operation, the system will return to the upper interface automatically.

2.8.6 Parameter List

1、Wiper

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
566	Trapper	Switch of needle lifter			OFF:The wiper is off ON:The wiper is on	0	Choose
557	Line dialer type selection	Line dialer type selection			0:Default 1: Use electromagnet wire sweeping device 2: Use pneumatic line sweeping device	0	Choose
A-1	Dial switch	Line puller (W) output switch			OFF:The wiper is off ON:The wiper is on	ON	Choose
A-2	Puller start time	The starting time of the line puller (W) can be set according to the time of line cutting, usually don't need to change.	ms	2	0~998	30	Input
A-3	Line puller hold time	The holding time of the line puller (W) can be set, which can be set according to the time of line cutting. The time can be extended if necessary	ms	2	0~998	30	Input
A-4	The delayer ends the delay	After the line puller action, delay waiting for the reset mechanism	ms	1	0~255	0	Input
A-6	The wire clip holds the current	The wire clip holds the current		1	0~16	8	Input
A-7	Dial the timing	Dial the timing			0:UP:mid-pressor top 1:MID:mid-pressor top(Down position) 2:DOWN:mid-pressor bottom	0	Choose

2、Thread Trim Sequence

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
150	The inverted needle goes up	Position Angle of needle after cutting thread			0: the needle 1: top dead center	0	Choose
164	Shear line switch	Shear line switch			0:OFF:OFF 1:ON:ON	1	Choose
B-2	Trimming mode	Trimming mode			0:MAG: Solenoid 1:AIR: Air valve 2:MOTOR: Motor	0	Choose

B-3	Shear velocity	Shear velocity	x10RPM	1	10~40	40	Input
B-5	Thread cutting delay	Thread cutting delay	x0.01s	1	0~255	12	Input
B-6	Cutting output startup Angle	Cutting output startup Angle	Degree	2	0~359	210	Input
B-7	Automatically add cutting line when printing	Automatically add cutting line when printing			0:OFF:OFF 1:ON:ON	1	Choose
B-8	Whether to cut the thread before sewing time and space	Whether to cut the thread before sewing time and space			0:OFF:OFF 1:ON:ON	0	Choose
B-9	Whether to cut the thread at the end of sewing	Whether to cut the thread at the end of sewing			OFF:OFF ON:ON	1	Choose
B-10	Correction of parking Angle in upper position after line cutting	Correction of parking Angle in upper position after line cutting	Degree	1	0~100	0	Input

3、Release Thread

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
551	The loose thread setting at the beginning of sewing	Set the number of stitches that the looser will open at the beginning of sewing	stitches	1	0~3	0	Input
552	Loose line synchronization during tangent	Start Angle of loose wire	Degree	2	0~359	300	Input
564	Looser turns on mode	0: Low, open, unlimited 1: in, off, 5 minutes 2: High, off, 1 minute 3: Medium, open, unlimited 4: High, off, 5 minutes 5: Action according to the given value of threading time and threading current		1	0~5	0	Input
567	Whether to open the thread looser after wire cutting by air	Whether to open the thread looser after wire cutting by air			0:OFF:close 1:ON:open	0	Choose

C-1	Type of wire clamper	Type Choose			0:MCN:Mechanical thread nipper 1:ELC:Electrical thread nipper	0	Choose
C-2	Loose wire delay	Loose wire delay			0~255	30	Input
C-4	Thread looser opens delay when threading	Thread looser opens delay when threading			0~255	0	Input
C-5	The wire looser turns on the current when threading	The wire looser turns on the current when threading			0~255	25	Input
C-6	Whether to open loose thread after sewing	Whether to open loose thread after sewing			0:OFF:OFF 1:ON:ON	0	Choose

4、Middle Presser

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
053	Delay time after intermediate presser up	Delay time to prevent colling with mold in movement	ms		0~255	0	Input
054	Intermittent presser foot lowering time	Intermittent presser foot lowering synchronization			0: Before the sewing machine head starts 1: Synchronize with the final presser foot	0	Choose
D-1	Intermittent presser foot type	Selection of intermittent presser foot gas valve, stepping and electromagnet			0:AIR:Air Valve 1:STP:Step motor 2:MAG:Solenoid	1	Choose
D-3	Intermittent presser foot current	Intermittent presser foot current			2~8	4	Input
D-5	Intermittent presser foot stroke setting	Setting of upper and lower values of intermittent presser foot	x0.1mm	2	0~220	150	Input
D-6	Intermittent presser foot lowering delay	Intermittent presser foot lowering delay			0~255	0	Input
D-7	Intermittent presser foot action speed	Intermittent presser foot action speed			8~17	13	Input
D-9	Does the intermittent presser foot follow	Does the intermittent presser foot follow			0:OFF:OFF 1:ON:ON	1	Choose
D-16	Number of stitches reduced by intermittent presser foot	Number of stitches reduced by intermittent presser foot			0~3	0	Input
D-17	Height of intermittent presser foot lowering	Height of intermittent presser foot lowering	x0.1mm		0~30	0	Input

5、Clamp

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
001	Presser foot rising mode after sewing	Presser foot status after sewing			0:After returning to the starting point, the presser foot rises again 1:The presser feet rise immediately after sewing 2:Return to the starting seam first, and then press the foot up after stepping on the pedal	0	choose
002	Left and right separation presser foot descending action (pneumatic)	Separate the presser foot from the left to the right			0: Lower the left and right presser feet simultaneously 1: The presser foot drops left and then right 2: Presser foot first right and then left drop	0	choose
003	Pressure frame drop action (motor)	Motor pressure frame simulates pedal control mode			0: Simulated descent: Decide the descent amount according to the step amount of the pedal, and finally start 1:1 stage drop: the pressure foot drops in the first gear, and starts in the second gear 2 Stage 2 descent: stop in the middle of gear 1, start after gear 2 descent	2	choose
050	Presser foot working mode	0: Standard double pedal, pressing foot pedal controls the big pressing foot, starting pedal starts the sewing 1: Standard double pedal, pressure foot pedal interval control large pressure foot and auxiliary pressure foot lifting, start the pedal to start the sewing 2: Standard double pedal, press foot pedal spacing left and right press foot, start the pedal to start sewing 3: Standard three			0~10	0	input

		<p>pedals, pressing foot pedal to control the big pressing foot, the middle pedal to control the auxiliary pressing foot, the starting pedal to start the sewing</p> <p>4: Left and right presser feet -> intermittent presser feet of 2 sections. Single pedal gear 1 is left and right presser foot, gear 2 is intermittent presser foot, gear 3 controls start. The middle pedal controls the lifting of intermittent presser foot</p> <p>5: 2 sections of presser foot alternately left and right. The pressing foot pedal controls the left and right order of the two pressing feet to be exchanged each time sewing</p> <p>6: Forward/Back Pedal. The press foot pedal controls the left and right press feet to lift up in turn, and the starting pedal controls the left and right press feet to fall down in order, and then presses on to start sewing after all falls down</p> <p>7: Step twice on the 2 stage presser foot. Single pedal control motor presser foot in the middle position, down, start three</p>					
--	--	---	--	--	--	--	--

		<p>position switch, when the presser foot back up. Double pedal pneumatic presser action is the same as mode 2</p> <p>8: Standard three pedal, press foot pedal control motor press foot to the height of the second stage, the middle pedal control motor press foot to drop to the position, start the pedal to start the seam</p> <p>9: Three pedals with origin detection. Special origin detection for the middle pedal, pressing foot pedal to control the lifting of the left and right pressing foot, starting pedal can only start sewing</p> <p>10: Special three pedals with origin detection. Special origin detection of the middle pedal, press foot pedal to control the left and right press foot rise and fall, press the starting pedal automatically down the right press foot and then start</p>					
051	Pressing plate action before origin detection	<p>Check whether the pressure plate before the origin is allowed to move</p>			<p>0: Before the origin detection, the up and down movement of the presser foot cannot be carried out</p> <p>1: Before the origin detection, the up and down movement of the presser foot can be carried out</p>	0	choose

052	Presser foot action during seam breaking procedure	Pressing plate state when stop midway			0: Press down the plate 1: the pressure plate is lifted	0	choose
055	Pneumatic pressure frame output polarity reversal	Pneumatic pressure frame output polarity reversal			0: invalid 1: Pneumatic specifications for valve output reversal 2: Because the two positioning valves correspond to each other, the output reverses the valve output at the same time	0	choose
058	The foot pressing movement at the end of sewing	After the completion of automatic processing, the press plate is lifted			0: The press plate will automatically lift after sewing 1: The press plate does not lift after sewing	0	choose
059	Pressing frame weight selection	Pressing frame weight selection			-1:light 1:Standard 0: heavy	-1	choose
E-1	Press type selection	Press type selection			0:AIR:pneumatic 1:MAG:electromagnet 2:MOTOR:motor	0	choose
E-2	Can we sew when the press is up	Can we sew when the press is up			0:OFF:Can't sew 1:ON:Can sew	0	choose
E-7	Left and right separation pressure plate lifting action	Left and right separation pressure plate lifting action			0:LRT:The press plate is lifted after processing 1:LTD:After finishing the machining, the left press plate is pressed down continuously 2:RTD:After finishing the machining, the right press plate is continuously pressed down	0	choose
E-9	Single foot pedal operation is allowed	Single foot pedal operation is allowed			0:OFF:Prohibit 1:ON:Permit	0	choose
E-10	Two stage press enabler	Two stage press enabler			0:OFF:Prohibit 1:ON:Permit	0	choose
E-11	Height of two stage press plate	Height of two stage press plate			0~255	80	Input
E-12	Press plate stroke setting	Press plate stroke setting			0~200	180	Input

E-13	Pressure plate current setting	Pressure plate current setting			0~15	2	Input
E-14	Delay start setting after pedaling	Delay start setting after pedaling			0:OFF:Prohibit 1:ON:Permit	0	choose
E-15	Start delay after pedaling	Start delay after pedaling			0~200	20	Input
E-16	Whether the external pressure frame is raised at the secondary origin	Whether the external pressure frame is raised at the secondary origin			0:DOWN:Don't lift pressure box 1:UP:Lift pressure box	0	choose

6、Stretch Presser

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
556	Turnover device	Support for turning and stretching the foot 0 - no 1- flip foot (F1 foot) 2- telescopic pressure foot (parking) 3 - F2 presser foot 4 - K presser foot 5- telescopic foot (no stopping)			0~255	0	Input
F-2	Telescopic foot action when returning to the origin	Telescopic foot action when returning to the origin			0:OFF:No action 1:MRH:Move out first and return to the origin 2:HRM:Return to the origin first and then move out	1	Choose
F-3	Extension delay of telescopic press foot	Extension delay of telescopic press foot	x0.01s	1	0~255	30	Input
F-4	Expansion foot rise delay	Expansion foot rise delay	x0.01s	1	0~255	45	Input

F-5	Telescopic foot drop delay	Telescopic foot drop delay	x0.01s	1	0~255	30	Input
-----	----------------------------	----------------------------	--------	---	-------	----	-------

7、Laser Cutting

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
G-1	Laser cutting switch	Laser cutting switch			0:OFF:OFF 1:ON:ON	0	Choose
G-2	Laser cut X offset	Laser cut X offset	x0.1mm		-5000~5000	0	Input
G-3	Laser cut Y offset	Laser cut Y offset	x0.1mm		-2000~2000	0	Input
G-4	Laser cutting speed	Laser cutting speed			1~9	1	Input
G-5	Laser suction switch	Laser suction switch			0:OFF:OFF 1:ON:ON	OFF	Choose
G-6	Laser suction opens the delay	Laser suction opens the delay			0~65535	100	Input
G-7	Laser suction closes the delay	Laser suction closes the delay			0~65535	100	Input
G-8	Delay before laser start	Delay before laser start			0~65535	100	Input
G-9	Delay after the laser head drops	Delay after the laser head drops			0~65535	100	Input
G-10	Delay after lifting the laser head	Delay after lifting the laser head			0~65535	0	Input
G-11	Inflection point deceleration mode	Inflection point deceleration mode			0: OFF: don't start 1:L-ON: laser phase only 2: S-ON starts only at the seam section 3: All laser section and seam section are activated	0	Choose

8、Halt

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
651	According to the stop switch to determine the sewing stop position	Pause timing pin position			0: Positioning of the down needle 1: Positioning of the up needle	1	Choose
652	The tangential action of a	Automatic trimming during			0: Automatic thread	1	Choose

	pause	pause			cutting 1: Don't cut line		
656	Reset mode during pause	Reset mode during pause			0: Moving to start point of sewing after reset 1: Do not return to the origin, and move backward on the sewing track to the starting point of sewing	0	Choose
H-2	Press action during pause	Press action during pause			0: DWN:Clamp down 1: UP:Clamp up	0	Choose
H-3	Pause switch type	Pause switch type			0: often shut 1: often open	0	Choose
H-5	Safety switch type	Safety switch type			0: often shut 1: often open	0	Choose

9、 Thread Breaking Sensor

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
554	Break line detection	Break line detection			0: OFF:Thread Breaking detection off 1: ON:Thread Breaking detection on	0	Choose
555	Detection sensitivity of broken wire detection device	The number of invalid stitches at the beginning of stitching during thread break testing			0~15	8	Input
I-3	The number of invalid stitches during sewing during the detection of broken thread	The number of invalid stitches during sewing during the detection of broken thread	stitches		0~15	3	Input
I-4	Whether to cut the wire when testing broken wire	Whether to cut the wire when testing broken wire			0: ON:Perform thread trimming when thread breaking 1: OFF:Don't perform thread trimming when thread breaking	0	Choose
I-5	Sensitivity of wire break sensor	Sensitivity of wire break sensor			1~10	4	Input

10、 Feed Method

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
200	1 needle test feed cloth	1 needle to detect the feeding mode			0: Push down the foot switch to automatically run to the last stitch	0	Choose

					1: Step down the foot switch and move forward needle by needle. After feeding the cloth, feed the cloth needle by needle by turning the hand wheel		
252	High speed test feeding cloth	High speed test feeding cloth			0: Usually slow step foot switch gear 1 for high speed cloth feeding 1: Test the speed of cloth feeding and sewing	0	Choose
260	Change all feeding synchronizations	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	-3	Input
261	Change sewing to start the first stitch feeding synchronize	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	-3	Input
262	Change sewing to start the 2nd stitch feeding synchronize	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	-3	Input
263	Change sewing to start the 3rd stitch feeding synchronize	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	0	Input
264	Change the feeding synchronization of 3 stitches before the end of sewing	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	-1	Input
265	Change the feeding synchronization of 2 stitches before the end of sewing	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to 8 degrees			-10~10	1	Input
266	Change the feeding synchronization of 1 stitch before sewing	0:-10: in advance 1:0:norm 2:10: delay Each digit corresponds to			-10~10	0	Input

		8 degrees					
267	The number of effective stitches in synchronous feeding	When the total feed synchronization changes from the initial value (set to No.260), specify the number of effective stitches: 0: Unlimited 1~99: If more than the number of stitches specified at the beginning of sewing, return to the standard feeding synchronization			0~99	0	Input
268	Change the base of feeding synchronization	Change the base of feeding synchronization			0: starting datum of cloth feeding 1: needle benchmark 2: the end of cloth feeding benchmark 3: speed linkage	0	Choose
J-1	Sewing type Choose	Sewing type Choose			0:Thin 1:Middle 2:Thick	0	Choose
J-2	Thin material thickness	Thin material thickness			0~255	0	Input
J-3	Medium material thickness	Medium material thickness			0~255	15	Input
J-4	Thick material thickness	Thick material thickness			0~255	30	Input
J-5	Fitting way	Fitting way			0:Stop the lift 1:Pick up and continue to move	0	Choose
J-10	Fast moving mode (type)	The mode of moving two points in printing and graphics modification			0: LINE:Linear movement 1:PAT:Follow the needle	1	Choose
J-15	Moving frame gain curve	Moving frame gain curve			1~3	1	Input
J-16	X axis rigidity fine tuning	X axis rigidity fine tuning			-15~ 15	0	Input
J-17	X axis speed adjustment	X axis speed adjustment			-50~ 50	0	Input
J-18	Y axis rigidity fine tuning	Y axis rigidity fine tuning			-15~ 15	0	Input
J-19	Y axis speed adjustment	Y axis speed adjustment			-50~ 50	0	Input

11、Bobbin Winding

No.	Brief description	Detailed instructions	Unit	Step	Range	Factory	Type
-----	-------------------	-----------------------	------	------	-------	---------	------

				length		value	
056	Whether winding is allowed before origin detection	Whether winding is allowed before origin detection			0:OFF:Can't winding 1:ON:Can be winding	0	Choose
K-1	Winding speed setting	Winding speed setting	x100RPM		2~27	13	Input
K-2	Setting the stop mode of winder	Setting the stop mode of winder			0:Stop winding when pedal up 1:Stop winding when stepping on pedal again 2:Time to stop winding	1	Choose
K-3	Fixed stop winding time setting (unit second)	Fixed stop winding time setting (unit second)	s	2	2~498	30	Input

12、Slow Start

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
100	Sewing start speed	Whether to slow up the needle			0:low speed 1: high speed	0	Choose
151	Fast first stitch start speed	Fast first stitch start speed	x100RPM		2~30	10	Input
152	Fast second stitch start speed	Fast second stitch start speed	x100RPM		2~30	15	Input
153	Fast third stitch start speed	Fast third stitch start speed	x100RPM		2~30	22	Input
154	Fast fourth stitch start speed	Fast fourth stitch start speed	x100RPM		2~30	30	Input
155	Fast fifth stitch start speed	Fast fifth stitch start speed	x100RPM		2~30	30	Input
156	Speed of 5 stitches before sewing	Speed of 5 stitches before sewing	x100RPM		4~27	25	Input
157	Speed of 4 stitches before sewing	Speed of 5 stitches before sewing	x100RPM		4~27	26	Input
158	Speed of 3 stitches before sewing	Speed of 3 stitches before sewing	x100RPM		4~27	12	Input
159	Speed of 2 stitches before sewing	Speed of 2 stitches before sewing	x100RPM		4~27	12	Input
L-1	First start speed	First start speed	x100RPM	1	2~30	3	Input
L-2	Second start speed	Second start speed	x100RPM	1	2~30	7	Input
L-3	Third starting speed	Third starting speed	x100RPM	1	2~30	10	Input
L-4	Fourth starting speed	Fourth starting speed	x100RPM	1	2~30	15	Input
L-5	Fifth start speed	Fifth start speed	x100RPM	1	2~30	20	Input

L-6	The method of seam reinforcement	The method of seam reinforcement			0:None 1:Condensed sewing at the first stitch 2:Backtack at beginning several stitches	0	Choose
L-7	Number of reinforcement stitches	Number of reinforcement stitches		1	-4~4	0	Input
L-8	End reinforcement method	End reinforcement method			0:None 1:Condensed sewing at the first stitch 2:Backtack at beginning several stitches	0	Choose
L-9	End reinforcement needle count	End reinforcement needle count			0~4	0	Input

13、Speed

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
251	Feed speed	The higher the value, the faster the airspeed	file		0~9	7	Input
M-1	High speed setting	High speed setting	x100RPM		2~30	23	Input
M-2	Low speed setting	Low speed setting	x100RPM		2~30	2	Input
M-3	Medium high speed setting	Medium high speed setting	x100RPM		2~30	15	Input
M-4	Medium-low speed setting	Medium-low speed setting	x100RPM		2~30	10	Input
M-5	Transfer delay setting	Transfer delay setting			0~255	0	Input
M-6	Version delay setting	Version delay setting			0~9	4	Input
M-11	Back stitch speed setting	Back stitch speed setting			0~9	7	Input
M-12	Find the interval at the origin	Find the origin time interval (the larger the value, the longer the time)			5~10	7	Input
M-13	Single step speed setting	Single step speed setting			0~40	30	Input
M-14	Sewing speed ratio	Sewing speed ratio	%	5	70~100	100	Input

14、Area Limit

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
460	Set the effective range to the left of X	Set the effective range to the left of X	mm		0~2000	500	Input
460-R	Set the effective range to the right of X	Set the effective range to the right of X	mm		0~2000	500	Input

461	Set the effective range in the Y up direction	Set the effective range in the Y up direction	mm		0~2000	3	Input
461-D	Set the effective range in the direction below Y	Set the effective range in the direction below Y	mm		0~2000	200	Input
N-1	Cancel range protection	Cancel range protection			0:OFF:Range protection off 1:ON:Range protection on	1	Choose
N-6	It's forbidden to move in the X direction	It's forbidden to move in the X direction			0:OFF:OFF 1:ON:ON	0	Choose

15、Motor

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
161	Penetrating force enhancement action	Penetrating force enhancement action			0:OFF:Invalid 1:ON:When the motor of the sewing machine is locked, the penetration enhancement action is carried out	0	Choose
165	Reverse the Angle at which the needle rises	Angle setting of upper dead center	Degree		0~50	3	Input
P-1	X motor steering	X motor steering			0:Positive 1:Negative	1	Choose
P-2	Y motor steering	Y motor steering			0:Positive 1:Negative	1	Choose
P-3	Z motor steering	Z motor steering			0:Positive 1:Negative	0	Choose
P-4	The X sensor is on the left or right side of the nose	The X sensor is on the left or right side of the nose			0:L:Left side 1:R:Right side	0	Choose
P-5	Is the Y sensor on the front or rear of the nose	Is the Y sensor on the front or rear of the nose			0:F:Front 1:B:Back	1	Choose
P-6	Spindle type Choose	Support for 550W and 750W types			0:550:550W 1:D00:750W-D00/F11 2:F00:750W-F00	1	Choose
P-7	Spindle motor stop Angle	Spindle motor stop Angle	Degree		30~63	59	Input
P-8	Upper dead point Angle setting	Set the Angle of parking to the top dead center	Degree		0~50	3	Input
P-9	P2 frame shift direction	P2 frame shift direction			0:Same	0	Choose

	setting	setting			1:Reverse		
--	---------	---------	--	--	-----------	--	--

16、 Home Position

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
057	The presser foot action when the starting point of sewing moves after the origin detection	Origin foot action			0: Press down the presser foot after returning to the origin 1: After returning to the origin, the presser foot is lifted	1	Choose
250	Mechanical origin reset at the end of sewing	Whether to retrieve the origin after sewing			0: No origin search, stop in situ 1: Origin (sub-origin) retrieval 2: Back up seam point 3: Go straight back to the origin	1	Choose
254	The route of movement towards the origin position and the starting point of sewing	Normal origin retrieval/origin reset circuit selection			0: standard 1: reverse 2:Y axis to X axis 3:X axis to Y axis 4: x, y axis synchronous	0	Choose
270	Origin action when pattern switching	Origin action when pattern switching			0: No origin retrieval action 1: The origin retrieval action is not carried out, but it passes through the regional center 2: Perform the origin retrieval action	0	Choose
450	The starting point movement mode when the pattern is switched	The origin action when switching patterns			0: Step on the pedal to start, and then move to the new pattern starting point 1: While switching patterns, move to the starting point of the new pattern	0	Choose
Q-1	It goes back to the origin	It goes back to the origin			0:OFF:Don't return to home position 1:ON:Return to home position	0	Choose
Q-2	Lifting back to the origin is prohibited	Lifting back to the origin is prohibited			0:OFF:Permit returning to home position 1:ON:Forbid returning to home position	0	Choose

Q-4	Set the reset path of the starting point	Set the reset path of the starting point			0: the line returns to the starting seam 1: return the starting point by pattern 2: search at the origin and then at the seam	0	Choose
Q-5	Whether to Choose the dead point when the origin is retrieved	Whether to Choose the dead point when the origin is retrieved			0:OFF:do not Choose the dead point when retrieving the origin 1:ON: Choose upper dead point when retrieving the origin	0	Choose
Q-8	Reverse origin retrieval/origin reset line Choose	Reverse origin retrieval/origin reset line Choose			0:Standard 1:Reverse 2:Y-Axis to X-Axis 3:X-Axis to Y-Axis 4:Synchronize X and Y axis	0	Choose

17、Counter

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
R-1	Counter mode	Counter mode			0:Up counter is not executed 1:Up counter increases every 1 sewing pattern is executed 2:Up counter increases every 1 combined data cycle is executed	1	Choose
R-2	Decrement counter mode	Decrement counter mode			0:Up counter is not executed 1:Up counter increases every 1 sewing pattern is executed 2:Up counter increases every 1 combined data cycle is executed	1	Choose
R-3	Whether the increment counter value is retained when importing the pattern	Whether the increment counter value is retained when importing the pattern			0:Clear 1:Reserve	1	Choose
R-4	Whether the decrement counter value is retained when importing the pattern	Whether the decrement counter value is retained when importing the pattern			0:Clear 1:Reserve	1	Choose
R-5	Remove calculator when power is restarted	Remove calculator when power is restarted			0:Clear 1:Reserve	1	Choose
R-6	The UP is not allowed to be modified	The UP is not allowed to be modified			0:OFF:The current value of the UP counter can be modified 1:ON:The current value of the UP counter can't be modified	0	Choose
R-7	The subtracter (DN) is	The subtracter (DN) is			0:OFF:The current value of the	0	Choose

	not allowed to be modified	not allowed to be modified			UP counter can be modified 1:TON:he current value of the UP counter can't be modified		
R-8	Operation of the sewing machine when the UP set point is reached	Operation of the sewing machine when the UP set point is reached			0: OFF:Stop sewing 1: ON:Sewing operation can be continued	0	Choose
R-9	Operation of the sewing machine when the subtracter (DN) setting value is reached	Operation of the sewing machine when the subtracter (DN) setting value is reached			0: OFF:Stop sewing 1: ON:Sewing operation can be continued	0	Choose
R-11	Counter shuttle change	Counter shuttle change			0: OFF:OFF 1: ON:ON	0	Choose

18、LCD Screen

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
401	Loop program setup	After opening, the "Program" button on the main interface P1 is changed to the function of cyclic PROGRAM editing			0: OFF:OFF 1: ON:ON	0	Choose
S-1	Buzzer sound setting	Buzzer sound setting			0: 0:Mute 1:1: Panel voice 2:2:Panel voice+alarm	2	Choose
S-3	Backlight auto off switch	Backlight auto OFF switch, OFF: not auto OFF, ON: auto OFF			0: OFF:Disable auto off 1: ON:Enable auto off	0	Choose
S-4	Backlight automatically turns off wait time	Backlight automatically turns off wait time	Minute		1~9	3	Input
S-5	Main interface pattern display Settings	Set main screen pattern to display background color 0: black 1: cyan 2: red 3: green 4: blue 5: purple 6: yellow			0~6	0	Input
S-7	Main interface button display style	Set the key display style under the main interface			0: ICN:Icon: 1: TXT:Text	0	Choose
S-8	Key display style	Set the display style of the key in detection mode and function mode			0: ICN:Icon: 1: TXT:Text	0	Choose
S-9	Modify and change the key display style	Modify and change the key display style			0: ICN:Icon: 1: TXT:Text	1	Choose

S-11	Large needle count pattern support	Large needle count pattern support			0: OFF:OFF 1: ON:ON	0	Choose
S-12	Vector graphics conversion stitch Settings	Vector graphics conversion stitch Settings	x0.1mm		10~127	30	Input
S-13	Description of sewing progress	Description of sewing progress			0: OFF:OFF 1: ON:ON	1	Choose
S-14	Switch lock display Settings	Work with template recognition			0: OFF:OFF 1: ON:ON	1	Choose
S-16	Main interface P1 display style	Main interface P1 display style			0:S1:style1 1:S2:style2	1	Choose
S-18	Pattern number shortcut key selection method	Pattern number shortcut key selection method			0: The position remains the same 1: It will automatically become the first one after selection 2: Arrange by size	0	Choose
S-19	Pattern number shortcut key display mode	Pattern number shortcut key display mode			0:Recent use of patterns	0	Choose
S-20	Pattern number shortcut key display mode	Pattern number shortcut key display mode			0~7	0	Input
S-21	Pattern number shortcut key display mode	Pattern number shortcut key display mode			0~2	0	Input
S-22	Main interface P1 function area location	Main interface P1 function area location			0:L:Left side 1:R:Right side	1	Choose
S-23	P1 addition and subtraction setting key on the main interface	P1 addition and subtraction setting key on the main interface			0: All:Both pattern number and speed key support setting 1:SPD: Speed setting 2:PAT:Pattern number setting	0	Choose
S-24	Key style of main interface	Key style of main interface			0:Dark 1:Light	0	Choose

19、Editing Settings

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
T-1	Operating style	Operating style			0: S1:Style 1 1: S2:Style 2	1	Choose
T-2	Multiple seam down algorithm	Multiple seam down algorithm			0:0:According to segment 1:1:Only start and end	1	Choose

T-3	Whether the first null is automatically added after the secondary origin	Whether the first null is automatically added after the secondary origin			0:OFF:OFF 1:ON-S:ON(Switch sewing) 2:ON-F:ON(Continue feed)	0	Choose
T-4	Curve corner shortcut	Curve corner shortcut			0:OFF:OFF 1:ON:ON	1	Choose
T-5	Make a version of the air after the return of the sewing style	Set up a version of the return to sewing style after empty send			0:0:Keep shape 1:1:Line	0	Choose
T-6	Stitch reduction after printing	Stitch reduction after printing			0: OFF:No 1: ON:Yes	0	Choose
T-8	Amplification method	Pattern printing version amplification method			0:0:Square 1:1:Length and width	1	Choose
T-9	Whether to show drop point	Whether to show drop point			0:0:No 1:1:Yes	1	Choose
T-10	Choose method of pattern transformation	Multiple seam, offset seam, inverted seam, zigzag seam, fore-and-aft exchange, etc			0:0:Stitch 1:1:Element	0	Choose
T-11	The zoom unit	The zoom unit			0:0:Percent 1:1:Size	0	Choose
T-12	Multiple seam scaling	Multiple seam scaling			0:0:Variable 1:1:Fixed	1	Choose
T-13	Size calculation under the zoom function	Size calculation under the zoom function			0:0:From home 1:1:From start sew point	0	Choose
T-14	Return mode after modification	Return mode after modification (dot and function code)			0:0:Function selection 1:1:Continue to modify	0	Choose
T-15	Multiple seam, offset seam, segment insertion modification	Multiple seam, offset seam, segment insertion modification (conversion affects the position of the following elements)			0:0:Relative 1:1:Absolute	0	Choose
T-16	The center of the graph is set to retain the initial null feed	Center Settings for pattern scaling and rotation			0:0:Reserve 1:1:Remove	1	Choose
T-17	Rotation function next time whether the origin rotation	Rotation function next time whether the origin rotation			0:0:No 1:1:Yes	0	Choose
T-18	Parallel curve algorithm	Parallel curve algorithm			0:A1:Algorithm-1 1:A2:Algorithm-2 2:A3:Algorithm-3	2	Choose

T-19	Form the standard of Angle	Angle standard: no Angle, 180: full Angle	Degree		0~180	90	Input
T-20	Empty feed spacing setting	Empty feed spacing setting	x0.1mm		10~120	120	Input
T-21	Whether to increase the inflection point deceleration after the version	Whether to increase the inflection point deceleration after the version			0:OFF:No 1:ON:Yes	0	Choose
T-22	Displays the range of shape points	Displays the range of shape points			0:OFF:OFF 1:ON:ON	0	Choose
T-23	Make a version of the shape outline display	Make a version of the shape outline display			0:OFF:OFF 1:ON:ON	1	Choose
T-24	Version following action Settings	Version following action Settings			0:OFF:Disable 1:ON:Enable	0	Choose
T-25	Small stitching shape fusion	For straight lines only, shape points within 1mm will fuse the previous element			0:OFF:OFF 1:ON:ON	0	Choose
T-26	Automatically enlarge according to the size of the pattern outline	Automatically enlarge according to the size of the pattern outline			0:OFF:OFF 1:ON:ON	0	Choose
T-27	Pause code to expand valve function	Pause code to expand valve function			0:OFF:OFF 1:ON:ON	0	Choose
T-28	Medium presser foot height modification method	Medium presser foot height modification method			0:0: Choose a shot 1:1: Select a paragraph	0	Choose
T-29	Segment movement mode	Segment movement mode			0:0:Simple 1:1: complex	0	Choose
T-30	Point move selection mode	Point move selection mode			0:0: Radio (absolute and relative mode modifications) 1:1: alternative	0	Choose
T-31	Point movement and segment movement change trajectories	Point movement and segment movement change trajectories			0:0: close 1:1:open	1	Choose
T-32	Empty delivery and consolidation after point movement	Empty delivery and consolidation after point movement			0:NO 1:YES	0	Choose

20、 Other

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
-----	-------------------	-----------------------	------	-------------	-------	---------------	------

550	Machine needle cooling device	Needle cooling with or without			0:OFF:without 1:ON:have	0	Choose
U-1	Language selection	Language selection			0:CH:中文 1:EN:English 2:Bur:Burmese 3:KR:한국어 4:TK:Turkish 5:JP:日本語 6:VI:Vietnamese 7:ITA:Italiano 8:PT:Portuguese 9:ES:Español	0	Choose
U-2	Voice setting	Voice function setting			0:OFF 1:ON	1	Choose
U-3	Key voice volume	Key voice volume			0~31	25	Input
U-7	The brightness of LED lights	The brightness of LED lights			0~100	50	Input
U-8	Used for automatic feeding machine	Used for automatic feeding machine			0~10	0	Input
U-9	Whether to automatically close the jump interface	After confirming the number of jump pins, whether to automatically close the jump interface			0:OFF:No 1:ON:Yes	0	Choose
U-10	Boot whether to enter the language selection	Boot whether to enter the language selection			0:OFF:No 1:ON:Yes	0	Choose
U-12	DXF file conversion method	DXF file conversion method			0:0:Simple 1:1: complex	0	Choose
U-13	Exporting other formats	Exporting other formats			0:0: close 1:1:open	0	Choose

21、Maintenance

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
V-1	Change the needle residual value	Change the needle residual value	x1000Sth		0~9999	0	Input

V-2	Change needle setting value	Change needle setting value	x1000Sth		0~9999	0	Input
V-3	Cleaning time residual value	Cleaning time residual value	Hour		0~9999	0	Input
V-4	Set cleaning time value	Set cleaning time value	Hour		0~9999	0	Input
V-5	Oil replacement residual value	Oil replacement residual value	Hour		0~9999	0	Input
V-6	Oil change Settings	Oil change Settings	Hour		0~9999	0	Input
V-9	Bottom line counter number of stitches left	Bottom line counter number of stitches left			0~60000	0	Input
V-10	The baseline counter alarms the number of stitches	The baseline counter alarms the number of stitches			0~60000	0	Input
V-11	Bottom line counting method	Segment calculation: alarm at the beginning of seam section Stitch count calculation: alarm during sewing			0:0: By segment 1:1: Count of stitches 1: ON: open	1	Choose
V-17	Baseline detection device residual length setting	Baseline detection device residual length setting	x0.1M		0~5000	0	Input
V-18	The thickness of the fabric	The thickness of the fabric	mm		0~20	0	Input
V-19	Length of the line	Length of the line	mm		0~50	0	Input

22、 Template Recognition

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
W-1	Template identification Settings	Template identification Settings			0:OFF:OFF 1:ON:ON	0	Choose
W-2	Template identification equipment	Template identification equipment			0:0:Useless 1:1:Bar code scanner 2:2:RFID read-write device	0	Choose
W-3	The marker is offset in the X direction	The marker is offset in the X direction	x0.1mm		-5000~5000	0	Input
W-4	The marker is offset Y	The marker is offset Y	x0.1mm		-2000~2000	0	Input
W-5	The speed of the marker	The speed of the marker			1~9	1	Input
W-7	Read the USB flash disk pattern when the pattern number does not exist	Read the USB flash disk pattern when the pattern number does not exist			0:OFF 1:ON	0	Choose

23、 Automatic shuttle change

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
-----	-------------------	-----------------------	------	-------------	-------	---------------	------

X-1	Automatic shuttle switch	Automatic shuttle switch			0:OFF: Close 1:ON: open	0	Choose
X-2	Shuttle change	Shuttle change			0:0:Manual shuttle change after the bottom thread alarm 1:1:Automatically change the shuttle when the bottom thread alarms	1	Choose
X-3	Start mode after shuttle change	Start mode after shuttle change			0:0:Manual start 1:1:Automatic start	1	Choose
X-4	Empty bobbin processing method	Empty bobbin processing method			0:0:Put back the shuttle 1:1:Put the storage box	1	Choose
X-5	Shuttle arm parking position	Shuttle arm parking position			0:0:Bobbin side 1:1:Nose side	1	Choose
X-6	Fine adjustment of shuttle arm to nose position	Fine adjustment of shuttle arm to nose position			-100~100	0	Input
X-7	Fine adjustment of shuttle arm to shuttle plate position	Fine adjustment of shuttle arm to shuttle plate position			-100~100	0	Input
X-8	Origin offset of shuttle motor	Origin offset of shuttle motor			-100~100	0	Input


24、 Automatic shuttle change

No.	Brief description	Detailed instructions	Unit	Step length	Range	Factory value	Type
163	Maximum sewing speed	Maximum sewing speed	x100RPM		2~30	23	Input
Y-2	Letter embroidery function enable	Letter embroidery function enable			0:OFF:Letter sew function off 1:ON:Letter sew function on	1	Choose
Y-3	Needle length deceleration curve	Internal needle length drop curve Choose			0~8	5	Input
Y-4	The maximum length of needle without lowering the speed	Maintain maximum needle length at maximum speed	x0.1mm		1~127	30	Input
Y-5	Communication rate increase	Communication rate increase			0~1	0	Input

2.9 Test Mode



In main interface P1 (or P2), press  to activate the catalog mode, and then press  to enter the test mode.



Functions:

No.	Functions	Content
A	LCD Test	Test LCD displayer
B	Touching Screen Correction	Correct the touching screen
C	Input Signal Test	Test the input signal of switches and sensors
D	Speed Test	Test the speed of main shaft motor
E	Output Signal Test	Test the output signal of pressers and thread-trimming devices
F	Continuous Running	Set continuous running parameter and enter aging status
G	Automatic shuttle changing	Automatic shuttle changing
H	XY Motor Origin Test	Test the motor origins of X /Y motors
I	Main Motor Installation Angle Adjustment	Display and set the installation angle of main shaft motor
J	Medium pressure Function Test	Used to test intermediate presser
K	RFID	For setting RFID
L	Quit	Quit test mode and return to main interface
M	Self-adjusting	For self-adjusting

N	Wireless module 2	For wireless module 2 detection
O	Shear line detection	For shear line detection

2.9.1 LCD Test





Function:

In the test mode, press  to activate LCD test function. Click the area other than  to have LCD screen display white, black, red, green and blue so that user can judge whether the LCD screen has problem.

Press  to return to the upper level interface.

2.9.2 Touching Screen Correction




Functions:

Under test mode, press  to display the interface for ID input, as shown on the right. Then input the ID and press  to enter touch screen correction function.

User has to correct 5 spots. The touching pen is recommended to be used at touching the cross icon on the interface. After the correction, the system will display the result of this operation

[Note]: During the correction, please perform the operation strictly according to the position of the cross icon, otherwise the touching screen may be unable to be used normally after the correction.

2.9.3 Input Signal Test



Function:

In the test mode, press  to activate the Input Signal Test Function.

ON: Activation OFF

: Deactivation Types


of Input Signal:

- ① Start switch (Pedal)
- ② Presser switch (Pedal)
- ③ Pause Switch
- ④ Thread-breakage Detection
- ⑤ X Motor Sensor
- ⑥ Y Motor Sensor
- ⑦ Intermediate presser origin
- ⑧ Security switch
- ⑨ External input 1 (PORG)
- ⑩ External input 2 (PSENS)
- ⑪ External input 3 (CORG)
- ⑫ External input 4 (CSENS)
- ⑬ External input 5 (AORG)
- ⑭ Three-in-one Pedal


Press  to return to the upper level interface.

Click the programmable IO key  to enter the interface of input signal configuration.






Examples:

Click the input 3(N3) key to enter the interface of customized input signal. You can click  to select the input signal, as follows:

- 1) No
- 2) Auxiliary press frame
- 3) Start sew
- 4) Sewing speed plus 5)
- Sewing speed reduction 6)
- Air pressure detection 7)
- Disconnection detection 8)
- Special input function 1~9

Click the ok key  to confirm and return to the input signal configuration interface, and click the cancel

key  to cancel the operation and return to the input signal configuration interface.



Click the detailed setting key  to enter the interface of self-determined input signal. The following parameters can be set:

- 1) The turning on and off logic of the input signal is switched:

Usual/Reverse

The default value: Usual

- 2) As for the alternation operation, the function that the input signal is set by turning on operates even if the input signal is done in off afterwards:

Usual/Alternation

The default value: Usual

2.9.4 Main Shaft Speed Test



Functions:

In the test mode, press  to enter the main shaft speed test function.

Use  and  to set the aim speed of main shaft motor. Through  and , the spindle motor can be set to turn forward or backward. After user

presses , the main shaft motor will rotate at the set speed. At this moment, the actual speed will be displayed in the input column of actual speed.

Press  to stop running

Press  to return to the upper level interface.

2.9.5 Output Signal Test



Functions:

In the test mode, press  to activate the output signal test function.


In this interface, user can press output signal button to test the status of output signals of solenoids

Types of Output signals:

- ① Thread-wiping
- ② Thread-trimming
- ③ Presser
- ④ Intermediate presser
- ⑤ Thread-loosing
- ⑥ Clamp T2
- ⑦ Auxiliary air valve 1~8

Press  to return to the upper level interface.

[Note]: The sewing machine will have the actual movement.



Output customizing setting:

Click [programmable IO] key to enter the interface of self-determined output signal

For example:



Click the "valve 1(V1)" key to enter the interface of customized output signal. You can select the output

signal by clicking the button  , as follows:

- | | |
|-----------------------------|-----------------------------|
| 1) no | 18) laser suction |
| 2) auxiliary pressure frame | 19) laser lifting |
| 3) turn over the foot | Cut line 20) |
| 4) spindle operation | Loose line 21) |
| 5) finish sewing | 22) line |
| 6) error status | 23) medium pressure foot |
| 7) find the origin | 24) external pressure |
| 8) secondary origin | frame |
| 9) stop in the middle | 25) knife before sewing |
| 10) lateral slip press foot | 26) blow after sewing |
| expansion | 27) needle cooling |
| 11) sideslip pressure foot | 28) disconnected output |
| lifting | 29) emergency stop output |
| 12) line | 30)Marker pen |
| 13) functions 1~9 | 31) Laser Positioning |
| 14) function A/B/C | Light-Left |
| 15)The pressure box falls | 32) Laser positioning |
| back to the origin | light-right |
| 16) back to the origin | 33) Auxiliary fixture 1~9 |
| pressure box fell | 34) Start automatic shuttle |
| 17) laser | change |
| | 35) Working indicator |
| | 36) Standby indicator |
| | 37)Special presser foot |
| | function 1~7 |

Click ok  to determine and return to the

output signal configuration interface, click cancel  to cancel the operation and return to the output signal configuration interface.




Detailed setting

Click the detailed setting key to enter the interface of self-determined output signal. The following parameters can be set:

- 1) state setting of signal switch:
Usual/Reverse
Default:Usual
- 2) output inversion:
Usual/Alternation
Default:Usual
- 3) start delay setting (start delay range 0-65535/10 microseconds)
Invalid/Valid
Default: invalid
- 4) close delay setting (close delay range 0-65535/10 microseconds)
Invalid/Valid
Default: invalid

2.9.6 Continuous Running



Function:

In the test mode, press  to enter the continuous running function

Click Action Interval bar or Origin Detection of Needle-withdrawing bar and use number keys to input

the figures. Press  to return to the upper level interface.

There are two ways to activate the aging status: pedal or origin; after setting this parameter, return to main interface P1 (or P2). Step pedal or press the Return to Origin key to run the machine, and enter continuous running mode.

2.9.7 XY Motor Origin Test



Functions:

In the test mode, press  to activate the XY Motor Origin Detection Function.

In this interface, use direction keys to move XY motor. During this process, the system will display the ON/OFF status of the sensors.



ON: Sensor Detected

OFF: Sensor Undetected


Press  to return to the upper level interface.

[Note]: The sewing machine will have the actual movement.

2.9.8 Main Motor Installation Angle Adjustment



2.9.9 Intermediate Presser Test



Functions:

In the test mode, press  to enter the main motor installation angle adjustment.

1) Keeping this interface on, dismantle the servo motor from the main shaft, and turn the hand wheel until needle reaches the highest point. Then reset the servo motor and assure its electrical angle value displayed between 0 to 30 or between 330 to 360. If it is then click the enter button , otherwise repeat this procedure.

2) Remove the spindle motor from the current interface, rotate the hand wheel to swing the sewing machine needle bar to the parking position, reinstall the spindle motor, confirm that the displayed electrical value is within the range of 23~83 degrees, and then press the confirmation key , otherwise remove the spindle and repeat the above actions

Functions:

In the test mode, press  to enter intermediate presser test.

:Intermediate Presser Down

:Intermediate Presser Up


:Shift Intermediate Presser Position

2.10 Function Setting



In main interface P1 (or P2), press  to activate the catalogue mode, and then press  to enter the Function Setting Mode.

Function setting interface:




Functions:

No.	Functions	Content
A	Version Inquiry	Inquire the version of system software
B	Pattern Connection	Edit combined pattern
C	Display Setting	Set background light, keyboard lock, lightness and so on
D	Function shortcut key	Users can edit this shortcut key according to their common functions and display it on the main page for convenient operation.
E	Pattern management	Data Transfer: Transfer pattern file between memory and U disk Formatting: Initialize the U disk, memory and pattern number hotkeys. Pattern Transformation in Batch: Change the patterns of non-standard formats into standard formats. Note: standard format means nsp format.
F	Back-up Parameter Recovery	Save parameter values into U disk for the parameter recovery in future
G	Default Parameters	Recovery and self-defined read-write function of the default

No.	Functions	Content
		parameter values
H	Parameter Encryption	Set passwords for each operation entrance in parameter mode.
I	Password Mode	Provide periodical password function
J	Time Setting	Set the date and time
K	Log	Alarm Record:Check the alarm statistic information Running Record:Check running information of machine
L	Software Update	Enter software update mode
M	System parameters	System parameters and TD system parameters can be set
N	Shift between Icon and Description	Shift between the icon and description of the hotkeys
O	Quit	Return to main interface
P	Pattern number list	Pattern number shortcut key editing operation.

2.10.1 Version Inquiry Mode




In function setting interface, press  to enter version inquiry mode.

Press  to output the software version to the base catalogue of the U disk with name “version.png”.

2.10.2 Pattern Connection Mode


In function setting interface, press  to enter Pattern Connection Mode. The pattern connection mode is mainly used to create and edit the combined pattern, which is to perform the combination edition on the basis of the existing patterns. The pattern used in combined pattern is called as sub-pattern.



Function:

No.	Description
A	Page
B	Name of Combined Pattern
C	Load Combined Pattern
D	Save Combined Pattern
E	Display Sub-pattern
F	Quit & Return to Previous Interface
G	Page Key
H	Add Pattern from Memory to Combined Pattern
I	Delete Sub-pattern
J	Cancel Combined Pattern
K	Enter

Operation:




1、 Select a Sub-pattern

Press  to enter Load Mode and select the pattern to add (select pattern No.612 as an example).

Press  to confirm it.

[Note]: Patterns should be added to the combined pattern in order.



2、 Continue Adding

Repeat the above operation to add more sub-patterns (Add patterns No.002)



If user wants to delete one of them, please select the number of the sub-pattern and then press .



3、 Save the Combined Pattern

Press  to enter the mode for saving combined pattern.

Name the combined pattern and press  to confirm it. For other operations within this interface, please refer to [2.6 Save Pattern].



4、 Return to Main Interface

After finishing edition of the combined pattern, press  to return to main interface.

As shown in right figure, there are some differences between the combined pattern sewing interface and the normal pattern sewing interface.

① The name of combined pattern is displayed behind the number and the name of the current sub-pattern will be displayed at the name area.

[Note]: If the combined pattern has no name, nothing will be displayed.

② The original pattern number hotkeys will display the sub-patterns in this combined pattern. Click the sub-pattern to start the sewing from that sub-pattern.

5、 Cancel the Combined Pattern


In order to cancel the combined pattern, user has to enter the pattern connection mode again, presses  and clicks .

6、 Load Combined Pattern


In pattern connection mode, if user presses  when the combined pattern exists, the system will display “Clear Current Combined Pattern”. Clicking  will clear the current combined pattern.

Press  again to enter the interface for loading the combined pattern, where users can select the combined pattern for sewing or editing.

2.10.3 Version Inquiry Mode



In function setting interface, press  to enter display setting mode, where user can perform the settings about the display, operation and so on.




1、 Backlight Auto Turn-off

By the set time, the screen backlight will be turned off automatically.

Range: 1~9 min

Default Value: Invalid

Releasing Method: if the backlight is off, user can touch any position of the screen to turn it on.



2、 Keyboard Lock

When it is set as “Valid”, all the buttons will turn to grey in display and become useless. Pressing  will directly return to main interface P1.

Default Value: Invalid

Releasing Method: Hold the title bar at main interface P1 for over 5 seconds, until user hear “Bee~m”. After that the lock is released. (After the releasing, this function will be set as Invalid.)

3、 Speed style in main window

[Section] and [speed]

Default Value: [Section]

4、 Pattern display setting in main interface

Range : 0~6 (0:Black, 1: Dark Blue, 2: Red, 3: Green, 4: Blue, 5: Purple, 6: Yellow)


Default Value: 0

5、 Adjust Led light

The adjustment range is 0~100.

Default Value: 50


2.10.4 Hotkey Setting



Hotkey function is used to set the four function keys at the lower right corner according to the user's habits.




Press  to enter hotkey function setting interface. Setting the common functions of origin, graphic zoom, threading, middle presser foot height, graphic copy, and winding.



Input setting:

Press the shortcut key that needs to be changed to Input, enter the shortcut key setting, select the function and display Input, press the confirm key , save and exit.



2.10.5 Data Transfer Mode




In the function setting interface, press  to open the graph management group. The following functions can be set:

- 1) Pattern transmission
- 2) Format
- 3) Batch Convert

2.10.5.1 Data Transfer Mode


In function setting interface, press  to enter data transfer mode, where two ways are provided: “Memory to U Disk” and “U Disk to Memory”



Functions:

No.	Description
A	Pattern List
B	Turn page query
C	Quit and Return to Upper Interface
D	Arrange the patterns according to the pattern number
E	Delete Pattern
F	Save pattern as
G	Select All Patterns
H	Load pattern from memory or U disk  : Activate the U Disk Load Mode: At this moment, user can not load pattern from memory.  : Activate the Memory Load Mode: At this moment, user cannot load pattern from U disk.
I	Enter

Operation:



1、Copy Mode Selection

The default setting is to copy pattern from memory

to U disk, user can press  to change the copy mode.

2、File Selection

Select the pattern for copy from the pattern list (here, we select No.001 and No.002). If the patterns are

so many, please use   to turn the page.

For copying all the patterns, please press 

and please press  to delete patterns.


3、Confirm the Copy

After selection, please press  and then the system will display “Copy the Selected Pattern”, where

user can press  to perform the operation. If the pattern is copied from memory to U disk, the system will automatically create a catalogue naming “dh_pat” at the base catalogue of U disk and save the pattern under that catalogue.

[Note]: During the copy process, if the memory contains the pattern with the number same to that of the pattern in the U disk, the new pattern will replace the old one.

2.10.5.2 Formatting Mode



In function setting interface, press  to activate formatting mode

There are four formatting methods in this interface: USB formatting, Memory formatting, Self-defined formatting and Pattern number hotkey formatting

1、USB Formatting:

Press “USB” to delete all the patterns in the U disk. So user need back up the data if necessary.


2、Memory Formatting:

Press “Memory” to delete all the patterns in the memory.

[Note]: After the memory formatting, pressing  will have system display “Pattern Not Found in

Memory”. Pressing  will automatically load the default patterns.

3、Self-defined Formatting:



Press “Self-defined” to enter the interface for Self-defined formatting

In that interface, user can delete all patterns or selected patterns.

[Note]: The pattern being sewn can not be deleted.

4、Hotkey Formatting:

Pressing “Hotkey” to delete the content of the hotkeys of pattern number.

[Note]: After the hotkey formatting, pressing  will have system display “Pattern List (Hotkey) Is

Empty”. Pressing  will automatically load the current pattern number to the hotkey.

2.10.5.3 Pattern Transformation in Batch



This batch transformation function can enable the continual availability of the patterns after software update.

The default pattern number after transformation can be allocated manually.

The default setting is to select all patterns, and pattern names marked with x are selected.

The original patterns will be deleted. If you want to keep them, please select Keep Original Patterns at the bottom.

2.10.6 Back-up Recovery Mode



In function setting interface, press  to enter back-up recovery mode.

User can save the value of changed parameter into the U disk for the parameter recovery in future.

For details, please refer to [2.8.4 Recovery and Back-up of Parameter]

2.10.7 Default Parameter Mode




In function setting interface, press  to input the password (the original password is the manufacturer ID). After the input of password, the system will enter Default Parameter Mode.

It is used to recover the default parameters and to save the parameter values for future.

Please refer to [2.8.5 Default Parameter Recovery] for details



2.10.8 Encrypt



Press the parameter encryption key  in the function setting interface to enter the parameter encryption mode, which is mainly used to encrypt and manage the specified parameters.

Please refer to [2.8.3 Parameter Encryption] for details.

2.10.9 Password Mode



In function setting interface, press  to activate the interface for inputting the user ID. Input the correct manufacturer ID to enter the password management mode, where user can set and manage the periodical password.

② At most 10 different password action times can be set.

② System can display the password information of the manufacturer.

1、 Input Board Number

Press “Board Number” to enter the interface for inputting the board number. The board is formed by four figures, the range is from 0000000000000000 to 9999999999999999. This can be used for the management of the password by the manufacturer. After





inputting the board number, user can press  to finish the operation and return to the previous interface. (Here, we input 0001 as the board number).

2、 Confirm the System Clock

Press “Clock” to enter the interface for setting system time and date. For changing the system clock,

user need press  after the modification (Refer to

[2.10.14 Date and Time Setting Mode], or press  to quit.



3、 Input the Super Password

Press “Super Password” to enter the interface for inputting the super password.



At most 15 figures can be inputted, which are displayed as “•”. After user presses , the system will ask user to input that password again for confirmation. If the inputted passwords in these two times are different, the system will ask user to input the super password again. After these two inputted passwords agree, user can press  to save it and quit.

4、 Input Activation Time and Periodical Password

Press “pw-1” to input the first activation date.

The activation date is the first time when the password is activated. This date shall be later than the system date.

Select the proper date and press  to finish the operation. At this moment, the system will turn to password input interface




The input method of the periodical password is the same as that of the super password. After the confirmation, press  to quit.

5、 Continue Inputting Periodical Password

If user need input the next activation date and password, he should repeat the above operation. At most, ten dates and passwords can be inputted.

[Note]: The next date shall be later than the previous one.



6、 Save Password

Input the needed password, and then press  to save the entire information. The system will display “Password Saved Successfully”.

After confirmation, the system will return to the previous interface.




[Note]: Only when user set at least one periodical password, can  be displayed.



7、 Save Password Information

Enter the password statistics interface to display the panel number and password, staged password and date. After inserting the USB disk, press the output key , enter a new name, and press the return key  to save. After the password is saved successfully, the password information will be displayed to save the successful prompt information.





8、 Clear Password before Activation

Clearing password is to delete the password before it activates.

The method for entering the password display interface is the same as that of password setting

After user input the right manufacturer ID, the system will display the current time and activation dates of periodical passwords, as shown in right figure

Press  to input the current password. The password is cleared in order of from front to behind.

At this moment, user can input two passwords. If the inputted password is the current password, the current password will be deleted. If the super password is inputted, the entire password will be deleted. If the current password is deleted and the current password is the last password, the system will have no password any

more. Press  to finish the operation.

The deleted password will display in red color as shown in the right picture. If the entire password is deleted, the system will return to the upper level interface.




9、 Clear Password at Activation

If the system has the password and that password is not canceled, the password will activate at the set date. At this moment, user has to input the effective password to have the machine continue to work normally.

The effective passwords include the current password and the super password. If the inputted password is the current password, the current password will be deleted. If the super password is inputted, the entire password will be deleted. If the password is current password and the current password is the last password, the system will have no password any more. If the machine still have other password other than the current password, the next password will activate according to the set date

2.10.10 Date and Time Setting



In function setting interface, press  to enter the date and time setting mode.

11、 Method for Setting Date

Click “Year” (Here, it is 2011) to display two arrows to adjust it

Click “Month” (Here, it is June) to display the list of months. User can select the proper month.

After the setting, the display of year and month will be refreshed to the right ones.

User can also use  &  to check the content in calendar.

Click the day to complete the setting.

[Note]: User has to set year, month and date to finish the setting. Only setting the year and month will not complete this operation.



12、 Method for Setting Time

In default, user has to set hour first. Press “hour” to shift the setting to minute (Pressing “hour” is to change it to “minute”) and then press the arrows to change the time.

User can also click the display area to shift between hour and minute.

After the setting of date and time, please press




to save it.




13、 Forbid to Change System Time

Once the machine is set with the periodical passwords, the system will deny the change on the system time. After all the passwords are cleared, the system will unlock the setting of the system time.




2.10.11 Alarm Record Mode



In the function setting interface, press the record key  to open the record group. The following records can be viewed:


- 1)Error Note
- 2)Run Note

2.10.11.1 Error Note




In function setting interface, press , then system will ask for the manufacturer ID. After user gives the right ID, the system will enter the alarm record mode

In this mode, the current alarm will be recorded. The smaller number means the later alarm.




Click each number, and the information of and solution for the error will be displayed.



Press the "data statistics view" key  to enter the alarm record statistics interface.

2.10.11.2 Run Note




In function setting interface, press , then system will ask for the manufacturer ID. After user gives the right ID, the system will Enter the running record mode.

- ① Accumulated Running Time: Record total sewing time of machine.
- ② Accumulated Sewing Pieces: Record the total number of the sewn patterns.
- ③ Accumulated Power-on Time: Record the total time of power-on
- ④ Accumulated Stitch Number: Record the total stitch number of the machine.

Additionally, click “Clear” to clear the counting value.


[Note]: If the Accumulated Sewing Pieces is cleared, the system will also clear the Accumulated Counter in the assistant information bar at main interface.



Press [on time]  on the operation record mode interface to view the power on/off time notes..

Use the page turning key   to turn the page, click the clear key  to delete the boot record.

2.10.12 Update Mode




In function setting interface, press . The system will ask for the manufacturer ID. Input the correct ID to enter the software update mode.


The updating software shall be located in the catalogue "Update" in the U disk.




First click the [select directory] key  to select the directory where you want to upgrade the software.




Then select and click the ok key  to return to the software upgrade interface and display all the upgradable software information in the directory.



Click the details key  to select the details of the software to be upgraded.

Click the "confirm" key  to return to the software upgrade interface. Press the "confirm" key  again to upgrade the corresponding software.




Click the [version] key  to query the current software version of the panel.


2.10.13 System Para



Press the system parameter key  in the function setting interface to enter the system parameter setting mode.



In the system parameter setting interface, click the [parameter setting] key  to enter the system parameter setting interface and perform related operations.



In the system parameter setting interface, click the [TD parameter] key  to enter the TD parameter setting interface and perform relevant operations.



In the system parameter setting interface, click the [TD parameter] key  to enter the parameter update setting interface and perform relevant operations.


2.11 Letter Sewing Edition



In main interface P1 (or P2), press  to activate the catalogue mode, and then press  to enter letter sewing edition mode.

[Note]: Parameter [Special] -> [Letter Sewing Function Enable] can be used to close the function of letter sewing edition. After that, this icon will not be displayed

2.11.1 Parameters of Letter Sewing



Functions:


No.	Functions	Content
A	Figure Input	Input figures. At most, 20 figures can be inputted
B	Font Selection	28 fonts are available.
C	Array Method	User can select "Horizontal", "Vertical", "Upper Arc" "Down Arc"
D	Letter Pitch	Set the interval between letters
E	Density of Satin	Set the satin density. The larger value means the denser satin stitches
F	Scaling in Height	Scale the height of letter, range: 50~200.
G	Scaling in Width	Scale the width of letter, range: 50~200.
H	Rotation/Follow (Not Follow)	When the array method is linear (vertical or horizontal), the content on the button will be displayed as "Rotation", which is to set the rotation angle of letter; When the array method is arc (Upper Arc or Down Arc), this button will display "Follow" or "Not Follow", which is to set whether the letter rotates with the arc.
I	Trim/Not Trim	Set whether to automatically insert thread-trimming code
J	Return	Quit and return to main interface
K	Enter	Confirm operations. And then enter pattern adjustment interface.

Instructions for



1、 Figure input


Press “Input” to enter figure input interface, where user have to input at least one figure. 20 figures can be inputted at most. Press  to save the input and quit.



2、 Font Selection


Press “Font” to enter font selection interface, where 28 types of fonts are provided. Input the numbers from 1 to 28 to select the font. Press  to save it and quit.

In this interface, the font will be displayed to users.



3、 Array Method

Press “Arrange” to enter the interface for setting array method, where user can select horizontal linear, vertical linear, upper arc and down arc. Press  to save it and quit.



4、 Figure Pitch


Press “Pitch” to enter the letter pitch setting interface.

In horizontal array, it is to set the horizontal pitch between letters.

In vertical array, it is to set the vertical pitch between letters.


In arc array, it is to set the distance between the letters on arc.

Range: 0~99.9mm。




5、 Density of Satin

Press “Density” to enter the interface for setting satin density. The range is among 50~200.




6、 Scaling in Height

Press “Height” to enter the interface for setting letter height, where user can scale the height of letter. Range: 50~200.



7、 Scaling in Width

Press “Width” to enter the interface for setting letter width, where user can scale the width of letter. Range: 50~200.



8、 Rotation Angle Setting


When the array method is set at “Horizontal” or “Vertical”, user can set the rotation angle of the letter. Press the “Rotation” to enter the interface for setting rotation angle.

The rotating direction is counter-clockwise. Range: 0°~359°.

[Note]: When the array method is arc (Upper Arc or Down Arc), this button is to set whether the letter rotates with the arc.

When the array method is arc (Upper Arc or Down Arc), user can set whether the letter rotates with the arc. Press “Follow” to shift it to “Not Follow”, vice versa.


[Note]: when the array method is “Horizontal” or “Vertical”, this button is to set the rotating angle.



9、 Trim/No Trim

In default setting, the system will add auto-trimming, which is to add trimming code at the end of sewing, joint of empty feeding (or sewing).

Press “Trim” to change the content on button and cancel the function for automatically adding trimming functions.



10、 Confirm the Pattern


Set the letter sewing pattern for generation. Press



to enter the interface for adjusting the letter sewing pattern.

2.11.2 Adjustment of Letter Sewing Pattern

In the interface for setting parameters of the letter sewing, user can press  to enter the interface for adjusting the letter sewing pattern. In this interface, user can have the further adjustment on the pattern.




Functions:

No.	Functions	Content
A	Font Selection	Change the font of selected letter. The setting method is the same as that in Parameter Setting.
B	Scale in Height	Scale the height of the selected letter. The setting method is the same as that in Parameter Setting.
C	Scale in Width	Scale the width of the selected letter. The setting method is the same as that in Parameter Setting.
D	X Position	Display the X coordinate of center point of the selected letter
E	Y Position	Display the Y coordinate of center point of the selected letter
F	X Size	Display the width of the selected letter
G	Y Size	Display the height of the selected letter
H	Pattern Display	Display the current pattern for letter sewing. The selected letters are displayed in red; the unselected letter is displayed in green.
I	Direction Key	Adjust the position of the selected letter.
J	Esc	Return to the previous interface
K	Previous Letter (from right to left)	Select the letter for adjustment from right to left. The selected figure is displayed in red. When the icon still goes to left at selecting the last letter, the entire letters will be selected.
L	Next Letter (from	Select the letter for adjustment from left to right. The selected figure is displayed in


No.	Functions	Content
	left to right)	red. When the icon still goes to right at selecting the last letter, the entire letters will be selected.
M	Left Tilt/Radian Down	When the array method is horizontal array or the vertical array, this button will display “Left Tilt”. Pressing this button will rotate the entire pattern counterclockwise in the center of origin When the array method is arc, this button will display “Radian Down”. Pressing this button will reduce the radian of entire pattern. [Note] This operation is for the entire pattern.
N	Right Tilt/Radian Up	When the array method is horizontal array or the vertical array, this button will display “Right Tilt”. Pressing this button will rotate the entire pattern clockwise in the center of origin When the array method is arc, this button will display “Radian Up”. Pressing this button will increase the radian of entire pattern. [Note] This operation is for the entire pattern.
O	Left Rotation	Adjust the rotating angle of the selected letter counterclockwise. The rotation center is the center of the letter
P	Right Rotation	Adjust the rotating angle of the selected letter clockwise. The rotation center is the center of the letter
Q	Enter	Press it to Enter the pattern save interface

Example:



1、 Select Single Letter for Adjustment

Press “Previous Letter” or “Next Letter” to select the single letter for adjustment. The selected letter is displayed in red, while the unselected are displayed in green



2、 Letter Position Adjustment

Press direction keys to adjust the position of the selected letter. User can see the coordinates from “X Position” and “Y Position”

With the same operations, user can adjust the position of other letters.




3、 Adjust the Rotating Angle of Entire Pattern

Press “Left Tilt” or “Right Tilt” to adjust the rotating angle of the entire pattern

“Left Tilt”: Counter-clockwise Rotation

“Right Tilt”: Clockwise Rotation

[Note]: When the array method is arc, these buttons will turn to “Radian Up”/ “Radian Down”, which are to adjust the radian of the entire pattern



4、 Rotation of Single Letter

Select a letter and then press “Left Rotation” or “Right Rotation” to adjust the rotating angle of the selected letter

[Note] When adjusting the rotating angle, user had better adjust the rotating angle of the entire pattern at first. If user adjust the rotating angle of the single letter at first, the adjustment will be canceled when user rotates the entire pattern.



5、 Save Pattern

After the adjustment, press  to enter interface for saving patterns.

Input name and number, and then press . The system will display “Letter Sewing Pattern Saved Successfully”. (For other operations, please refer to [2.6 Save Pattern].)

[Note] After the successful saving, the letter sewing pattern will not turn to current pattern automatically. User has to enter the pattern loading interface to select it.

3 Appendix 1

3.1 Warning Information List

Number	Name of Malfunction	Solution
E-001	Pedal not at centre position	Please adjust pedal position
E-002	Machine is in emergency stop	<p>Check the condition of emergency switch. Turn and release the emergency button. If the screen keep displaying this hint, please check in the following way:</p> <ol style="list-style-type: none"> 1、 Check whether the emergency stop switch is pressed 2、 Check whether the emergency stop switch cable is in good contact; 3、 If there is no problem with the switch cable, please replace the electric control;
E-003	The nose tip over	<ol style="list-style-type: none"> 1 Turn off the power and check whether the nose is overturned 2 Check whether the switch position of the machine head is normal and whether the cable is in good contact; 3 Turn off the nose tip switch parameters or replace the electric control
E-004	Input voltage is too low	<p>Please turn off power and check system hardware</p> <ol style="list-style-type: none"> 1、 Check if the AC power supply has abnormal fluctuation; Make sure there is no high-power device that is turned on/off frequently; equip the voltage regulator. 2、 If the AC power supply is normal, the problem may be at the hardware. Please return the main control board for repair.
E-005	AC mains are too high	<ol style="list-style-type: none"> 1、 Check if the AC power supply has abnormal fluctuation; Make sure there is no high-power device that is turned on/off frequently; equip the voltage regulator. 2、 If the AC power supply is normal, the problem may be at the hardware. Please return the main control board for repair.
E-007	IPM is over-voltage or over-current	<p>Please turn off power and check system hardware</p> <ol style="list-style-type: none"> 1、 Make sure no short circuit at main motor; check if the value of each winding is equal and not 0; 2、 Check whether the output at U\ V\ W is shorted out to earth or the 300V power supply, so as to judge the condition of IPM.
E-008	Solenoid valve failure	<ol style="list-style-type: none"> 1. Power off and unplug the external solenoid valve cable. 2. If no more error is reported, please check whether the external solenoid valve is short circuit. 3. Error still reported after troubleshooting the external fault, please replace the electric control.
E-009	Auxiliary power is too low	<p>Please turn off power and check system hardware.</p> <ol style="list-style-type: none"> 1、 Check if the peripheral solenoids and valves are damaged; 2、 Check whether there is a short circuit in the inner core of the plug at both ends of the connecting wire between the electric control box and the nose

		board; 3、 Check whether the nose transfer plate is short circuit with the nose during installation.
E-010	Fan or electromagnet failure	1. Turn off the power and unplug the external electromagnet. 2. If no more errors are reported, please check whether the external electromagnet is damaged. 3. Error still reported after troubleshooting the external fault, please replace the electric control.
E-011	Stepper motor over speed	If closed loop motor, please check: 1、 Check whether the motor encoder is damaged; 2、 Check whether the encoder cable is damaged.
E-012	Stepper motor out of tolerance	If closed loop motor, please check: 1、 Check whether the motor encoder is damaged; 2、 Check whether the encoder cable is damaged.
E-013	Spindle encoder is malfunctioning or not connected	Turn off the power and check whether the spindle encoder is connected properly.
E-014	Spindle motor runs abnormally	1. Turn off the power to check whether the machine is stuck, to ensure that the machine can run smoothly without dead spots. 2. Replace spindle motor. 3. Replace the electric control box.
E-015	Exceeds sewing area	Check if the pattern is out of the range of the panel Settings
E-016	Please turn the code plate position of spindle motor	Turn the hand wheel to lift the needle bar to the upper position of the upper dead point, and then step the pedal.
E-017	Disconnection detection anomaly	1. Check whether the position of broken wire detection equipment is correct; 2. Check whether the cable is normally connected; 3. Appropriately increase the number of broken wire detection needles; 4. If still not solved, you can choose to turn off the broken line detection function or replace the electric control;
E-018	Trimmer position abnormal	Please turn off power.
E-019	Emergency switch is not at the right position	1. Check whether the emergency stop switch is pressed; 2. Check whether the emergency stop switch cable is in good contact; 3. If there is no problem with the switch cable, please replace the electric control. Note: If the emergency stop switch is pressed and returns to normal, please change the type of emergency stop switch.
E-020	Error reading E2PROM	
E-021	Error writing E2PROM	
E-023	Abnormal position of grabber line	Please turn off the power.
E-024	Wrong connection between operation head and sewing	Please turn off power.

	machine	
E-025	X origin detection abnormal	<p>1. Turn off the power. First of all, make sure that the machine can move normally without sticking points, X sensor and baffle can work normally, and the cable connection between X motor and sensor is intact.</p> <p>2. Switch on the machine and enter the signal detection interface to detect X Sensor. If the signal does not jump, replace the sensor and electric control in turn for testing.</p> <p>3. If the signal can jump normally, enter the XY detection interface to detect the action of X motor;</p> <p>4. If X motor can work normally but the steering direction is opposite, please change the steering parameters of X motor;</p> <p>5. If the X motor cannot work normally, replace the X motor and electric control box in turn for testing.</p>
E-026	Y origin detection abnormal	<p>1. Turn off the power. First of all, make sure that the machine can move normally without sticking points, Y inductor and baffle can work normally, and Y motor and inductor cable are well connected;</p> <p>2. Switch on the machine and enter the signal detection interface to detect Y sensor. If the signal does not jump, replace the sensor and electric control in turn for testing.</p> <p>3. If the signal can jump normally, enter the XY detection interface to detect the action of Y motor;</p> <p>4. If the Y motor can work normally but the steering direction is opposite, please change the steering parameters of Y motor;</p> <p>5. If Y motor cannot work normally, replace Y motor and electric control box in turn for testing;</p>
E-027	Presser origin detection abnormal	Please turn off power.
E-028	Thread-catching origin detection abnormal	Please turn off power.
E-029	Intermediate presser origin detection abnormal	<p>1. First of all, make sure that the machine can move normally without sticking points, the sensor and the baffle of the middle presser foot can work normally, and the motor of the middle presser foot and the sensor cable are intact.</p> <p>2. Start the machine and enter the signal detection interface to detect the sensor of medium pressure foot. If the signal does not jump, replace the sensor and electric control in turn for testing;</p> <p>3. If the signal can jump normally, enter the middle presser foot detection interface to detect the motor action of the middle presser foot;</p> <p>4. If the motor of the middle presser foot can work normally but the steering direction is opposite, please change the steering parameters of the motor of the middle presser foot;</p> <p>5. If the motor of medium presser foot cannot work normally, replace the motor of medium presser foot and electric control box in turn for testing;</p>
E-030	Master and step communication	1. Please check whether the program version is correct;

	error	<p>2. Re-upgrade the master control and step procedure to check whether it is normal;</p> <p>3. Replace the electric control;</p>
E-031	Stepping motor over-current	<p>Please turn off power</p> <p>The stepping motor is broken; user needs to replace the stepping motor</p> <p>2、 The stepping drive board is broken; user needs to replace the stepping drive board</p>
E-032	Stepping driver power abnormal	Please turn off power.
E-034	Spindle drive short circuit	<p>1. Turn off the power and check whether the spindle motor is damaged;</p> <p>2. If the motor is not damaged, replace the electric control box;</p>
E-035	Spindle drive over current 1	<p>1. Turn off the power, check whether the machine is stuck, to ensure that the machine can run smoothly without dead point.</p> <p>2. Replace the spindle motor;</p> <p>3. Replace the electric control box.</p>
E-036	Spindle drive over current 2	<p>1. Turn off the power, check whether the machine is stuck, to ensure that the machine can run smoothly without dead point;</p> <p>2. Replace the spindle motor;</p> <p>3. Replace the electric control box;</p>
E-037	Motor is blocked 1	<p>Please turn off power.</p> <p>1、 Due to the wrong location of the main shaft angle, the trimmer is jammed on the needle when cutting the thread, thus causes the main shaft to be blocked. Solution: Relocate the main shaft angle</p> <p>2、 The needle rod is jammed on the intermediate presser at moving, which causes the blockage of the main shaft. Solution: check the action of the intermediate presser and the connection between the air valve and the solenoid valve.</p> <p>3、 The trimmer can't cut the thread due to lacking of strength, which causes the blockage of the main shaft. Solution: adjust the main shaft parameter and increase the strength of trimming.</p> <p>4、 The mechanism has dead point, so the main shaft is blocked. Solution: adjust the mechanism;</p> <p>5、 The encoder at the main shaft motor has problem, which responses the wrong signal, thus causes the blockage of the motor. Solution: replace the main shaft motor</p>
E-038	Motor is blocked 2	<p>Please turn off power.</p> <p>1、 The used fabric is too thick to be penetrated by the needle. Solution: adjust the main shaft parameters or change to a motor with larger power capacity;</p> <p>2、 The needle rod is jammed on the intermediate presser at moving, which causes the blockage of the main shaft. Solution: check the action of the intermediate presser and the connection between the air valve and the solenoid valve</p> <p>3、 The mechanism has dead point, so the main shaft is blocked. Solution: adjust the mechanism</p> <p>4、 The encoder at the main shaft motor has problem, which responses the wrong signal, thus causes the blockage of the motor. Solution: replace the main shaft motor</p>

E-039	Motor over speed	Please turn off power. Spindle motor encoder has a problem, the signal feedback is wrong.
E-040	Over current in stop status	Please turn off power. Spindle motor encoder has a problem, the signal feedback is wrong.
E-041	Motor overload	Please turn off power.
E-042	Bus voltage abnormal	Please turn off power.
E-043	X stepping motor position error	Please turn off power.
E-044	Y stepping motor position error	Please turn off power.
E-045	Presser not down	Step the pedal
E-046	Not at origin cannot operate	Press key to return to origin
E-047	Spindle motor runs abnormally	1. Turn off the power, check whether the machine is stuck, to ensure that the machine can run smoothly without dead point. 2. Replace the spindle motor; 3. Replace the electric control box;
E-048	Abnormal origin position of middle presser foot	Please turn off power.
E-050	X motor over current	1. Turn off the power and check whether the connector of X motor is firmly connected and whether the cable is intact and without damage; 2. Replace X motor; 3. Replace the electric control.
E-051	Y motor over current	1. Turn off the power and check whether the connector of Y motor is firmly connected and whether the cable is intact and without damage; 2. Replace Y motor; 3. Replace the electric control.
E-052	X Large current of motor	X Large current of motor
E-053	Y Large current of motor	Y Large current of motor
E-054	X Motor is running abnormally	1. Turn off the power and make sure that no sticking point can be moved normally in the X direction of the machine. 2. Ensure that the cable connection of X motor is correct and firm without damage; 3. Replace X motor; 4. Replace the electric control.
E-055	Y Motor is running abnormally	1. Turn off the power and make sure that no sticking point can be moved normally in the Y direction of the machine. 2. Ensure that the cable connection of Y motor is correct and firm without damage; 3. Replace Y motor; 4. Replace the electric control.
E-056	X Motor stall	X Motor stall
E-057	Y Motor stall	Y Motor stall
E-058	Curve calculation error	Curve calculation error
E-059	Master and step communication	1. Verify that the software version is correct

	error 1	2. Re-import system parameters 3. Replace the electric control.
E-060	Master and step communication error 2	1. Initialization parameter 2. Replace the electric control.
E-061	Servo communication error 3	Servo communication error 3
E-062	X Motor is locked	X Motor is locked
E-063	Y Motor is locked	Y Motor is locked
E-064	X Motor instruction coverage	Please turn off power.
E-065	Y Motor instruction coverage	Please turn off power.
E-066	Coverage of X motor fast walking instruction	Please turn off power.
E-067	Coverage of Y motor fast walking instruction	Please turn off power.
E-068	Abnormal calculation of servo moving frame curve	Please turn off power.
E-069	Supply voltage is too high	Please turn off power.
E-070	Front and rear motion sensor failure	Please turn off power.
E-071	Left sensor failure	Please turn off power.
E-072	Right sensor failure	Please turn off power.
E-073	Left and right sensor failure	Please turn off power.
E-074	X Motor over speed	Please turn off power.
E-075	Y motor over speed	Please turn off power.
E-076	X motor current reference value is abnormal	Please turn off power.
E-077	Y motor current reference value is abnormal	Please turn off power.
E-078	The XY motor current reference value is abnormal	Please turn off power.
E-079	Communication of servo motor is abnormal	Please turn off power.
E-080	Bottom line cylinder action is not in place	Please try again.
E-081	The bottom line is insufficient	Press the confirm button to restore after replacing the bottom line
E-082	Oil shortage	
E-083	Variant data error 1	
E-084	Variant data error 2	
E-085	The origin of the wire cutting motor was not found	
E-086	Write drive program failed	Please restart the system and upgrade again.
E-087	Mechanical limit	
E-088	Abnormal detection of bobbin bobbin	1. Please check whether the shuttle tray is empty. If so, press confirm after replacing the shuttle tray.

		2.If there is a bobbin on the bobbin, please turn it off and restart it and check whether the bobbin sensor is normal.
E-089	The automatic shuttle changer is abnormal	
E-090	Automatic shuttle change in progress	
E-091	Unrecognized template	Please replace the template
E-092	Parameter mismatch of master stepping curve	Please update the curve parameters
E-093	Medium presser foot motor over current	1、 Turn off the power and check whether the motor connector of the middle presser foot is firmly connected and whether the cable is intact and without damage 2、 Replace motor of medium presser foot 3、 Replace the electric control
E-094	Over current of wire cutting motor	Please turn off the power.
E-095	Abnormal operation of medium presser foot motor	1. Turn off the power and confirm that the mechanical parts of the middle presser foot can move smoothly without sticking points; 2. Ensure that the motor cable of the middle presser foot is connected correctly and firmly without damage; 3. Replace motor of medium presser foot 4. Replace the electric control
E-096	Abnormal wire cutting motor	Please turn off power.
E-097	The card reader module is abnormal	Please power off and check whether the card reader module is damaged or not connected
E-098	Main power protection	Please turn off power.
E-099	Control box does not match operation head type	Please replace the panel.
E-100	Solenoid valve failure	Please turn off power.
E-101	The air valve action timed out	Please check the air valve
E-102	Air pressure is insufficient	Please check the air valve
E-103	Abnormal communication between master and DSP1	
E-104	Abnormal communication between master and DSP2	
E-105	Abnormal communication between master and DSP3	
E-106	Abnormal communication between master and DSP4	
E-107	Over current or blocking of the upper spindle motor	

E-108	The motor of the lower spindle is over current or blocked	
E-109	Low oil rate alarm	The oil quantity of the mechanical oil storage pot is too low, please replenish the oil!
E-110	Warning against danger	Rotating head rotating area is close to someone or its object, please stay away!
E-111	The bottom line is insufficient	Press the OK button to cancel the alarm.
E-112	Loss of needle or out of position during sewing	<ol style="list-style-type: none"> 1. Please shut down and check whether the signal connection plug of the spindle encoder is correct and reliable, and whether the connecting wire is damaged. 2. Please check whether the moving frame Angle fine-tuning and moving frame time fine-tuning are the default values in transfer mode. 4. Please check whether there is any unrecognized function code information and whether there is continuous repetition in the pattern Function code.
E-113	The upper rotation axis looks for the origin anomaly (beyond the limited number of steps)	<ol style="list-style-type: none"> 1. Please turn it off and check whether the connecting plug of the sensor at the origin of the upper rotation shaft is correct and firm, and whether the connecting wire is damaged. 2. Please check whether the origin sensor of the upper rotation axis is damaged. 3. Please check whether the related machinery of the upper rotation shaft is loose, whether the rotation is smooth, and whether there is rotation blocking.
E-114	The lower rotation axis looks for the origin anomaly (beyond the limited number of steps)	<ol style="list-style-type: none"> 1. Please turn it off and check whether the connecting plug of the sensor at the origin of the rotation axis is correct and firm, and whether the connecting wire is damaged. 2. Please check whether the origin sensor of the rotation axis is damaged. 3. Please check whether the related machinery of the rotating shaft is loose, whether the rotation is smooth, and whether there is blocking rotation.
E-115	Upper spindle servo drive failure	<ol style="list-style-type: none"> 1. Please check the alarm code displayed on the spindle servo driver and check the warning code instructions in the driver manual. 2. Please shut down and check whether the connecting plug of the control line of the spindle servo drive is correct and reliable, and whether the connecting wire is damaged. 3. Please check whether the mechanical structure of the upper spindle is loose, whether the rotation is smooth, and whether there is rotation blocking. 4. Please restart the machine and check whether the needle and spindle are positioned correctly.
E-116	Lower spindle servo drive failure	<ol style="list-style-type: none"> 1. Please check the alarm code displayed on the spindle servo driver and check the warning code instructions in the driver manual. 2. Please shut down and check whether the connecting plug of the control line of the spindle servo drive is correct and reliable, and whether the connecting wire is damaged. 3. Please check whether the mechanical structure of the spindle is loose, whether the rotation is smooth, and whether there is blocking rotation. 4. Please restart the machine and check whether the needle and spindle are

		positioned correctly.
E-117	Over current of upper rotating shaft motor	<p>1. Please turn off the machine and check whether the related machinery of the upper rotation shaft is loose, whether the rotation is smooth and whether there is blocking.</p> <p>2. Please check whether the connecting plug of the encoder of the upper rotating shaft motor is correct and firm, and whether the connecting wire is damaged.</p> <p>3. Please check whether the connecting plug of the power cord of the upper rotating shaft motor is correct and firm, and whether the connecting wire is damaged.</p> <p>4. Please check whether the motor parameters of the upper rotating shaft are configured correctly.</p>
E-118	Lower rotating shaft motor over current	<p>1. Please turn off the machine and check whether the related machinery of the rotating shaft is loose, whether the rotation is smooth, and whether there is blocking rotation.</p> <p>2. Please check whether the connecting plug of the encoder of the rotary shaft motor is correct and reliable, and whether the connecting wire is damaged.</p> <p>3. Please check whether the connecting plug of the power cord of the rotating shaft motor is correct and firm, and whether the connecting wire is damaged.</p> <p>4. Please check whether the configuration of rotary shaft motor parameters is correct.</p>
E-119	The motor of the upper rotating shaft is out of tolerance	<p>1. Please turn off the machine and check whether the related machinery of the upper rotation shaft is loose, whether the rotation is smooth, and whether there is blocking rotation.</p> <p>2. Please check whether the connecting plug of the encoder of the upper rotating shaft motor is correct and reliable, and whether the connecting wire is damaged.</p> <p>3. Please check whether the connecting plug of the power cord of the upper rotating shaft motor is correct and firm, and whether the connecting wire is damaged.</p> <p>4. Please check whether the motor parameters of upper rotating shaft are configured correctly.</p>
E-120	The motor of the lower rotating shaft is out of tolerance	<p>1. Please turn off the machine and check whether the related machinery of the rotating shaft is loose, whether the rotation is smooth, and whether there is blocked rotation Situation.</p> <p>2. Please check whether the connecting plug of the encoder of the rotary shaft motor is correct and reliable, and whether the connecting wire is damaged.</p> <p>3. Please check whether the connecting plug of the power cord of the rotating shaft motor is correct and firm, and whether the connecting wire is damaged.</p> <p>4. Please check whether the configuration of rotary shaft motor parameters is correct.</p>
E-121	DSP3 first line motor over current	Power off, unplug the power cable, confirm the motor or plate fault, contact professional maintenance personnel

E-122	DSP4 first line motor over current	Power off, unplug the power cable, confirm the motor or plate fault, contact professional maintenance personnel
E-123	DSP3 second circuit motor over current	Power off, unplug the power cable, confirm the motor or plate fault, contact professional maintenance personnel
E-124	DSP4 second circuit motor over current	Power off, unplug the power cable, confirm the motor or plate fault, contact professional maintenance personnel
E-125	DSP3 first circuit motor out of tolerance	Turn off the machine and check whether the encoder plug is loose or whether there is a foreign body that prevents the motor from running
E-126	DSP4 first circuit motor out of tolerance	Turn off the machine and check whether the encoder plug is loose or whether there is a foreign body that prevents the motor from running
E-127	DSP3 second circuit motor out of tolerance	Turn off the machine and check whether the encoder plug is loose or whether there is a foreign body that prevents the motor from running
E-128	DSP4 second circuit motor out of tolerance	Turn off the machine and check whether the encoder plug is loose or whether there is a foreign body that prevents the motor from running
E-129	The upper rotation axis and the lower rotation axis are out of sync	<ol style="list-style-type: none"> 1. Please turn off the machine and check whether the related machinery of the rotating shaft is loose and smooth. 2. Please check whether the encoder wire and power cord of the rotary shaft motor are normal and damaged. 3. Please check whether the configuration of rotary shaft motor parameters is correct.
E-130	The motor of the upper spindle is out of tolerance	<ol style="list-style-type: none"> 1. Please turn off the machine and check whether the related machinery of the upper spindle is loose, whether the rotation is smooth and whether there is blocking. 2. Please check whether the connecting plug of the encoder of the upper spindle motor is correct and reliable, and whether the connecting wire is correct Have been broken. 3. Please check whether the connecting plug of the power cord of the upper spindle motor is correct and reliable, and whether the connecting wire is correct Have been broken. 4. Please check whether the motor parameters of the upper spindle are configured correctly.
E-131	The motor of the lower spindle is out of tolerance	<ol style="list-style-type: none"> 1. Please turn off the machine and check whether the related machinery of the lower spindle is loose, whether the rotation is smooth and whether there is blocking. 2. Please check whether the connecting plug of the encoder of the lower spindle motor is correct and reliable, and whether the connecting wire is correct 3. Please check whether the connecting plug of the power cord of the lower spindle motor is correct and reliable, and whether the connecting wire is correct Have been broken. 4. Please check whether the motor parameters of the lower spindle are

		configured correctly.。
E-132	Abnormal synchronization between upper spindle and lower spindle	<ol style="list-style-type: none"> 1. Please turn off the spindle and check whether the related machinery is loose and rotation is smooth 2. Please check whether the encoder wire and power cord of the spindle motor are normal and damaged 3. Please check whether the spindle motor parameters are configured correctly.
E-133	Spindle parking overtime or parking position out of tolerance	<ol style="list-style-type: none"> 1. Please turn off the spindle and check whether the related machinery is loose and rotation is smooth 2. Please check whether the encoder wire and power cord of the spindle motor are normal and damaged 3. Please check whether the spindle motor parameters are configured correctly.
E-134	Spindle lock time out not completed	<ol style="list-style-type: none"> 1. Please turn off the spindle and check whether the related machinery is loose and rotation is smooth 2. Please check whether the encoder wire and power cord of the spindle motor are normal and damaged 3. Please check whether the spindle motor parameters are configured correctly.
E-135	Troubleshooting...	After troubleshooting, confirm key for automatic shuttle change, cancel key for manual shuttle change
E-136	The head lifting action is abnormal!	Please check whether the head lifting mechanism is normal and whether the electrical wiring is intact
E-137	The automatic shuttle changeover module failed to connect	<ol style="list-style-type: none"> 1. Please check whether the power supply of the automatic shuttle changing module is normal. 2. Please shut down and check whether the related lines are correct and reliable, and whether the connecting lines are damaged. 3. Please check whether the program version of the automatic shuttle changing module is normal.
E-138	Bobbin motor malfunction	<ol style="list-style-type: none"> 1. Please turn off the shuttle-board and check whether the shuttle-board mechanism is smooth or not. 2. Please check whether the plug of the shuttle motor is correct and firm, and whether the connecting wire is damaged. 3. Please check whether the shuttle motor is damaged.
E-139	Abnormal detection of spindle motor origin	<ol style="list-style-type: none"> 1. Please turn off the shuttle-board and check whether the shuttle-board mechanism is smooth or not. 2. Please check whether the plug of the shuttle motor is correct and firm, and whether the connecting wire is damaged. 3. Please check whether the origin signal of shuttle motor is normal.
E-140	The bobbin arm rotation is abnormal	<ol style="list-style-type: none"> 1. Please shut down and check whether the bobbin arm rotation mechanism is smooth and whether there is a jam. 2. Please check whether the switch plug is correct and reliable, and whether the connecting wire is damaged. 3. Please check whether the relevant sensor is normal.
E-141	Abnormal expansion of shuttle	1. Please shut down and check whether the shuttle boom expansion mechanism

	changer arm	<p>is smooth and whether there is a jam.</p> <p>2. Please check whether the telescopic plug of the shuttle changer arm is correct and reliable, and whether the connecting wire is damaged.</p> <p>3. Please check whether the relevant sensor is normal.</p>
E-142	The bobbin core is abnormal when changing bobbin arm	<p>1. Please power off and check whether the bobbin arm and bobbin butt position are consistent.</p> <p>2. Please check whether the bobbin clamping mechanism is normal.</p> <p>3. Please check whether the bobbin sensor is normal.</p>
E-143	Abnormal starting Angle of spindle synchronous action	<p>1. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>2. Please contact relevant after-sales service personnel for problem solving.</p>
E-144	Abnormal position of spindle synchronous rotation axis	<p>1. During sewing, the rotating shaft failed to rotate normally, resulting in the deviation of needle Angle.</p> <p>2. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>3. Please contact relevant after-sales service personnel for problem solving.</p>
E-145	Abnormal position of spindle synchronous middle presser foot	<p>1. The middle presser foot (follow up) fails to lift or fall properly, resulting in height deviation.</p> <p>2. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>3. Please contact relevant after-sales service personnel for problem solving.</p>
E-146	Spindle synchronous X- axis position abnormal	<p>1. During sewing, the X axis failed to complete the action according to the pattern, resulting in the deviation of the X axis direction frame.</p> <p>2. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>3. Please contact relevant after-sales service personnel for problem solving.</p>
E-147	Spindle synchronous Y- axis position abnormal	<p>1. During sewing, the Y axis failed to complete the action according to the pattern, resulting in the deviation of the Y axis frame.</p> <p>2. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>3. Please contact relevant after-sales service personnel for problem solving.</p>
E-148	Spindle synchronous frame position abnormal	<p>1. During sewing, XY axis failed to complete the action according to the pattern, resulting in the deviation of the frame.</p> <p>2. Restore the recently modified parameters, making sure that the parameters have changed within the appropriate range.</p> <p>3. Please contact relevant after-sales service personnel for problem solving.</p>
E-149	The pattern is beyond the scope of sewing	<p>Please press OK to remove the fault.</p> <p>1、 Please modify the starting point;</p> <p>2、 Check that the sewing range set by the operator head does not match the selected pattern.</p>
E-150	The calibration Angle value of	Please enter the spindle motor calibration interface to reset the spindle

	spindle motor is abnormal	installation Angle
E-151	Laser offset out of stitching range	Adjust the laser or brush offset parameters
E-152	The extension module is not connected	Shut down the system and check the connection and power supply between the extension module and the system
E-153	Extended module over current error	Close the system, check whether there is an external valve short circuit, pull out the valve one by one to eliminate
E-254	Undefined error	An undefined error occurred in communication

3.2 Hint Information List

No.	Name	Content of Sub-information
M-001	Up counter reaches set value	Press Enter
M-002	Down counter reaches set value	Press Enter
M-003	Not at origin, cannot operate	Return to origin firstly
M-004	Pattern data not exist	Please reload or input again
M-005	Set value is too large	Please input value within valid range
M-006	Set value is too small	Please input value within valid range
M-007	Please press "Return to Origin"	
M-008	Save parameter abnormal	Press Enter to restore the default values
M-009	Cannot find pattern in memory	Press Enter to load the default patterns
M-010	Memory full	Please delete the idle sewing data
M-011	Delete pattern data from memory?	Press OK to delete the operation and cancel to exit the current operation.
M-012	Replace pattern data in memory?	Press OK to delete the operation and cancel to exit the current operation.
M-013	Can not delete pattern data.	The selected sewing data is being used
M-014	Format memory?	Press OK to delete the operation and cancel to exit the current operation. All memory pattern data will be deleted after formatting!
M-015	Communication error	Abnormal event occurs in the communication between the operation head and the control box.
M-016	Beyond sewing range	Make sure pattern data is in sewing range
M-017	Fail to load letter sewing file	
M-018	Operation head does not match the type of control box	Please check the model and the software version
M-019	Wrong pattern number	Please input the right pattern number
M-020	Beyond max stitch interval	
M-021	Wrong password	Please input password again
M-022	Hardware clock error	The hardware clock has problem, please contact manufacturer for repair.
M-023	Stitch number beyond range	Please enter [Operation Settings]->[LCD Screen], select 'Large Sticker Count Pattern Support' parameter set to ON
M-024	Inputted stitch interval is too low	Please input value within valid range
M-025	Inputted stitch interval is too low	Please input value within valid range
M-026	Offset origin existed	User can only input one offset origin.
M-027	Please press Return to Origin	
M-028	Copy the pointed pattern?	Do you want to overwrite the original graph?

		Yes: Enter, no: X
M-029	Restore to default setting?	Press OK to delete the operation and cancel to exit the current operation.
M-030	USB is pulled out	U Disk Is Pulled Out!
M-031	Cannot find pattern data in U disk	
M-032	At least input one letter	At making pattern of letter sewing, user has to input at least one letter
M-033	No alarm record	
M-034	Replace needle	Reach set value for needle replacement, please replace needle!
M-035	Replace oil	Reach set value for oil replacement, please replace oil!
M-036	Clean machine	Reach set value for cleaning machine, please clean machine!
M-037	Different data format	Please confirm the data format
M-038	Cannot create curve	Please input again according to the standards of curve input.
M-039	Cannot insert trimming at current position	Please add trimming behind sewing data
M-040	Cannot add same function code in one position	
M-041	Cannot insert offset origin at current position	Please add offset origin after feeding
M-042	Cannot create arc or circle at the inputted point	Please input again
M-043	Cannot create overlapped sewing data	Please add overlapped sewing after close shape
M-044	Cannot insert trimming after down pause	
M-045	Cannot insert down pause before trimming	
M-046	Select wrong position	
M-047	Cannot scale	
M-048	Wrong pattern data	
M-049	Create arc?	
M-050	Create circle?	
M-051	Create curve?	
M-052	Create polygon?	
M-053	Presser is not down	Please step pedal
M-054	Wrong User ID	Please input again
M-055	Cannot change system time	The periodical password is set. Can not change system time.
M-056	Fail to save password file	
M-057	Fail to load password file	
M-058	Password saved successfully	
M-059	Fail to clear all passwords	Cannot delete password file
M-060	Fail to clear password	After the password is cleared, the file input becomes abnormal

M-061	Password file is deleted without authorization	Periodical password is deleted without authorization, please turn off machine
M-062	User ID file damage	
M-063	Input pattern name	
M-064	Please clear current combination data	Press “CLR” to delete current combination data
M-065	Empty input invalid	Please enter your password.
M-066	Password not match	Please re-enter the current password
M-067	New password is different.	Please re-enter a new password and reconfirm
M-068	Touching panel correction successful	Correction is successful. Please turn off power to restart.
M-069	Clear alarm records?	Yes: Enter No: X
M-070	Delete the selected file?	Yes: Enter No: X
M-071	Copy all patterns	Cover the original patterns? Yes: Enter No: X
M-072	Fail to copy file	Please check the space in memory
M-073	Fail to copy file	Please check if the USB disk is pulled out!
M-074	Fail to open file	Fail to open file
M-075	Format not match	Formats don't match, current load denied
M-076	Please create catalogue and file	Please create catalogue bakParam in U disk. Name the back-up file as backup.param and copy it to bakParam catalogue !
M-077	File I/O error	File I/O error
M-078	Please select file	Select the file for input/ output
M-079	File not exist	Cannot find the corresponding file
M-080	Not input move amount	Please input move amount
M-081	Determine to perform the current action?	Are you sure? Yes: Enter, no: X
M-082	Clear accumulated running time?	Are you sure? Yes: Enter, no: X
M-083	Clear accumulated sewing pieces?	Are you sure? Yes: Enter, no: X
M-084	Clear accumulated power-on time?	Are you sure? Yes: Enter, no: X
M-085	Clear accumulated stitch numbers?	Are you sure? Yes: Enter, no: X
M-086	Periodical passwords can't be same to super password	Please input password again
M-087	Cannot change up counter (NUP)	At change, please turn off setting (NUP)
M-088	Cannot change down counter (NDP)	At change, please turn off setting (NUP)
M-089	Pattern list (hotkey) is empty	If the pattern list is empty, the system will automatically input the current pattern to list

M-090	Not select update item	Please select item for updating. At least select one item
M-091	Some selected update items don't exist.	The item not existing will be cancelled after return. For updating the rest items, please confirm again
M-092	Update successful	Update is successful, please restart machine.
M-093	Format U Disk?	Press Enter to perform formatting operation. Press Esc to quit current operation. After formatting, all pattern files will be deleted.
	Update successful	Update is successful, please restart machine.
M-094	Successful	Current operation is successful!
M-095	Failed	Current operation is failed!
M-096	Format pattern list (hotkey)?	Press Enter to perform formatting operation. Press Esc to quit current operation
M-097	Cover the pattern with same name in U disk?	Press Enter to cover files. Press Esc to quit current operation
M-098	Fail to correct touching panel	Please perform correction again
M-099	The selected pattern is not normal format, please transform.	Press Enter to perform transforming operation. Press Esc to quit current operation
M-100	Cannot transform this pattern	Please confirm pattern
M-101	Restore all the settings?	Are you sure? Yes: Enter, no: X
M-102	Restore the selected item?	Are you sure? Yes: Enter, no: X
M-103	Not select item	Please select one or more parameters
M-104	Parameters initialization	Clear all data in . Please turn off power and restore the setting of DIP switch.
M-105	Cannot copy and cover current pattern	Current pattern number in copy group, system cannot cover it.
M-106	Need transform pattern format	Select pattern is not a standard file format, please convert it to use
M-107	Cannot perform operation to combined pattern	Please enter pattern connection mode, press "CLR" to cancel the combined pattern
M-108	Delete original pattern?	Delete original pattern after format transforming? Yes: Enter No: X
M-109	Intermediate presser in down position	Please lift intermediate presser
M-110	Turn off machine, Bye	
M-111	Large stitching pattern file format	Not support this pattern format in this system
M-112	Wrong transformed pattern format	Please confirm pattern
M-113	Transformed pattern data is too long	Please enter [Operation Settings]->[LCD Screen], select 'Large Sticker Count Pattern Support' parameter set to ON
M-114	Cannot open transformed pattern	Please confirm pattern
M-115	Wrong accuracy of transformed pattern	Set the resolution in the platemaking software to 0.1mm(Tools -> Options Settings - BBB>

		Resolution)
M-116	Parameter recovery successful	Parameter recovery is successful, please restart machine
M-117	Software version saving successfully	Software version is saved to the base catalogue of U disk successfully
M-118	Successfully set	The machine needs to be restarted
M-119	USB drive does not exist	Please insert the USB drive containing the MP3 files
M-120	There is no second origin	There is no second origin for the current pattern.
M-121	Validation failed while upgrading master program	
M-122	Threading a thread...	
M-123	Whether to restore the saved custom parameters	Determine the key to perform the operation, cancel the key to exit the operation
M-124	The current pattern is locked by the template	Please unlock the template!
M-125	Parameter loading failed	Please contact the manufacturer for maintenance!
M-126	The bottom line is insufficient	Please change the bottom line, press the OK key and re-count
M-127	Cannot generate multiple slit data	
M-128	Complete the graph copy?	
M-129	Memory allocation error	
M-130	Continued use will convert to dot seam	
M-131	The panel does not match the main control	The current system has a staging password, you need to contact the manufacturer to unlock!
M-132	The current panel has a password and needs to be synchronized	There is a password in the panel, but no password in the master control!
M-133	Current master exists password, need synchronization	There is a password in the master control, but there is no password in the panel!
M-134	You need to replace the font, please turn off the power and restart	Special languages turn off speech
M-135	Motherboard ID does not exist	
M-136	Language font is missing	Please update the required font file
M-137	C pattern Failed to open	Error in pattern file, will be deleted!
M-138	Incorrect content of pattern shortcut key	
M-139	The batch conversion function cannot be accessed	
M-140	The number has been taken	
M-141	A trace could not be generated	
M-142	Internal data exception	

M-143	There arc	The ellipse will be converted to point slits
M-144	Determine clearance of production records?	Are you sure? Yes: Enter, no: X
M-145	Clock in success	
M-146	Clock in failure	
M-147	Shrinkage seam conversion is successful	Shrinkage seam part has become a point seam, can not be converted to shrink seam again, it is suggested to keep the original pattern, for the next modification
M-148	Determine clear switch machine record?	Are you sure? Yes: Enter, no: X
M-149	No switching machine record	
M-150	Failed to upgrade the drive program	
M-151	The request failed	
M-152	Password information saved successfully	
M-153	The upgrade file does not exist	The directory does not exist or there are no files in the directory
M-154	Please set the add counter invalid	
M-155	Please set the subtraction counter invalid	
M-156	Are you sure to correct the spindle?	Are you sure? Yes: Enter, no: X
M-157	Invalid block number	
M-158	Reject the current operation	
M-159	The receive parameter is null	
M-160	The parameters have not changed	
M-161	QR code display failed	
M-162	The current position needs to be corrected due to reading new patterns	Please press the OK button
M-163	Shrinkage stitch number exceeds actual stitch number	
M-164	Cannot generate slot data	
M-165	Are you sure to correct the upper shaft?	Are you sure? Yes: Enter, no: X
M-166	Are you sure to correct the lower shaft?	Are you sure? Yes: Enter, no: X
M-167	No input point	Coincident with the previous input point position

M-168	Generate curve data?	
M-169	The software does not match the file system	
M-170	Password date change failed	The date entered should be before the date of the next password attack
M-171	Whether to confirm winding	Are you sure? Yes: Enter, no: X
M-172	Start pin contains function code, please confirm whether to modify	The "OK" key means to modify the function code, and the "Cancel" key means to exit and reselect. If you want to keep the function code, please refer to the code information on the right side of the interface to continue moving and make the starting pin the function code.
M-173	The panel is not encrypted, the master control is encrypted	Please confirm whether a new panel has been replaced
M-174	The panel is encrypted, the main control is not encrypted	Determines key synchronization encryption status
M-175	Remote staging Settings already exist on the system	Determine the key to continue operation, cancel the key to exit operation
M-176	Wireless module 1 connection failed	System speed reduced to the minimum, please contact the manufacturer
M-177	Do you want to update the pattern thumbnails immediately?	The thumbnail image will also be generated after the pattern is used
M-178	The system has been set to not network mode	After the networking function is turned on, it can be detected
M-179	A join failure	
M-180	Unable to convert	
M-181	This machine has a password, please note!	
M-182	Whether to delete the selected shape point	
M-183	Whether to modify shape point properties	
M-184	Trick does not exist, whether to download from the server	Are you sure? Yes: Enter, no: X
M-185	The request pattern is not in standard NSP format	
M-186	There is no request pattern on the server	
M-187	Server update software, whether to upgrade operation	Do you want to upgrade immediately? Yes: Enter, no: X
M-188	Machine not registered	
M-189	The action did not complete and timed out	

M-190	Location query timeout	
M-191	Stretch will affect the shrinkage data	There is a shrinkage seam in the sewing data, and the shrinkage seam will be automatically added by expansion, which will destroy the previous shrinkage seam data. Please pay attention to save another pattern
M-192	Upgrade of boot screen is abnormal	
M-193	Please scan the code and start processing	
M-194	Herringbone seam width is too large, need to insert transverse stitch number	
M-195	The panel is not connected to the main control	Dial switch 5 is turned on
M-196	The pattern accuracy is higher than the system accuracy	There will be a loss of precision in the pattern data
M-197	Whether to overwrite other format patterns of the same name on a USB disk	Press OK to overwrite the file, and press Cancel to exit the current operation.
M-198	Generate pattern, continue editing?	Enter, continue to set parameters or function code; No: X, exit save pattern.
M-199	Do you restore rigidity of all stitches to their original values?	Are you sure? Yes: Enter, no: X
M-200	Do you want to save laser offset values?	Are you sure? Yes: Enter, no: X
M-201	Do you want to save the origin offset value?	Are you sure? Yes: Enter, no: X

4.Appendix 2


4.1 Operating box mounting dimensions

4.2 Control box mounting dimensions

4.3 Diagram and Cable Connection



创新永无止境



BeiJing DaHao Technology company limited
Address: 1 Jiuxianqiao East Road, Chaoyang District, Beijing
postal code: 100015
Telephone: 010-59248888
Fax: 010-59248866
Email: sales@dahaobj.com