

# Operation Manual of Single Needle Interface


# Catalog

Chapter 1 Brief Introduction of Main Interface .....	2
Chapter 2 Brief Introduction of Import/Delete File.....	4
Chapter 3 Brief Introduction of Setting Parameters .....	6
Chapter 4 Brief Introduction of Location Parameters .....	7
Chapter 5 Brief Introduction of Speed Parameters .....	10
Chapter 6 Brief Introduction of Working Parameters .....	13
Chapter 7 Brief Introduction of Movement Parameters .....	17
Chapter 8 Brief Introduction of Detection Setting .....	19
Chapter 9 Brief Introduction of Software Setting .....	20

Chapter 10 Brief Introduction of Output Control .....	21
Chapter 11 Brief Introduction of Motor Control .....	22
Chapter 12 Brief Introduction of Hardware Configuration .....	23

## Chapter I. Brief Introduction of Main Interface

### 1.1 Introduction of Operation Panel Functions



#### 1. Showing Area of LCD

Showing the pattern info of being operated, status of machine, process of operation, RPM of working, can also be showed different interface info according to different functions.

#### 2. Shortcut Function

**'nto take plat'** Status of Switching Bobbins: It means the status of switching bobbins.

**'quilted state'** Status of Sewing: It means the status of sewing.

change once: It means change the bobbin one time.

first bobbin: It means first bobbin.

N-R reset: It means position of needle shuttle resets.

All zero: It means the spindle, needle shuttle and frame back zero position.

Name: Name of pattern.

Start: Start point of quilted.

Anchor: Anchor of quilted.

Range: Range of quilted.

Position: Current position of coordinate.

Index: Index of pattern.


Production: Quantity of quilted.

Up down: Rise and fall of sewing head.

Cut thread: Manual cutting thread of sewing head.

Process reset: Reset of machine's operation.

Switch state: It means switching of working status and simulation status.



1. Back to zero: It means back to the designed zero position.
2. Back to the sewing: It means back to the designed starting position.
3. Set the starting point: Setting the starting point of needed sewing.
4. Operation Manually: It means shortcuts of First Bobbin, Threading Point, Offset Point, Needle Zero, Shuttle Zero, Needle Shuttle Reset, Head Up, Head Down, Auto change bobbin one, Install first bobbin, Shut from **platm** to head, Shut from head to **platm**, Bottom line count clear, Production count clear.

Manual

first bobbin	Head down
threading point	auto change bobbin one
offset point	install first bobbin
needle zero	shut from platm to head
shuttle zero	shut from head to platm
needle shuttle reset	Bottom line count clear
Head up	production count clear

Pages:1/1
Page up
Page down
Ok
Cancel



5. Forward and backward: It means set the number of forward and backward.

Forward backward	
2	
Home	End
-10000	+10000
-1000	+1000
-100	+100
-10	+10
-1	+1
ok	cancal


6. Reset Process: Reset the process.

## Chapter II. Brief Introduction of Import/Delete Files

### 2.1 Introduction of Importing files from USB flash








Import the patterns which in the flash directly to operation box, continue to choose to operate.

## 2.2 Introduction of Deleting file function



Open the 'Delete Files', choose the files you need to delete, click 'OK' to delete.

## Chapter III. Brief Introduction of Setting Parameters

### 3.1 Set file parameters

The screenshot shows a software interface for setting parameters. At the top, it says 'Setting parameters' and 'Set file parameters'. Below this is a table with two columns: 'Anchor point X' and '0.0 mm'. The second row is 'Anchor point Y' and '0.0 mm'. There are several empty rows below. At the bottom left is '1/1'. At the bottom right are four buttons: 'Page up', 'Page down', 'Ok', and 'Cancel'.

Anchor point X	0.0 mm
Anchor point Y	0.0 mm

1/1

Page up Page down Ok Cancel

1. Anchor point X: Coordinate of X
2. Anchor point Y: Coordinate of Y

## Chapter IV. Brief Introduction of Location Parameters

### 4.1 Introduction of location parameters

Parameter setting

Location setting

Migration point coordinate valid symbol	Xy is valid at the same time
Migration point coordinate in X	526.52 mm
Migration point coordinate in Y	86.74 mm
Threading point coordinate valid symbol	invalid
Threading point coordinates X	0.00 mm
Threading point coordinates Y	0.00 mm
Main shaft zero reset compensation angle	0.00 deg
Software limit XY move allowed	Off
X Sewing area negative boundary	-33333.33 mm
X Sewing area positive boundary	950400.00 mm

1/2

Page up Page down OK Cancel

1. Migration point coordinate valid symbol: Valid coordinate position of migration point.
  2. point coordinate in X: Coordinate X of migration point.
  3. Migration point coordinate in Y: Coordinate Y of migration point
  4. Threading point coordinate valid symbol: Valid coordinate of threading point.
  5. Threading point coordinate X: Coordinate X of threading point.
  6. Threading point coordinate Y: Coordinate Y of threading point.
  7. Main shaft zero reset compensation angle: The angle of sensor while main shaft zero reset compensation.
  8. Software limit XY move allowed: It means if XY allowed to move.
- X sewing area negative boundary: The max. boundary of X can be sewed negative.
9. X sewing area positive boundary: The max. boundary of X can be sewed positive.

Parameter setting

Location setting

---

Y Sewing area negative boundary	-33333.33 mm
Y Sewing area positive boundary	96800.00 mm
X movable area negative boundary	-9200.00 mm
X movable area positive boundary	9504.00 mm
Y movable area negative boundary	-770.00 mm
Y movable area positive boundary	988.00 mm

2/2

Page up Page down Ok Cancel

10.Y Y sewing area negative boundary: The max. boundary of Y can be sewed negative.

11.Y sewing area positive boundary: The max. boundary of Y can be sewed positive.

12.X moveable area negative boundary: The max. boundary of X can be moved negative.

13.X moveable area positive boundary: The max. boundary of X can be moved positive.

14.Y moveable area negative boundary: The max. boundary of Y can be moved negative.

15. Y moveable area positive boundary: The max. boundary of X can be moved positive.

## Chapter V. Brief Introduction of Speed Parameters

### 5.1 Introduction of Speed Parameters

Speed setting	
Sewing main shaft working speed	800 r/min
Spindle corner speed	1 r/min
Main shaft zero reset speed	120 r/min
Main shaft running speed	300 r/min
Main shaft running acceleration	50 r/ss
Main shaft brake acceleration	100 r/ss
Main shaft start stop speed	100 r/min
Cut thread, main shaft speed	120 r/min
Needle reset, main shaft speed	400 r/min
Main shaft start slow speed	500 r/min

1/3

Page up Page down Ok Cancel

1. Sewing main shaft working speed: We can set RPM of main shaft sewing through this button.
2. Spindle corner speed: We can set rotate speed of spindle corner speed through this button, range 1-3000 rpm.
3. Main shaft zero reset speed: We can set the rotate speed of main shaft zero, rotate speed of main shaft start-stop, zero reset rotate speed, range 1-3000 rpm
4. Main shaft running speed: We can set the rotate speed of main shaft running, rotate speed of main shaft start-stop, range 1-3000 rpm
5. . Main shaft running acceleration: We can set the running acceleration of main shaft, range 1-100 rpss.
6. Main shaft brake acceleration: We can set the main shaft brake acceleration, range 1-100 rpss.
7. Main shaft start stop speed: We can set the rotate speed of main shaft start stop, range 1-300 rpm.

8. Cut thread, main shaft speed: We can set the cut thread rotate speed of main shaft.
9. Needle reset, main shaft speed: We can set the needle reset rotate speed of main shaft.
10. Main shaft start slow speed: We can set the main shaft start slow speed.

Parameter setting

Speed setting

No. of slow stitch at beginning	3 Needle
Sewing acceleration	50 r/ss
XY start stop speed	10 mm/s
XY zero reset speed	100 mm/s
XY simulate running speed	300 mm/s
XY movement acceleration	1000 mm/s <sup>2</sup>
XY brake acceleration	10000 mm/s <sup>2</sup>
XY manual movement speed 1	10 mm/s
XY manual movement speed 2	100 mm/s
XY manual movement speed 3	300 mm/s

2/3

Page up Page down Ok Cancel

11. No. of slow stitch at beginning: we can set the number of needles through this button, how many needles in need while needle started, Defaults:3.
12. Sewing acceleration: We can set the sewing acceleration.
13. XY start stop speed: We can set the XY start-stop speed through this button. Range 1-1000 mm/s
14. XY zero reset speed: We can set the XY zero reset speed. Range 1-1000 mm/s.
15. XY simulate running speed: We can set the XY simulate running speed through this button, range 1-1000 mm/s
16. XY movement acceleration: We can set the XY movement acceleration through this button, range 1-10000 mm/s<sup>2</sup>
17. XY brake acceleration: We can set the XY brake acceleration through this button, range 1-10000 mm/s<sup>2</sup>
18. XY manual movement speed 1: We can set the XY manual movement speed 1, range 1-1000 mm/s

19.XY manual movement speed 2: We can set the XY manual movement speed 2, range 1-1000 mm/s

20.XY manual movement speed 3: We can set the XY manual movement speed 3, range 1-1000 mm/s

Parameter setting

Speed setting

XY maximum moving speed

800 mm/s

3/3

Page up

Page down

Ok

Cancel

21.XY maximum moving speed: We can set the XY maximum moving speed through this button.

## Chapter VI. Brief Introduction of Work Parameters

### 6.1 Introduction of work parameters

Parameter setting

Work setting

---

Production preset	999999999
Loop work allowed	Not allow
<hr/>	
<hr/>	
<hr/>	
<hr/>	
<hr/>	
<hr/>	
<hr/>	
<hr/>	

1/1

Page up Page down Ok Cancel

1. Production preset: The expected output.
2. Loop work allowed: If it is allowed to work recurrently.



## Chapter VII. Brief Introduction of Action Parameters

### 7.1 Introduction of action parameters.

Parameter setting	
Action setting	
Moving basket Loose line	allowed
Sewing frame movement mode	Xy intermittent moving frame
No. of slow stitch at beginning	3 Needle
Cut thread allowed	Automatic thread trimming
Thread cut, catch upper thread allowed	allowed
Oiling mode selection	Oiling intermittently by working hours
Automatic bobbin change device	No device
Oiling interval by needle stitch	0 Needle
Oiling interval by working time	1800 s
Oiling sustained time	3 s

1/2

Page up Page down Ok Cancel

1. 移框松线允许：移框松线是否打开。

Moving basket loose line: If the moving basket is opened.

2. 缝纫动框方式：缝纫动框方式选择。

Sewing frame movement mode: Choose the way of sewing frame movement.

3. 起针慢动针数：按此功能键可以进行针数设置，在针起动时需要几针，默认：3 针。

No. of slow stitch at beginning: We can set the number of needle through this button, Default: 3.

4. 剪线允许：剪线动作是否自动允许。

Cut thread allowed: If the action of cut thread is allowed automatically.

5. 剪线时动作夹线允许：剪线时动作夹线是否打开。

Thread cut, catch upper thread allowed: If the catch upper thread is opened while thread cutting.

6. 加油方式选择：选择加油方式。

Oiling mode selection: Choose the mode of oiling.

7. 自动换梭装置：选择自动换梭装置。

Automatic bobbin change device: Choose the automatic bobbin device.

8. 加油针数间隔：加油针数间隔设置。

Oiling interval by needle stitch: Set the oiling interval by needle stitch.

9. 加油时间间隔：加油时间间隔设置。

Oiling interval by working time: Set the oiling interval by working time.

10. 加油持续时长：加油持续时长设置。

Oiling sustained time: Set the oiling sustained time.

Parameter setting

Action setting

Shuttle Oiling sustained time	0 s
Main shaft stop position selection after work complete	start point
Sewing move head up down	allowed
Trimming frame direction	right
Minimum speed deviation angle	0 deg

2/2

Page up Page down Ok Cancel

11. Shuttle Oiling sustained time: Set the shuttle oiling sustained time.

12. Main shaft stop position selection after work complete: Set the main shaft stop position after work completed.

13. Sewing move head up down: Set the sewing move head up and down.

14. Trimming frame direction: Set the trimming frame direction.

15. Minimum speed deviation angle: Set the minimum speed deviation angle.

## Chapter VIII. Brief Introduction of Detection Setting

### 8.1 Detection setting

Parameter setting

Detection setting

No. of stitch detect if thread broken	0 Needle
Bobbin change reminder function	Count by number of slices
Bobbin thread length	0.00 mm
Bobbin thread correction per stitch	0.00 mm
Bobbin change as per sewed pieces	3 times
Safety input pressure allowed	allowed
Secure input light curtain allows	Not allow

1/1

Page up Page down Ok Cancel

1. No. of stitch detect if thread broken.
2. Bobbin change reminder function: Set the bobbin change reminder function.
3. Bobbin thread length: Set the bobbin thread length.
4. Bobbin thread correction per stitch: Set the bobbin thread correction per stitch.
5. Bobbin change as per sewed pieces: Set the bobbin change as per sewed pieces.
6. Safety input pressure allowed: Set the safety input pressure allowed.
7. Secure input light curtain allows: Set the secure input light curtain allows.

## Chapter IX. Brief Introduction of Software settings

### 9.1 Brief introduction of software settings

The screenshot shows a 'Parameter setting' window with a 'Software settings' tab. The window contains a list of settings, each with a label and a corresponding input field. The 'language settings' field is currently set to 'English'. The settings are: language settings, Master upgrade \*, Interface upgrade \*, Old parameter input\*, Parameter input \*, Parameter output \*, Parameter restore \*, and Time setting. At the bottom left, it shows '1/1'. At the bottom right, there are four buttons: 'Page up', 'Page down', 'Ok', and 'Cancel'.

Setting	Value
language settings	English
Master upgrade *	
Interface upgrade *	
Old parameter input*	
Parameter input *	
Parameter output *	
Parameter restore *	
Time setting	

1. Language setting: set the language of interface.
2. Master upgrade: Upgrade the main control panel.
3. Interface upgrade: Upgrade the interface program.
4. Old parameter input: Input the parameters of old machines.
5. Parameter input: Input the new parameters.
6. Parameter output: Output this machine's parameters.
7. Parameter restore: Restore the parameter data.
8. Time setting: Set the time of system.

## Chapter X. Brief Introduction of Output Control

### 10.1 Output control

The screenshot shows a 'Debug tool' window with a tab labeled 'Output control \*'. The interface contains a list of control items on the left, each with corresponding 'open' and 'close' buttons. The items are: 'Down cut', 'buckle line', 'Elastic line', 'add oil', 'flashlight', 'Head lift', 'Clamp line', 'change bobbin grab', 'change bobbin sway', and 'change bobbin push'. The 'Head lift' item has 'up' and 'down' buttons instead of 'open' and 'close'. There is also a 'change bobbin spin' item with 'open' and 'close' buttons. At the bottom left, it says '1/1'. At the bottom right, there are four buttons: 'Page up', 'Page down', 'Ok', and 'Cancel'.


Control Item	Open Button	Close Button
Down cut	open	close
buckle line	open	close
Elastic line	open	close
add oil	open	close
flashlight	open	close
Head lift	up	down
Clamp line	open	close
change bobbin grab	open	close
change bobbin sway	extend	back
change bobbin push	open	close
change bobbin spin	open	close

1. Down cut: Set the lower knife cutting through this button, open or close.
2. Buckle line: Set the buckle line, open or close.
3. Elastic line: Set the elastic line, open or close.
4. Add oil: Set the oiling, open or close.
5. Flashlight: Set the flashlight, open or close.
6. Head lift: Set the head lift or down.
7. Clamp line: Set the clamp line, open or close.
8. Change bobbin grab: Set the change bobbin grab, open or close.
9. Change bobbin sway: Set the change bobbin sway, extend or back.
10. Change bobbin push: Set the change bobbin push, open or close.

11. Change bobbin spin: Set the change bobbin spin, open or close.
12. Install the first shuttle case: Press this function key to configure the installation of the first shuttle case and select "Install".

## Chapter XI. Brief Introduction of Motor Control

### 11.1 Introduction of motor control



1. X Axis: Set the X Axis, choose to Find zero, Enable, Disable, Forward, Reverse.
2. Y Axis: Set the Y Axis, choose to Find zero, Enable, Disable, Forward, Reverse.
3. Spindle motor: Set the spindle motor, choose to Find zero, Enable, Disable, Forward, Reverse.
4. Needle motor: Set the needle motor, choose to Find zero, Enable, Disable, Forward, Reverse.
5. Hook motor: Set the hook motor, choose to Find zero, Enable, Disable, Forward, Reverse.
6. Lift motor: Set the lift motor, choose to Find zero, Enable, Disable, Up, Down.

## Chapter XII. Brief Introduction of Hardware Configuration

### 12.1 Hardware configuration

Debug tool

Super user \*\*

Machine type	Sewing machine
product type	Single head sewing machine
Number of heads	1
Number of Needles per head	1
X axis configuration	Have this axis
X-axis motor drive selection	Single motor
X-axis coordinate system selection	Negative coordinate system
X axis moving object selection	frame
X-axis zero sensor selection	Yes
X-axis speed reduction sensor selection	Yes

1/41

Page up

Page down

Ok

Cancel

1. 机器类型：指机器的类型。

Machine type: It means the type of machine.

2. 产品类型：指机器产品的类型。

Product type: It means the type of products.

3. 机头数：指机头的个数。

Number of heads: number of heads.

4. 机头针数：指机头针的个数。

Number of needles per head: The number of needles per head.

5. X 轴配置：X 轴配置包括无该轴和有该轴。

X axis configuration: It includes 'Have this axis' and 'Nothis axis'

6. X 轴电机驱动选择：X 轴电机驱动选择包括双电机和单电机。

X-axis motor drive selection: Includes Single motor and double motors.



7. X 轴坐标系统选择: X 轴坐标系统选择包括坐标系统为正和坐标系统为负。  
X-axis coordinate system selection: Includes Positive and Negative coordinate system.

8. X 轴移动对象选择: X 轴移动对象选择包括框和机头。  
X-axis moving object selection: Includes frame and head.

9. X 轴零位传感器选择: X 轴零位传感器选择包括有和无。  
X-axis zero sensor selection: Includes Yes and No.

10. X 轴降速传感器选择: X 轴降速传感器选择包括有和无。  
X-axis speed reduction sensor selection: Includes Yes and No.

Debug tool

Super user \*\*

X-axis positive limit sensor selection	Yes
X-axis negative limit sensor selection	Yes
X axis zero direction selection	Negative direction
X-axis sensor function selection	Zero separate
Y axis configuration	Have this axis
Y-axis motor drive selection	Single motor
Y-axis coordinate system selection	Negative coordinate system
Y axis moving object selection	frame
Y-axis zero sensor selection	Yes
Y-axis speed reduction sensor selection	Yes

2/41

Page up

Page down

Ok

Cancel

11. X-axis positive limit sensor selection: Includes Yes and No.

12. X-axis negative limit sensor selection: Includes Yes and No.

13. X-axis zero direction selection: Includes Positive and Negative direction.

14. X-axis sensor function selection: Includes: Zero separate and Zero speed reduction.

15. Y axis configuration: Includes 'Have this axis' and 'No this axis'

16. Y-axis motor drive selection: Includes Single motor and double motors.
17. Y-axis coordinate system selection: Includes Positive and Negative coordinate system.
18. Y-axis moving object selection: Includes frame and head.
19. Y-axis zero sensor selection: Includes Yes and No.
20. Y-axis speed reduction sensor selection: Includes Yes and No.

Debug tool

Super user \*\*

Y-axis positive limit sensor selection	Yes
Y-axis negative limit sensor selection	Yes
Y axis zero direction selection	Negative direction
Y-axis sensor function selection	Zero separate
X2 axis configuration	No such axis
X2 axis motor drive selection	Single motor
X2 axis coordinate system selection	Positive coordinate system
X2 axis moving object selection	Machine head
X2 axis zero sensor selection	No
X2 axis speed reduction sensor selection	No

3/41

Page up
Page down
Ok
Cancel

21. Y-axis positive limit sensor selection: Includes Yes and No.
22. Y-axis negative limit sensor selection: Includes Yes and No.
23. Y-axis zero direction selection: Includes Positive and Negative direction.
24. Y-axis sensor function selection: Includes: Zero separate and Zero speed reduction.
25. X2 axis configuration: Includes 'Have such axis' and 'No such axis'

26. X2 axis motor drive selection: Includes Single motor and double motor.
27. X2 axis coordinate system selection: Includes Positive and Negative coordinate system.
28. X2 axis moving object selection: Includes frame and head.
29. X2 axis zero sensor selection: Includes Yes and No.
30. X2 axis speed reduction sensor selection: Includes Yes and No.

Debug tool

Super user \*\*

X2 axis positive limit sensor selection	No
X2 axis negative limit sensor selection	No
X2 axis zero direction selection	Negative direction
X2 axis sensor function selection	Zero separate
Y2 axis configuration	No such axis
Y2 axis motor drive selection	Single motor
Y2 axis coordinate system selection	Positive coordinate system
Y2 axis moving object selection	Machine head
Y2 axis zero sensor selection	No
Y2 axis speed reduction sensor selection	No

4/41

Page up
Page down
Ok
Cancel

31. X2 axis positive limit sensor selection: Includes Yes and No.
32. X2 axis negative limit sensor selection: Includes Yes and No.
33. X2 axis zero direction selection: Includes Negative direction and positive direction.
34. 。 X2 axis sensor function selection: Includes zero separate and speed reduction function.
35. Y2 axis configuration: Includes Have such axis and No such axis.
36. .Y2 axis motor drive selection: Includes single motor and double motors.

37. Y2 axis coordinate selection: Includes Positive coordinate system and negative coordinate system.

38. Y2 axis moving objective selection: Includes frame and head.

39. Y2 axis zero sensor selection: Includes Yes and No.

40. Y2 axis speed reduction sensor selection: Includes Yes and No.

Debug tool

Super user \*\*

Y2 axis positive limit sensor selection	No
Y2 axis Negative limit sensor selection	No
Y2 axis Zero direction selection	Negative direction
Y2 axis sensor function selection	Zero separate
Sewing main shaft configuration	Have this axis
Needle and rotray hook configuration	Needle rotary hook separated
Lift motor configuration	No such axis
Presser foot motor configuration	No such axis
Rotate motor configuration	Have this axis
Rotate motor coordinate system	Double motor

5/41

Page up

Page down

Ok

Cancel

41. Y2 axis positive limit sensor selection: Includes Yes and No.

42. Y2 axis negative limit sensor selection: Includes Yes and No.

43. Y2 axis zero direction selection: Includes Negative direction and positive direction.

44. Y2 axis sensor function selection: Includes zero separate and speed reduction function.

45. Sewing main shaft configuration: Includes have this axis and no this axis.

46. Needle and rotary hook configuration: Includes Needle rotary hook separated.

47. Lift motor configuration: Includes Have such axis and No such axis.
48. Presser foot motor configuration: Includes Have such axis and No such axis.
49. Rotate motor configuration: Includes Have this axis and no this axis.
50. . Rotate motor coordinate system: Includes single motor and double motors.

Debug tool

Super user \*\*

Rotate motor coordinate system	Negative coordinate system
Rotate motor rotating object selection	Machine head
Rotate limitation selection	Unlimited
Bobbin trimmer drive selection	Cylinder
Bobbin trimmer mode selection	Cam trimming
Upper trimmer drive selection	cylinder
Upper thread break detection device selection	Pick wire spring
Bobbin thread break detection device selection	No device
Thread break detection mode selection	Direct detection
Upper thread hook device selection	cylinder

6/41

Page up
Page down
Ok
Cancel

51. Rotate motor coordinate system: Includes Negative and positive coordinate
52. motor rotating object selection: Includes machine head and frame.
53. Rotate limitation selection: Includes Unlimited and Limited.
54. Bobbin trimmer drive selection: Includes cylinder, AC motor, Stepper motor, Electromagnet, without bobbin trimmer device.
55. Bobbin trimmer mode selection: Includes Cam trimming, Dynamic trimming, Static trimming, Cam trimming separately.
56. Upper trimmer drive selection: Includes cylinder and without upper trimmer drive.

57. Upper thread break detection device selection: Includes Pick wire spring, electronic disconnecter, and no device.

58. Bobbin thread break detection device selection: Includes Grating wheel, magnetic encoder.

59. Thread break detection mode selection: Includes Direct detection and Peripheral board detection.

60. Upper thread hook device selection: Includes cylinder, electromagnet and no thread hook device.

Debug tool

Super user \*\*

Upper thread loosen device selection	cylinder
Upper thread tensile device selection	No tensile device
Bobbin thread buckling device selection	Magnet
Second Upper thread loosen device selection	cylinder
Template recognition device	Bar code
Rotary hook direction	forward
Template detecting device	No detection device
Automatic bobbin change device	No device
tension range	0 cN
Upper thread tension collection device trigger angle	0.00 deg

7/41

Page up

Page down

Ok

Cancel

61. 松面线装置选择：松面线装置包括气缸、电磁铁和无松面线装置。  
Upper thread loosen device selection: Includes cylinder, electromagnet and no device.

62. 拉面线装置选择：拉面线装置包括气缸、电磁铁和无拉面线装置。  
Upper thread tensile device selection: Includes cylinder, electromagnet and no device.

63. 扣底面线装置选择：扣底线装置包括气缸、电磁铁和无扣底线装置。  
Bobbin thread buckling device selection: Includes cylinder, electromagnet and no device.

64. Second Upper thread loosen device selection: Includes cylinder, electromagnet and no device.
65. Template recognition device: Includes Bar code, code hole and no device.
66. Rotary hook direction: Includes Forward, Left, Right and Up.
67. Template detection device: Includes No detection device and have detection device.
68. Automatic bobbin change device: Includes no device, Japan bobbin change device and Richpeace bobbin change device.
69. Tension range: Set the tension range of collection device.
70. Upper thread tension collection device trigger angle: Set the angle of upper thread tension collection device trigger angle.

Debug tool

Super user \*\*

X frame sensor coordinates	100.00 mm
Y frame sensor coordinates	100.00 mm
Main shaft stop sensor angle	45.00 deg
Lift sensor coordinates	122.00 mm
Presser foot sensor coordinates	1.00 mm
Rotate sensor angle	90.00 deg
Hook thread, main shaft sensor angle	202.00 deg
Perforation head stop angle	0.00 deg
Cutter stop angle	0.00 deg
X2 frame sensor coordinates	0.00 mm

8/41

Page up
Page down
Ok
Cancel

71. X frame sensor coordinates: Set the X frame sensor coordinates through this button, dimension is 0.01mm.
72. Y frame sensor coordinates: Set the Y frame sensor coordinates through this button, dimension is 0.01mm.

73. Main shaft stop sensor angle: Set the main shaft stop sensor angle, dimension is 0.01°

74. Lift sensor coordinates: Set the lift sensor coordinates, dimension is 0.01mm.

75. Presser foot sensor coordinates: Set the presser foot sensor coordinates, dimension is 0.01mm.

76. Rotate sensor angle: Set the rotate sensor angle, dimension is 0.01mm.

77. Hook thread, main shaft sensor angle: Set the main shaft sensor angle, dimension is 0.01°

78. Perforation head stop angle: Set the perforation head stop angle, dimension is 0.01°

79. Cutter stop angle: Set the cutter stop angle, dimension is 0.01°

80. X2 frame sensor coordinates: Set the X2 frame sensor coordinates, dimension is 0.01mm.

Debug tool

Super user \*\*

Y2 frame sensor coordinates	0.00 mm
Pulling motor sensor coordinates	0.00 mm
Point move, main shaft stop angle	0.00 deg
Flat embroidery main shaft stop angle	0.00 deg
YZR sensor coordinates	0.00 mm
LFL sensor coordinates	0.00 mm
RFL sensor coordinates	0.00 mm
Cut sensor coordinates	0.00 mm
X movable area negative boundary	-9200.00 mm
X movable area positive boundary	9504.00 mm

9/41

Page up

Page down

Ok

Cancel

81. Y2 frame sensor coordinates: Set the Y2 frame sensor coordinates, dimension is 0.01mm



82. Pulling motor sensor coordinates: Set the pulling motor sensor coordinates, dimension is 0.01mm.

83. Point move, main shaft stop angle: Set the main shaft stop sensor angle, dimension is 0.01°

84. Flat embroidery main shaft stop angle: Set the main shaft stop angle, dimension is 0.01°

85. YZR sensor coordinates: Set the YR frame sensor coordinates, dimension is 0.01mm.

86. LFL sensor coordinates: Set the sensor coordinates, dimension is 0.01mm.

87. RFL frame sensor coordinates: Set the RFL frame sensor coordinates, dimension is 0.01mm.

88. Cut sensor coordinates: Set the cut sensor coordinates.

89. X movable area negative boundary: Range-2147483648—2147483647, dimension is 0.01mm.

90. X movable area positive boundary: Range-2147483648—2147483647, dimension is 0.01mm.

Debug tool

Super user \*\*

Y movable area negative boundary	-770.00 mm
Y movable area positive boundary	988.00 mm
Head lifting top boundary	125.00 mm
Head lifting bottom boundary	78.00 mm
Presser foot lifiting top boundary	7.00 mm
Presser foot lifiting bottom boundary	1.00 mm
Motor presser pulse equivalent molecule	10000
Motor presser pulse equivalent denominator	467
Rotation range positive limit angle	430.00 deg
Rotation range negative limit angle	-230.00 deg

10/41

Page up

Page down

Ok

Cancel

91. Y movable area negative boundary: Range-2147483648—2147483647, dimension is 0.01mm.

92. Y movable area positive boundary: Range-2147483648—2147483647, dimension is 0.01mm.

93.Head lifting top boundary: Set the head lifting top boundary, dimension is 0.01mm.

94.Head lifting bottom boundary: Set the head lifting bottom boundary, dimension is 0.01mm.

95.Presser foot lifting top boundary: Set the presser foot lifting top boundary, dimension is 0.01mm.

96.Presser foot lifting bottom boundary: Set the presser foot lifting bottom boundary, dimension is 0.01mm.

97.Motor presser pulse equivalent molecule: Set the motor presser pulse equivalent molecule, Default 1000000.

98.Motor presser pulse equivalent denominator: Set the motor presser pulse equivalent denominator, Default 1115.

99.Rotation range positive limit angle: Set the rotation range positive limit angle, dimension is 0.01mm.

100. Rotation range negative limit angle: Set the rotation range negative limit angle, dimension is 0.01mm.

Debug tool

Super user \*\*

Perforation head migration in X	-200.00 mm
Perforation head migration in Y	0.50 mm
X Sewing area negative boundary	-33333.33 mm
X Sewing area positive boundary	950400.00 mm
Y Sewing area negative boundary	-33333.33 mm
Y Sewing area positive boundary	98800.00 mm
Perforation area negative boundary in X	92.00 mm
Perforation area positive boundary in X	672.38 mm
Perforation area negative boundary in Y	151.33 mm
Perforation area positive boundary in Y	953.52 mm

11/41

Page up

Page down

Ok

Cancel

101. Perforation head migration in X: Set the perforation head migration, dimension is 0.01mm.
102. Perforation head migration in Y: Set the perforation in Y, dimension is 0.01mm.
103. X sewing area negative boundary: range -2147483648—2147483647, dimension is 0.01mm.
104. X sewing area positive boundary: range -2147483648—2147483647, dimension is 0.01mm.
105. Y sewing area negative boundary: range -2147483648—2147483647, dimension is 0.01mm.
106. Y sewing area positive boundary: range -2147483648—2147483647, dimension is 0.01mm.
107. Perforation area negative boundary in X: range -2147483648—2147483647, dimension is 0.01mm.
108. Perforation area positive boundary in X: range -2147483648—2147483647, dimension is 0.01mm.
109. Perforation area negative boundary in Y: range -2147483648—2147483647, dimension is 0.01mm.
110. Perforation area positive boundary in Y: range -2147483648—2147483647, dimension is 0.01mm.

Debug tool

Super user \*\*

Right sewing head migration in X	0.00 mm
Right sewing head migration in Y	0.00 mm
Cutter head migration in X	0.00 mm
Cutter head migration in Y	0.00 mm
Cut area negative boundary in X	0.00 mm
Cut area positive boundary in X	0.00 mm
Cut area negative boundary in Y	0.00 mm
Cut area positive boundary in Y	0.00 mm
XY start stop speed	10 mm/s
XY zero reset speed	100 mm/s

12/41

Page up
Page down
Ok
Cancel

111. Right sewing head migration in X: Set the right sewing head migration in X, dimension is 0.01mm.
112. Right sewing head migration in Y: Set the right sewing head migration in Y, dimension is 0.01mm.
113. Cutter head migration in X: Set the cutter head migration in X, dimension is 0.01mm.
114. Cutter head migration in Y: Set the cutter head migration in Y, dimension is 0.01mm.
115. Cut area negative boundary in X: range -2147483648—2147483647, dimension 0.01mm.
116. Cut area positive boundary in X: range -2147483648—2147483647, dimension 0.01mm.
117. Cut area negative boundary in Y: range -2147483648—2147483647, dimension 0.01mm.
118. Cut area positive boundary in Y: range -2147483648—2147483647, dimension 0.01mm.
119. 。 XY start stop speed: Set the speed of XY start-stop, range 1-100 mm/s, Default 10.
120. XY zero reset speed: Set the speed of XY zero reset, range 1-100 mm/s, Default 100.

Debug tool

Super user \*\*

XY simulate running speed	300 mm/s
XY movement acceleration	1000 mm/s <sup>2</sup>
XY brake acceleration	10000 mm/s <sup>2</sup>
XY manual movement speed 1	10 mm/s
XY manual movement speed 2	100 mm/s
XY manual movement speed 3	300 mm/s
XY maximum moving speed	800 mm/s
Main shaft start stop speed	100 r/min
Main shaft zero reset speed	120 r/min
Main shaft running speed	300 r/min

13/41

Page up

Page down

Ok

Cancel

121. XY simulate running speed: Set the speed of XY simulate running, range 1-1000 mm/s, Default 300.

122. XY movement acceleration: Set the acceleration of XY movement, range 1-10000 mm/s<sup>2</sup>, Default 1000.

123. XY brake acceleration: Set the acceleration of XY brake, range 1-10000 mm/s<sup>2</sup>, Default 1000.

124. XY manual movement speed 1: Set the manual movement speed 1 of XY, range 1-1000 mm/s, Default 10.

125. XY manual movement speed 2: Set the manual movement speed 2 of XY, range 1-1000 mm/s, Default 100.

126. XY manual movement speed 3: Set the manual movement speed 3 of XY, range 1-1000 mm/s, Default 100.

127. XY maximum moving speed: Set the maximum moving speed of XY, range 1-1000 mm/s, Default 300.

128. Main shaft start stop speed: Set the start-stop speed of main shaft, range 1-300 rpm, Default 100.

129. Main shaft zero reset speed: Set the zero reset speed of main shaft, range 1-3000 rpm, Default 120.

130. Main shaft running speed: Set the running speed of main shaft, range 1-3000 rpm, Default 300.

Debug tool

Super user \*\*

Main shaft running acceleration	50 r/ss
Main shaft brake acceleration	100 r/ss
Sewing main shaft Max. speed	1200 r/min
Head lift start end speed	10 mm/s
Head lift zero reset speed	50 mm/s
Head lift move speed	200 mm/s
Head lift acceleration	500 mm/s <sup>2</sup>
Head movement brake acceleration	1000 mm/s <sup>2</sup>
Presser foot lifting speed	10 mm/s
Presser foot lift zero reset speed	30 mm/s

14/41

Page up

Page down

Ok

Cancel

131. Main shaft running acceleration: Set the running acceleration of main shaft, range 1-100 r/ss, Default 50.

132. Main shaft brake acceleration: Set the brake acceleration of main shaft, range is 1-100 r/ss, Default 100.

133. Sewing main shaft max. speed: Set the max. speed of sewing main shaft, range is 1-3000 rpm Default 3000.

134. Head lift start end speed: Set the start-stop speed of head lift, range is 1-250 mm/s, Default 10.

135. Head lift zero reset speed: Set the zero reset speed of head lift, range 1-250, Default 50.

136. Head lift move speed: Set the movement speed of head lift, range is 1-250, Default 200.

137. Head lift acceleration: Set the acceleration of head lift, range is 1-10000, dimension is mm/s<sup>2</sup>, Default 500.

138. Head movement brake acceleration: Set the brake acceleration of head movement, range is 1-10000, dimension is mm/s<sup>2</sup>, default 1000.

139. Presser foot lifting speed: Set the lifting speed of presser foot, range is 1-100, dimension is mm/s, default 10.

140. Presser foot lift zero reset speed: Set the speed of lift zero reset of presser foot, range is 1-100, dimension is mm/s, default 30.

Debug tool

Super user \*\*

Presser foot lifting speed	100 mm/s
Presser foot lifting acceleration	1000 mm/s <sup>2</sup>
Presser foot lift brake acceleration	10000 mm/s <sup>2</sup>
Head rotation start stop speed	10 deg/s
Head rotate zero reset speed	120 deg/s
Head rotate speed	400 deg/s
Head rotate acceleration	360 deg/s <sup>2</sup>
Head rotate brake acceleration	1000 deg/s <sup>2</sup>
Head rotate Max. speed	160 deg/s
Min. pen drawing speed	10 mm/s

15/41

Page up

Page down

Ok

Cancel

141. Presser foot lifting speed: Set the lifting speed of presser foot, range is 1-100, dimension is mm/s, default 10.

142. Presser foot lifting acceleration: Set the lifting acceleration of presser foot, range is 1-10000mm/s<sup>2</sup>, default 500.

143. Presser foot lifting brake acceleration: Set the lifting brake acceleration of presser foot, range 1-10000mm/s<sup>2</sup>, default 1000.
144. Head rotation start stop speed: Set the start-stop speed of head rotation.
145. Head rotation zero reset speed: Set the zero reset speed of head rotating.
146. Head rotate speed: Set the speed of head rotating.
147. Head rotate acceleration: Set the acceleration of head rotate.
148. Head rotate brake acceleration: Set the brake acceleration of head rotate.
149. Head rotate Max. speed: Set the maximum speed of head rotate.
150. Min. pen drawing speed: Set the minimum speed of pen drawing.

Debug tool

Super user \*\*

Max. pen drawing speed	100 mm/s
Pen drawing acceleration	500 mm/s <sup>2</sup>
Pen drawing decrease min. deviation angle	3000 deg
Conveyor belt start stop speed	0 mm/s
Manual speed of conveyor belt	0 mm/s
Conveyor belt speed speed	0 mm/s
Conveyor belt walking acceleration	0 mm/s <sup>2</sup>
Conveyor belt braking acceleration	0 mm/s <sup>2</sup>
Template frame start and stop speed	1 mm/s
Template frame move speed	20 mm/s

16/41

Page up

Page down

Ok

Cancel

151. Max. pen drawing speed: Set the maximum pen drawing speed.
152. Pen drawing acceleration: Set the acceleration of pen drawing.
153. Pen drawing decrease min. deviation angle: Set the decrease min. deviation angle of pen drawing.



- 154. Conveyor belt start stop speed: Set the start-stop speed of conveyor belt.
- 155. Manual speed of conveyor belt: Set the manual speed of conveyor belt
- 156. Conveyor belt walking speed: Set the walking speed of conveyor belt.
- 157. Conveyor walking acceleration: Set the walking acceleration of conveyor belt.
- 158. Conveyor brake acceleration: Set the brake acceleration of conveyor belt.
- 159. Template frame start and stop speed: Set the start-stop speed of template frame.
- 160. Template frame walking speed: Set the walking speed of template frame.

Debug tool

Super user \*\*

Template frame move acceleration	4 mm/s <sup>2</sup>
Template frame brake acceleration	10 mm/s <sup>2</sup>
Upper head rotate zero reset compensation angle	0.00 deg
Lower head rotate zero reset compensation angle	5.00 deg
Main shaft zero reset compensation angle	0.00 deg
X-axis zero reset compensation	0.00 mm
Y-axis zero reset compensation	0.00 mm
Flat embroidery had migration in X	0.00 mm
Flat embroidery had migration in Y	0.00 mm
Flat embroidery X area negative boundary	0.00 mm

17/41

Page up
Page down
Ok
Cancel

- 161. Template frame walking accelerator: Set the walking accelerator of template frame.
- 162. Template frame brake acceleration: Set the brake acceleration of template frame.
- 163. Upper head rotate zero reset compensation angle: Set the rotate zero reset compensation angle of upper head

164. Lower head rotate zero reset compensation angle: Set the rotate zero reset compensation angle of lower head
165. Main shaft zero reset compensation angle: Set the zero reset compensation angle of main shaft.
166. X-axis zero reset compensation: Set the X-axis zero reset compensation
167. Y-axis zero reset compensation: Set the Y-axis zero reset compensation
168. Flat embroidery head migration in X: Set the migration in X of flat embroidery, dimension is 0.01mm.
169. Flat embroidery head migration in Y: Set the migration in Y of flat embroidery, dimension is 0.01mm.
170. Flat embroidery X area negative boundary: range -2147483648—2147483647, dimension is 0.01mm.

Debug tool

Super user \*\*

Flat embroidery X area positive boundary	0.00 mm
Flat embroidery Y area negative boundary	0.00 mm
Flat embroidery Y area positive boundary	0.00 mm
Punch rotation start and stop speed	0 deg/s
Punch rotation speed to zero	0 deg/s
Punch rotation speed	0 deg/s
Punch rotation acceleration	0 deg/s
Punch rotation brake acceleration	0 deg/s
Maximum speed of punch rotation	0 deg/s
Speed of pendulum start and stop	0 mm/s

18/41

Page up
Page down
Ok
Cancel

171. Flat embroidery X area positive boundary: range -2147483648—2147483647, dimension is 0.01mm.

172. Flat embroidery Y area negative boundary: range -2147483648—2147483647, dimension is 0.01mm.
173. Flat embroidery Y area positive boundary: range -2147483648—2147483647, dimension is 0.01mm.
174. Punch rotation start and stop speed: Set the speed of punch rotation start and stop.
175. Punch rotation speed to zero: Set the zero reset of punch rotation.
176. Punch rotation speed: Set the speed of punch rotation.
177. Punch rotation acceleration: Set the acceleration of punch rotation.
178. Punch Rotation brake acceleration: Set the brake acceleration of punch rotation.
179. Maximum speed of punch rotation: Set the maximum speed of punch rotation.
180. Speed of pendulum start and stop: Speed of pendulum start and stop

Debug tool

Super user \*\*

Pendulum needle return speed	0 mm/s
Pendulum speed	0 mm/s
Pendulum movement acceleration	0 mm/s <sup>2</sup>
Pendulum needle	0
Pendulum negative border	0
Pendulum needle change compensation	0
Pen migration in X	0.00 mm
Pen migration in Y	75.00 mm
Tufting migration in X	0.00 mm
Tufting migration in Y	0.00 mm

19/41

Page up
Page down
Ok
Cancel

181. Pendulum needle return speed: Set the speed of pendulum needle zero reset.

182. Pendulum speed: Set the pendulum speed.
183. Pendulum movement acceleration: Set the movement acceleration of pendulum needle.
184. Pendulum needle: Set the positive boundary of pendulum needle.
185. Pendulum negative boundary: Set the negative boundary of pendulum needle.
186. Pendulum needle change compensation: Set the pendulum needle change compensation.
187. Pen migration in X: Set the X coordinates of pen migration, dimension is 0.01mm.
188. Pen migration in Y: Set the Y coordinates of pen migration, dimension is 0.01mm.
189. Tufting migration in X: Set the X coordinates of tufting migration, dimension is 0.01mm.
190. Tufting migration in Y: Set the Y coordinates of tufting migration, dimension is 0.01mm.

Debug tool

Super user \*\*

Encoder coefficient molecule	0
Encoder coefficient denominator	0
Zero cut distance	0.00 mm
Feeding device selection	No
Cross cutting device selection	No
Fabric clamp device selection	No
Tension device selection	No
Edge cutting device selection	No
Left feeding device selection	No
Right Feeding device selection	No

20/41

Page up
Page down
Ok
Cancel

191. Encoder coefficient molecule: Set the encoder coefficient molecule.
192. Encoder coefficient denominator: Set the encoder coefficient denominator.
193. Zero cut distance: Range -2147483648—2147483647, dimension is 0.01mm.
194. Feeding device selection: Includes Yes and No.
195. Cross cutting device selection: Includes Yes and No.
196. Fabric clamp device selection: Includes Yes and No.
197. Tension device selection: Includes Yes and No.
198. Edge cutting device selection: Includes Yes and No.
199. Left feeding device selection: Includes Yes and No.
200. Right feeding device selection: Includes Yes and No.

Debug tool

Super user \*\*

Cutting confirmation function	No
Side cutting lifting device	No
Return material motor device	No
Spreading motor device	No
Left loading point X	-304.63 mm
Left loading point Y	103.00 mm
Right loading point X	1370.04 mm
Right loading point Y	103.00 mm
Template frame width	50.00 mm
Non-stop sewing area negative boundary in frame left X-axis 0.00 mm	

21/41

Page up

Page down

Ok

Cancel

201. Cutting confirmation function: Includes Yes and No.

202. Side cutting lifting device: Includes Yes and No.
203. Return material motor device: Includes Yes and No.
204. Spreading motor device: Spreading motor device  
Spreading motor device: Includes Yes and No.
205. Left loading point X: Set the point X of left loading, range -2147483648—2147483647, dimension is 0.01mm.
206. Left loading point Y: Set the point Y of left loading, range -2147483648—2147483647, dimension is 0.01mm.
207. Right loading point X: Set the point X of right loading, range -2147483648—2147483647, dimension is 0.01mm.
208. Right loading point Y: Set the point Y of right loading, range -2147483648—2147483647, dimension is 0.01mm.
209. Template frame width: Set the width of template, range -2147483648—2147483647, dimension is 0.01mm.
210. Non-stop sewing area negative boundary in frame left X-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.

Debug tool

Super user \*\*

---

Non-stop sewing area positive boundary in frame left X-axis 0.00 mm

---

Non-stop sewing area negative boundary in frame left Y-axis 0.00 mm

---

Non-stop sewing area positive boundary in frame left Y-axis 0.00 mm

---

Non-stop sewing area negative boundary in frame right X-axis 0.00 mm

---

Non-stop sewing area positive boundary in frame right X-axis 0.00 mm

---

Non-stop sewing area negative boundary in frame right Y-axis 0.00 mm

---

Non-stop sewing area positive boundary in frame right Y-axis 0.00 mm

---

Sewing main shaft working speed

800 r/min

---

Cut thread, main shaft speed

120 r/min

---

Needle reset, main shaft speed

400 r/min

---

22/41

Page up

Page down

Ok

Cancel

211. Non-stop sewing area positive boundary in frame left X-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
212. Non-stop sewing area negative boundary in frame left Y-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
213. Non-stop sewing area positive boundary in frame left Y-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
214. Non-stop sewing area negative boundary in frame right X-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
215. Non-stop sewing area positive boundary in frame right X-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
216. Non-stop sewing area negative boundary in frame right Y-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
217. Non-stop sewing area positive boundary in frame right Y-axis: Set this boundary, range -2147483648—2147483647, dimension is 0.01mm.
218. Sewing main shaft working speed: Set the speed of main shaft working, dimension is rpm.
219. Cut thread, main shaft speed: Set the rotate speed of main shaft cutting thread, dimension is rpm.
220. Needle reset, main shaft speed: Set the needle reset speed of main shaft, dimension is rpm.

Debug tool

Super user \*\*

Main shaft start slow speed	500 r/min
Reverse equivalent main shaft running value	1000 r/min
Sewing frame movement mode	Xy intermittent moving frame
Sewing acceleration and deceleration mode	Xy sine acceleration and decelerat:
Sewing head rotate mode	Xy intermittent rotation
Sewing head deceleration mode	Intermittent acceleration and dece:
Sewing frame start angle	280.00 deg
Sewing frame steadiness angle	150.00 deg
No. of slow stitch at beginning	3 Needle
Needle action, thread loosen allowed	Not allow

23/41

Page up
Page down
Ok
Cancel

221. Main shaft start slow speed: Set the start slow speed of main shaft, dimension is rpm.

222. Reverse equivalent main shaft running value: Set the running value of reverse equivalent main shaft.

223. Sewing frame movement mode: Choose the mode of sewing frame movement, includes XY intermittent moving frame and XY continuous moving frame.

224. Sewing acceleration and deceleration mode: Includes XY sine acceleration and deceleration, and no acceleration and deceleration.

225. Sewing head rotate mode: Includes XY intermittent rotation and continuous rotation.

226. Sewing head deceleration mode: Includes Intermittent acceleration and deceleration and no acceleration and deceleration.

227. Sewing frame start angle: Set the start angle of sewing frame, range 0-36000, dimension is 0.01°, default 28000.

228. Sewing frame steadiness angle: Set the steadiness angle of sewing frame, range 0-36000, dimension is 0.01°, default 15000.



229. No. of slow stitch at beginning: It means the number of needle from still to acceleration, range 0-10, dimension is 1, default 3.

230. Needle action, thread loosen allowed: Set the allowance, includes allow and not allow.

Debug tool

Super user \*\*

Needle action,tight bobbin spring allowed	Not allow
Needle action, catch upper thread allowed	allowed
Needle action, needle swing allowed	Not allow
Cut thread allowed	Automatic thread trimming
Trimmer cutting angle	150.00 deg
Trimming completion angle	60.00 deg
Thread cut, upper thread loosen allowed	allowed
Thread cut, tensile thread allowed	Not allow
Thread cut, catch upper thread allowed	allowed
Thread cut, presser foot lift allowed	Not allow

24/41

Page up
Page down
Ok
Cancel

231. Needle action, tight bobbin spring allowed: Set the allowance of needle action, includes allow and not allow.

232. Needle action, catch upper thread allowed: Set the allowance of catch upper thread, includes allow and not allowed.

233. Needle action, needle swing allowed: Set the needle sewing, includes allow and not allowed.

234. Cut thread allowed: Set the allowance of cut thread, includes automatic thread trimming, data trimming and no trimming.

235. Trimmer cutting angle: Set the trimmer cutting angle. Range 0-36000, dimension is 0.01°,default 20000.

236. Trimming completion angle: Set the trimming completion angle, range 0-36000, dimension is 0.01°, default 6000.

237. Thread cut, upper thread loosen allowed: Set the allowance of loosen, includes allow and not allow.

238. Thread cut, tensile thread allowed: Set the allowance of tensile thread, includes allow and not allow.

239. Thread cut, catch upper thread allowed: Set the allowance of catching upper thread, includes allow and not allow.

240. Thread cut, presser foot lift allowed: Set the allowance of presser foot lift, includes allow and not allow.

Debug tool

Super user \*\*

No. of stitch detect if thread broken	0 Needle
Thread brake detection, main shaft angle	80.00 deg
Bobbin change reminder function	Count by number of slices
Bobbin thread length	0.00 mm
Bobbin thread correction per stitch	0.00 mm
Bobbin change as per sewed pieces	3 times
Oiling mode selection	Oiling intermittently by working hou
Oiling interval by needle stitch	0 Needle
Oiling interval by working time	1800 s
Oiling sustained time	3 s

25/41

Page up

Page down

Ok

Cancel

241. No. of stitch detect if thread broken: Set the number of stitch detect, default 3.

242. Thread brake detection, main shaft angle: Set the main shaft angle, range 0-36000, dimension is 0.01°, default 3000.

243. Bobbin change reminder function: Set the count by piece number, reminder immediately by length, disable, delay length remind. Default Disable.

244. Bobbin thread length: Set the length of bobbin thread, dimension is 0.01mm, default 10000000.

245. Bobbin thread correction per stitch: Set the bobbin thread correction per stitch, dimension is 0.01mm.

246. Bobbin change as per sewed pieces: Set the count of bobbin change pieces, default 0.

247. Oiling mode selection: No oiling, oiling intermittently by working hours, oiling intermittently by number of working needles, oiling continuously.

248. Oiling interval by needle stitch: default 10000.

249. Oiling interval by working time: dimension is second.

250. Oiling sustained time: Dimension is second.

Debug tool

Super user \*\*

Main shaft stop position selection after work complete	start point
Migration point coordinate valid symbol	Xy is valid at the same time
Migration point coordinate in X	526.52 mm
Migration point coordinate in Y	86.74 mm
Threading point coordinate valid symbol	invalid
Threading point coordinates X	0.00 mm
Threading point coordinates Y	0.00 mm
Head lift bottom position	8.00 mm
Head lift top position	0.00 mm
Production preset	999999999

26/41

Page up

Page down

Ok

Cancel

251. 完成后停车位置选择：机器完成当前工作时的停车位置选择。可以设置为：当前位置、回起点、回上料点、回定位点、回偏移点。默认为：回偏移点。  
Main shaft stop position selection after work complete: Current position, back to start position, feeding position, location point, offset point. Default is back to offset point.

252. Migration point coordinate valid symbol:
253. Migration point coordinate in X: Set the migration point coordinate in X, dimension 0.01mm.
254. Migration point coordinate in Y: Set the migration point coordinate in Y, dimension 0.01mm.
255. Threading point coordinate valid symbol: Set this valid symbol, such as, invalid, X valid, Y valid, XY valid concurrently. Default invalid.
256. Threading point coordinate in X: Set the threading point coordinate in X, dimension 0.01mm.
257. Threading point coordinate in Y: Set the threading point coordinate in Y, dimension 0.01mm.
258. Head lift bottom position: Set the height of head lift bottom, dimension 0.01mm.
259. Head lift top position: Set the height of head lift top, dimension 0.01mm.
260. Production preset: Set the production preset.

Debug tool

Super user \*\*

Illumination brightness	128
Delay after pneumatic frame off	500
Sewing acceleration	50 r/ss
Trimming frame displacement	6.00 mm
Needle cooling(air blow) allowed	allowed
Needle action, needle swing allowed	Not allow
Automatic move to threading point allowed	Not allow
Head rotate allowed	allowed
Strips sending allowed	Not allow
Perforation air blow allowed	allowed

27/41

Page up
Page down
Ok
Cancel

261. Illumination brightness: Set the illumination brightness, range 0-255, default 128.
262. Delay after pneumatic frame off: Set the delaying time after pneumatic frame off.
263. Sewing acceleration: Set the sewing acceleration.
264. Trimming frame displacement: Set the trimming frame displacement.
265. Needle cooling(air blow) allowed: Set open or close to needle cooling.
266. Needle action, needle swing allowed: Set open or close to needle action sewing.
267. Automatic move to threading point allowed: Set the automatic move to threading point.
268. Head rotate allowed: Set the head rotate.
269. Strips sending allowed: Set the allowance of strips sending.
270. Perforation air blow allowed: Set the allowance of perforation air blow.

Debug tool

Super user \*\*

Vacuum cleaner off delay	5 s
Perforation main shaft speed	800 r/min
Perforation acceleration	20 r/min
Perforation frame movement mode	Xy intermittent moving frame
Perforation acceleration and deceleration mode	Xy sine acceleration and deceleration
Perforation frame start angle	200.00 deg
Perforation frame sustained angle	200.00 deg
Sewing move head up down	allowed
Punching move head up down	allowed
Moving basket Loose line	allowed

28/41

Page up
Page down
Ok
Cancel

271. Vacuum cleaner off delay: Set the time of vacuum cleaner off delaying.
272. Perforation main shaft speed: Set the rotate speed of perforation main shaft.
273. Perforation acceleration: Set the rotate speed of perforation acceleration.
274. Perforation frame movement mode: Set the mode of perforation frame movement.
275. Perforation acceleration & deceleration mode: Set the mode of perforation acceleration & deceleration.
276. Perforation frame start angle: Set the angle of perforation frame start.
277. Perforation frame sustained angle: Set the sustained angle of perforation frame.
278. Sewing move head up down: Set the allowance while sewing move head up and down.
279. Punching move head up down: Set the allowance while punching move up and down.
280. Moving basket loose line: Set the allowance while moving basket loose line.

Debug tool

Super user \*\*

Moving basket Clamp line	Not allow
Auto boxing allowed	Not allow
Software limit XY move allowed	Off
Software limit sewing head lifting allowed	Not allow
Software limit punch head lifting allowed	Not allow
Software limit cutter head lift	Not allow
Shuttle rotation angle	180.00 deg
Rotational continuous angle	280.00 deg
Number of Needle hooks	3 Needle
Presser foot height during sewing work	0.00 mm

29/41

Page up
Page down
Ok
Cancel

281. Moving basket clamp line: Set the allowance while moving basket clamp line.
282. Auto boxing allowed: Set the allowance of auto boxing.
283. Software limit XY move allowed: Set the allowance of software limit XY move.
284. Software limit sewing head lifting allowed: Set the allowance of software limit sewing head lifting.
285. Software limit punch head lifting allowed: Set the allowance of software limit punch head lifting.
286. Software limit cutter head lift: Set the allowance of software limit cutter head lift.
287. Shuttle rotation angle: Set the angle of shuttle rotation sensor.
288. Rotational continuous angle: Set the angle of rotational continuous sensor.
289. Number of Needle hooks: Set the number of needle hooks.
290. Presser foot height during sewing work: Set the height of presser foot while sewing.

Debug tool

Super user \*\*

Head height during simulated work	0.00 mm
Cutter working speed	1200 r/min
Cutter acceleration	20 r/ss
Trimming frame direction	right
track formed up and down	0.00 mm
Spindle corner speed	1 r/min
Minimum speed deviation angle	0 deg
Early speed reduction	0
Delayed speed step	0
Cloth roller speed coefficient	0 %

30/41

Page up
Page down
Ok
Cancel

291. Head height during simulation work: Set the height of head while simulation working.
292. Cutter working speed: Set the speed of cutter working.
293. Cutter acceleration: Set the acceleration of cutter.
294. Trimming frame direction: Set the trimming frame direction. Includes forward, backward, left and right.
295. Track formed up and down: Set the track of formed up and down.
296. Spindle corner speed: Set the rotation speed of spindle corner.
297. Minimum speed deviation angle: Set the angle minimum deviation sensor.
298. Early speed reduction: Set the needle step of early reduction.
299. Delayed speed step: Set the needle step of delayed reduction.
300. Cloth roller speed coefficient: Set the rate of cloth roller speed coefficient.

Debug tool

Super user \*\*

Action when begin	0
Work head selection 1	allowed
Work head selection 2	allowed
Work head selection 3	Not allow
Work head selection 4	Not allow
Work head selection 5	Not allow
Work head selection 6	Not allow
Work head selection 7	Not allow
Work head selection 8	Not allow
Work head selection 9	Not allow

31/41

Page up
Page down
Ok
Cancel



301. Action when begin: Set the action when start the machine.
302. Work head selection 1: Set the work head selection 1, includes allow and not allow.
303. Work head selection 2: Set the work head selection 2, includes allow and not allow.
304. Work head selection 3: Set the work head selection 3, includes allow and not allow.
305. Work head selection 4: Set the work head selection 4, includes allow and not allow.
306. Work head selection 5: Set the work head selection 5, includes allow and not allow.
307. Work head selection 6: Set the work head selection 6, includes allow and not allow.
308. Work head selection 7: Set the work head selection 7, includes allow and not allow.
309. Work head selection 8: Set the work head selection 8, includes allow and not allow.
310. Work head selection 9: Set the work head selection 9, includes allow and not allow.

Debug tool

Super user \*\*

Work head selection 10	Not allow
Work head selection 11	Not allow
Work head selection 12	Not allow
Work head selection 13	Not allow
Work head selection 14	Not allow
Work head selection 15	Not allow
Work head selection 16	Not allow
Work head selection 17	Not allow
Work head selection 18	Not allow
Work head selection 19	Not allow

32/41

Page up
Page down
Ok
Cancel

311. Work head selection 10: Set the work head selection 10, includes allow and not allow.
312. Work head selection 11: Set the work head selection 11, includes allow and not allow.
313. Work head selection 12: Set the work head selection 12, includes allow and not allow.
314. Work head selection 13: Set the work head selection 13, includes allow and not allow.
315. Work head selection 14: Set the work head selection 14, includes allow and not allow.
316. Work head selection 15: Set the work head selection 15, includes allow and not allow.
317. Work head selection 16: Set the work head selection 16, includes allow and not allow.
318. Work head selection 17: Set the work head selection 17, includes allow and not allow.
319. Work head selection 18: Set the work head selection 18, includes allow and not allow.
320. Work head selection 19: Set the work head selection 19, includes allow and not

Debug tool

Super user \*\*

Work head selection 20	Not allow
Work head selection 21	Not allow
Work head selection 22	Not allow
Work head selection 23	Not allow
Work head selection 24	Not allow
Work head selection 25	Not allow
Work head selection 26	Not allow
Work head selection 27	Not allow
Work head selection 28	Not allow
Work head selection 29	Not allow

33/41

Page up

Page down

Ok

Cancel

321. Work head selection 20: Set the work head selection 20, includes allow and not allow.

322. Work head selection 21: Set the work head selection 21, includes allow and not allow.

323. Work head selection 22: Set the work head selection 22, includes allow and not allow.

324. Work head selection 23: Set the work head selection 23, includes allow and not allow.

325. Work head selection 24: Set the work head selection 24, includes allow and not allow.

326. Work head selection 25: Set the work head selection 25, includes allow and not allow.

327. 。 Work head selection 26: Set the work head selection 26, includes allow and not allow.

328. Work head selection 27: Set the work head selection 27, includes allow and not allow.

329. Work head selection 28: Set the work head selection 28, includes allow and not allow.

330. Work head selection 29: Set the work head selection 29, includes allow and not allow.

Debug tool

Super user \*\*

Work head selection 30	Not allow
Work head selection 31	Not allow
Secure input light curtain allows	Not allow
Safety input pressure allowed	allowed
Safe input power-on signal allowed	Not allow
Safe door allowed	Not allow
Manual / Auto allowed	Not allow
Pneumatic frame off	allowed
Penumatic frame on	allowed
Automatic air frame closing delay	1000 ms

34/41

Page up

Page down

Ok

Cancel

331. Work head selection 30: Set the work head selection 30, includes allow and not allow.

332. Work head selection 31: Set the work head selection 31, includes allow and not allow.

333. Secure input light curtain allows: Includes allow and not allow.

334. Safety input pressure allowed: Includes allow and not allow.

335. Safe input power-on signal allowed: Includes allow and not allow.

336. Safe door allowed: Includes allow and not allow.

337. Manual/Auto allowed: Choose to manual or auto mode.

338. Pneumatic frame off: Includes allow and not allow.

339. Pneumatic frame on: Includes allow and not allow.

340. Automatic air frame closing delay: Set the closing delay time of automatic air frame.

Debug tool

Super user \*\*

Stitch offset allows	Not allow
Loop work allowed	Not allow
Right Work head selection 1	Not allow
Right Work head selection 2	Not allow
Right Work head selection 3	Not allow
Right Work head selection 4	allowed
Right Work head selection 5	Not allow
Right Work head selection 6	Not allow
Right Work head selection 7	Not allow
Right Work head selection 8	Not allow

35/41

Page up

Page down

Ok

Cancel

341. Stitch offset allows: Includes allow and not allow.

Loop work allowed: Includes allow and not allow.

342. Right Work head selection 1: Includes allow and not allow.

343. Right Work head selection 2: Includes allow and not allow.

344. Right Work head selection 3: Includes allow and not allow.

345. Right Work head selection 4: Includes allow and not allow.

346. Right Work head selection 5: Includes allow and not allow.

347. Right Work head selection 6: Includes allow and not allow.

348. Right Work head selection 7: Includes allow and not allow.

349. Right Work head selection 8: Includes allow and not allow.

Debug tool

Super user \*\*

Right Work head selection 9	Not allow
Right Work head selection 10	Not allow
Right Work head selection 11	Not allow
Right Work head selection 12	Not allow
Right Work head selection 13	Not allow
Right Work head selection 14	Not allow
Right Work head selection 15	Not allow
Right Work head selection 16	Not allow
Right Work head selection 17	Not allow
Right Work head selection 18	Not allow

36/41

Page up Page down Ok Cancel

350. Right Work head selection 9: Includes allow and not allow.
351. Right Work head selection 10: Includes allow and not allow.
352. Right Work head selection 11: Includes allow and not allow.
353. Right Work head selection 12: Includes allow and not allow.
354. Right Work head selection 13: Includes allow and not allow.
355. Right Work head selection 14: Includes allow and not allow.
356. Right Work head selection 15: Includes allow and not allow.
357. Right Work head selection 16: Includes allow and not allow.
358. Right Work head selection 17: Includes allow and not allow.
359. Right Work head selection 18: Includes allow and not allow.

Debug tool

Super user \*\*

Right Work head selection 19	Not allow
Right Work head selection 20	Not allow
Right Work head selection 21	Not allow
Right Work head selection 22	Not allow
Right Work head selection 23	Not allow
Right Work head selection 24	Not allow
Right Work head selection 25	Not allow
Right Work head selection 26	Not allow
Right Work head selection 27	Not allow
Right Work head selection 28	Not allow

37/41

Page up

Page down

Ok

Cancel

360. 右工作头选择 19：按此功能键可以对工作头选择 19 进行设置，包括允许和不允许。

Right Work head selection 19: Includes allow and not allow.

361. 右工作头选择 20：按此功能键可以对工作头选择 20 进行设置，包括允许和不允许。

Right Work head selection 20: Includes allow and not allow.

362. 右工作头选择 21：按此功能键可以对工作头选择 21 进行设置，包括允许和不允许。

Right Work head selection 21: Includes allow and not allow.

363. 右工作头选择 22：按此功能键可以对工作头选择 22 进行设置，包括允许和不允许。

Right Work head selection 22: Includes allow and not allow.

364. 右工作头选择 23：按此功能键可以对工作头选择 23 进行设置，包括允许和不允许。

Right Work head selection 23: Includes allow and not allow.

365. 右工作头选择 24：按此功能键可以对工作头选择 24 进行设置，包括允许和不允许。

Right Work head selection 24: Includes allow and not allow.

366. Right Work head selection 25: Includes allow and not allow.

367. Right Work head selection 26: Includes allow and not allow.

368. Right Work head selection 27: Includes allow and not allow.

369. Right Work head selection 28: Includes allow and not allow.

Debug tool

Super user \*\*

Right Work head selection 29	Not allow
Right Work head selection 30	Not allow
Right Work head selection 31	Not allow
Pulling motor pull position	0.00 mm
Pull length	0.00 mm
Cutting length	0.00 mm
Shuttle Oiling sustained time	0 s
Clamping force 1	0 %
Clamping force 2	0 %
Clamping force 3	0 %

38/41

Page up

Page down

Ok

Cancel

370. Right Work head selection 29: Includes allow and not allow.

371. Right Work head selection 30: Includes allow and not allow.

372. Right Work head selection 31: Includes allow and not allow.

373. Pulling motor pull position: Set the pulling position of pulling motor.

374. Pull length: Set the length of pulling material.

375. Cutting length: Set the cutter length.

376. Shuttle Oiling sustained time: Set the sustained time of shuttle oiling.



377. Clamping force 1: Set the clamping force 1.

378. Clamping force 2: Set the clamping force 2.

379. Clamping force 3: Set the clamping force 3.

Debug tool

Super user \*\*

Clamping force 4	0 %
Flat embroidery spindle working speed	0 r/min
Flat embroidery acceleration	0 r/ss
Flat embroidery frame	Xy continuous moving frame
Flat embroidery acceleration mode	No acceleration or deceleration
Flat embroidery frame starting angle	0.00 deg
Flat embroidery frame continuous angle	0.00 deg
Spindle Speed of Flat Embroidery Jump Needle	0 r/min
Flat stitch jump stitches	0 Needle
Maximum speed of flat embroidery moving frame	0 mm/s

39/41

Page up

Page down

Ok

Cancel

380. Clamping force 4: Set the clamping force 4.

381. Flat embroidery spindle working speed: Set the working speed of flat embroidery spindle.

382. Flat embroidery acceleration: Set the acceleration of flat embroidery.

383. Flat embroidery frame: Set the mode of flat embroidery frame, includes XY continuous moving frame and XY intermittent moving frame.

384. Flat embroidery acceleration mode: Includes no acceleration or deceleration and XY sine acceleration & deceleration.

385. Flat embroidery frame starting angle: Set the starting angle of flat embroidery frame.

386. Flat embroidery frame continuous angle: Set the continuous angle of flat embroidery frame.

387. Spindle speed of flat embroidery jump needle: Set the max. spindle speed of flat embroidery jump needle.

388. Flat stitch jump stitches: Set the jump stitches of flat stitch.

389. Maximum speed of flat embroidery moving frame: Set the maximum speed of flat embroidery moving frame.

Debug tool

Super user \*\*

Manual clamp force 1	0 %
Manual clamp force 2	0 %
Second clamp force 1	0 %
Second clamp force 2	0 %
Second clamp force 3	0 %
Second clamp force 4	0 %
Tensioning distance	0.00 mm
Non-Stop work mode	independent
Feeding direction of hopper 1 motor	Coil
Feeding direction of hopper 2 motor	Coil

40/41

Page up

Page down

Ok

Cancel

390. 手动夹线 1：按此功能键可以对手动夹线 1 进行设置。

Manual clamp force 1: Set the manual clamp force 1.

391. 手动夹线 2：按此功能键可以对手动夹线 2 进行设置。

Manual clamp force 2: Set the manual clamp force 2.

392. 第二加夹线力度 1：按此功能键可以对第二加夹线力度 1 进行设置。

Second clamp force 1: Set the second clamp force 1.

393. 第二加夹线力度 2：按此功能键可以对第二加夹线力度 2 进行设置。

Second clamp force 2: Set the second clamp force 2.

- 394. Second clamp force 3: Set the second clamp force 3.
- 395. Second clamp force 4: Set the second clamp force 4.
- 396. Tensioning distance: Set the distance of tensioning.
- 397. Non-stop work mode: Set the mode of non-stop working.
- 398. Feeding direction of hooper 1 motor: Set the feeding direction of hooper 1 motor.
- 399. Feeding direction of hooper 2 motor: Set the feeding direction of hooper 2 motor.

Debug tool

Super user \*\*

---

Fixture jig size	0.00 mm
Cylinder action mode	back
High of knife	0.00 mm
Low of knife	0.00 mm
Angle of knife	0.00 deg

41/41

Page up
Page down
Ok
Cancel

- 400. Fixture jig size: Set the size of fixture jig.
- 401. Cylinder action mode: Set the mode of cylinder action.
- 402. High of knife: Set the height of knife.
- 403. Low of knife: Set the low of knife.
- 404. Angle of knife: Set the angle of knife.