



SunStar®

USER'S MANUAL

SPS/A-Pattern Series SPS/B-Pattern Series SPS/C-Pattern Series

Electronically Controlled
Pattern Sewing Machine
(Electronic Control Part)



- 1) FOR AT MOST USE WITH EASINESS, PLEASE CERTAINLY READ THIS MANUAL BEFORE STARTING USE.
- 2) KEEP THIS MANUAL IN SAFE PLACE FOR REFERENCE WHEN THE MACHINE BREAKS DOWN.

SUNSTAR MACHINERY CO., LTD.

MEE-080701




1. Thank you for purchasing our product. Based on the rich expertise and experience accumulated in industrial sewing machine production, SUNSTAR will manufacture industrial sewing machines, which deliver more diverse functions, high performance, powerful operation, enhanced durability, and more sophisticated design to meet a number of user's needs.
2. Please read this user's manual thoroughly before using the machine. Make sure to properly use the machine to enjoy its full performance.
3. The specifications of the machine are subject to change, aimed to enhance product performance, without prior notice.
4. This product is designed, manufactured, and sold as an industrial sewing machine. It should not be used for other than industrial purpose.



SUNSTAR MACHINERY CO., LTD.

Organization of the Pattern S/M Model



- ☐ Pattern Type
 - A : Belt Type
 - B : Direct Type
 - C : Separated upper and lower operation type

- ☐ Sewing Type
 - 1306 : X(130mm), Y(60mm)
 - 1310 : X(130mm), Y(100mm)
 - 1507 : X(150mm), Y(70mm)
 - 1811 : X(180mm), Y(110mm)
 - 2211 : X(220mm), Y(110mm)
 - 2516 : X(250mm), Y(160mm)
 - 3020 : X(300mm), Y(200mm)
 - 5030 : X(500mm), Y(300mm)
 - 5050 : X(500mm), Y(500mm)
 - 8050 : X(800mm), Y(500mm)

- ☐ Material Type
 - G:General Material
 - H:Heavy Material

- ☐ Stitch
 - S:Standard Stitch
 - P:Perfect Stich

- ☐ Feed Frame
 - 10:Electronic
 - 20:Pneumatic Monolithic Feeding Frame
 - 22:Pneumatic Separately-Driven Feeding
 - 23:Pneumatic Reverse Device
 - Attach/Separate Feed Frame

- ☐ SPS/C-Series
 - 01:Arm Lifting Type
 - 02:Fixed Arm Type

CONTENT

1. Machine Safety Regulations	6
2. I/O Board Dip Switch Setting	9
3. Basic Operational Method	10
1) Name and roles of each key on operation unit	10
2) Name and description of each display contents on general operation mode	11
3) Flow chart of general operation	12
4) Work flow of pattern programming	13
5) Operating after reading the patterns from floppy disks	14
6) Confirming the working pattern read from the floppy disks	14
7) When a machine stops operating during sewing by the thread cut	15
8) Emergency stop during operation	15
9) Winding the thread	15
10) Safety Functions	16
4. Applicable Operation	19
1) Pattern Data Generation Function	19
1-1) Program example 1 : Generating the square pattern	19
1-2) Program example 2 : Generating the circle pattern	21
1-3) Program example 3 : Generating the double curve pattern	23
1-4) Program example 4 : Pattern generation by using the second origin and pause	26
1-5) Zigzag shape selecting function to generate zigzag	30
2) Pattern Data Edit Function	32
2-1) One stitch movement function	32
2-2) Partial movement function of pattern data	33
2-3) A fix number of stitch delete function	35
2-4) Partial pattern data delete function	36
2-5) Partial stitch width changing function	38
2-6) Pattern partial copy function	39
2-7) Pattern data inserting function	41
3) Pattern Data Application Function	43
3-1) Operating after moving to a random start point to sew or the second origin	43
3-2) Program example 5 : Change of sewing speed within a pattern	44
3-2-1) Changing the sewing speed from an existing pattern data	44
3-2-2) Changing the sewing speed by making new pattern data	47
3-3) Program example 6 : Use of reversal	49
3-3-1) Pattern programming by using reversal	49
3-3-2) Adding the code to already programmed pattern	52
3-4) Using the extension/reduction modes	54
3-5) Using the chain sewing mode	56
3-6) Change/saving function of pattern data start point	58
3-7) Change/saving function of pattern 2nd original point	60
3-8) Change/saving function of maximum pattern sewing speed and extension/reduction rate	61
3-9) Symmetrical shape creating function of pattern	63
3-10) Condensed sewing stitch inserting function	64
3-11) Automatic Back Tack(B/T) inserting function	66
3-12) OverLap sewing stitch inserting function	67
3-13) Automatic insertion of thread trimmer code when deleting stitches	69
3-14) Setting-up reference point for zooming	70
3-15) Embroidery design call function	72
3-16) JUKI Design Call	73
3-17) Sewing limit function	74
3-18) Quick origin search motion function for 1811 machines	76
3-19) Setting origin search function of upper and lower shafts after finishing sewing [only applied for SPS/C-Series]	77
3-20) Setting machine Head up or down function [Only for SPS/C-Series]	78
3-21) Setting reverse rotation after trimming [Only applied for SPS/B/C-Series]	79
3-22) Setting the angle of reverse rotation after trimming [Only applied for SPS/B/C-Series]	80

3-23) Setting output port [Only applied for SPS/C-Series]	81
3-24) Setting time delay when output port is being used [Only applied for SPS/C-Series]	84
3-25) 3rd Thread Adjusting Device (TR3) Setting	85
3-26) Basic Clamp Position Setting	88
4) Pattern Data General Function	89
4-1) Checking and deleting the pattern number	89
4-2) Making a copy the pattern to another number or diskette	90
4-3) Pattern store function	91
4-4) Pattern information displaying function	92
4-5) Change of parameter related to general sewing	93
4-6) Initialization of parameter related to general sewing	94
4-7) System program update	95
4-8) Confirmation for version of system program	96
4-9) Bobbin counter setting by design	97
4-10) Saving in the Internal Memory after Creating Pattern Designs	99
5. High Operating Method	100
1) Understanding the function of machine test	100
1-1) Encoder test	100
1-2) Step motor-main shaft motor test (X-Y Main Test)	100
1-3) Main motor test	101
1-4) Interrupt test	102
1-5) PWM test	102
1-6) LCD test	103
1-7) Keyboard test	104
1-8) Input 0 test	104
1-9) Input 1 test	105
1-10) Input 2 Test	106
1-11) Input 3 Test	106
1-12) Input 4 Test [Only applied for SPS/C-Series]	107
1-13) Input 5 Test [Only applied for SPS/C-Series]	107
1-14) Input 6 Test [Only applied for SPS/C-Series]	108
1-15) Lower Shaft Encoder Test (Encoder1 Test) [Only applied for SPS/C-Series]	109
1-16) Solenoid Test	109
1-17) Output 4 Test [Only applied for SPS/C-Series]	110
1-18) Output 5 Test [Only applied for SPS/C-Series]	111
1-19) Other output ports[only applied for SPS/C-Series]	111
1-20) Manual operation test of step motor (XY Jog Test)	112
1-21) Origin Test	112
1-22) Jump Test	113
1-23) Communication test between the main shaft board and the CPU/IO board (Async Test)	113
6. Description on Parameter Related to General Sewing Operation	115
1) Function no. related pattern programming	162
2) Pattern chart	164
3) Parameter number related to general sewing	165
4) Error list	170
5) SPS/A/B/C-Series block diagram	173
6) Table drawing	177
7) Basic Manual	179
7. Emergency Recovery	181
1) Emergency recovery when problems occur in flash memory	181
2) User's emergency self-restoration and operating program installation	182
8. Special Functions	183
1) Auto Call Function	183
2) Design auto call through handy barcode	191
9. Parameter save function	194
1) Parameter Write	194
2) Parameter Read	195

MACHINE SAFETY REGULATIONS




Safety instruction on this manual are defined as Danger, Warning and Notice.

If you do not keep the instructions, physical injury on the human body and machine damage might be occurred.

Danger : This indication should be observed definitely. If not, danger could be happen during the installation, conveyance and maintenance of machines.

Warning : When you keep this indication, injury from the machine can be prevented.

Notice : When you keep this indication, error on the machine can be prevented.

<p>1-1) Machine Transportation</p>  <p>Danger</p>	<p>Those in charge of transporting the machine should know the safety regulations very well. The following indications should be followed when the machine is being transported.</p> <ul style="list-style-type: none"> Ⓐ More than 2 people must transport the machine. Ⓑ To prevent accidents from occurring during transportation, wipe off the oil on the machine well.
<p>1-2) Machine Installation</p>  <p>Warning</p>	<p>The machine may not work well or breakdown if installed in certain places, Install the machine where the following qualifications agree.</p> <ul style="list-style-type: none"> Ⓐ Remove the package and wrappings starting from the top. Take special notice on the nails on the wooden boxes. Ⓑ Dust and moisture stains and rusts the machine. Install an airconditioner and clean the machine regularly. Ⓒ Keep the machine out of the sun. Ⓓ Leave sufficient space of more than 50cm behind, and on the right and left side of the machine for repairing. Ⓔ EXPLOSION HAZARDS Do not operate in explosive atmospheres. To avoid explosion, do not operate this machine in an explosive atmosphere including a place where large quantities of aerosol spray product are being used or where oxygen is being administered unless it has been specifically certified for such operation. Ⓕ The machine were not provided with a local lighting due to the feature of machine. Therefore the illumination of the working area must be fulfilled by end user. <p>[Refer] Details for machine installment are described in Mechanical Structure Manual 4. Machine Installment.</p>
<p>1-3) Machine Repair</p>  <p>Notice</p>	<p>When the machine needs to be repaired, only the assigned troubleshooting engineer educated at the company should take charge.</p> <ul style="list-style-type: none"> Ⓐ Before cleaning or repairing the machine, close down the motive power and wait 5 minutes till the machine is completely out of power. Ⓑ Not any of the machine specifications or parts should be changed without consulting the company. Such changes may make the operation dangerous. Ⓒ Spare parts produced by the company should only be used for replacements. Ⓓ Put all the safety covers back on after the machine has been repaired.

1-4) Machine Operation



Warning

A(B) Pattern Series is made to sew patterns on fabrics and other similar material for manufacturing.

Follow the following indications when operating the machine.

- Ⓐ Read through this manual carefully and completely before operating the machine.
- Ⓑ Wear the proper clothes for work.
- Ⓒ Keep hands or other parts of the body away from the machine operation parts(needle, shuttle, thread take-up lever, and pulley etc.) when the machine is being operated.
- Ⓓ Keep the covers and safety plates on the machine during operation.
- Ⓔ Be sure to connect the earthing conductor.
- Ⓕ Close down the electric motive power and check if the switch is turned "off" before opening electric boxes such as the control box.
- Ⓖ Stop the machine before threading the needle or checking after work.
- Ⓗ Do not step on the pedal when turning the power on.
- Ⓘ Do not connect several motors to the same concent.
- Ⓙ If possible, install the machine away from loud noise such as high frequency welding machines
- Ⓚ Be careful when the upper feed plate comes down to press. Otherwise, the finger or hand might be hurt at smacking.

[Warning]


Belt will crush or amputate finger or hand, keep cover in place before operating, turn off power before inspecting or adjusting.

1-5) Devices for Safety



Notice

- Ⓐ Safety label : It describes cautions during operating the machine.
- Ⓑ Thread take-up cover : It prevents from any contact between body and take-up lever.
- Ⓒ Belt Cover : It prevents from insertion of hands, feet or clothes by V-belt Motor.
- Ⓓ Step motor cover : It prevents from accidents during rotation of step motors.
- Ⓔ Label for specification of power : It describes cautions for safety to protect electric shock during the motors' rotation. (Voltage input / use Hz)
- Ⓕ Safety plate : It protects eyes against needle breaks.
- Ⓖ Finger guard : It prevent from contacts between a finger and needle.



1-6) Caution Mark Position




Do not operate without finger guard and safety devices. Before threading, changing bobbin and needle, cleaning etc. switch off main switch.
손가락 보호대와 안전장치 없이 작동하지 마십시오.
실, 보빈, 바늘교환시나 청소전에는 반드시 주전원의 스위치를 꺼 주십시오.



Hazardous voltage will cause injury. Be sure to wait at least 360 seconds before opening this cover after turn off main switch and unplug a power cord.
고압 전류에 의해 감전될 수 있으므로 커버를 열 때는 전원을 내리고 전원 플러그를 뽑고 나서 360초간 기다린 후 여십시오.

Caution mark is attached on the machine for safety.
When you operate the machine, observe the directions on the mark.

Position of Warning Mark
[View from the right-front]



1-7) Contents of Marks



Caution

1)



Do not operate without finger guard and safety devices. Before threading, changing bobbin and needle, cleaning etc. switch off main switch.
손가락 보호대와 안전장치 없이 작동하지 마십시오.
실, 보빈, 바늘교환시나 청소전에는 반드시 주전원의 스위치를 꺼 주십시오.

2)




Hazardous voltage will cause injury. Be sure to wait at least 360 seconds before opening this cover after turn off main switch and unplug a power cord.
고압 전류에 의해 감전될 수 있으므로 커버를 열 때는 전원을 내리고 전원 플러그를 뽑고 나서 360초간 기다린 후 여십시오.

2


I/O Board Dip Switch Setting

This shows how to set up the dip switch(SW1) on the I/O board.



The figure above is based on the SPS/C-5050 I/O board.


The following describes each dip switch number.

<p>SW1</p> 	1	Not used
	2	Not used
	3	Main shaft motor type ON : Direct drive OFF : Belt type
	4	If the main shaft motor is a direct drive type , activate the serial communication with the CPU card.
	5	New I/O board setting (After REV 21)
	6	Not used
	7	Distinction between integrated and non-integrated versions ON : Non-integrated version setting OFF : Integrated version setting
	8	Not used

3

BASIC OPERATIONAL METHOD

1) Name and Roles of Each Key on Operation Unit



2) Name and Description of Each Display Contents on General Operation Mode

It is an initial screen when power is on for the first time, but display of screen can be changed according to the general sewing related parameter.

POWER LED ●	NO : 000	NOR_SEW
READY LED ○	XS : 100%	
ERROR LED ○	YS : 100%	SP : 1500
	BC : 000	PC : 0000


- A. "POWER LED" : When you turn on the power, this lamp also comes to light on.
- B. "READY LED" : This lamp comes to light on when a machine is ready to work by reading patterns. During reading or writing the patterns, the lamp flickers. If you press **ENTER**, you can get out of the "READY" state.
- C. "ERROR LED" : When errors including sensing thread and emergency stop happen this lamp comes to light on.
- D. "NO" : It indicates pattern No. Press **NO** key and input the pattern number you want by pressing **digit** keys. (000 ~ 999)
- E. "XS" : It indicates a rate of enlargement and reduction for width. You can change the value at your option by using **digit** keys after pressing down **X SCALE** key. (001[%] ~ 400[%])
- F. "YS" : It indicates a rate of enlargement and reduction for length. You can change the value at your option by using **digit** keys after pressing down **Y SCALE** key. (001[%] ~ 400[%])
- G. "SP" : It indicates sewing speed. You can change the speed you want by pressing down **SPEED** key. (200[SPM] ~ 2500[SPM])
 ※ Maximum sewing speed varies depending on the sewing machine. See "Setting-Up the Speed".
- H. "BC" : It indicates setting value of bottom thread exchange counter. You can change the value at your option by using **digit** key after pressing down **B. SET** key. (000 ~ 999)
- I. "PC" : It indicates setting value of working capacity. You can change the value at your option by using **digit** keys after pressing down **P. SET** key. (0000 ~ 9999)
- J. "NOR_SEW" : It shows working condition. General sewing and chain sewing are available.
 "NOR_SEW" indicates the general sewing and "CHN_XX" means chain sewing.
 ※ Reference : 00~15 are available in XX of "CHN_XX"

※ In case of SPS/C-series :


**Needle & Hook
Origin....**

In case of SPS/C-series, when the power is on first, upper-lower shaft origin search motion will start. After origin search motion, the highest position of thread take-up is set as the different way from the existing pattern. Because origin search motion will perform to set upper-lower shaft hook time. This will not cause problem during sewing or trimming. The position will be set as the existing pattern when the machine stops or trims during sewing.

3) Flow Chart of General Operation



4) Work Flow of Pattern Programming



5) Operating After Reading the Patterns from Floppy Disks

※ Caution : If **READY LED** turns on or upper feed plate is under, some keys are not available.
It happened, operate the keys after lifting the upper feed plate or pressing **ENTER** key.

- A. Insert a floppy disk having patterns that you want to use into a floppy disk drive.
- B. After pressing **NO** key, input the pattern number by using **digit** keys. (If you want to work with "001" pattern, press [0][0][1])
- C. Press **ENTER** key. Read the pattern and change to sewing available mode.
- D. At the moment, the upper thread plate comes to descend, then ascend again after moving to the sewing start point. The **READY LED** comes to light on.
- E. Press **SPEED** key and adjust the speed properly.
- F. If you step on **the pedal switch on the right side**, the upper feed plate comes to descend, and if you step on **the pedal switch on the left side**, the machine starts relevant work.
- G. When you finish operating, the machine backs to the origin or sewing start point, and the upper feed plate comes to ascend.

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 2000
BC : 000	PC : 0000

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 1500
BC : 000	PC : 0000

6) Confirming the Working Pattern Read from the Floppy Disks

- A. Insert a floppy disk into a floppy disk drive.
- B. After pressing **NO** key, input the pattern number by using **digit** keys. (If you want to work with "001" pattern, press [0][0][1])
- C. Press **ENTER** key. Read the pattern and change to sewing available mode.
- D. At the moment, the upper thread plate comes to descend, then ascend again after moving to the sewing start point. The **READY LED** comes to light on.
- E. Press **SPEED** key and adjust the speed properly.
- F. If you step on **the pedal switch on the right side**, the upper feed plate comes to descend.
- G. If you press **FORW** and **BACK** keys to progress and reverse 1 stitch, you can confirm the real shape to be sewn. If you press continuously, it moves to the start or to the end of pattern data consecutively.
- H. If you want to finish working, press **ORIGIN** key.
- I. If you want to continue sewing at the forward or backward point, step on **the left pedal switch**.
- J. When you finish operating, the machine backs to the origin or sewing start point, and the upper feed plate comes to ascend.

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 2000
BC : 000	PC : 0000

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 1500
BC : 000	PC : 0000

7) When a Machine Stops Operating During Sewing by the Thread Cut

- A. You can get the screen like a figure on the right side.
- B. If you want to sew continuously at the same position, insert thread again, then step on the left pedal switch. If you want to sew at the 1 stitch forward or backward point, after moving by using **FORW** and **BACK** key and step on the left pedal switch.
- C. If you want to stop operation and restart sewing from the beginning, press **ORIGIN** key. The feed plate moves to the origin or sewing start point and ascend.
- D. When you finish operating, the machine backs to the origin or sewing start point, and the upper feed plate comes to ascend.

Err18

Thread Broken!

NO:001 NOR_SEW
XS:100%
YS:100% SP:2000
BC:000 PC:0000

8) Emergency Stop During Operation

- A. The machine stops operating immediately by pressing **EMERGENCY STOP** switch during sewing. Then you can get the screen like a figure on the right side.
- B. If you want to restart sewing from the beginning after discontinuing it, Press the **EMERGENCY STOP** switch once more to perform trimming. (When manual trimming is set after emergency stop) then press **ORIGIN** key. The feed plate moves to origin then comes to ascend.
- C. If you want to continue sewing, step on the left pedal switch. If you finish every working, a needle moves to origin and the upper feed plate ascends.

Err17

Emergency Stop!

NO:001 NOR_SEW
XS:100%
YS:100% SP:2000
BC:000 PC:0000

9) Winding the Thread

- A. Inset the empty bobbin into a head of the sewing machine.
- B. Press **MODE** key.
- C. Move to "3. Bobbin Wind" by using direction keys **▲▼**, then press **ENTER** key. At this time, the upper feed plate comes to descend.
- D. If you step on the left pedal switch, thread winding starts to progress, and if you step on the left pedal switch one more time, thread winding comes to discontinue temporarily.
- E. If you finish the thread winding work, complete the thread winding with the left pedal switch or **ESC** key.

<< Main Menu >>
3. Bobbin Wind
4. Machine Test
5. Pattern List

<<Bobbin Wind>>

10) Safety Functions


10-1) Threading and Cancellation Key

When the sewing machine is in the ready position, press No. 5 key for threading (the presser foot and the clamp descend). While threading, a user might mistakenly step on the operation pedal, and start the operation, causing a safety problem. To prevent accidents, the function to freeze the operation after threading was added.

However, the operation freeze status can be canceled by pressing the same No. 5 key again.

A. Sewing ready position

NO:001	NOR_SEW
XS:100%	
YS:100%	SP:1500
BC:001	PC:0001



B. Press No. 5 key for threading. The following message is displayed on the screen, and all keys become disabled. The sewing operation pedal switch is also disabled.

Threading...
To Release...
Press(5) again!

C. To cancel the freeze mode, press No. 5 key again.

D. When the safety mode is cancelled, the screen returns to the original status.

NO:001	NOR_SEW
XS:100%	
YS:100%	SP:1500
BC:001	PC:0001

10-2) Emergency Stop, Thread Sensing or Pause Code.

In order to provide maximum safety to users, when a sewing machine is stopped due to emergency stop, thread sensing or pause code, the operation of the pedal start switch, the clamp up/down switch and the operation box keys become disabled. When the safety mode is cancelled, the keys are enabled again and the sewing machine operation is back to normal.

To cancel the safety function, press the "EXE" key on the left bottom of the OP Box. When this key is pressed, the sewing machine operation will go back to normal.

When the sewing machine is stopped in relation to emergency stop, thread sensing or pause code, the clamp takes the down position.

The safety mode can be set as follows:

- A. Press **MODE** and move to "Parameter Set" on the Main Menu.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

- B. Press **ENTER** to get into "Parameter Set". Move to "095. Safety Mode".

```
<Parameter Set>
095.Safety Mode
096.Jump Speed
097.Auto Call
```

- C. The default value is **1) DISABLE**.

```
095.Safety Mode
1) DISABLE      <-
2) ENABLE
```

- D. To activate the safety mode, move the cursor to **2) ENABLE** and press **ENTER**.

```
095.Safety Mode
1) DISABLE
2) ENABLE      <-
```

- E. If the setting is completed, the safety mode will be enabled in time of **emergency stop, thread sensing or pause code** while sewing is conducted.

F. The following shows an example of situations where the safety mode is activated. Thread is broken in the middle of sewing.


When the thread is sensed, an alarm is issued and the OP Box displays the following message. While the message is displayed on the OP Box screen, Pedal Start Switch, Clamp Up/Down Switch, and Keys of the OP Box remain disabled in order to protect users.

Only when the **exit key** is entered, the functions mentioned above are operable. To cancel the safety mode, press **"EXE"** on the left bottom of the OP Box. When this key is pressed, the sewing machine operation will go back to normal.

While the safety mode is effective, the clamp is located down.

Err18

Thread Broken!
Press EXE Key



G. To cancel this function, press **EXE Key** on the OP Box. This is the message you can see on the OP Box screen.

After the function is cancelled, the sewing machine can be operated again.

Sewing is ready
OK!

H. Sewing can be started by pressing the Pedal Start Switch.


NO:003 **NOR_SEW**
XS:100%
YS:100% **SP:2000**
BC:100 **PC:0000**

4

APPLICABLE OPERATION

1) Pattern Data Generation Function

1-1) Program Example 1 : Generating the Square Pattern



A. Insert a floppy disk into a floppy disk drive.

B. Press **MODE** key.

C. Move to "2. Program" by using **direction** keys **▲▼**, then press **ENTER** key. At this time, the upper feed plate comes to descend.

D. After pressing **JUMP** key, move to the initial point of square by using **direction** keys. Then, press **PNT SET** key.

E. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data.

F. After pressing **LINE** key, input the stitch width by using the **digit** keys, then press **ENTER** key. (For example, if you want to set the stitch width as 3mm, input [0][3][0].)

```
<< Main Menu >>
```

```
2. Program
```

```
3. Bobbin Wind
```

```
4. Machine Test
```

```
ORIGIN
```

```
X:00000A N:00000
```

```
Y:00000A
```

```
Function Code? 
```

```
004:JUMP
```

```
X:-0650
```

```
Y:00300
```

```
N:001 
```

```
JUMP NONE
```

```
X:-0650A N:00065
```

```
Y:00300A
```

```
Function Code? 
```

```
007:LINE
```

```
WIDTH:030[0.1mm]
```

G. Move to each edge of the square by using **direction** keys, then press **PNT SET** key to input coordinates of each edge point. Whenever you press the **PNT SET** key, the number on screen will be increased.

```
007:LINE
X:-0650
Y:00300
N:004
```

H. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data.

```
LINE                NONE
X:-0650A  N:00193
Y:00300A
Function Code?
```

I. Press **TRIM** key to input the trimming code. Then, "000:TRIM" appears on the screen for a little while, and you can see the screen like a figure on the right side.

```
TRIM                NONE
X:-0650A  N:00194
Y:00300A
Function Code?
```

J. If you press **FORW** and **BACK** keys to progress and reverse 1 stitch, you can confirm the real shape to be sewn. Whenever you once press the keys, you can see the operating form and coordinates at that time. If you want to perform test sewing, goes to the next step directly. If you press continuously, it moves to the start or to the end of pattern data consecutively.

```
LINE                NONE
X:-0650A  N:00193
Y:00300A
Function Code?
```

K. Press **TEST** key.

The upper feed plate moves to origin and to the sewing start point, then goes up again. **READY LED** lights up. Press **SPEED** key and adjust the speed properly. Then if you step on the **pedal switch on the right side**, the upper feed plate comes to descend, and if you step on the **pedal switch on the left side**, the machine starts test sewing. If the test sewing is finished, the upper feed plate moves to the sewing start point, then comes to ascend.

<Test Sewing>

SP:1200

L. Press **TEST** key one more time and finish the test sewing. Then, the upper feed plate comes to descend and moves to origin with the turning off the **READY LED**.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code?
```

M. Press **WRITE** key and input the number you want to save by using **digit** keys, then press **ENTER** key. (For example, if you want to save a pattern number as 300, input [3][0][0].) If you do that, the generated pattern data will be saved in a floppy disk to that number. During saving the pattern, the **READY LED** flickers.

```
015:PTRN WRITE
NO   :300
```

N. If there already exists the pattern number that you want to save in a floppy disk, you can see the screen like a figure on the right side. If you want to save the pattern with the same number, just press **ENTER** key, but if you want to save it with another number, press **ESC** key and save to the other number.


```
Pattern Exist!
OverWrite?
Y(ENTER)/N(ESC)
```

O. For finishing a pattern generation, press **MODE** key. Then, the upper feed plate moves to the origin and comes to ascend. Press **ESC** key to back to the initial screen.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

1-2) Program Example 2 : Generating the Circle Pattern

To generate circle patterns, input 3 random coordinates that pass on the circle.



A. Insert a floppy disk into a floppy disk drive.

B. Press **MODE** key.

C. Move to "2. Program" by using **direction** keys **▲▼**, then press **ENTER** key. At this time, the upper feed plate comes to descend.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **JUMP** key, move to a random coordinates (For example, X:00000, Y:00300) that passes on circle by using **direction** keys. Then, press **PNT SET** key.

```
004:JUMP
X:00000
Y:00300
N:001
```

E. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data.

F. After pressing **CODE** key, if you know function codes related to pattern programming, input three digit number, but if not, move to "10. Circle" by using **direction** keys **▲▼** after pressing **ENTER** key, then press **ENTER** key again.

G. Input the stitch width by using the **digit** keys, then press **ENTER** key. (For example, if you want to set the stitch width as 3mm, input [0][3][0].)

H. Move to the second random coordinates that passes on a circle (For example, X:00300 Y:00000) by using **direction** keys, then press **PNT SET** key. Same as above, move to the third random coordinates that passes on a circle (For example, X:00000 Y:-00300), then press **PNT SET** key. Whenever you press **PNT SET** key, the number of screen increases.

I. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data.

J. Press **TRIM** key to input the trimming code. Then, "000:TRIM" appears on the screen for a little while, and replace the screen like a figure on the right side.

K. If you press **FORW** and **BACK** keys to progress and reverse 1 stitch, you can confirm the real shape to be sewn. Whenever you once press the keys, you can see the operating form and coordinates at that time. If you want to perform test sewing, goes to the next step directly. If you press continuously, it moves to the start or to the end of pattern data consecutively.

L. Press **TEST** key.
The upper feed plate comes to ascend and moves to the origin or sewing start point, then goes up. After that, **READY LED** turns on. Press **SPEED** key and adjust the speed properly. Then if you step on **the pedal switch on the right side**, the upper feed plate comes to descend, and if you step on **the pedal switch on the left side**, the machine starts test sewing. If the test sewing is finished, the upper feed plate moves to origin and comes to ascend.

```
JUMP                NONE
X:00000A  N:00027
Y:00300A
Function Code? █
```

```
<Function Code>
010:CIRCLE          <█
011:JUMP            SPD
012:STI             SPD
```

```
010:CIRCLE
WIDTH:030[0.1mm]
```

```
010:CIRCLE
X:00000
Y:-0300
N:002 █
```

```
CIRCLE                NONE
X:00000A  N:00090
Y:00300A
Function Code? █
```

```
TRIM                  NONE
X:00000A  N:00091
Y:00300A
Function Code? █
```

```
CIRCLE                NONE
X:00000A  N:00090
Y:00300A
Function Code? █
```

```
<Test Sewing>

SP:1500 █
```

M. Press **TEST** key one more time and finish the test sewing. Then, the upper feed plate comes to descend and move to origin with the turning off the **READY LED**.

N. Press **WRITE** key and input the number you want to save by using **digit** keys, then press **ENTER** key. Then, save the generated pattern data in a floppy diskette as a relevant number. (For example, if you want to save a pattern number as 301, input [3][0][1].)

During saving the data, **READY LED** flickers. If you want to save the pattern with the same number, just press **ENTER** key, but if you want to save it with another number, press **ESC** key and save to the other number. After finishing saving process, the upper feed plate backs to the origin.

O. For finishing a pattern generation, press **MODE** key. Then, the upper feed plate moves to the origin and comes to ascend. Press **ESC** key to back to the initial screen.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```


```
015:PTRN WRITE
NO : 301
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

1-3) Program Example 3 : Generating the Double Curve Pattern

Input a curving spot that inclines largely among spots that pass on a curve. We give 5 curving lines for examples here.



A. Insert a floppy disk into a floppy disk drive.

B. Press **MODE** key.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

C. Move to “2. Program” by using **digit** keys **▲ ▼**, then press **ENTER** key. At this time, the upper feed plate comes to descend and moves to the origin.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

D. After pressing **JUMP** key, move to a random coordinates (For example X:-0600, Y:00000) that passes on a circle by using **direction** keys. Then, press **PNT SET** key.

```
004:JUMP
X:-0600
Y:00000
N:001 █
```

E. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data.

```
JUMP NONE
X:-0600A N:00054
Y:00000A
Function Code? █
```

F. After pressing **CODE** key, If you know function codes related to pattern programming, input three digit number, but if not, move to “28. Curve DBL” by using **direction** keys **▲ ▼**, after pressing **ENTER** key, then press **ENTER** key again.

```
<Function Code>
028:CURVE DBL <
029:ARC DBL
030:CIRCLE DBL
```

G. Input the stitch width by using the **digit** keys, then press **ENTER** key. (For example, if you want to set the stitch width as 3mm, input [0][3][0].) Input the distance between the two curves by using **digit** keys, then press **ENTER** key. (For example, if you want to set 5mm, input [0][5][0].) Input a direction from standard curve by using **digit** keys, then press **ENTER** key. (For example, if you want to place another curve on above the standard curve, input [0].)

```
028:CURVE DBL
WIDTH:030[0.1mm]
OFFSET:050[0.1mm]
DIR:0[0/1]
```

H. Move to the next coordinates (For example, X:-0300 Y:00200) by using **direction** keys, then press **PNT SET** key. Same as above, move to the other three coordinates in turns by using **direction** keys and press **PNT SET** key. At this time, whenever you press **PNT SET** key, the number of screen increases.

```
028:CURVE DBL
X:00600
Y:00000
N:004 █
```

I. If you press **EXE** key, the machine operates pattern data, then the feed plate moves according to the operated data. At this time, the sewing machine discontinues for a while.

```
CURVE DBL NONE
X:-0635A N:00157
Y:00035A
Function Code? █
```


J. Press **TRIM** key to input the trimming code. Then, "000:TRIM" appears on the screen for a little while, and you can see the screen like a figure on the right side.

```
TRIM                NONE
X:-0635A  N:00158
Y:00035A
Function Code? █
```

K. If you press **FORW** and **BACK** keys to progress and reverse 1 stitch, you can confirm the real shape to be sewn. Whenever you once press the keys, you can see the operating form and coordinates at that time. If you want to perform test sewing, goes to the next step directly. If you press continuously, it moves to the start or to the end of pattern data consecutively.

```
CURVE  DBL  NONE
X:00600A  N:00103
Y:00000A
Function Code? █
```

L. Press **TEST** key.

The upper feed plate comes to ascend and moves to origin, then goes up. After that, **READY LED** lights up. Press **SPEED** key and adjust the speed properly. Then if you step on the pedal switch on the right side, the upper feed plate comes to descend, and if you step on the pedal switch on the left side, the machine starts test sewing. If the test sewing is finished, the upper feed plate moves to origin or sewing start point and comes to ascend.

<Test Sewing>

SP:1500

M. Press **TEST** key one more time and finish the test sewing. Then, the upper feed plate comes to descend and moves to origin with the turning on the **READY LED**.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

N. Press **WRITE** key and input the number you want to save by using **digit** keys, then press **ENTER** key. Then, save the generated pattern data in a floppy diskette as a relevant number. (For example, if you want to save a pattern number as 302, input [3][0][2].)

During saving the data, **READY LED** flickers.

If you want to save the pattern with the same number, just press **ENTER** key, but if you want to save it with another number, press **ESC** key and save to the other number. After finishing saving process, the upper feed plate backs to the origin.

```
015:PTRN  WRITE
NO   :302
```


```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

O. For finishing a pattern generation, press **MODE** key. Then, the upper feed plate comes to ascend after moving to origin. Press **ESC** key to back to the initial screen.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

1-4) Program Example 4 : Pattern Generation by Using the Second Origin and Pause

To program as below, input as the following orders : JUMP → SEC_Org → JUMP → CIRCLE → TRIM → PAUSE → JUMP → LINE → TRIM



- Insert a floppy diskette into floppy disk drive.
- Press **MODE** key.
- By using **direction** keys **▲▼**, move to "2. Program" menu, then press **ENTER** key. At this time the upper feed plate descends, and moves to the origin.

<< Main Menu >>

2. Program
3. Bobbin Wind
4. Machine Test

- After pressing **JUMP** key, make the second origin move to the coordinates (For example, X:00000 Y:00300) you want by using **direction** keys, then press **PNT SET** key.

ORIGIN

X:00000A N:00000
Y:00000A
Function Code? █

- By pressing **EXE** key, after operating the pattern data, the feed plate moves according to the operated pattern data.

004:JUMP

X:00000
Y:00300
N:001 █

JUMP NONE

X:00000A N:00027
Y:00300A
Function Code? █

F. After pressing **CODE** key, input the three digit numbers if you know the pattern programming related function code, but if you don't know it, press **ENTER** key and move to "001: SEC_ORG" by using **direction** keys **▲ ▼**, then press **ENTER** key again.

```
<Function Code>
001:SEC_ORG  <
002:PAUSE
003:EMPTY
```

G. After pressing **JUMP** key, move to one random coordinates that passes through circle (for example, X:-0100, Y:00000), then press **PNT SET** key.

```
004:JUMP
X:-0100
Y:00000
N:001
```

H. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.

```
JUMP          NONE
X:-0100A  N:00056
Y:00000A
Function Code? 
```

I. After pressing **CODE** key, input the three digit numbers if you know the pattern programming related function code, but if you don't know it, press **ENTER** key and move to "010: Circle" by using **direction** keys **▲ ▼**, then press **ENTER** key again.

```
<Function Code>
010:CIRCLE  <
011:JUMP    SPD
012:STI     SPD
```

J. By using **digit** keys, input the stitch width and press **ENTER** key.
(For example, if you set up the stitch width as 3mm, input [0][3][0].)

```
010:CIRCLE
WIDTH:030[0.1mm]
```

K. By using **direction** keys, move to the second random coordinates that passes through circle (for example, X:-0300 Y:00200), then press **PNT SET** key.
Likewise move to the third coordinates that passes through circle (for example, X:-0500 Y:00000), then press **PNT SET** key.
At this time the number on screen increases whenever you press **PNT SET** key.

```
010:CIRCLE
X:-0500
Y:00000
N:002
```

L. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.

```
CIRCLE                NONE
X:-0100A  N:00098
Y:00000A
Function Code? █
```

M. By pressing **TRIM** key, input the code for trim. Then, after appearing "00:TRIM" on the screen for a moment, then a screen of the right side appears.

```
TRIM                  NONE
X:-0100A  N:00099
Y:00000A
Function Code? █
```

N. After pressing **CODE** key, input the three digit numbers if you know the pattern programming related function code, but if you don't know it, press **ENTER** key and move to "002: PAUSE" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<Function Code>
002:PAUSE           <█
003:EMPTY
004:JUMP
```

O. After pressing **JUMP** key, move to the one random coordinates of straight line (for example, X:00100 Y:00200) by using **direction** keys, then press **PNT SET** key.

```
004:JUMP
X:00100
Y:00200
N:001 █
```

P. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.

```
JUMP                NONE
X:00100A  N:00125
Y:00200A
Function Code? █
```

Q. After pressing **CODE** key.
If you know the function number related to pattern programming, input three-figure number and if you do not know the number, press **ENTER** key and transfer to "007:Line" menu by using **direction** key **▲▼**, and then press **ENTER** key.

```
<Function Code>
007:LINE           <█
008:CURVE
009:ARC
```

Ref.) "LINE" and "CURVE" function is set to use with hot key on the operation panel and so you may press this key.

- R. By using the **digit** keys, input the stitch width and press **ENTER** key.
(For example, if you set up the stitch width as 3mm, input [0][3][0].)

```
007:LINE
WIDTH:030[0.1mm]
```

- S. By using **direction** key, move to the another coordinates in turns that passes through line, then press **PNT SET** key.
At this time the number on screen increases whenever you press **PNT SET** key.

```
007:LINE
X:00100
Y:00200
N:004
```

- T. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.

```
LINE                NONE
X:00100A  N:00181
Y:00200A
Function Code?
```

- U. By pressing **TRIM** key, input the code for trim. Then, after appearing "00:TRIM" on the screen for a moment, then a screen of the right side appears.

```
TRIM                NONE
X:00100A  N:00182
Y:00200A
Function Code?
```

- V. After pressing **WRITE** key, input the number you want to save by using **digit** keys. then press **ENTER** key. Save the generated pattern data in a floppy diskette as a relevant number. (For example, if you want to save the pattern number as 303, input [3][0][3].) During saving the pattern, the **READY LED** flickers. When a pattern of same number is in a floppy diskette and if you want to save another pattern as same number, press **ENTER** key. If you want to save the pattern as another number, press **ESC** key and save it as another number. After finishing saving, the upper feed plate moves to the origin again.

```
015:PTRN WRITE
NO   :303
```


```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code?
```

- W. For finishing pattern generation, press **MODE** key. Then the upper feed plate moves to the origin and ascends. Press **ESC** key to back to the initial screen.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

1-5) ZigZag Shape Selecting Function to Generate ZigZag

It was made to select 4 kinds of "DIR" values from existing 0/1 to 0/1/2/3 among three parameters inputting to create Line ZigZag, Curve ZigZag, Arc ZigZag, Circle ZigZag and accordingly ZigZag shapes are classified into 4 type.



A. Input floppy diskette into floppy disk driver.

B. Press **MODE** key.

```
<< Main Menu >>
2. Program <
3. Bobbin Wind
4. Machine Test
```

C. Move to "2. Program" menu by using **direction** key **▲▼** and press **ENTER** key. Then, the upper feed plate comes down and moves the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **JUMP** key, move to the coordinate (for example: X:-0650 Y:00000) to locate by using **direction** key. Then, press **PNT SET** key.

```
JUMP
X:-0650A
Y:00000A
N:001
```

E. If you press **EXE** key, after calculation on pattern data, feed plate moves according to the calculated data.

```
JUMP NONE
X:-0650A N:00000
Y:00000A
Function Code?
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three figure digit number and if you do not know the number, press **ENTER** key. Then after moving to "019: LINE ZIG" menu by using **direction** key, press **ENTER** key.

```
<Function Code>
019:LINE    ZIG    <
020:CURVE   ZIG
021:ARC     ZIG
```

G. Input ZigZag width by using **digit** key, press **ENTER** key and input ZigZag stitch width. Then, press **ENTER** key and input **DIR** value by using **digit** key to select ZigZag shape to create. And press **ENTER** key.

```
010:LINE    ZIG
WIDTH:030[0.1mm]
PITCH:030[0.1mm]
DIR:3[0->3]
```

H. Move ZigZag line (Ex: X: 00650 Y: 00000) to the last sewing coordinate by using **direction** key again and press **PNT SET** key.

```
017:LINE    ZIG
X:00650
Y:00000
N:001
```

I. If you press **EXE** key, after calculation on pattern data, feed plate moves according to the calculated data.

```
LINE    ZIG    NONE
X:00650A N:00000
Y:00000A
Function Code?
```

J. Input thread trimmer key by pressing **TRIM** key. Then "00:TRIM" screen appears for a second and then the screen like the figure in the right side appears again.

```
TRIM                      NONE
X:00650A N:00000
Y:00000A
Function Code?
```

K. You can confirm the shape to be actually sewed by pressing **FORW** key and **BACK** key. Every time you press once, it moves by one stitch and show work mode and coordinate at the moment. When you want to actually do initial sewing, skip to next. If you press continuously, it moves to the start or to the end of pattern data consecutively.

```
LINE    ZIG    NONE
X:00650A N:00000
Y:00000A
Function Code?
```

L. Press **TEST** key. The upper feed plate moves to the original point or sewing start point and goes up and **READY LED** is turned on. After adjusting appropriate initial sewing speed by pressing **SPEED** key, step on the pedal switch in the right. Then, the upper feed plate comes down and stepping on the left pedal, it performs initial sewing. The upper feed plate that completed initial sewing moves to the original point or sewing start point and then goes up.

```
<Test Sewing>


SP:1500
```

M. The order of saving and completion is the same as the previous example.

2) Pattern Data Edit Function

2-1) One Stitch Movement Function

It uses when correcting the location of **one stitch** in the formed sewing shape.



A. Insert floppy diskette containing the pattern to change movement of a stitch.

B. Press **MODE** key.

```
<< Main Menu >>
2. Program <
3. Bobbin Wind
4. Machine Test
```

C. After moving to "2. Program" menu by using **direction** key **▲ ▼**, press **ENTER** key. At this time, the upper feed plate comes down and move the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to change movement of a stitch by moving the **digit** key and read in the pattern by pressing **ENTER** key. (For example, to read pattern number 001, input [0][0][1]).

```
014:PTRN      READ
NO  :001
```

E. Go to the location of stitch to correct by using **FORW** and **BACK** key.

```
LINE
X:-0001A N:00059
Y:00000A
Function Code?
```

F. After pressing **CODE** key, if you know the function number 051 related to pattern programming, input three figure of digit number and if you do not know the number, press **ENTER** key and move to "051:STITCH DRAG" by using **direction** key **▲ ▼**. Then, press **ENTER** key.

```
<Function Code>
051:STITCH DRAG<
052:STITCH DEL
053:MOV SEWSTAR
```


G. Move to the location desired movement of one stitch by using **direction** key.

※ X-Y coordinate value is different according to location of needle.

```
051:STITCH  DRAG
X:-00001
Y:-00060
N:000
```


H. If you press **EXE** key, change to new needle location is completed.

I. Confirm if needle location was changed to the desired location by using **FORW** and **BACK** key.

```
LINE
X:-0001A  N:00059
Y:-0060A
Function Code?
```

2-2) Partial Movement Function of Pattern Data

Move part of pattern to different location among the sewing shape.



A. Insert partial pattern data into the floppy diskette containing the pattern to move and change.

B. Press **MODE** key.

```
<< Main Menu >>
2. Program <
3. Bobbin Wind
4. Machine Test
```

C. After moving to "2. Program" menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to move and change partial pattern data by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO   :001
```

E. Go to the needle location to partially move by using **FORW** and **BACK** key.

Reference) Location of the needle for partial movement should be placed at the first start needle location that actually sews. Therefore, if the sewing data that has line property after jump appears, the last location of JUMP data is the first start location of needle correction.

```
JUMP
X:00174A N:00070
Y:00183A
Function Code? █
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three figure digit number 046, but if you do not know the number, press **ENTER** key. Then after move to "046:MOV PTRN" by using **direction** key **▲▼**, press **ENTER** key.

```
<Function Code>
046:MOV      PTRN<█
052:COPY     PTRN
053:DEL      PTRN
```

G. Go to the last location of pattern to move by using **FORW** key.

※ The indicated values are different according to current location.

```
<RANGE SETTING>
X:00174A N:00088
Y:00183A █
```

H. If you press **EXE** key, it becomes the state that the selected pattern for partial movement can move to the optional location.

```
046:MOV      PTRN
X:00174
Y:00183
N:000 █
```

I. Move to the location to move by pressing **direction** key.

```
046:MOV      PTRN
X:00174
Y:-0101 █
N:000
```


J. If you press **EXE** key, movement is completed.

```
LINE
X:00174A N:00096
Y:-00101A
Function Code? █
```

K. Confirm if movement was properly made by using **FORW** and **BACK** key.

2-3) A Fixed Number of Stitch Delete Function

Delete 1-99 stitch in the pattern data shape after the start point to delete at present.



A. Insert floppy diskette containing the pattern to delete stitches.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲ ▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```

ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
  
```

D. After pressing **READ** key, input the pattern number to delete stitch by using the **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern 001.)

```

014:PTRN      READ
NO  :001
  
```

E. Go to needle location to delete by using **FORW** and **BACK** key.

※ X-Y coordinate value is different according to needle location.

```

LINE
X:-0025A N:00059
Y:00000A
Function Code?
  
```

F. After pressing **CODE** key, if you know the function number 052 related to pattern programming, input three-figure digit number and if you do not know, press **ENTER** key. Then after moving to "052:STITCH_DEL" by using **direction** key **▲ ▼**, press **ENTER** key.

```

<Function Code>
052:STITCH_DEL <
053:MOV SEWSTRT
054:MOV 2ndORG
  
```

G. Input the number of stitch to delete behind from current location.

```
052:STITCH DEL
NUM:10[STITCH]
```

H. Press **ENTER** key.

I. Stitch is deleted as many as the input number.


Reference) After deleting as much as the number of defined stitches, if end point and start point of two sewing data existing at both sides do not match and have distances, a jump is automatically made between the two sewing data. If you want to input automatic thread trimming, you can set up at "057:AUTO TRM".

```
TRIM
X:-0233A N:00033
Y:00120A
Function Code?
```

J. Confirm if the stitches were deleted as many as desired number by using **FORW** and **BACK** key.

2-4) Partial Pattern Data Delete Function

Delete one of the generated pattern data shapes selectively (For example: Jump, Line, Curve, Arc, Circle).



A. Insert floppy diskette containing the partial pattern to delete.

B. Press **MODE** key.

C. After moving to “2. Program” menu by using **direction** key **▲ ▼** press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

D. After pressing **READ** key, input the pattern number to delete partial pattern by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001).

```
014:PTRN      READ
NO   :001
```

E. Go to the pattern that the shape to delete exists by using **FORW** and **BACK** key.

※ X-Y coordinate value is different according to needle location.

```
CIRCLE
X:-0067A  N:00052
Y:-0092A
Function Code? █
```

F. Delete is available by two methods as below.

- After pressing **CODE** key, input **Function code** **039** and press **ENTER** key.
- Or press **PTN. DEL** key of **OP**.

G. Press **PTN.DEL** key on operation box (OP).

Reference) After deleting as much as the number of defined stitches, if end point and start point of two sewing data existing at both sides do not match and have distances, a jump is automatically made between the two sewing data. If you want to input automatic thread trimming, you can set up at “057:AUTO TRM”.


```
TRIM
X:-0220A  N:00029
Y:00040A
Function Code? █
```

H. Confirm if desired partial pattern shape was deleted by using **FORW** and **BACK** key. (Line is deleted by once.)

I. Delete the partial pattern data to delete repeatedly in the order of **E-F-G**.

2-5) Partial Stitch Width Changing Function

Change stitch width by selecting a fixed part from the pattern shape.



A. Insert floppy diskette containing the pattern to change stitch width.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲ ▼**, press **ENTER** key. At this time, the upper feed plate comes to descend.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

D. After pressing **READ** key, input the pattern number to change stitch width by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO  :001
```

E. Go to the location to start **change of stitch width** by using **FORW** and **BACK** key.

```
LINE
X:-0070A  N:00021
Y:00140A
Function Code? █
```

※ X-Y coordinate value is different according to needle location.

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 013, and if you do not know, press **ENTER** key. Then after moving to "013:STI WIDT" by using **direction** key **▲ ▼**, press **ENTER** key.

```
<Function Code>
013:STI      WIDT<
014:PTRN     READ
015:PTRN     WRITE
```

G. Input the **stitch width** value to change and press **ENTER** key.

```
013:STI      READ
WIDTH: 020 [ 0.1mm ]
```

H. Move to the location to complete **stitch width change** by using **FORW** and **BACK** key.

```
<RANGE SETTING>
X:00142A  N:00029
Y:00089A
```

I. If you press **EXE** key, change of stitch width is completed.


※ X-Y coordinate values are different according to current location.

```
ARC
X:00133A  N:00052
Y:00061A
Function Code?
```

J. Confirm if change of stitch width was made properly by using **FORW** and **BACK** key.

2-6) Pattern Partial Copy Function

Set a fixed part of pattern shape and copy to desired location.



A. Insert floppy diskette containing partial pattern to make partial copy.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to copy partial pattern by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN READ
NO :001
```

E. Go to copy start location by using **FORW** and **BACK** key.

Reference) Location of the needle for partial copy should be placed at the first start needle location that actually sews. Therefore, if the sewing data that has line property next jump appears, the last location of JUMP data is the first start location of needle correction.

```
JUMP
X:00174A N:00070
Y:00183A
Function Code?
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 047, and if you do not know the number, press **ENTER** key. Then, after moving to "047: COPY PTRN" by using **direction** key **▲▼**, press **ENTER** key.

```
<Function Code>
047: COPY PTRN<
048: DEL PTRN
049: REV SET
```

G. Go to the copy completing location of pattern by using **FORW** key.

※ X-Y coordinate values are different according to current location.

```
<RANGE SETTING>
X:00174A N:00088
Y:00183A
```

H. If you press **EXE** key, it becomes the state to move to the location to copy.

```
047: COPY PTRN
X:00174
Y:00183
N:000
```


I. Move to the location to copy by pressing **direction** key.

※ The indicated values are different according to current location.

```
047: COPY      PTRN
X: 00174
Y: -0133
N: 000
```


J. If you press **EXE** key, copy is completed.

```
LINE
X: 00174A N: 00088
Y: 00183A
Function Code?
```

K. Confirm if copy was made properly by using **FORW** and **BACK** key.

2-7) Pattern Data Inserting Function

It is the function made that pattern data inserting is available because the behind data is protected though new pattern data is added in the middle of pattern data.



A. Insert floppy diskette containing the pattern to insert.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X: 00000A N: 00000
Y: 00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to insert pattern by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO   :001
```

E. Go to the location of data to insert by using **FORW** and **BACK** key.

```
LINE
X:-0012A  N:00032
Y:00000A
Function Code? █
```

F. Select LINE of operation box (OP) of the function code to insert. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number and if you do not know the number, press **ENTER** key. Then after selecting the function number by using **direction** key **▲▼**, press **ENTER** key.

```
<Function Code>
047:LINE      <█
048:CURVE
049:CIRCLE
```

G. Input **stitch width** and press **ENTER** key.

```
007:LINE
WIDTH:020[01.mm]
```

H. Insert data of the shape to insert by using **direction** key. (Same as sewing data generation by using LINE)

```
007:LINE
X:-0203
Y:-0207
N:001 █
```

I. If you input data of the shape to insert each, press **EXE** key.

```
LINE
X:-0209A  N:00071
Y:00000A
Function Code? █
```


J. Confirm if new pattern data was inserted properly by using **FORW** and **BACK** key.

3) Pattern Data Application Function

3-1) Operating After Moving to a Random Start Point to Sew or the Second Origin

It is possible to move to the sewing start point or the second origin by using **direction** keys in the sewing available state. To decide the moving point, whether it is the sewing start point or the second origin, set up 1) PNT_STR_POS or 2) SECND_ORG at the general sewing related parameter No. "001. Move to starting point/the second origin manually."

※ Note : It is available when **READY LED** turns on, and this function is used for movement to the temporary sewing start point or the second origin. By setting up the second origin within pattern data, the same position can be set up as the second origin.



- A. Insert a floppy disk into a floppy disk drive.
- B. Press **NO** key, then input the pattern number by using **digit** keys. (If you want to work with "001" pattern, input [0][0][1].)
- C. Press **ENTER** key to read a pattern and to change to sewing available mode.
- D. The upper feed plate comes to descend and moves to the origin or sewing start point then ascends. **READY LED** lights up.
- E. Press **SPEED** key to adjust speed properly.
- F. If you step on **the pedal switch on the right side**, the upper feed plate comes to descend.
- G. After moving to a random second origin by using **direction** keys, if you step on **the pedal switch on the left side**, the machine moves to the sewing start point or the second origin and starts relevant works. At this time, be careful not to exceed the transfer limit of feed plate.
- H. If the work is finished, a needle moves to the origin or the sewing start point and the upper feed plate comes to ascend. If you want to back to the initial sewing start point or the first origin, press **ENTER** key to read the pattern to work one more time.

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 2000
BC : 000	PC : 0000

NO : 001	NOR_SEW
XS : 100%	
YS : 100%	SP : 1500
BC : 000	PC : 0000

3-2) Program Example 5 : Change of Sewing Speed Within a Pattern


There are two ways to change sewing speed within a pattern.

- 1) Changing the sewing speed from an existing pattern data
- 2) Changing the sewing speed with creating new pattern data

※ Ref. : Several sections of speed change is available, but they should be within real sewing range.

Maximum speed varies depending on the pattern of the sewing machine.

3-2-1) Changing the Sewing Speed from an Existing Pattern Data



(1) Reading the Pattern that is Supposed to Change the Sewing Speed

A. Insert the floppy diskette of a pattern that is supposed to change the sewing speed.

B. Press **MODE** key.

C. By using **direction** keys **▲▼**, move to "2. Program" menu, then press **ENTER** key.

At this time the upper feed plate descends, and moves to the origin.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

D. After pressing **READ** key, input the pattern number that is supposed to change the sewing speed by using **digit** keys, then press **ENTER** to read the pattern.

(For example, to read the pattern number 500, input [5][0][0].)

```
014:PTRN READ
NO :500
```

(2) Setting up the Range of Sewing Speed Change

A. By using **FORW**, **BACK** keys, move to the start point (R1) of section that the sewing speed is supposed to change.

```
LINE
X:-0350A N:00075
Y:00300A
Function Code? █
```

B. After pressing **CODE** key, input three digit numbers if you know the pattern programming related function code, but if you don't know it press **ENTER** key and move to the "012: STI SPD" by using **direction** keys **▲▼**, then press **ENTER** again.

```
<Function Code>

CODE No : 012
```

C. By using **digit** keys, input the sewing speed you want to change, then press **ENTER** key.
(For example, if you want to change the speed into 500spm, input [0][5])

```
012:STI      SPD
STSPM:05[100spm]
```

D. By using **FORW**, **BACK** keys, move to the end point (R2) of section that the sewing speed is supposed to change.
Then after pressing **PNT SET** key, press **EXE** key.

```
<RANGE SETTING>
X:00360A N:00099
Y:00300A
Function Code? █
```

(3) Test Sewing

A. Press **Test** key.

After moving to the origin, the upper feed plate moves to the sewing start point, then ascends and the **READY LED** turns on. After adjusting **proper** test sewing speed by pressing **SPEED** key, if you press down once the **foot plate on the right side**, the upper feed plate descends, and if press down once the **plate on the left side**, the test sewing is performed.

After completing the test sewing, the upper feed plate moves to the sewing start point, then ascends.

```
<Test Sewing>

SP:1200 █
```

- B. By pressing **TEST** key, complete the test sewing. The upper feed plate descends and moves to the origin, then **READY LED** turns off.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

(4) Saving as New Pattern Number

- A. After pressing **WRITE** key, input the number you want to save by using **digit** keys. then press **ENTER** key. Save the generated pattern data in a floppy diskette as a relevant number. (For example, if you want to save the pattern number as 550, input [5][5][0].) During saving the pattern, the **READY LED** flickers.

When a pattern of same number is in a floppy diskette and if you want to save another pattern as same number, press **ENTER** key. If you want to save the pattern as another number, press **ESC** key and save it as another number.

After finishing saving, the **READY LED** turns off, the upper feed plate moves to the origin again.

```
015:PTRN WRITE
NO :550
```


```
Pattern Exist!
OverWrite?
Y(ENTER)/N(ESC) █
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

- B. For finishing pattern generation, press **MODE** key. Then the upper feed plate moves to the origin and ascends. Press **ESC** key to back to the initial screen.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

3-2-2) Changing the Sewing Speed by Making New Pattern Data



- A. Insert a floppy diskette into floppy disk drive.
- B. Press **MODE** key.
- C. By using **direction** keys **▲▼**, move to "2. Program" menu, then press **ENTER** key. At this time the upper feed plate descends, and moves to the origin.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

- D. After pressing **JUMP** key, move to the initial point of square by using **direction** keys, then press **PNT SET** key.

```
004:JUMP
X:-0650
Y:00300
N:001 █
```

- E. By pressing **EXE** key, the feed plate moves according to the operated pattern data after operating the data.

```
JUMP NONE
X:-0650A N:00065
Y:00300A
Function Code? █
```

- F. After pressing **LINE** key, input the stitch width by using **digit** keys, then press **ENTER** key. (For example, if you want to set up the stitch width as 3mm, input [0][3][0].)

```
007:LINE
WIDTH:030[0.1mm]
```

- G. By using **direction** keys, move to the end point(R2) of section that the sewing speed is supposed to change and press **PNT SET** key.

```
007:LINE
X:00360
Y:00300
N:001
```

- H. By pressing **EXE** key, the feed plate moves according to the operated pattern data after operating the data.

```
LINE          NONE
X:00360A  N:00099
Y:00300A
Function Code?
```

- I. By using **FORW**, **BACK** keys, move to the start point (R1) of section that the sewing speed is supposed to change.

```
LINE
X:-0350A  N:00075
Y:00300A
Function Code?
```

- J. After pressing **CODE** key, input the three digit numbers if you know the pattern programming related function code, but if you don't know it, press **ENTER** key and move to "012. STI SPD" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<Function Code>
CODE No : 012
```

- K. By using **digit** keys, input the sewing speed you want to change, then press **ENTER** key.
(For example, if you want to change the speed into 500spm, input [0][5])

```
012:STI      SPD
STSPM:05[100spm]
```

- L. By using **FORW**, **BACK** keys, move to the end point (R2) of section that the sewing speed is supposed to change.
Then after pressing **PNT SET** key, press **EXE** key.

```
<RANGE SETTING>
X:00360A  N:00099
Y:00300A
Function Code?
```


M. Complete the program for the rest part of the square by using **LINE**.


N. After performing test sewing, store the programmed pattern with new number.

O. To complete pattern creation, press **MODE** key.
The upper feed plate moves up after returned to the origin. Return to the initial screen by pressing **ESC** key.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

3-3) Program Example 6 : Use of Reversal

It is used when reversal devices is available. Careful attention must be paid to that reversal pressure plate or reversal cylinder drive part is not to be interfered with needle bar when programming the pattern. There are two ways to input the code for reversal (an order to drive the reversal devices), one is to add only code for reversal after calling the already programmed pattern, and the other is to program newly.



3-3-1) Pattern Programming by Using Reversal

- Insert a floppy diskette into floppy disk drive.
- Press **MODE** key.
- By using direction keys **▲▼**, move to "2. Program" menu, then press **ENTER** key.
At this time the upper feed plate descends, and moves to the origin.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

```
ORIGIN
X:00000A N:00099
Y:00000A
Function Code? █
```

D. After pressing **JUMP** key, move to the A point by using **direction** key. Then press **PNT SET** key.

```
004:JUMP
X:-0150
Y:00300
N:001 ■
```

E. By pressing **EXE** key, the feed plate moves according to the operated pattern data after operating the pattern data.

```
JUMP                NONE
X:-0150A  N:00028
Y:00300A
Function Code? ■
```

F. After pressing **CODE** key, set up the second origin by pressing [0][0][1] with **digit** keys.

```
<Function Code>

CODE No : 001
```

G. Press **ENTER**  key.


```
SEC_ORG            NONE
X:-0150A  N:00029
Y:00300A
Function Code? ■
```

H. After pressing **JUMP** key, move to the sewing start point P1 by using **direction** keys. Then press **PNT SET** key.

```
004:JUMP
X:00000
Y:00280
N:001 ■
```

I. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.

```
JUMP                NONE
X:00000A  N:00042
Y:00280A
Function Code? ■
```

J. After pressing **LINE** key, input the sewing width by using **digit** keys, then press **ENTER**  key. (For example, if you set up the stitch width as 3mm, input [0][3][0].)

```
007:LINE
WIDTH:030[0.1mm]
```

K. Move to P2, P3, P4 by using **direction** keys, then press **PNT SET** to input coordinates of each edge.



```
007:LINE
X:-0300
Y:00000
N:003
```

L. By pressing **EXE** key, the feed plate moves according to the operated data after operating the pattern data.


```
LINE          NONE
X:-0300A  N:00082
Y:00000A
Function Code?
```

M. After pressing **CODE** key, input an order for reversal by pressing **digit** keys, [0][4][9].

```
<Function Code>
CODE No : 049
```

N. Press **ENTER**  key.
After pressing **digit** key **1**, press **ENTER**  key to operate the reversal cylinder.

```
049:REV      SET
POS   : 1[0/1]
```

O. After checking for sure, input the code for reversal once again by pressing **ENTER**  key.

```
REV      SET  NONE
X:-0300A  N:00083
Y:00000A
Function Code?
```

P. By using **LINE** key, make program the other two points, P5, P6

```
007:LINE
X:00020
Y:00280
N:002
```

- Q. By pressing **TRIM** key, input the code for trim.
 "000:TRIM" appears on the screen for a while,
 then replace it with the screen of the right side.

```
TRIM                NONE
X:00020A  N:00105
Y:00280A
Function Code? █
```

- R. After pressing **JUMP** key, move to the B point
 by using **direction** keys.
 Then press **PNT SET** key.

```
004:JUMP
X:-0100
Y:00280
N:001 █
```

- S. By pressing **EXE** key, the feed plate moves
 according to the operated data after operating
 the pattern data.

```
JUMP                NONE
X:-0100A  N:00115
Y:00280A
Function Code? █
```

- T. Perform test sewing.

- U. After pressing **WRITE** key, input the number
 you want to save by using **digit** keys, then
 press **ENTER** key. Save the generated pattern
 data in a floppy diskette as a relevant number.
 (For example, if you want to save the pattern
 number as 551, input [5][5][1]).

```
015:PTRN WRITE
NO   :551
```

- V. For completing the pattern generation, press
MODE key. The upper feed plate moves to
 origin and ascends. By pressing **ESC** key, back
 to the initial screen.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

3-3-2) Adding the Code to Already Programmed Pattern

(1) Reading the Pattern that does not have Code for Reversal

- A. Insert a floppy diskette holding a pattern that
 you want to add.
- B. Press **MODE** key.
- C. By using **direction** keys **▲▼**, move to "2.
 Program" menu, then press **ENTER** key. At
 this time the upper feed plate descends, and
 moves to the origin.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

- D. After pressing **READ** key, input the pattern number that sewing speed is supposed to change, then press **ENTER** key to read the pattern. (For example, input [5][0][0] to read pattern number 500.)

```
015:PTRN READ
NO : 500
```

(2) Inserting the Code for Reversal

- A. By using **FORW**, **BACK** keys, move to the point P4 that you want to add code for reversal.

```
007:LINE
X:-0300A N:00085
Y:00000A
Function Code? █
```

- B. After pressing **CODE** key, input an order for reversal by pressing **digit** keys, [0][4][9].

```
<Function Code>
CODE No : 049
```

- C. Press **ENTER** key.
After pressing **digit** key, **1**, and operate the reversal cylinder by pressing **ENTER** key.

```
049:REV SET
POS : 1[0/1]
```

- D. After checking for sure, input the code for reversal once again by pressing **ENTER** key.

```
REV SET NONE
X:-0300A N:00084
Y:00000A
Function Code? █
```

(3) Test Sewing

- A. Press **TEST** key.
After moving to the origin, the upper feed plate moves to the sewing start point, then ascends and the **READY LED** turns on. After adjusting the proper test sewing speed by pressing **SPEED** key, if you press down once the **foot plate on the right side**, the upper feed plate descends, and if press down once the **plate on the left side**, the test sewing is performed.
After completing the test sewing, the upper feed plate moves to the sewing start point, then ascends.

```
<Test Sewing>
SP:1200 █
```

- B. By **TEST** key, complete the test sewing.
The upper feed plate descends and moves to the origin, then **READY LED** turns off.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

(4) Saving as New Pattern Number

- A. After pressing **WRITE** key, input the number you want to save by using **digit** keys, then press **ENTER** key. Save the generated pattern data in a floppy diskette as a relevant number. (For example, if you want to save the pattern number as 552, input [5][5][2].) During saving the pattern, the **READY LED** flickers. When finishing the save, the **READY LED** turns off, and the upper feed plate moves to the origin again.

```
015:PTRN WRITE
NO :552
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

- B. For finishing pattern generation, press **MODE** key. Then the upper feed plate moves to the origin and ascends. Press **ESC** key to back to the initial screen.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

3-4) Using the Extension/Reduction Modes

It is used when you want to extend or reduce the already programmed sewing patterns, and you should be careful not to exceed the transfer limit during the setting for rate of extension/reduction. You can extend or reduce with **STITCH_LEN** by the stitch width, and with **STITCH_NUM** by the numbers of stitches. To use these functions, the parameter number related to general sewing, "053. Extension/Reduction mode" should be set to "2)STITCH_LEN" or "3)STITCH_NUM".

(1) Setting the Extension/Reduction Mode

- A. Press **MODE** key.
B. Move to "1. Parameter Set" by using **direction** keys **▲▼**.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

C. If you press **ENTER** key, you can get the screen like a figure on the right side, then input [0][6][3].

※ Appendix :

Refer "Parameter number related to general sewing."

<Parameter Set>

PARA No : 063

D. After pressing **ENTER** key, decide whether you use extension/reduction or not by using **direction** keys **▲ ▼**.

Here set we "2)STITCH__LEN: Extension/Reduction by stitch length".

063:Scale MODE

1) DISABLE

2) STITCH_LEN <-

3) STITCH_NUM

E. Press **ENTER** key.

Press **ESC** key to back to the initial screen.

<< Main Menu >>

1. Parameter Set

2. Program

3. Bobbin Wind

(2) Setting the Rate for Extension/Reduction

A. Press **X SCALE** and set the rate you want. For example, if you want to reduce 70%, input [0][7][0].

NO:001 NOR_SEW

XS:070%

YS:100% SP:2000

BC:000 PC:0000

B. Press **Y SCALE** and set the rate you want. For example, if you want to reduce 50%, input [0][5][0].

NO:001 NOR_SEW

XS:070%

YS:050% SP:2000

BC:000 PC:0000

C. Press **NO** key and **input** the pattern number by using digit keys. (For example, if you want to work with "001" pattern, input [0][0][1].)

D. Press **ENTER** key to read patterns and to be sewing available mode.


NO:001 NOR_SEW

XS:070%

YS:050% SP:2000

BC:000 PC:0000

3-5) Using the Chain Sewing Mode



It is used to work with the various patterns randomly. To use the function, the parameter number related to general sewing, "054 Chain No." should be set to the other numbers except "0". Set the parameter number related to general sewing, "055 Chain Select." to be automatic or manual.

(1) Setting the Chain Sewing Environment

A. Press **MODE** key.

B. Move to "1. Parameter Set" by using **direction** keys **▲▼**.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

C. If you press **ENTER** key, you can get the screen like a figure on the right side, then input [0][6][4].

※ Appendix :

Refer "Parameter number related to general sewing."

```
<Parameter Set>

PARA No : 064
```

D. After pressing **ENTER** key, input the number of chain sewing you want by using **direction** keys **▲▼**. Here we input 2 for example.

```
064.Chain Number
 2
```

E. Press **ENTER** key. If you press **ENTER** key again, you can get the screen like a figure on the right side, then input [0][6][5].

※ Appendix :

Refer "Parameter number related to general sewing."

```
<Parameter Set>

PARA No : 065
```


F. Input if you want an automatic operation or manual for the change of chain number by using direction keys ▲ ▼, after pressing **ENTER** key. Here we change automatically.

```
065:Chain Select
1.MANUAL
2.AUTO          <-
3.EXTERNAL
```

G. 066. Chain Clamp Setting selects up or down of the clamp for chain work. In other words, if user conducts a chain work having four patterns, it is done in the order of 000, 001, 002, and 003. If **1) DISABLE** is chosen, when the first chain work of 000 is finished, it moves to 001 and the clamp ascends.

```
066:Chain Clamp
1.DISABLE      <-
2.ENABLE
```

As such, when **1) DISABLE** is chosen, the move to the next pattern occurs, and then the clamp ascends.

If **2) ENABLE** is chosen, a cycle of a chain work is completed and the chain number returns to 000 to keep the clamp in the lifted position.

```
066:Chain Clamp
1.DISABLE
2.ENABLE      <-
```

H. After pressing **ENTER** key, and press **ESC** key to back to the initial screen.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

(2) Correspondence of a Chain No. to a Pattern

A. Press **NO** key. When the cursor is located on "CHN__XX", input [0][0]. At this time, input less number than the number of chain sewing.

```
NO:001      CHN__00
XS:100%
YS:100%    SP:2000
BC:000      PC:0000
```

B. Press **NO** key. When the cursor is located on "NO:XX", input the pattern No. that corresponds to the chain No. "00". For example, if you want to work with No."001" pattern, input [0][0][1].

```
NO:001      CHN__00
XS:100%
YS:100%    SP:2000
BC:000      PC:0000
```

C. Press **ENTER** key. Then the **READY LED** comes to flicker. After reading a pattern, the machine comes to be in sewing available mode.

```
NO:001      CHN__00
XS:100%
YS:100%    SP:2000
BC:000      PC:0000
```

D. Press **ENTER** key again.

E. Press **NO** key. If a cursor is located on "CHN__XX", input [0][1] for chain No. At this time, input less number than the number of chain sewing.

NO:001	CHN__01
XS:100%	
YS:100%	SP:2000
BC:000	PC:0000

F. Press **NO** key. When the cursor is located on "NO:XX", input the pattern No. that corresponds to the chain No. "00". For example, if you want to work with No. "002" pattern, input [0][0][2].

NO:002	CHN__01
XS:100%	
YS:100%	SP:2000
BC:000	PC:0000

G. Press **ENTER** key.

Then the **READY LED** comes to flicker. After reading a pattern, the machine comes to be in sewing available mode.


※ If you want to back to the general sewing mode from the chain sewing mode, set "054 Chain No." should be set to "0".

NO:002	CHN__01
XS:100%	
YS:100%	SP:2000
BC:000	PC:0000

H. If the setting is conducted for all selected chains, press number keys and select the first CHN__00. Press **ENTER** and return to the original position where the work was initially started for a new work.

3-6) Change/Saving Function of Pattern Data Start Point

Change and save pattern data start point already set up when punching.



A. Insert floppy diskette containing the pattern to change start point.

B. Press **MODE** key.

C. After moving “2. Program” menu by using **direction** key ▲▼, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

D. After pressing **READ** key, input the pattern number to change start point by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO  :001
```

E. Go to sewing start point by using **FORW** and **BACK** key.

Reference) It does not matter if you place needle location to change start point at the optional location of actual sewing.

```
JUMP
X:-0400A N:00038
Y:00200A
Function Code? █
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 053, and if you do not know the number, press **ENTER** key. Then, after moving to “053:MOV SEWSTR” by using **direction** key ▲▼, press **ENTER** key.

```
<Function Code>
053:MOV SEWSTAR<█
054:MOV 2ndORG
055:AUTO TRIM
```

※ X-Y coordinate value is different according to sewing start point.

```
053:MOV SEWSTAR
X:-0400
Y:00200
N:000 █
```

G. Move to new pattern start point by using **direction** key.

```
053:MOV SEWSTAR
X:-0600
Y:00280 █
N:000
```

H. Complete input of new pattern start point by pressing **EXE** key.

```
JUMP
X:-0600A N:00056
Y:00280A
Function Code? █
```


I. Confirm if change was made properly by using **FORW** and **BACK** key.

J. Save the pattern of changed start point by pressing **WRITE** key.

```
015:PTRN      WRITE
NO  :007
```

3-7) Change/Saving Function of Pattern 2nd Original Point

Change the already setup 2nd original point to new 2nd original point and save it.



A. Insert floppy diskette containing the pattern to change the 2nd original point.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲ ▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```

ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
  
```

D. After pressing **READ** key, input the pattern number to change the 2nd original point by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```

014:PTRN READ
NO :001
  
```

E. Go to the location of 2nd original point by using **FORW** and **BACK** key.

```

SEC_ORG NONE
X:-0260A N:00025
Y:00120A
Function Code?
  
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure **digit** number 054 and if you do not know the number, press **ENTER** key. Then, after moving to "054:MOV 2nd ORG" by using direction key **▲ ▼**, press **ENTER** key.

※ X-Y position value may differ according to the 2nd original point.

```
<Function Code>
054:MOV 2ndORG<
055:AUTO TRIM
056:SCALE REFER
```

```
054:MOV 2ndORG
X:-0260
Y:00120
N:000
```

G. Move to new **2nd** original point by using **direction** key.

```
054:MOV 2ndORG
X:-0260
Y:-0050
N:000
```

H. Complete input of new **2nd** original point by pressing **EXE** key.

```
JUMP
X:-0260A N:00023
Y:-0050A
Function Code?
```

I. Confirm if change was made properly by using **FORW** and **BACK** key.

J. Save the pattern of the changed 2nd original point by pressing **WRITE** key.

```
015:PTRN WRITE
NO :008
```

3-8) Change/Saving Function of Maximum Pattern Sewing Speed and Extension/Reduction Rate

Set up maximum sewing speed and extension/reduction rate by pattern.

A. Insert floppy diskette containing the pattern to change maximum sewing speed and extension/reduction rate.

B. Press **MODE** key.

C. After moving to “2. Program” menu by using **direction** key ▲▼, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to change maximum sewing speed and extension/reduction rate by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO  :001
```

E. Go to pattern data start location by using **FORW** and **BACK** key.

```
JUMP
X:-0400A  N:00038
Y:00200A
Function Code?
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 050 and if you do not know, press **ENTER** key. Then, after moving to “050:SPD CHNG” by using **direction** key ▲▼, press **ENTER** key.

```
<Function Code>
050:SPD      CHNG<
051:STITCH  DRAG
052:STITCH  DEL
```

G. Input maximum sewing speed value **STSPM** and press **ENTER** key.

```
050:SPD      CHNG
STSPM:25[100spm]
```

H. Input **XSCAL**, the extension/reduction rate for X-direction and press **ENTER** key.

```
050:SPD      CHNG
STSPM:25[100spm]
XSCAL:100%
```

I. Input **YSCAL**, the extension/reduction rate for Y-direction and if you press **ENTER** key, all setting is completed.


```
050:SPD      CHNG
STSPM:25[100spm]
XSCAL:100%
YSCAL:100%
```

J. Save the pattern by pressing **WRITE** key.

```
015:PTRN      READ
NO   :009
```

3-9) Symmetrical Shape Creating Function of Pattern

Make three types of symmetrical shapes for optional point in X and Y axes.



A. Insert floppy diskette containing the pattern to create symmetrical shape.

B. Press **MODE** key.

C. After moving to “2. Program” menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? █
```

D. After pressing **READ** key, input the pattern number to create symmetrical shape by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO   :001
```

E. Go to pattern data start location by using **FORW** and **BACK** key.

(Reference) You may place the needle location to create symmetrical shape in X and Y axes at the optional needle location to sew. However, symmetry by the optional point becomes symmetric on the basis of the end point of sewing data and so you should place needle location at the end point of sewing data.

```
CURVE
X:-0060A  N:00005
Y:00059A
Function Code? █
```

- F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 043 and if you do not know the number, press **ENTER** key. Then, after moving to "043:SYMMETRY X" by using **direction** key **▲▼**, press **ENTER** key.
- X-axis symmetry is **Function Code 043**
 - Y-axis symmetry is **Function Code 044**
 - Optional point symmetry is **Function Code 045**


```
<Function Code>
043:SYMMETRY  X<
044:SYMMETRY  Y
045:SYMMETRY  P
```

- G. Confirm if symmetrical shape was made properly by using **FORW** and **BACK** key.

```
CURVE
X:00000A  N:00023
Y:00059A
Function Code? 
```

3-10) Condensed Sewing Stitch Inserting Function

It is the function to prevent stitches from being untangled by making stitch width condensed in sewing start part and sewing end part of pattern data.



- A. Insert floppy diskette containing the pattern to insert condensed sewing stitch.

- B. Press **MODE** key.

- C. After moving to "2. Program" menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A  N:00000
Y:00000A
Function Code? 
```


D. After pressing **READ** key, input the pattern number to insert condensed sewing stitch by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO   :001
```

E. Go to pattern data end location by using **FORW** and **BACK** key.

```
CURVE
X:-0060A  N:00040
Y:00039A
Function Code? █
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 041 and if you do not know the number, press **ENTER** key. Then, after moving to "041:CONDNS STI" by using **direction** key **▲ ▼**, press **ENTER** key.

```
<Function Code>
041:CONDNS      STI<█
042:OVLAP       STI
043:SYMMETRY    X
```

G. After inputting the number of **initial condensed sewing stitch**(1~9 stitch), press **ENTER** Key.

```
041:CONDNS      STI
SNUM:4[STITCH]
```

H. After inputting the number of **final condensed sewing stitch**(1~9 stitch), press **ENTER** key.

```
041:CONDNS      STI
SNUM:4[STITCH]
ENUM:4[STITCH]
```

I. After inputting condensed stitch width, if you press **EXE** or **ENTER** Key, input of **condensed sewing stitch** is completed.

※ The stitch width of the number of stitches set up at sewing start point(the number of **initial condensed sewing stitch**) and sewing end point(the number of **end condensed sewing stitch**) is changed into condensed stitch sixth.


```
041:CONDNS      STI
SNUM:3[STITCH]
ENUM:3[STITCH]
WIDTH:010[0.1mm]
```

J. Confirm if the number of **condensed sewing stitch** was made properly by using **FORW** and **BACK** key.

```
LINE
X:-0160A  N:00080
Y:00039A
Function Code? █
```

3-11) Automatic Back Tack(B/T) Inserting Function

You can apply automatic back tack inserting function for several pattern.



A. Insert floppy diskette containing the pattern to insert automatic back tack.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```

ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
  
```

D. After pressing **READ** key, input the pattern number to insert automatic back tack by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```

014:PTRN      READ
NO  :001
  
```

E. Go to the location that pattern data ends by using **FORW** and **BACK** key.

```

LINE
X:-0160A N:00040
Y:00039A
Function Code?
  
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 040 and if you do not know the number, press **ENTER** key. Then, after moving to "040:BACK TACK" by using **direction** key **▲ ▼**, press **ENTER** key.


```
<Function Code>
040:BACK      TACK<
041:CNDNS     STI
042:OVLAP     STI
```


G. Input the number of back tack to insert and press **ENTER** key.

```
040:BACK      TACK
BTNUM:4[STICH]
```

H. Input back tack mode. Press **ENTE** key.

Mode Type

Mode 0: 

Mode 1: 


```
040:BACK      TACK
BTNUM:4[STICH]
BTMOD:0[0/1]
```

I. Confirm if back tack was made properly by using **FORW** and **BACK** key.

```
LINE
X:-0160A N:00040
Y:00039A
Function Code?
```

3-12) OverLap Sewing Stitch Inserting Function

You can apply automatic overlap sewing stitch inserting function for several patterns.



OverLap function can apply to the pattern design of closed roof that start point and end point meet. Except, though it is not closed roof type of pattern and start point and end point have 1mm of distance, OverLap function can use.

Be able to select a maximum of **20 stitch**.

A. Insert floppy diskette containing the pattern to insert overlap sewing stitch.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key ▲ ▼, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to insert overlap sewing stitch by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO   :001
```

E. Go to the location that pattern data ends in order to apply overlap function by using **FORW** and **BACK** key.

```
CIRCLE
X:00000A N:00030
Y:00100A
Function Code?
```

F. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 042 and if you do not know the number, press **ENTER** key. Then, after moving to "042:OVLAP STI" by using **direction** key ▲ ▼, press **ENTER** key.

```
<Function Code>
042:OVLAP      STI<
043:SYMMETRY   X
044:SYMMETRY   Y
```

G. Input the number of overlap stitch to insert and press **ENTER** key.


```
042:OVLAP      STI
OVNUM:4[STICH]
```

H. Confirm if back tack was made properly by using **FORW** and **BACK** key.

```
CIRCLE
X:-0092A N:00034
Y:00037A
Function Code?
```

3-13) Automatic Insertion of Thread Trimmer Code when Deleting Stitches

If the user deletes any section of pattern or the stitches, the user can define whether to insert thread trimmer code on the related location.



A. Use **direction** key **▲ ▼** to select "2. Program", and then press **ENTER**.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

B. Press code key again on the Operation Box.

```
ORIGIN      NONE
X:00000A  N:00000
Y:00000A
Function Code? █
```

C. If the function **code** No. related to the pattern programming were known, enter three digits of number, **055**. If not, press **ENTER** and use **direction** key **▲ ▼** to move the cursor on "055: AUTO TRIM", and then press **ENTER**.

```
<Function Code>

CODE NO    :055
```

D. On the following screen, press **"1"** to change **"0"** to **"1"**, and then press **ENTER** to set automatic thread trimmer function.

```
055:AUTO TRIM

TRIM:1[0/1]
```

E. When deleting stitches or pattern, the user can confirm the automatic insertion of thread trimmer by either making new design or retrieving the existing design saved in a disk. Please refer to "2-3) Delete Number of Stitches" and "2-4) Partially Delete Pattern Data".

```

ORIGIN          NONE
X:00000A  N:00000
Y:00000A
Function Code?

```

3-14) Setting-Up Reference Point for Zooming

On the sewing mode, the user can zoom design based on machine origin, second origin, sewing starting point or user-defined reference point. However, the second origin and user-defined reference point must be set in the pattern design before zooming based on those reference points.

A. Press **MODE**.

B. Use **direction** key **▲ ▼** to select "1. Parameter Set" menu.

```

<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind

```

C. Press **ENTER** to open a screen shown on the right. Input [0][7][6] and press **ENTER** to move onto the 076. Scale Refer item.

```

<Parameter Set>

PARA No    :076

```

D. The following four items of zooming reference point are displayed.

By default, it is set on **MACHINE_ORG**. Use **direction** key **▲ ▼** to select the item desired, and then press **ENTER** to set.

```

076. Scale Refer
1) MACHINE_ORG
2) SECOND_ORG
3) SEWING_STR
4) REFER_PNT

```

Descriptions of each item are as follows:

MACHINE_ORG : Zooming based on the machine origin.

SECOND_ORG : Zooming based on the second origin.

SEWING_STR : Zooming based on the sewing starting point.

REFER_PNT : Zooming based on the point defined by user at program code No. 076 of Function Code.

E. Setting-Up Reference Point for Punching.

- ① After creating any pattern design, use **back/forth** stitch function to move it to the reference point to be set, and then press code key.

<Function Code>

Code No : 076

- ② Input **076** for the code No., and press **ENTER**.

SCALE REFER NONE

X: -0300A N: 00097


Y: -0300A


Function Code?

- ③ On the following SCALE REFER item, use back/forth stitch function to confirm whether the reference point would be inserted.

F. After setting-up the reference point item and the reference point, **store** the decided design into floppy diskette, press **ESC** to return to the **sewing mode**, and then apply the scale desired.

The following illustration shows the zooming functions for each reference point item.





3-15) Embroidery Design Call Function

It means the function converting to sew by calling SunStar's "*.SST Sewing Design File" and TAJIMA's "*.DST Sewing Design File".

A. Insert floppy diskette containing the sewing design into floppy disk driver.

B. Press **MODE** key.

C. After moving to "6. EMB Call" by using **direction** key **▲▼**, press **ENTER** key.

D. The next screen appears and **READY LED** light of operation box flickers. Select TAJIMA sewing design by pressing Number 1 key.

E. The next screen appears again. (Current screen can be difference according to sewing design in the diskette.) After selecting the design to convert by using **direction** key, press **ENTER** key.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```

```
<< Main Menu >>
6. EMB Call
```

```
Insert Disk
SWF(0)/TAJIMA(1)

To Exit (ESC)...
```

```
<< FILE LIST >>
G013.dst
```


F. Then screen changes again and input the design number by using **digit** key to save into pattern file. And press **ENTER** key.

```
Enter Number to
be stored
```

```
NO : 001
```

G. **READY LED** on operation box flickers continuously and there comes the sounds reading floppy diskette.

H. If you converted and read sewing design into pattern file, the next screen appears.

```
<< Main Menu >>
6. EMB Call
```

I. Return to initial sewing screen by pressing **ESC** key. (The screen in the next can be different according to sewing design type, user's working order and environment.

```
NO:000      NOR_SEW
XS:100%
YS:100%     SP:2500
BC:058      PC:0058
```

J. After inputting pattern file number saved in the front by pressing No. key button on the operation box, call the design by pressing **ENTER** key.

```
NO:001      NOR_SEW
XS:100%
YS:100%     SP:2500
BC:058      PC:0058
```

K. Fasten the working material by pressing foot plate of right pedal and start sewing by stepping start pedal.

3-16) JUKI Design Call

The function of converting JUKI's AMS-Series design files was added.

A. Select No. 7 "OtherPtrnCall" from the main menu.

```
<< Main Menu >>
7. OtherPtrnCall <
```

B. Insert a diskette, and press No. 0.

```
Insert Disk
JUKI/Press(0)
To Exit(ESC)...
```

C. The list of JUKI files saved in the diskette shows up on the screen.
Move the cursor to the conversion target file, and press "Enter."

```
<< FILE List >>
100.M3      <
200.M3
300.M3
```

D. Enter a new name for the file, which will be converted and saved, and press "Enter."

```
Enter Number to  
be stored
```

```
NO:001
```

E. When conversion is finished, the screen returns to the original status.

```
<< Main Menu >>  
7. OtherPtrnCall <
```

F. Press No. 5 "Pattern List" from the main menu, and check whether the converted file from the diskette is properly saved.

```
<< Main Menu >>  
5. Pattern List <  
6. EMB Call  
7. OtherPtrnCall
```

G. Press No. 1.

```
Memory(0)/FDD(1)  
  
To Exit(ESC)...
```

H. The list of design patterns saved is displayed.

```
<< Pattern List >>  
001 <
```

3-17) Sewing Limit Function

This function for setting sewing limit is designed to expand the mechanical sewing limit of the machine. First mechanically expand the X-Y feeding area of the machine, and set the sewing limit in the parameter in accordance with the expanded area.

※In case of C-Series, the area can be expanded up to 25000×25000mm.

Refer to the following for set-up.

A. Press **MODE** and select Parameter Set in Main Menu.

```
<< Main Menu >>  
1. Parameter Set  
2. Program  
3. Bobbin Wind
```

B. Use the direction change cursor in the Parameter Set and select **078. Sewing Limit**.

```
< Parameter Set >  
078. Sewing Limit  
079. XPLUS Limit  
080. XMINUS Limit
```

C. Sewing Limit is defaulted at **1) DISABLE**.

```
078.Sewing Limit  
1) DISABLE <  
2) ENABLE
```

D. Use the direction change cursor to select **2) ENABLE** and press **ENTER**.

```
078.Sewing Limit
1) DISABLE
2) ENABLE
```

E. Use the direction change cursor to select **079. XPLUS Limit**.

The default value is set at 65mm (for SPS-1306 machines). Use the up/down **direction** key **▲ ▼** to increase the limit as desired.

※ In case of C-Series, the unit can be set by the unit of [50mm]. As such, in case of 5050, it is displayed as X : 00050. In other words, 50×50[mm] equals 2500mm. Likewise, if the maximum expansion is X: 00250, it means 250×50[mm] = 12500mm.

※ Ex) If you increase the X-axis mechanical feeding limit to a maximum 140mm, you can set up to 70mm in the X-axis plus direction.

```
< Parameter Set >
079. XPLUS Limit
080. XMINUS Limit
081. YPLUS Limit
```

```
079. XPLUS Limit
X:00065
```

```
079. XPLUS Limit
X:00070
```

F. To increase limit in the opposite direction, select **080. XMINUS Limit**.

The default value is set at -65mm (for SPS-1306 machines). Use the up/down **direction** key **▲ ▼** to increase the limit as desired.

※ Ex) If you increase the X-axis mechanical feeding limit to a maximum 140mm, you can set up to -70mm in the X-axis minus direction.


```
< Parameter Set >
080. XMINUS Limit
081. YPLUS Limit
082. YMINUS Limit
```

```
080. XMINUS Limit
X:-00065
```

```
080. XMINUS Limit
X:-00070
```


G. If you increased the mechanical feeding limit of Y-axis, refer to the above instructions to expand the feeding limit.

After setting the sewing limit in accordance with the mechanically expanded limit, you can check if the machine feeds to the actual expanded limit. Use the X-Y Jog Test function in Machine Test function to check whether the machine feeds to the actual expanded limit.



Caution) The sewing limit function is always defaulted at DISABLE and the sewing limit is set at the standard size for each type at the factory.

3-18) Quick Origin Search Motion Function for 1811 Machines



As SPS-1811 machines is equipped with reverse devices, origin search motion is performed as shown in the Before picture and feeds back to the starting point of sewing. However, if there is no reverse device, search motion takes place very slowly. This quick origin search motion function ensures fast origin search as shown in the After picture and feeding back to the starting point of sewing.

Refer to the following for set-up.

- A. Press **MODE** to select Parameter Set in Main Menu.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

- B. Use the direction change cursor in Parameter Set and select 083. FFOrign 1811.

```
< Parameter Set >
083. FFOrign 1811
084. AFC Down Time
085. AFC Up Time
```

- C. FFOrigin 1811 is defaulted at 1) DISABLE.
This setting ensures slow origin search motion all the time.

```
083.FFOrigin 1811
1) DISABLE <
2) ENABLE
```

- D. Use the direction change button **▲ ▼** to select 2) ENABLE and press **ENTER**. This setting ensures fast origin search motion all the time.

```
083.FFOrigin 1811
1) DISABLE
2) ENABLE <
```

3-19) Setting Origin Search Function of Upper and Lower Shafts after Finishing Sewing [only applied for SPS/C-Series]

How to set origin search motion of upper and lower shafts (hook timing) is described below. Upper and lower shafts of SPS/5050 Series are separated with each other, operating independently, which means that hook timing by the operation of both shafts is important. If the timing becomes improperly set during operation or trimming process, this function can always guarantee the proper hook timing by resetting it through origin search motion of upper and lower shafts after completion of sewing.

How to set origin search function of upper and lower shaft.

- A. Press **MODE** key and select Parameter Set from Main Menu.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

- B. Select **084. HOOKORG MODE** from Parameter Set by pressing **direction** keys **▲ ▼**.

```
< Parameter Set >
084. HOOKORG MODE
085. HEAD En/Dis
086. RevAfterTrim
```

- C. **084. HOOKORG MODE** is originally set at **2)JOB_READY**.

- 1) **1)JOB_SETUP**: After completion of sewing, origin search motion gets deleted.
- 2) **2)JOB_READY**: After completion of sewing, origin search motion gets set.

```
084.HOOKORG MODE
1) JOB_SETUP
2) JOB_READY <
```

- D. Deleting origin search motion move to **1)JOB_SETUP** and press **ENTER** key.

3-20) Setting Machine Head up or Down Function [only for SPS/C-Series]

How to set machine Head up or down function is described below. Vertical control of Head is easy, because Head of SPS/C-Series is connected with air pressure cylinder. Parameter is originally set not to raise machine Head after completion of sewing. However, change in setting will raise machine Head after completion of sewing. This function is available, depending on material and operating environment.

How to set machine Head up or down function:

- A. Choose Parameter Set from Main Menu by pushing **MODE**.

```
<< Main Menu >>  
1. Parameter Set  
2. Program  
3. Bobbin Wind
```

- B. Choose **085. HEAD En/Dis** from Parameter Set by using **direction** keys **▲ ▼**.

```
< Parameter Set >  
085. HEAD En/Dis  
086. RevAfterTrim  
087. ReverseAngle
```

- C. When choosing, **085. HEAD En/Dis** is set at **1)DISABLE**.

1)DISABLE: After finishing sewing, leave the Head of machine down.

2)ENABLE: After finishing sewing, leave the Head of machine up.

```
085.HEAD En/Dis  
1) DISABLE  
2) ENABLE <-
```

- D. To up the Head, move to **2)ENABLE**, and then **ENTER** **↵** key.

3-21) Setting Reverse Rotation after Trimming [Only applied for SPS/B/C-Series]

Function of Reverse rotation after trimming is as follows. When sewing material is thick, the thick material can interfere with needle if the needle is placed at the highest point of thread take-up. In that case, the interference will be prevented if the needle is placed in reverse order. Therefore, after trimming, set the point of reverse rotation as the applicable angle by using the reverse rotation function. If sewing material is not thick, don't use the function.

Setting method is as follows.

- A. Choose Parameter Set from Main Menu by pushing **MODE** key.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

- B. Choose **086. RevAfterTrim** from Parameter Set by using **direction** keys ▲ ▼.

```
< Parameter Set >
086. RevAfterTrim
087. ReverseAngle
088. Oil Control
```

- C. When choosing, **086. RevAfterTrim** is set at **1)DISABLE**.

1)DISABLE: After trimming, don't use the reverse rotation function after trimming.

2)ENABLE: After trimming, use the reverse

```
086. RevAfterTrim
1) DISABLE
2) ENABLE <
```

- D. Move to **2)ENABLE** and press **ENTER** key in order to use this function

3-22) Setting the Angle of Reverse Rotation after Trimming [only applied for SPS/B/C-Series]

How to set the angle of reverse rotation, after trimming, is described below.

This function is available only when post-trimming reverse rotation function of **076. RevAfterTrim** mentioned above is set at **Enable**.

Setting method is as follows.

A. Press **MODE** key and choose Parameter Set from Main Menu.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

B. Choose **087. ReverseAngle** from Parameter Set by pressing **direction** keys **▲ ▼**.

```
< Parameter Set >
087. ReverseAngle
088. Oil Control
089. OilOffTime
```


C. **087. ReverseAngle** is originally set at **15[degree]**.
The angle can be reset from **1 to 40[degree]**.
Angle can be reset by pressing **direction** keys **▲ ▼** on the OP box.

```
087.ReverseAngle
15[degree]
```

D. Press **ENTER** key to save the reset angle.


```
087.ReverseAngle
40[degree]
```

[Post-trimming Reverse Rotation Function Setting In Case Of SPS/A-Series Belt-type Machine]



Fortuna S-II P/U

Fortuna S-II P/U




1. Turn off the power and connect with Fortuna S-II P/U.
2. Turn on the power while pressing the Prog button of P/U.
3. Wait until the beep sound is heard.
4. Move the A-Group parameter by pressing the A button and the Prog button of P/U at the same time.
5. Move to A-Group #60 by pressing the N2 button (to determine whether to use the post-trimming reverse rotation function)
6. Press the C button to change the value from "0" to "1".
7. Press the ENTER button to save the setting.
8. Press the N2 button again to go to A-Group #61 (to determine the volume of post-trimming reverse rotation)
9. Press the C button to set the volume of post-trimming reverse rotation. The maximum volume is 40.
10. Press the ENTER button to save the setting.
11. Press the Prog button to end the parameter setting.
12. Turn the power off and remove the cable.
13. Then, after trimming, the reverse rotation function will be applied according to the set value.

※ For more information, see the Fortuna S-II P/U manual.

3-23) Setting Output Port [Only applied for SPS/C-Series]

The function is that a user can program devices that are set to certain places when punching. The list of the devices is as follows.

NO	Device	Content
00	PF	Presser Feet
01	FF	Feed Plate
02	TT	Trimming
03	TH	Thread Holder
04	WP	Wiper
05	FF__L	Left Feed Plate
06	TWO__STG	Two-Step Stroke Feed Plate
07	REV__DEV	Inverting Device
08	REAR__FF	Rear Feed Plate
09	TR	Thread Release
10	AFC	Material Conveying Pressing Device
11	TR3	Thread Release 3
12	HEAD	Machine Head
13	OP55~OP57	Other Ports [Don't use]
14	OP60~OP67	Other Ports [Don't use]



The process of program to operate **thread control device 3** in specific range of general square pattern is as follows.

A. Press **MODE** key.

```
<< Main Menu >>  
2. Program  
3. Bobbin Wind  
4. Machine Test
```

B. Move to "2. Program" by pressing **direction** keys **▲ ▼** and press **ENTER [↵]** key.
Upper feed plate will come down and move to original point.

```
ORIGIN  
X:00000A N:00000  
Y:00000A  
Function Code?
```

C. Press **JUMP** key and move to the original position of the square by pressing **direction** keys **▲ ▼**.
And then press **PNT.SET** key.

```
004:JUMP  
X:-0650  
Y:00300  
N:001
```

D. Pressing **EXE** key will move feed plate according to the computed data after computing pattern data.

```
JUMP NONE  
X:-0650A N:00065  
Y:00300A  
Function Code?
```

E. Press **LINE** key, input stitch width by pressing number keys and then press **ENTER [↵]** key.
(Ex. Press **[0][3][0]** to set stitch width at 3mm.)

```
007:LINE  
WIDTH:030[0.1mm]
```

F. Move to the first point position of LINE by pressing **direction** keys **▲ ▼**.
Press **PNT.SET** key.

```
007:LINE  
X:00650  
Y:00300  
N:001
```

G. Register the first point position of square by pressing **EXE** key. After computing pattern data, feed plate will move according to the computed data.

```
LINE NONE  
X:00650A N:00104  
Y:00300A  
Function Code?
```

H. Press **CODE** key to program **TR3**(Thread Release 3)

Function code is **number 057**. If function code number is not identified, press **ENTER** key to see function code list and then move to **number 057 SET OP** by pressing **direction** keys **▲ ▼**.

I. Move to **number 11 TR3** in SET OP functions list by pressing **ENTER** key. Press **ENTER** key.

J. Pressing **ENTER** key shows the following screen. Move to ON and then press **ENTER** key.

At the same time, the **thread control device 3** is programmed at the end of the **created Line**.

K. Return to the initial screen. To create **Second Line**, input switch width by using Line key.

L. Press **PNT.SET** key and then resister **Second Line** by using **EXE** key.

After computing pattern data, feed plate moves according to the data.

M. To program **TR3**, press **CODE** key. Function is 57. If the code number is not identified, press **ENTER** key to indicate function code list and move to **57 SET OP** by using **direction** keys **▲ ▼**.

N. Move to **number 11 TR3** in the SET OP function list by using **ENTER** key. Press **ENTER** key.

```
<Function Code>
057:SET      OP    <
058:CHK IP
059:TIME DELAY
```

```
057:SET      OP
11:TR3              <
12:HEAD
13:OP55
```

```
057:SET      OP
TR3 :OFF      <
      ON
```

```
TR3      ON      NONE
X:00650A  N:00105
Y:00300A
Function Code?
```

```
LINE      NONE
X:00650A  N:00125
Y:-0300A
Function Code?
```

```
<Function Code>
057:SET      OP    <
058:CHK IP
059:TIME DELAY
```

```
057:SET      OP
11:TR3              <
12:HEAD
13:OP55
```

O. Pressing **ENTER** key shows the following screen. To delete the set **TR3**, go to **OFF** and then press **ENTER** key. At the same time, the **thread control device 3** is programmed at the end of the created Line.

```
057:SET      OP
TR3:OFF      <
          ON
```

P. Return to the initial screen.

```
TR3      OFF      NONE
X:00650A  N:00126
Y:-0300A
Function Code?
```

Q. Create third and **fourth line** as the way the first and second lines are created. And then press **TEST** to check whether **TR3** is operating or not.

TR3 is set at **OFF** in the **first LINE**. **TR3** will be at **ON** at the beginning of the **second LINE** and **OFF** at the **end of the second LINE**.

R. If there is no problem with sewing, press **TEST** key again, and then press **WRITE** key to save design.

3-24) Setting Time Delay when Output Port is Being Used [only applied for SPS/C-Series]

The function is to program applicable time delay when output port is being used.

The program will be explained later in **J. of 3-23) Setting Output Port**.

A. Pressing **ENTER** key will show following page. Move to **ON** and press **ENTER** key. At the same time, **thread control device 3** will be programmed at the end of the created line.


```
057:SET      OP
TR3:OFF      <
          ON
```

B. Return to the initial page of program.
Program **Time Delay** before creating second LINE.

```
TR3      ON      NONE
X:00650A  N:00105
Y:00300A
Function Code?
```

C. Press **CODE** key to program **Time Delay**.
Function code is number 58. If function code number is not identified, press **ENTER** key to see function code list and then move to number **059 TIME DELAY** by pressing **direction** keys **▲ ▼**.

```
<Function Code>
059:TIME DELAY <
060:SET TR3
000:TRIM
```

- D. Press **ENTER**  key to set Time Delay.
 Time Delay is originally set at 0[ms].
 Time delay unit is 4[ms]. Set desired Time delay by using number keys. Input 50[ms]. If 50[ms] is input, the real Time Delay is 200[ms].

```
059:TIME DELAY
DELAY:0050[x4ms]
```

- E. Return to the initial screen.
 To create Second Line, input switch width by using Line key.

```
TIME DELAY NONE
X:00650A N:00106
Y:00300A
Function Code?
```

- F. After pressing **PNT.SET** key, register Second Line by using **EXE**.
 After computing pattern data, feed plate moves according to the data.


```
LINE NONE
X:00650A N:00126
Y:-0300A
Function Code?
```

- G. The rest part is the same with **L~R in 3-23) Output Port Setting Function**.

So, when time delay is programmed, **TR3** will operate shortly before second Line sewing following first Line sewing. And the operation will discontinue for 200[ms] shortly before sewing and then second Line sewing will start. By doing so, a user can set delay time at each designated device and take motion when operating device related output port.

3-25) 3rd Thread Adjusting Device (TR3) Setting

This function allows users to make additional adjustment of the upper thread tension for a certain section.



A. Press **MODE** key.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

B. Move to "2. Program" by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.
Upper feed plate will come down and move to original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

C. Press **JUMP** key and move to the original position of the square by pressing **direction** keys **▲ ▼**.
And then press **PNT.SET** key.

```
004:JUMP
X:-0650
Y:00300
N:001
```

D. Pressing **EXE** key will move feed plate according to the computed data after computing pattern data.

```
JUMP                NONE
X:-0650A N:00065
Y:00300A
Function Code?
```

E. Press **LINE** key, input stitch width by pressing number keys and then press **ENTER** **↵** key.
(Ex. Press **[0][3][0]** to set stitch width at 3mm.)

```
007:LINE
WIDTH:030[0.1mm]
```

F. Move to the first point position of LINE by pressing **direction** keys **▲ ▼**.
Press **PNT.SET** key.

```
007:LINE
X:00650
Y:00300
N:001
```

G. Register the first point position of square by pressing **EXE** key. After computing pattern data, feed plate will move according to the computed data.

```
LINE                NONE
X:00650A N:00104
Y:00300A
Function Code?
```

H. Press **CODE** key to program **TR3(Thread Release 3)**
The concerned function code is 063. If you want to search it from the function code list, press **ENTER** **↵** and move to **063 SET TR3** with **direction** keys **▲ ▼**.

```
<Function Code>
063:SET    TR3 <
```

I. When **ENTER** is pressed, the following screen appears. Move the cursor to ON and press **ENTER**. Upon striking **ENTER**, the 3rd line adjuster code is created at the end of the line.

```
063:SET      TR3
TR3 :OFF
          ON      <
```

J. Return to the initial screen. To create **Second Line**, input switch width by using Line key.

```
TR3      ON      NONE
X:00650A  N:00105
Y:00300A
Function Code?
```

K. Press **PNT.SET** key and then resister **Second Line** by using **EXE** key.

The feed plate moves to the set position in accordance with the data calculation result.

```
LINE      NONE
X:00650A  N:00125
Y:-0300A
Function Code?
```

L. To program **TR3**, press **CODE** key. Function is 63. The concerned function code is 063. If you want to search it from the function code list, press **ENTER** and move to **063 SET TR3** with direction keys **▲ ▼**.

```
<Function Code>
063:SET      TR3 <
```

M. When **ENTER** is pressed, the following screen appears. To cancel the **TR3** setting, move the cursor to **OFF** and press **ENTER**. At the same time, the **thread control device 3** is programmed at the end of the created Line.

```
063:SET      TR3
TR3:OFF
          ON      <
```

N. Return to the initial screen.

```
TR3      OFF      NONE
X:00650A  N:00126
Y:-0300A
Function Code?
```

O. Create third and **fourth line** as the way the first and second lines are created. And then press **TEST** to check whether **TR3** is operating or not.

TR3 is set at **OFF** in the **first LINE**. **TR3** will be at **ON** at the beginning of the **second LINE** and **OFF** at the **end of the second LINE**.

P. If there is no problem with sewing, press **TEST** key again, and then press **WRITE** key to save design.

3-26) Basic Clamp Position Setting

※ This function is to set the basic position of the clamp. When parameters need to be changed, clamp's pneumatic lines **A and B** shall be exchanged in accordance with conditions.

A. Select **Parameter Set**.

```
<< Main Menu >>  
1. Parameter Set <-  
2. Program  
3. Bobbin Wind
```

B. To change the basic position of the clamp to **Down**, go to Parameter **104. Clmp Ref POS** and select **2)Ref_DOWN**.
(Default is **1) Ref_UP**.)

```
104 : Clmp Ref POS  
1)Ref_UP          <-  
2)Ref_DOWN
```

※ Key Points

1. If the value of **104.Clmp Ref POS** is changed to **Ref_DOWN**, the two pneumatic tubes connected to the clamp shall be exchanged.

4) Pattern Data General Function

4-1) Checking and Deleting the Pattern Number

It is used to check or delete the pattern number in floppy diskette and inner memory.

- A. Press **MODE** key.
- B. By using **direction** keys **▲▼**, move to "5. Program List" menu.

```
<< Main Menu >>
5. Pattern List
6. EMB CALL
```

- C. If you press **ENTER** key, the screen of the right sides appears. To check the pattern number in inner memory, press **digit** key, **0**, and to check the pattern number in a floppy diskette, press **digit** key, **1**

```
Memory(0)/FDD(1)

To Exit(ESC)... █
```

- D. If you press **digit** key, **1**, the pattern number in a floppy diskette is shown.

```
<<Pattern List>>
002          <-█
003
004
```

- E. If a **pattern number** is not indicated on one screen, check it by using **direction** key **▲▼**, with moving forward and downward.

```
<<Pattern List>>
004          <-█
005
006
```

- F. After moving to the pattern number that you want to delete by using **direction** keys **▲▼**, if you press **PTN DEL** key, the screen of the right side appears. To delete the pattern, press **ENTER** key, and to cancel, press **ESC** key.


```
Are YOU Sure?

Y(ENTER)/N(ESC)
```

- G. By pressing **ESC** key, complete the check of pattern number. By pressing **ESC** key, back to the initial screen.

4-2) Making a Copy the Pattern to Another Number or Diskette

It is used to make a copy the pattern to another number or diskette. It is available to check, make a copy or delete the pattern number.



- A. Insert a floppy diskette that you want to make a copy.
- B. Press **MODE** key.
- C. By using **direction** keys **▲▼**, move to “2. Program” menu, then press **ENTER** key.
At this time the upper feed plate descends, and moves to the origin.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

- D. After pressing **READ** key, input the pattern number that is to be copied by using **digit** keys.
(For example, to make a copy “001”, input [0][0][1].)

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

- E. Press **ENTER** key. The **READY LED** flickers during reading the pattern data.

```
014:PTRN READ
NO :001
```

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code? █
```

F. After the **READY LED** turns off, if you want to make a copy the pattern to the same floppy diskette as another pattern number, press **WRITE** key and input the pattern number that is to be copied by using **digit** keys.
(For example, input [0][0][2] to make a copy as "002".)

To make a copy to other floppy diskette, take out the existing diskette and insert other floppy diskette, then press **WRITE** key to input the pattern number you want to make a copy by using **digit** keys.

(For example, input [0][0][1] to make a copy as "001".)

G. After leaving the programming menu by pressing **MODE** key, back to the initial screen by pressing **ESC** key.

※ Referring to "Pattern Number Check", check the copied pattern number.

015:PTRN WRITE
NO :002


<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test

4-3) Pattern Store Function

This function is designed to summon pattern design data stored in CPU memory and store it in the floppy disk while the machine is in sewing mode. In the past, users themselves punched designs in the program mode and stored in floppy disk, but could not call design data in CPU memory and store them in floppy disk during sewing mode.

Refer to the following for set-up.

- To store design, the machine has to be in the sewing mode.
- While the machine is in the sewing mode, key in the desired pattern design number and press **ENTER**.
- If the machine is in the sewing mode, a light will come up in **Ready LED** located at the upper left corner.
- Press **ENTER** again. The sewing mode will be turned off and the light will go off in Ready LED.
- By following the step A, B, C, D only once, stored designs in CPU memory can be stored in floppy disks.
- Insert a disk into the floppy drive and press a key at the left bottom of the OP Box to store.
- In the LCD display of the OP Box, the sewing mode will be changed to storing mode.
- Key in desired design number and press **ENTER** to store design in the disk.



4-4) Pattern Information Displaying Function

Upon punching, it displays various information on the pattern currently saved in the memory.

A. Insert floppy diskette containing the pattern to use pattern information displaying function.

B. Press **MODE** key.

C. After moving to "2. Program" menu by using **direction** key **▲ ▼**, press **ENTER** key. At this time, the upper feed plate comes down and moves to the original point.

```
ORIGIN
X:00000A N:00000
Y:00000A
Function Code?
```

D. After pressing **READ** key, input the pattern number to display pattern information by using **digit** key and read in the pattern by pressing **ENTER** key. (For example, input [0][0][1] to read the pattern number 001.)

```
014:PTRN      READ
NO  :001
```

E. After pressing **CODE** key, if you know the function number related to pattern programming, input three-figure digit number 017 and if you do not know the number, press **ENTER** key. Then, after moving to "017:INFO DISP" by using **direction** key **▲ ▼**, press **ENTER** key.

```
<Function Code>
017:INFO      DISP<
018:CORD      SIS
019:LINE      ZIG
```

F. The meaning of information being displayed on the screen is as follows:

NO - Pattern number
XS - Extension/reduction rate of **X-axis** direction.
YS - Extension/reduction rate of **Y-axis** direction.
SP - Maximum sewing speed
RV - Whether to use a reversal device.
 NONE (not use) YES (use)
ST - Total number of actually sewed stitches

```
017:INFO      DISP
NO:000        SP:2000
XS:100%       RV:NONE
YS:100%       ST:00100
```

G. If you press **ESC** key, return to previous state.

4-5) Change of Parameter Related to General Sewing

It is used when you want to change the working condition of electrically controlled pattern sewing machine to be best for working efficiency and user's need.

A. Press **MODE** key.

B. Move to "1. Parameter Set" by using **direction** keys **▲▼**.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

C. When you press **ENTER** key, you can get the screen like a figure on the right side. If you know the parameter number related to general sewing, input the three digit parameter number. For example, if you want to change "004:Strt Ret Mod", input [0][0][4]. At this time, you should input [0] twice for the first and second digits.

```
<Parameter Set>

PARA No : 004
```

※ Appendix :

Refer "Parameter number related to general sewing."

D. If you don't know any relevant number, press **ENTER** key to move to the parameter number you want by using **direction** keys **▲▼**.

※ Appendix :

Refer "Parameter number related to general sewing."

```
<Parameter Set>
004.Strt Ret Mod
005.Bobbin Count
006.Prodct Count
```

E. After pressing **ENTER** key, change the setting value or any state you want by using **direction** keys **▲▼**.

```
004:Strt Ret Mod
1) SHORTEST <-
2) ORG_TO_STR
3) REV_ORG_STR
```

F. If you press **ENTER**, the changed condition will be valid and the machine backs to the previous menu. If you don't want any change, press **ESC** to cancel it.

```
<Parameter Set>
004.Strt Ret Mod
005.Bobbin Count
006.Prodct Count
```

G. If you want to back to the previous menu, press **ESC** key.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

H. Press **ESC** key to back to the initial screen.

※ You can confirm the machine backs to the sewing start point directly without passing through the origin after finishing sewing.

4-6) Initialization of Parameter Related to General Sewing

It is used for parameter related to general sewing to back to the factory-installed setting value. It is recommendable that only professional A/S engineer handles it.

A. Press **MODE** key.

```
<< Main Menu >>  
0. Initialize  
1. Parameter Set  
2. Program
```

B. Press **ENTER** key.

```
<< Initialize >>  
1. Para. Init.  
2. Sys. UpDate
```

C. After moving to "1. Para. Init." menu by using **direction** keys **▲▼**, press **ENTER** key. Then you can see the screen like a figure on the right side. When a parameter initialization is finished, previous screen appears.

```
System Parameter  
Initializing....  
■
```

D. Press **ESC** key to back to the general sewing mode.

```
NO:000    NOR_SEW  
XS:100%  
YS:100%    SP:1500  
BC:000    PC:0000
```

4-7) System Program Update

It is used for the system program that handles electrically controlled pattern sewing machine to be updated. Only professional A/S engineers allow to operate it.

A. Insert a floppy disk having system program that you want to update into a floppy disk drive.

B. After pressing **MODE** key, press **ENTER** key.

※ Caution

If **READY LED** turns on or upper feed plate is under, some keys are not available. It happened, operate the keys after lifting the upper feed plate or pressing **ENTER** key.

C. Move to "2. Sys. Update" by using **direction** keys **▲ ▼**, then press **ENTER** key.

D. You can see the screen like a figure on the right side.

E. If you press any key, the system program will be updated after reading a floppy disk. During updating, **READY LED** flicker.

※ Caution

During reading a floppy disk, do not take out the floppy disk from a disk drive or do not turn off the main power.

F. When update is finished, you can see the screen like a figure on the right side. By rebooting after turning off the power, the update on the system program is completed.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```

```
<< Initialize >>
2. Sys. UpDate
```

```
Insert System
Disk...
Press Any Key
To Continue... █
```

```
Updating.....- █
```

```
System Updated!

Power Off & On!
To Restart..... █
```

4-8) Confirmation for Version of System Program

A. Press **MODE** key.

※ Caution

If **READY LED** turns on or upper feed plate is under, some keys are not available. It happened, operate the keys after lifting the upper feed plate or pressing **ENTER** keys.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```

B. Press **ENTER** key.

```
<< Initialize >>
0. S/W Version
1. Para. Init.
2. Sys. UpDate
```

C. If you press **ENTER** key, you can get the screen like a figure on the right side. You can confirm the date when the system program was made.

※ Here XXXX means machine model.

```
S/W Version
2000/01/02-XXXX

Press Any key
```

D. Press any key to confirm the version, then back to the initial screen by pressing **ESC** key.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```


4-9) Bobbin counter setting by design

In the old versions, the value of bobbin counter, once set, stayed the same regardless of pattern design unless the user changed the value. (Except for initialization) However, for updated versions, the user can set and store the value of bobbin counter for the pattern design created.

There are two ways to set bobbin counter.

Method 1: Setting during design creation.

A. In the initial screen, press **B.SET** to set the value of bobbin counter as the user desires.

```
NO:001      NOR_SEW
XS:100%
YS:100%     SP:2000
BC:100      PC:0000
```

B. Go to **Program Mode** in Main Menu.

```
<< Main Menu >>
2. Program
3. Bobbin Wind
4. Machine Test
```

C. Create a design as desired.

```
LINE
X:-0012A  N:0032
Y:0000A
Function Code?
```

D. Save the design in **FDD**.

```
015:PTRN      WRITE
NO :001
```

E. In **001** design created, the value of bobbin counter will be saved as **100**.

When reading 001 design, the value of bobbin counter in the initial screen will be set as 100.

Method 2: Setting by saving pattern stored in internal memory into floppy disc.

A. Insert design disc into **FDD**.

B. Input pattern number you wish to read from the initial screen, and press **Enter** to read design.

NO:003	NOR_SEW
XS:100%	
YS:100%	SP:2000
BC:100	PC:0000

C. With **READY LED** activated on OP box, press **Enter** to turn off READY.

D. Press **B. SET** bobbin counter button in the initial screen to set the desired value of bobbin counter.

NO:003	NOR_SEW
XS:100%	
YS:100%	SP:2000
BC:005	PC:0000

E. Click **WRITE save button** in the OP box to save onto **FDD**. Re-write under the same name, or save under a different name.

015:PTRN	WRITE
NO :002	

F. New value of bobbin counter will be saved in design

4-10) Saving in the Internal Memory after Creating Pattern Designs

Previously, users are required to save pattern designs, which are created with OP, in FDD only. However, the added function can allow them to save the pattern designs in the internal memory. Users can choose the place of storage from the parameter menu following the direction below.

Setting method is as follows.

- A. Press the **MODE** key to move to the Parameter Set of the Main Menu.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

- B. Press **Enter** and move to **090. Save Type**.

```
<Parameter Set>
090. Save Type
091. DsgnOpnCtrl
092. Safty Mode
```

- C. The default value is set at **1) SAVE FDD**, which is a previously used method.

```
090: Save Type
1) SAVE FDD    <-
2) SAVE FLASH
```

- D. Move the cursor to **2) SAVE FLASH** to save the patterns in the internal memory and press **Enter**.

```
090: Save Type
1) SAVE FDD
2) SAVE FLASH <-
```

- E. Since the setting is complete, when users save the pattern designs created using OP, they will be saved in **the internal memory (Flash Memory)**, not in FDD.

- F. Return to the main screen and press the number of saved pattern and then **Enter**. The concerned pattern design will be read for sewing.

```
NO: 003      NOR_SEW
XS: 100%
YS: 100%     SP: 2000
BC: 100      PC: 0000
```

5

HIGH OPERATING METHOD

1) Understanding the Function of Machine Test : The order can be different depending on SPS/A/B/C-Series.

1-1) Encoder Test

It is a test if input of encoder and synchronizer is proper along with the present position of needle bar.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. After moving to "4. Machine Test" by using **direction** keys **▲ ▼**, press **ENTER** key.

```
<< Test Menu >>
0. Encoder Test
1. XY-Main Test
2. MainMotorTest
```

C. Press **ENTER** key. Upper feed plate comes to descend, and moves to origin. At this time, if you slowly turn the upper shaft pulley manually, the pulse value of encoder, relative position of the upper shaft synchronizer sensor, and turning times of upper shaft will be marked.

```
Enc Val = 00000
Pos Val = 00000
Syn Num = 00000
PulySize = 01150
```

D. If you want to finish encoder test, press **ESC** key.
If you want to finish test menu, press **ESC** also.

E. Back to the general sewing mode by pressing **ESC** key.

1-2) Step Motor-Main Shaft Motor Test (X-Y Main Test)

It is a test if a step motor and main shaft motor works properly at the same time.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. After moving to "4. Machine Test" by using **direction** keys **▲ ▼**, press **ENTER** key.

C. After moving to "1. XY-Main Test" by using **direction** keys **▲ ▼**, press **ENTER** key. The upper feed plate descends and moves to the origin.

```
<< Test Menu >>
1. XY-Main Test
2. MainMotorTest
3. InterruptTest
```

D. Input the speed of main shaft and distance of transfer, then press **ENTER** key. If you want to test with the factory-installed setting value, just press **ENTER** key. You can see the beginning angle of upper shaft transfer, turning times of upper shaft and number of stitches. Drive the step motor and main shaft motor SPM/10times, then finish the step motor-main shaft motor test automatically.

```
X-Y-Main Motor
Test.....
SPM:0200
dx:020 dy:020
```

E. If you want to finish test menu, press **ESC** key. Press **ESC** one more time to back to the initial screen.

```
Start = 00240
```

1-3) Main Motor Test

It is to test if the main shaft motor operates properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. After moving to "4. Machine Test" by using **direction** keys **▲▼**, press **ENTER** key.

C. After moving to "2. Main Motor Test" by using **direction** keys **▲▼**, press **ENTER** key.

```
<< Test Menu >>
2. MainMotorTest
3. InterruptTest
4. PWM          Test
```

D. Upper feed plate comes to descend. Press **ENTER** key. If you want to change the speed of main shaft, press **SPEED** key.

```
PEDAL START
Speed = 0200 ■
```

E. If you want to finish main shaft motor test, press **ESC** key. If you want to finish test menu, press **ESC** key.

F. Back to the initial screen by pressing **ESC** key.

1-4) Interrupt Test

It is to test if the CPU board operates properly.

A. Press **MODE** key.

B. Move to "4. Machine Test" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

C. Move to "3. Interrupt Test" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<< Test Menu >>
3. InterruptTest
4. PWM          Test
5. LCD          Test
```

D. IRQ1 indicates the times that key is pressed, and IRQ4 means the times of synchronizer counted. IRQ5 indicates the sensing times of main power off, IRQ7 shows the timer operation of inside CPU. At this time, if you press a key or turn the upper shaft manually, the relevant value will be changed.

```
IRQ1 : 0000000
IRQ4 : 0000000
IRQ5 : 0000000
IRQ7 : 0000000
```

E. If you want to finish Interrupt Test, press **ESC** key. If you want to finish test menu, press **ESC** key also.

F. Back to the initial screen by pressing **ESC** key.

1-5) PWM Test

It is to test if solenoid works properly. Only professional A/S engineers allow to handle it.

A. Press **MODE** key.

B. After move to "4. Machine Test" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

C. After move to "4. PWM Test" by using **direction** keys **▲▼**, then press **ENTER** key.

```
<< Test Menu >>
4. PWM          Test
5. LCD          Test
6. Keyboard Test
```

D. Press any key to perform the test.

```
PWM output Test.
Press any key...
```

E. If you want to finish PWM test, press **ESC** key.
If you want to finish test menu, press **ESC** key.

F. Back to the initial screen by pressing **ESC** key.

1-6) LCD Test

It is to test if LCD works properly. If you press a key, the relevant key appears on the screen.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. After moving to "4. Machine Test" by using **direction** keys **▲▼**, press **ENTER** key.

C. After moving to "5. LCD Test" by using **direction** keys **▲▼**, press **ENTER** key.

```
<< Test Menu >>
5. LCD          Test
6. Keyboard Test
7. Input0       Test
```

D. If you press a key, relevant key value appears on the screen.

```
<<< LCD Test >>>

3333322222
```

E. If you want to finish LCD test, press **ESC** key.
If you want to finish test menu, press **ESC** key.

F. Back to the initial screen by pressing **ESC** key.

1-7) Keyboard Test

It is to test if key work properly. If you press a key, value of the relevant key appears on the screen.

A. Press **MODE** key.

B. After moving to “4. Machine Test” by using **direction** keys **▲▼**, press **ENTER** key.

C. After moving to “6. Keyboard Test” by using **direction** keys **▲▼**, press **ENTER** key.

D. If you press a key, value of the relevant key appears on the screen.

E. If you want to finish keyboard test, press **ESC** key.
If you want to finish test menu, press **ESC** key.

F. Back to the general sewing mode by pressing **ESC** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

```
<< Test Menu >>
6.Keyboard Test
7.Input0      Test
8.Input1      Test
```

```
Key Code = 00
```

1-8) Input 0 Test

It is to test if each sensor input signal works properly. For testing, separate step motor output connector from control box.

A. Press **MODE** key.

B. After moving to “4. Machine Test” by using **direction** keys **▲▼**, press **ENTER** key.

C. After moving to “7. Input 0 Test” by using **direction** keys **▲▼**, press **ENTER** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

```
<< Test Menu >>
7.Input0      Test
8.Input1      Test
9.Input2      Test
```


- D. Check if the values of X0rg and Y0rg are changed when the feed plate passes on origin making it move manually to X and Y shaft.
Confirm if the value of ThSen is changed when you release a take up lever spring after pulling slightly.

```
XPSen 1 X0rg 1
XMSen 1 YPSen 0
Y0rg 1 ThSen 0
```

- E. If you want to finish Input0 test, press **ESC** key.
If you want to finish test menu, press **ESC** key.
- F. Back to the initial screen by pressing **ESC** key.

1-9) Input 1 Test

It is to test if peripheral switch input among all input signals works properly.

- A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

- B. After moving to "4. Machine Test" by using **direction** keys **▲▼**, press **ENTER** key.

- C. After moving to "8. Input 1 Test" by using **direction** keys **▲▼**, press **ENTER** key.

```
<< Test Menu >>
8. Input1 Test
9. Input2 Test
10. Input3 Test
```

- D. Check if the value of EM_SW is changed when we press **EMERGENCY STOP** switch.
Check if the value of FF_SW is changed when we step on **the right pedal switch** or **ST_SW** when we step on **the left pedal switch**.

```
MMErr 1 Sync 0
EM_SW 1 ST_SW 1
FF_SW 1 FFLSW 1
TS_SW 1
```

- E. If you want to finish Input1 test, press **ESC** key.
If you want to finish test menu, press **ESC** key.
- F. Back to the initial screen by pressing **ESC** key.

1-10) Input 2 Test

This function can be used to check whether, of the input signals, air pressure input signals and inputs related to direct connection are working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4. Machine Test" by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to "9. Input2 Test" by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
9. Input2      Test
10. Input3     Test
11. Input4     Test
```

D. **LOWPR** : Air pressure error (normal: 1)

BDNEW : New I/O Board (0)

DIRECT : Direct connection type (0)

ASYNC : Communication between main shaft board and main shaft motor (0), if direct connection is used.

IOB21 : If IO Board is number 21, (0).

NEWOP : If OP is old, it is set at (1). If OP is new, it is set at (0).

IP26,27 : Not in use

```
LOWPR  1  BDNEW  0
DIRECT  0  ASYNC  0
IOB21   0  NEWOP  1
IP26    1  IP27   0
```

E. Press **ESC** key to end Input 2 Test. Press **ESC** key to end Test Menu.

F. Press **ESC** key to return to the initial page.

1-11) Input 3 Test

This function is to test whether or not each input signal is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4. Machine Test" by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to "10.Input3 Test" by using **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
10. Input3     Test
11. Input4     Test
12. Input5     Test
```

D. Now Input3 is not in use.

IP30	1	IP31	1
IP32	1	IP33	1
IP34	1	IP35	1
IP36	1	IP37	1

E. To end Input3 Test, press **ESC**. To end Test Menu, press **ESC**.

F. Return to the initial screen by pressing **ESC**.

1-12) Input 4 Test [only applied for SPS/C-Series]

This is used to check whether or not X-Y Motor Error input signal is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4 Machine Test" by using **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to "11.Input4 Test" by using **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
11. Input4 Test
12. Input5 Test
13. Input6 Test
```

D. **YMErr**: Error signal of Y shaft Servo Motor
(Normal: 1)

XMErr: Error signal of X shaft Servo Motor
(Normal: 1)

Other Input ports are not in use.

YMErr	1	XMErr	1
IP42	1	IP43	1
IP44	1	IP45	1
IP46	1	IP47	1

E. To end Input 4 Test, press **ESC**. To end Test Menu, press **ESC**.

F. Return to the initial screen by pressing **ESC**.

1-13) Input 5 Test [only applied for SPS/C-Series]

This function can be used to check whether or not each input signal is working properly.

A. Press **MODE** key

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4. Machine Test" by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to “12.Input5 Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
12. Input5 Test
13. Input6 Test
14.Encoder1 Test
```

D. Input 5 is not in use.

```
DIP10  1 DIP11  1
DIP12  1 DIP13  1
DIP14  1 DIP15  1
DIP16  1 DIP17  1
```

E. Press **ESC** key to end Input 5 Test. Press **ESC** key to end Test Menu.

F. Press **ESC** key to return to initial page.

1-14) Input 6 Test [only applied for SPS/C-Series]

This function can be used to check whether or not lower shaft motor input signal is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to “4. Machine Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to “13.Input6 Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
13. Input6 Test
14.Encoder1 Test
15.Solenoid Test
```

D. **Sync1**: Check whether or not detecting signal from lower motor sync.

MErr1: Detect unusual signal related lower motor shaft (Normal: 1)

Other Input signals are used.

```
Sync1  1 MErr1  1
IP62   1 IP63   1
IP64   1 IP65   1
IP66   1 IP67   1
```

E. To end Input 6 Test, press **ESC**. To end Test Menu, press **ESC**

F. Return to the initial screen by pressing **ESC**.

1-15) Lower Shaft Encoder Test (Encoder1 Test) [Only applied for SPS/C-Series]

This is used to check whether or not Input of Lower Shaft Encoder and Synch is normal and test the current position of needle bar.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4 Machine Test" by using **direction** keys **▲ ▼** and press **ENTER** key.

C. Move to "14.Encoder1 Test" by using **direction** keys **▲ ▼** and press **ENTER** key.

```
<< Test Menu >>
14.Encoder1 Test
15.Solenoid Test
16.Output4 Test
```

D. Press **ENTER** key. Upper feed plate will descend and go to the original point. At this time, turning upper shaft pulley by hand will indicate pulse value of lower encoder, distance from synch sensor, and rotation number.

```
Enc Val = 00000
Pos Val = 00000
Syn Num = 00000
```

E. To end lower shaft encoder test, press **ESC** key. To end test menu, press **ESC** key.

F. Return to the initial screen by pressing **ESC** key.

1-16) Solenoid Test

This is used to check whether or not Solenoid is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4. Machine Test" by pressing **direction** keys **▲ ▼** and press **ENTER** key.

C. Move to "15.Solenoid Test" by pressing **direction** keys **▲ ▼** and press **ENTER** key.

```
<< Test Menu >>
15.Solenoid Test
16.Output4 Test
17.Output5 Test
```

D. Repeat turning on and off relevant solenoid by pressing the number of solenoid to be tested.

1. **PF**: Presser Foot
2. **FF**: Upper feed plate
3. **TT**: Trimming
4. **TH**: Thread Holder
5. **WP**: Wiper
6. **FFL**: Detachable left upper feed plate
7. **TS**: Two step Stroke
8. **RV**: Reverse device

1	PF	Of	2	FF	Of
3	TT	Of	4	TH	Of
5	WP	Of	6	FFL	Of
7	TS	Of	8	RV	Of

E. Press **ESC** key to end solenoid test. Press **ESC** key to end Test Menu.

F. Press **ESC** key to return to initial page.

1-17) Output 4 Test [only applied for SPS/C-Series]

This function can be used to check whether or not air pressure devices are working properly.

A. Press **MODE** key.

B. Move to “4. Machine Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

C. Move to “16.Output4 Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
16.Output4 Test
17.Output5 Test
18.Output6 Test
```

D. Repeat turning on and off relevant air pressure port by pressing the number of air pressure port to be tested.

1. **PFA**: Presser Foot
2. **FFA**: Upper Feed Plate
3. **TTA**: Thread Trimming
4. **THA**: Thread Holder
5. **WPA**: Wiper
6. **FFLA**: Detachable Left Upper Feed Plate
7. **TSA**: Two-Step Stroke
8. **RVA**: Reverse Device

1	PFA	Of	2	FFA	Of
3	TTA	Of	4	THA	Of
5	WPA	Of	6	FFLA	Of
7	TSA	Of	8	RVA	Of

E. To end air pressure port test, press **ESC** key. To end test menu, press **ESC** key.

F. Return to the initial screen by pressing **ESC** key.

1-18) Output5 Test [Only applied for SPS/C-Series]

This is used to check whether or not air pressure device related to SPS/C-Series is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4 Machine Test" by using **direction** keys **▲▼** and press **ENTER** **↵** key.

C. Move to "16.Output4 Test" by using **direction** keys **▲▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
17.Output5 Test
18.Output6 Test
19.Output7 Test
```

D. Repeat turning on and off relevant air pressure port by pressing the number of air pressure port to be tested.

1. **RFF**: Rear Clamp
2. **TRS**: Thread Release device
3. **AFC**: material conveying pressing device
4. **TRS3**: Thread Release device 3
5. **HEAD**: Head of machine
6. **LPT**: Laser Point
7. **AX6**: not in use
8. **AX7**: not in use

```
1 RFF Of 2TRS Of
3 AFC Of 4TRS3 Of
5 HEAD Of 6LPT Of
7 AX6 Of 8AX7 Of
```

E. Press **ESC** key to end air pressure port test. Press **ESC** key to end Test Menu.

F. Press **ESC** key to return to initial page.

1-19) Other Output Ports [Only applied for SPS/C-Series]

Following output port tests are not in use.

```
18.Output6 Test
19.Output7 Test
20.DAC0
21.DAC1
```

1-20) Manual Operation Test of Step Motor (XY Jog Test)

This function can be used to manually test XY step motor.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to “4. Machine Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to “22.XY-Jog Test” by pressing **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
22.XY-Jog      Test
23.Origin      Test
24.Jump        Test
```

D. If you press **direction** keys **▲ ▼**, the position shows coordinates of X and Y shaft and present position among 4 section moving to a step each.

```
X-Y jogging Test
ESC to Exit
X:0000   Y:0000
Xsen:1   Ysen:1
```

E. To end manual operation of step motor, press **ESC** key. To end test menu, press **ESC** key.

F. Return to the initial screen by pressing **ESC** key.

1-21) Origin Test

This is used to check whether or not movement of original point is working properly.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to “4 Machine Test” by using **direction** keys **▲ ▼** and press **ENTER** **↵** key.

C. Move to “23.Origin Test” by using **direction** keys **▲ ▼** and press **ENTER** **↵** key.

```
<< Test Menu >>
23.Origin      Test
24.Jump        Test
25.MotorType   Test
```


D. Pressing any key will go to original point and original test automatically.

```
Origin Test.
Press AnyKey
```

E. To end test menu, press **ESC** key.

F. Return to the initial screen by pressing **ESC** key.

1-22) Jump Test

This is used to check whether or not XY step motor is working properly and do jump test.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4 Machine Test" by using **direction** keys **▲ ▼** and press **ENTER** key.

C. Move to "24.Jump Test" by pressing **direction** keys **▲ ▼** and press **ENTER** key.

```
<< Test Menu >>
24.Jump          Test
25.MotorType    Test
26.Async        Test
```

D. Input the time for repeating Jump transfer distance of XY and press **ENTER** key. Just press **ENTER** key to conduct test with the factory-installed setting value.

```
X-Y Jump Test
Delay : 0007[ms]
jmp_dx : 0020
jmp_dy : 0020
```

E. Press **ESC** key to end Test Menu.

F. Return to the initial screen by pressing **ESC** key.

1-23) Communication Test between the Main Shaft Board and the CPU/IO Board (Async Test)

The communication function with the main shaft driver has been added to set up the phase stopping position as parameter in the direct models. The test shall be done according to the following procedure.

A. Press **MODE** key.

```
<< Main Menu >>
4. Machine Test
5. Pattern List
6. EMB Call
```

B. Move to "4. Machine Test" by pressing **direction** keys **▲ ▼** and press **ENTER** key.

- C. Move to “25.Async Test” by pressing direction keys ▲ ▼ and press ENTER ↵ key.

```
<< Test Menu >>
26.Async      Test
```

- D. Initial speed setting value has been set up by 100, it is shown by “MotorStop”. Press ENTER ↵ key.

```
Async.      Test
Speed  =   100
MotorStop
```

- E. At the moment the ENTER ↵ key is pressed, the main shaft will turn one time. And it will show “MotorRun” on the LCD characters.

When you will press the ENTER ↵ key continually as above, the main shaft motor will turn one time. Therefore, to progress such movements signifies to go on the communication between the main shaft board and the I/O board normally.

(This function is applied only for the direct type motors, for reference.)

- F. Press ESC key to end Test Menu.

- G. Press ESC key to return to initial page.



6



DESCRIPTION ON PARAMETER RELATED TO GENERAL SEWING OPERATION

※ The order can be different depending on SPS/A/B/C-Series.

※ The shadow area indicates factory-installed condition.

Function No. : 000		Function Name : Manual Operation En/Dis
000. Jog En/Dis		It is to set moving of feed plate manually by using direction keys.
Setting Value	1) DISABLE	It is impossible for feed plate to move by using direction keys.
		<p>[Contents] It is impossible to make the feed plate move manually by using direction keys in the sewing available mode.</p> <p>[Caution] It is possible to make the feed plate move manually by using direction keys without having relation to setup, under the condition of pattern programming. It you set up for "Disable", you can't use the Function No 001 <u>'Moving to start position/the 2nd origin by manual drive'</u>.</p>
	2) ENABLE	It is possible to make the feed plate move by using direction keys. (Factory installed condition)
		<p>[Contents] It is possible to make the feed plate move manually by using direction keys in the sewing available mode.</p> <p>[Caution] It is only possible when upper feed plate is down.</p>

Function No. : 001		Function Name : Moving to start position/the 2nd origin by manual drive
001. Jog Mode		It is to set to move to the sewing start position or the 2nd origin by using direction keys after making the feed plate move manually in the sewing available mode.
Setting Value	1) PTN_STR_POS	It is to set up for sewing start position. (Factory installed condition)
		<p>[Contents] Provided that the feed plate moves manually by using direction keys in the sewing available mode, the sewing operation will be started in that point without relation to the programmed sewing start position.</p> <p>[Caution] Before getting out of the sewing available mode after setup, the sewing operation starts at the position where the feed plate moves manually. However, if you once get out of the sewing available mode, the set sewing available mode becomes unavailable and the machine starts from the sewing operation starts machine for programmed pattern.</p>
	2) SECND_ORG	It is to set up for the second origin.
		<p>[Contents] Provided that the feed plate moves manually by using direction keys in the sewing available mode, the sewing operation will be started in that point without relation to the programmed the 2nd origin.</p> <p>[Caution] Before getting out of the sewing available mode after setup, the sewing operation starts as a 2nd position at the position where the feed plate moves manually. However, if you once get out of the sewing available mode, the set 2nd origin becomes unavailable whereas the programmed 2nd origin becomes available.</p>
<div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;">  <p>[Setup for sewing start Position]</p> </div> <div style="text-align: center;">  <p>[Setup for the 2nd origin]</p> </div> </div>		

Function No. : 002		Function Name : Return to the machine origin after finishing sewing operation
002. Machine Org1		It is to decide whether it moves directly to the sewing start position without passing through the machine origin after finishing sewing operation or it moves to the sewing start position through the machine origin.
Setting Value	1) DISABLE	It is to move directly to the sewing start position without passing through machine origin. (Factory installed condition)
		[Contents] It moves directly to the sewing start position without passing through machine origin after finishing sewing operation. But if it reads patterns newly, the machine moves to the sewing start position after passing through origin. [Caution] You should set a return mode for sewing start in the Function No. 004 as '1) SHORTEST' for making the above setup available
	2) ENABLE	It is to move to the sewing start position after passing through the machine origin.
		[Contents] The machine moves to the sewing start position after passing through the origin every after finishing sewing
<div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;"> <p>Start Position Finish Position</p>  <p>[The moves to the start position directly without passing through the machine origin]</p> </div> <div style="text-align: center;"> <p>Start Position Finish Position</p>  <p>[The moves to the start position after passing through machine origin]</p> </div> </div>		

Function No. : 003		Function Name : Return to the origin when limit error occurs
003. Machine Org2		When a feed plate exceed transfer limit during sewing operation, limit error occurs. At this time, if you press ESC key, you can decide whether the machine moves to the sewing start position without passing through the machine origin, or moves to the sewing start position after passing through the machine origin.
Setting Value	1) DISABLE	It is to move directly to the sewing start position without passing through machine origin.
		[Contents] When a feed plate exceed transfer limit during sewing operation, limit error occurs. At this time, if you press ESC key, you can move directly to the sewing start position without passing through the machine origin.
	2) ENABLE	It is to move to the sewing position after passing through the machine origin. (Factory-installed condition)
		[Contents] When a feed plate exceed transfer limit during sewing operation, limit error occurs. At this time, if you press ESC key, you can move directly to the sewing start position after passing through the machine origin.

Function No. : 004		Function Name : Return mode to the sewing start position
004. Strt Ret Mod		It is to set the moving mode to the sewing start position after finishing sewing operation.
Setting Value	1) SHORTEST	It is to moves to the sewing start position through the shortest route.(Factory installed condition)
		<p>[Contents] It moves directly to the sewing start position without passing through machine origin after finishing sewing operation by the shortest route. But if it reads patterns newly, the machine moves to the sewing start position after passing through origin.</p> <p>[Caution] You should set return to the machine origin after finishing sewing operation in the function No. 002 as '1) DISABLE' for making the above setup available.</p>
	2) ORG_TO_STR	It is to move to the sewing start position after passing through the machine origin.
		[Contents] The machine moves to the sewing start position after passing through the machine origin everytime after finishing sewing.
	3) REV_ORG_STR	It is to move to the sewing start position after returning to the machine origin by the reverse tracing of sewing patterns.
		[Contents] After finishing the sewing operation, the machine moves in reverse according to the sewing patterns, then it passes through the machine origin to move to the sewing start position.
	4) Strt Ret Mod	Change of return method to sewing start point when using chain function
		[Contents] In the past, when working on several patterns by using chain function, always should pass through the original point of machine to go to sewing start point when skipping from one pattern to another. But it reduces working hour by enabling direct movement to sewing start point according to setup of [Parameter 004. Strt Ret.Mod].
	<p>The diagrams show three return methods: 1) SHORTEST (direct movement from Finish Position to Start Position), 2) ORG_TO_STR (movement from Finish Position to Origin to Start Position), and 3) REV_ORG_STR (reverse tracing from Finish Position to Origin to Start Position). Below these, a chain function diagram shows three patterns (001, 002, 003) connected by dashed lines. Arrows indicate the movement path: from Pattern 001 to Pattern 002 (labeled 2), and from Pattern 002 to Pattern 003 (labeled 3). A crosshair marks the origin point.</p> <p>[Return Method when using Chain Function]</p>	

Function No. : 005		Function Name : Lower thread counter counting method
005. Bobbin Count		The method of counting for the lower thread shall be determined.
Setting Value	1) UP_COUNT	Counting by adding the number of finished sewing until reaching the target number (default value)
		[Contents] Whenever sewing of a design is fully completed, the number is counted up. [Caution] The timing for lower thread replacement is not indicated.
	2) DN_COUNT	Counting by reducing the number of finished sewing from the target number
		[Contents] Whenever sewing of a design is fully completed, the number is counted down.
	3) DESIGN_UP	Counting by adding the number of finished sewing by design
		[Contents] When there are many identical designs included within a pattern, the number is counted by raising up the number whenever sewing of the design is completed. [Caution] The timing for lower thread replacement is not indicated.
	4) DESIGN_DN	Counting by lowering the number of finished sewing from the target number
		[Contents] When there are many identical designs included within a pattern, the number is counted by lowering the number whenever sewing of the design is completed. The initial value of the lower thread counter shall be set before use.



Function No. : 006		Function Name : Use of products counter
006. Prodct Count		It is to set use of products counter.
Setting Value	1) DISABLE	It is not to use the products counter
		[Contents] Products counter is not used that informs products quantity whenever each operation finishes figure increases once by one. [Caution] Products counter on the LCD screen is not used.
	2) ENABLE	It is to use the products counter. (Factory installed condition)
		[Contents] Products counter is used that informs products quantity whenever each operation finishes figure increases one by one.

Function No. : 007		Function Name : Time for reading patterns
007. Pattern Read		It is to set the time to read pattern from floppy diskettes or memory.
Setting Value	1) JOB__SETUP	It is available to read patterns just before the preparation for sewing operation. [Contents] The machine can read patterns under the condition that ready lamp for sewing operation turns off. Upon reading patterns, the ready lamp for sewing operation turns on and becomes sewing available condition. Under the condition, NO key does not operate. [Caution] After Pressing ENTER key to make the ready lamp turn off, you can read the pattern again.
	2) JOB__READY	It can read patterns even after finishing sewing preparation.(Factory installed condition) [Contents] The machine can read patterns in the sewing available mode just as sewing ready lamp turns off. Upon reading patterns, the ready lamp turns on and becomes sewing available condition. Under the condition, if you press NO key, the preparation lamp turns off, and the machine can read the patterns again.

Function No. : 008		Function Name : Trimming during emergency stop
008. Trim EM Stop		It is to set trimming method, either automatic or manual, when you stop the machine by pressing the emergency stop switch.
Setting Value	1) AUTO__TRIM	It is to trim automatically when emergency stop occurs. [Contents] The machine performs trimming automatically if you press the emergency stop switch during sewing operation.
	2) MANU__TRIM	It trims by pressing emergency stop switch. (Factory installed condition) [Contents] The machine stops if you press emergency stop switch during sewing operation. If you press emergency stop switch one more time to perform trimming after the machine stops. [Caution] If you step on pedal for starting operation under the condition that trimming is not available, the sewing operation will be restarted. The ORIGIN key does not operate.

Function No. : 009		Function Name : Main shaft speed acceleration																	
009. Slow Start		It sets the sewing speed acceleration when sewing starts. Default value: SLOW__START3 (In case of SPS/A/B-1507, SLOW__START1)																	
Setting Value	Needle speed Series Features	1st Needle Speed		2nd Needle Speed		3rd Needle Speed		4th Needle Speed		5th Needle Speed		6th Needle Speed		7th Needle Speed		8th Needle Speed		Remarks	
		A/B	C	A/B	C	A/B	C	A/B	C	A/B	C	A/B	C	A/B	C	A/B	C		
	1) SLOW__START0	200	200	400	200	600	400	800	800	1000	1200		1600		1800		2000		
	2) SLOW__START1	300	200	500	200	700	400	900	800	1200	1000		1200		1400		1600		
	3) SLOW__START2	400	200	500	200	800	200	1000	400	1200	600		800		1000		1200		
	4) SLOW__START3	500	200	600	200	900	400	1100	400	1300	600		800		1200		1400		
	5) SLOW__START4	500	200	500	400	500	400	800	600	1000	800		1200		1600		1800		
	6) SLOW__START5	600	200	600	400	600	400	800	600	1200	800		1200		1600		2000	During embroidery work	
	7) USER__START																	User define	
		[Caution] In the case where the sewing speed set by user is slower than the stitching speed, the user-defined sewing speed will prevail. ※ The set value may vary depending on models. For functional enhancement, it can be changed.																	

[Features of sewing speed acceleration]



Function No. : 010		1 st Needle Speed Setting
010. USER__SLOW__1		User sets the speed for the 1 st needle.
Setting Value	2~25[100ms]	User sets the speed for the 1 st needle (default value: 2[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 011		2 nd Needle Speed Setting
011. USER__SLOW__2		User sets the speed for the 2 nd needle.
Setting Value	2~25[100ms]	User sets the speed for the 2 nd needle (default value: 2[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 012		3 rd Needle Speed Setting
012. USER__SLOW__3		User sets the speed for the 3 rd needle.
Setting Value	2~25[100ms]	User sets the speed for the 3 rd needle (default value: 4[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 013		4 th Needle Speed Setting
013. USER__SLOW__4		User sets the speed for the 4 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 4 th needle (default value: 6[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is ") User Define."

Function No. : 014		5 th Needle Speed Setting
014. USER__SLOW__5		User sets the speed for the 5 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 5 th needle (default value: 8[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."


Function No. : 015		6 th Needle Speed Setting
015. USER__SLOW__6		User sets the speed for the 6 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 6 th needle (default value: 10[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 016		7 th Needle Speed Setting
016. USER__SLOW__7		User sets the speed for the 7 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 7 th needle (default value: 12[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 017		8 th Needle Speed Setting
017. USER__SLOW__8		User sets the speed for the 8 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 8 th needle (default value: 14[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 018		9 th Needle Speed Setting
018. USER__SLOW__9		User sets the speed for the 9 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 9 th needle (default value: 16[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 019		10 th Needle Speed Setting
019. USER__SLOW__10		User sets the speed for the 10 th needle.
Setting Value	2~25[100ms]	User sets the speed for the 10 th needle (default value: 18[100ms])
		[Contents] This function is used when the set value of Parameter "009. Slow Start Main Shaft Acceleration" is "7) User Define."

Function No. : 020		Function Name : Maximum speed limit of sewing
020. Max Speed		It limits the maximum speed of sewing machine.
Setting Value	1) 2500spm(1306)	It limits the speed under 2500spm. (Factory installed condition)
	2) 2000spm	It limits the speed under 2000spm.
	3) 1700spm	It limits the speed under 1700spm.
	4) 1300spm	It limits the speed under 1300spm.
		<p>[Caution] The sewing speed set within patterns has priority than maximum sewing speed. For example, though the maximum speed of sewing set as 1700spm if the sewing speed within patterns is set as 2100spm, the real speed of sewing is 2100spm.</p> <p>Maximum speed of the sewing machines other than 1306 would be 2000 spm.</p>
 <p>[Limit of maximum sewing speed]</p>		

Function No. : 021		Function Name : Opening angle of feed plate transfer
021. Feed End Pos		It is to adjust an opening angle of feed plate transfer based on needle bar.
Setting Value	0~100°	<p>It is to adjust an opening angle of feed plate transfer according to the thickness of sewing materials. (Factory default : SPS/A-Series 0°, SPS/B-Series 24°, SPS/C-Series 50°)</p>
		<p>[Contents] You should adjust the opening angle of feed plate transfer based on needle bar according to the thickness of sewing materials. As seen in the below fig. the opening angle of feed plate transfer indicates relative position of needle tip based on the needle plate side. Set as 0° when the needle tip is positioned on the needle plate side.</p> <p>[Caution] Below figure shows not the real time of feed plate transfer, but an adjustment of time(angle) which an order for feed plate transfer. Until the transfer starts after transmitting the order of feed plate transfer, delay time exists, so the real time(angle) to start the feed plate transfer is when a needle is positioned on the needle plate side.</p>
<div data-bbox="260 1182 1441 1738"> </div> <p>[Opening angle of feed plate transfer]</p>		

Function No. : 022		Function Name : Operation condition of feed plate when sewing operation finishes
022. FF Operation		<p>It is to set a condition of upper feed plate when the feed plate moves again to the sewing start position after finishing sewing operation.</p> <p>[Caution] The setup of Function No. 013 "Descent maintenance of upper feed plate" has a priority.</p>
Setting Value	1) STRT__OPEN	It is to raise the upper feed plate, after moving to the start position under the condition that the upper feed plate is down. (Factory installed condition)
		[Contents] After finishing sewing operation, the upper feed plate moves to the start position under the condition that the upper feed plate is down, and after moving to the start position, you can put into sewing materials with raising upper feed plate.
	2) STRT__HOLD	After moving to the sewing start position, the machine maintains the condition that the upper feed plate is down.
		[Contents] The machine moves to the start position under the condition that the upper feed plate is down, and even after moving to the sewing start position, the condition is maintained. At this time, it is possible to operate the upper feed plate by the foot switch.
	3) OPEN__STRT	It is to move to the sewing start position under the condition that the upper feed plate is up.
		[Contents] The machine moves to the sewing start position after finishing sewing operation under the condition that the upper feed plate is up.
	4) OPEN__STRT1	It is to move to the sewing start position under the condition that the upper feed plate raises to the first stage.
		[Contents] This setup is effective when you use the function for two stage stroke. The machine moves to the sewing start position after finishing sewing operation under the condition that the upper feed plate raises to the first stage in the second stage. After moving, raises the upper feed plate to the end to insert sewing materials.
	5) OPEN__STRT2	It is to move to the sewing start position under the condition that the upper feed plate raises to the second stage.
		[Contents] This setup is effective when you use the function for two stage stroke. The machine moves to the sewing start position after finishing sewing operation under the condition that the upper feed plate raises to the second stage in the second stage.

Function No. : 023		Function Name : Descent maintenance of upper feed plate
023. FF Close En		It is to set descent maintenance of upper feed plate after finishing sewing is down.
Setting Value	1) DISABLE	The machine does not maintain always the condition that the upper feed plate is down. (Factory installed condition)
		[Contents] The machine moves to the sewing start position after finishing sewing operation according to the setup of Function No. 012 "Operation condition of feed plate when sewing operation finishes", then the upper feed plate goes up.
	2) ENABLE	The machine always maintains the condition that the upper feed plate is down.
		[Contents] After finishing sewing operation, the machine always maintains the condition that the upper feed plate is down. [Caution] It is impossible to operate the upper feed plate by the foot switch. For raising the upper feed plate, change the setup as DISABLE.

Function No. : 024		Function Name : Signal mode of Pedal 1
024. Pedal 1 Mode		It is to set how to treat signal of pedal 1(pedal for upper feed plate).
Setting Value	1) LATCH	The upper feed plate goes down when you step on a pedal once and take off your foot from the pedal. (Factory installed condition)
		[Contents] If you step on the pedal 1(pedal for upper feed plate) once, the signal is treated as effective one even though you take off foot from the pedal, and the machine maintains the condition that the upper feed plate is down. If you want to raise the upper feed plate, step on the pedal 1 just one more time. [Ref.] As above LATCH means a signal system that if once a signal comes (when you step on a pedal), the signal is treated as an effective one though the signal is cancelled (even when you take off foot from the pedal).
	2) FLIP	The upper feed plate goes down just when you step on a pedal.
		[Contents] The upper feed plate goes down just when you step on the pedal 1 (pedal for upper feed plate), but if you take off foot from the pedal 1, the upper feed plate goes up again. [Ref.] As above, FLIP means a signal system that the signal is treated as an effective one just when the signal is coming (just when you step on a pedal).

Function No. : 025		Function Name : Signal mode of pedal 2
025. Pedal 2 Mode		It is to set how to treat the signal of pedal 2(Pedal for sewing start).
Setting Value	1) LATCH	<p>Sewing operation starts when you step on a pedal once and take off your foot from the pedal. (Factory installed condition)</p> <p>[Contents] If you step on the pedal 2(pedal for sewing start) once, the signal is treated as effective one even though you take off foot from the pedal, and the sewing operation will be started.</p> <p>[Ref.] As above LATCH means a signal system that if once a signal comes(when you step on a pedal), the signal is treated as an effective one though the signal is cancelled(even when you take off foot from the pedal).</p>
	2) FLIP	<p>The sewing operation performs just when you step on a pedal.</p> <p>[Contents] The sewing operation performs just when you step on the pedal 2(pedal for sewing start), but if you take off foot from the pedal 2, the sewing operation will be stopped.</p> <p>[Ref.] As above, FLIP means a signal system that the signal is treated as an effective one just when the signal is coming(just when you step on a pedal).</p>

Function No. : 026		Function Name : Setup for presser foot operation
026. PF Operation		It is to set the operation condition of presser foot.
Setting Value	1) ALWAYS_DN	<p>It is to maintain the presser foot down all the time.</p> <p>[Contents] The machine maintains the presser foot down all the time even not in use.</p>
	2) SEW_DN	<p>The presser foot is up except during sewing operation. (Factory installed condition)</p> <p>[Contents] The machine goes down the presser foot just when the sewing operation performs. When the sewing operation stops or finishes, the presser foot goes up.</p> <p>[Ref.] If you press 5 key, the presser foot goes down to make thread inserted.</p>
	3) TRIAL_DN	<p>The machine goes down the presser foot in the progress or reverse of one stitch as well as in the sewing operation.</p> <p>[Contents] The presser foot goes down not only in the progress and reverse of one stitch but during the sewing operation.</p>

Function No. : 027		Function Name : Setup for descent time of presser foot
027. PF Down Mode		<p>It is to set the descent time of presser foot.</p> <p>[Caution] This function is not available if <u>Function No. 016. Pf Operation sets as 1)ALWAYS__DN.</u></p>
Setting Value	1) WITH__STRT	The presser foot goes down at the same time as main shaft turns. (Factory installed condition)
		[Contents] When the main shaft turns, the presser foot goes down simultaneously.
	2) WITH__FEED	The presser foot goes down at the same time as the upper feed plate descend.
		[Contents] When the upper feed plate descends, the presser foot goes down simultaneously.

Function No. : 028		Function Name : Setup for wiper operation
028. WP Operation		It is to set the operation and kinds of wiper.
Setting Value	1) ALWAYS__OFF	It is to prohibit the operation of wiper.
		[Contents] Operation of wiper is prohibited. You can set this function when you don't want to use the wiper.
	2) ELEC__TYPE	It is to use wiper electronically. (Factory installed condition)
		[Contents] It is to set use of electronic wiper.
		[Caution] If the setup is not proper, operation of wiper can be unavailable.
	3) AIR__TYPE	Wiper is used pneumatically
		[Contents] It is set when pneumatic wiper is used.
		[Caution] If the setup is not proper, operation of wiper can be unavailable.

Function No. : 029		Function Name : Setup for wiper operation position
029. WP Position		<p>It is setup the position of wiper operation.</p> <p>[Caution] This function is not available if <u>Function No. 018. WP operation sets as 1) ALWAYS_OFF.</u></p>
Setting Value	1) BET_NEDL_PF	It is to set the position between needle and middle presser foot. (Factory installed condition)
		[Contents] The position of wiper operation is set between needle and middle presser foot.
	2) BELW_PF	It is to set the position under the presser foot.
		[Contents] The wiper is set to operate under the middle presser foot.

Function No. : 030		Function Name : Setup for thread detection
030. Thrd Detect		<p>It is not to set to detect thread</p> <p>[Related functions] Function No. 021 "Thrd. Stitch 1" Function No. 022 "Thrd. Stitch 2"</p>
Setting Value	1) DISABLE	It is not to use the function of thread detection.
		[Contents] The machine does not stop working till pattern working finishes even though thread runs out or cuts.
	2) ENABLE	It is to use the function of thread detection. (Factory installed condition)
		[Contents] If thread runs out or cuts, the machine stops working with a message on the LCD screen.

Function No. : 031		Function Name : Detecting the stitch number in starting sewing
031. Thrd Stitch 1		<p>It is to set the number of stitches when sewing operation starts.</p> <p>[Caution] This function is not available of <u>Function No. 020. "Thrd Detect" sets as "1) DISABLE"</u>.</p>
Setting Value	0~15	<p>It is to set to detect the number of stitches. (Factory installed condition : "5"), (SPS/C-5050, 8050 : 10)</p>
		<p>[Contents] If you start sewing operation under the condition that there's no thread or thread is cut, the machine detects the condition directly and make a decision when operation stops. For example, if you set "0", as soon as the machine detects no thread available, the machine stops operation.</p> <p>[Caution] In case that set value is small, misdetection can occur.</p>


Function No. : 032		Function Name : Detecting the stitch number during sewing
032. Thrd Stitch 2		<p>It is to set the number of stitches during operation.</p> <p>[Caution] This function is not available if <u>Function No. 020. "Thrd Detect" sets as "1) DISABLE"</u>.</p>
Setting Value	0~15	<p>It is to set to detect the number of stitches. (Factory installed condition : "3"), (SPS/C-5050, 8050 : 5)</p>
		<p>[Contents] If thread is cut during operation, the machine detecting the condition directly and make a decision when operation stops, For example, if you set "0", as soon as the machine detects no thread available, the machine stops operation.</p> <p>[Caution] In case that set value is small, misdetection can occur.</p>

Function No. : 033		Function Name : Use of trimming function
033. Trim En/Dis		<p>It is to set if the machine uses the trimming function or not.</p>
Setting Value	1) DISABLE	<p>Trimming function is not available.</p>
		<p>[Contents] If the machine gets trimming code within pattern data or detects thread cut during operation, the machine does not perform the trimming function.</p>
	2) ENABLE	<p>Trimming function is available. (Factory installed condition)</p>
		<p>[Contents] If the machine gets trimming code within pattern data or detects thread cut during operation, the machine performs the trimming function.</p>

Function No. : 034		Function Name : Manual operation time in speed level 1
034. Jog Time 1		It is to set the manual operation of the feed plate to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 1. (Factory installed condition : "400ms")
		[Contents] When the feed plate is manually operated by the direction keys, it sets the time for feed plate transfer speed level 1.

Function No. : 035		Function Name : Manual operation time in speed level 2
035. Jog Time 2		It is to set the manual operation of the feed plate to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 2. (Factory installed condition : "1000ms")
		[Contents] When the feed plate is manually operated by the direction keys, it sets the time for feed plate transfer speed level 2.

Function No. : 036		Function Name : Manual operation time in speed level 3
036. Jog Time 3		It is to set the manual operation of the feed plate to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 3. (Factory installed condition : "2000ms")
		[Contents] When the feed plate is manually operated by the direction keys, it sets the time for feed plate transfer speed level 3.



Function No. : 037		Function Name : Time for function of the speed level 1 key
037. Con Key Tm 1		It is to set the feed plate transfer to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 1. (Factory installed condition:"400ms")
		[Contents] When pressing the FORW , BACK keys continuously to move the feed plate, set the time for the transfer speed at level 1.

Function No. : 038		Function Name : Time for function of the speed level 2 key
038. Con Key Tm 2		It is to set the feed plate transfer to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 2. (Factory installed condition:"100ms")
		[Contents] When pressing the FORW , BACK keys continuously to move the feed plate, set the time for the transfer speed at level 2.

Function No. : 039		Function Name : Time for function of the speed level 3 key
039. Con Key Tm 3		It is to set the feed plate transfer to speed up.
Setting Value	0~9900ms	It is to set the time for operation in speed level 3. (Factory installed condition:"3000ms")
		[Contents] When pressing the FORW , BACK keys continuously to move the feed plate, set the time for the transfer speed at level 3.

Function No. : 040		Function Name : Electric wiper operation time
040. Elc WP On Tm		It is to set the time for the electric wiper operation.
Setting Value	0~1020ms	It is to set the time for the electric wiper operation. (Factory installed condition : "52ms")
		<p>[Contents] When using the electric wiper, set the time for operation. The higher the level, the longer the operation. The wiper may not operate when the time is set too short.</p>


Function No. : 041		Function Name : Electric wiper standby time
041. Elc WP Off Tm		It is to set the standby time for the electric wiper operation.
Setting Value	0~1020ms	It is to set up the standby time until the next operation of the electric wiper. (Factory installed condition : "100ms")
		<p>[Contents] The interval until the next operation after the electric Wiper has operated. The higher the level, the longer the interval between operations. On the other hand, the wiper may not operate, if the level is too low</p>

Function No. : 042		Function Name : Pneumatic wiper operation time
042. Air WP On Tm		It is to set the time for the pneumatic wiper operation.
Setting Value	0~1020ms	It is to set the time for the wiper operation. (Factory installed condition : "100ms")
		<p>[Contents] When using the pneumatic wiper, set the time for its operation. The higher the level, the longer the operation. But when the level is too low, the wiper may not operate.</p>

Function No. : 043		Function Name : Pneumatic wiper standby time
043. Air WP Off Tm		It is to set the standby time until the next operation of the pneumatic wiper.
Setting Value	0~5ms	It is to set the standby time until the next operation of the pneumatic wiper. (Factory installed condition : "100ms")
		<p>[Contents] The interval until the next operation when using the pneumatic wiper. The higher the level, the longer the operation. But if the level is too low, the wiper may not operate.</p>

Function No. : 044		Function Name : Standby time for completely lowered presser foot
044. PF Down Time		It is to set the standby time till the next step after the presser foot has been lowered.
Setting Value	0~1020ms	Set the standby time till the next step after the presser foot has been lowered. (Factory installed condition : "152ms")
		[Contents]

Function No. : 045		Function Name : Standby time for completely uplifted presser foot
045. PF Up Time		It is to set up the standby time till the next operation after the presser foot has been lifted.
Setting Value	0~1020ms	Set up the standby time until the next step after lifting the presser foot. (Factory installed condition : "152ms")
		[Contents]

Function No. : 046		Function Name : Presser foot full on time
046. PF Full On Tm		It is to set the beginning strength of the presser foot solenoid.
Setting Value	0~1020ms	It is to set the time period the highest electric current passes through the solenoid. (Factory installed condition : "200ms")
		<p>[Contents] In cases of electric solenoids, set the beginning strength of the presser foot by adjusting the time period high current flows through (Full on time).</p> <p>[Caution] If set too low, the solenoid may not operate, and when set too high, too much electric current may overheat and damage the solenoid and fuse.</p> <p>[Reference] The operation time and strength of the actuators (presser foot, trimmer, wiper) which use the solenoid, can be adjusted by adjusting the electric current of the solenoid. Full on time is the period when the solenoid's electric current is at the highest point.</p>
<div style="text-align: right; margin-bottom: 10px;"> 0~t1 : Full On Time (Period of highest electric current) 0~t2 : Solenoid operation time t1~t2 : Period when electric current flows from duty </div>  <p>The first graph shows 'solenoid electric current' vs 'Time'. The current rises from 0 at time 0 to a peak at time t1, then decays with oscillations until time t2. A dashed line indicates the 'highest electric current' level. The area under the peak is labeled 'Full On Time'.</p> <p>The second graph shows 'Solenoid operation signal' vs 'Time'. It is a high-frequency pulse train from 0 to t2. A circle highlights a portion of this signal, which is expanded in the third graph.</p> <p>The third graph shows a detailed view of the duty cycle. It is a square wave with 'Ton' (on time) and 'Toff' (off time) intervals. The total period is 'Tperiod'.</p> <p>*Duty = $\frac{Ton}{Tperiod} \times 100(\%)$</p> <p>*Duty is the rate of time the signal light is lighted during a period of time. For example, when the duty is 50%, Ton and Toff are the same.</p>		

Function No. : 047		Function Name : Feed plate full on time
047. FF Full On Tm		It is to set the operation beginning strength of the feed plate solenoid.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In cases of feed plates with electric solenoids, the trimming strength at the beginning part can be adjusted by adjusting the Full on time.

Function No. : 048		Function Name : Thread trimming full on time
048. TT Full On Tm		It is to set the time strength of the thread trimming solenoid at the beginning of the operation.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] When thread trimming with electric solenoids, the strength of the trimming operation at the beginning can be adjusted by adjusting the Full on time.


Function No. : 049		Function Name : Thread Retaining Full On Time
049. TR Full On Tm		It is to set the strength of the thread retaining solenoid operation at the beginning.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In cases of thread retaining with electric solenoids, the operation strength at the beginning can be adjusted by adjusting the full on time. [Caution] The function is not used on SPS/A-Series Electronic Control Sewing Machines.

Function No. : 050		Function Name : Wiper full on time
050. WP Full On Tm		It is to set the beginning strength of the wiper solenoid.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In cases of wipers with electric solenoids, the strength of the wiper operation at the beginning can be adjusted by adjusting the Full on time.

Function No. : 051		Function Name : Left feed plate full on time
051. FFLFull On Tm		It is to set the operation starting power of solenoid in left feed plate.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In case of using solenoid in left feed plate, the machine adjusts the time when the maximum current is permitted to solenoid (Full on time) for setting the power when relevant actuator starts operation.

Function No. : 052		Function Name : 2 step stroke full on time
052. TSFull On Tm		It is to set the operation starting power of solenoid in 2step stroke.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In case of using solenoid in 2 step stroke, the machine adjusts the time when the maximum current is permitted to solenoid (Full on time) for setting power when relevant actuator starts operation.

Function No. : 053		Function Name : Inverting device full on time
053. RVFull On Tm		It is to set the operation starting power of solenoid in auxiliary output 2.
Setting Value	0~1020ms	It is to set the time when the maximum current is permitted to solenoid. (Factory installed condition : "200ms")
		[Contents] In case of using solenoid in auxiliary output 2, the machine adjusts the time when the maximum current is permitted to solenoid (Full on time) for setting power when relevant actuator starts operation.

Function No. : 054		Function Name : Presser foot duty
054. PF Duty		It is to set the maintenance capacity of presser foot solenoid.
Setting Value	33~40%	<p>It is to set the amount of holding current permitted to solenoid. (Factory installed condition : 80%), (SPS/A/B-1306, 1507 : 33)</p>
		<p>[Contents] In case of presser foot used with electronic solenoids, it sets the power that maintains the raised presser foot by permitting the adjusted current through duty to the solenoid.</p> <p>[Caution] If the default is too small, the solenoid may operate only once and spring back to its origin to make sewing impossible. On the other hand, if it is too large, the solenoid may be overheated and it can lead to the damage of solenoid and fuse.</p> <p>[Reference] As seen in the figure, duty means a rate of time when signal is lighted on during a period of time. In the area with low voltage input, raise the duty value of failure by 5%.</p>
<div style="text-align: right; margin-bottom: 10px;"> 0~t1 : Full On Time (point of highest electric current) 0~t2 : Solenoid operation time t1~t2 : Permissive time of current by duty </div>  <p>*Duty = $\frac{Ton}{Tperiod} \times 100$ [%]</p> <p>* Duty is the rate of time the signal is lighted during a period of time. For example, when the duty is 50%, Ton and Toff are the same.</p>		

Function No. : 055		Function Name : Feed plate duty
055. FF Duty		It is to set the maintenance capacity of feed plate solenoid.
Setting Value	40~48%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 80%), (SPS/A/B-1306, 1507 : 43)
		[Contents]In case of feed plate used with electronic solenoid, it sets the maintenance power that presses the feed plate by permitting the adjusted current through duty to the solenoid. [Reference]In the area with low voltage input, raise the duty value of failure by 5%.

Function No. : 056		Function Name : Thread trimming duty.
056. TT Duty		It is to set the maintenance capacity of the thread trimming solenoid.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 50%)
		[Contents]In case of thread trimming used with electronic solenoid, it sets the power that keeps trimming operation by permitting the adjusted current through duty to the solenoid.













Function No. : 057		Function Name : Thread retaining duty
057. TR Duty		It is to set the maintenance capacity of the thread retaining solenoid.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 50%)
		[Contents]In case of thread retaining used with electronic solenoid, it sets the power that keeps thread retaining operation by permitting the adjusted current through duty to the solenoid.





Function No. : 058		Function Name : Wiper duty
058. WP Duty		It is to set the maintenance capacity of the wiper solenoid.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 50%)
		[Contents]In case of wiper used with electronic solenoid, it sets the power that keeps wiper operation by permitting the adjusted current through duty to the solenoid.



Function No. : 059		Function Name : Left feed plate duty
059. FFL Duty		It is to set the maintenance capacity of solenoid in left feed plate.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 80%)
		[Contents] In case of using solenoid in left feed plate, it sets the power that keeps the relevant operation by permitting the adjusted current through duty to the solenoid.

Function No. : 060		Function Name : 2 step stroke duty
060. TS Duty		It is to set the maintenance capacity of solenoid in 2 step stroke.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 80%)
		[Contents] In case of using solenoid in 2 step stroke, it sets the power that keeps the relevant operation by permitting the adjusted current through duty to the solenoid.

Function No. : 061		Function Name : Reverting device duty
061. RV Duty		It is to set the maintenance capacity of solenoid in reverting device.
Setting Value	30~80%	It is to set the amount of maintenance current permitted to solenoid. (Factory installed condition : 80%)
		[Contents] In case of using solenoid in <u>reverting device</u> , it sets the power that keeps the relevant operation by permitting the adjusted current through duty to the solenoid.

Function No. : 062		Function Name : Pattern data reading mode						
062. PTRN RD MODE		It is to set the mode of searching and reading the pattern data.						
Setting Value	1) DISABLE	<p>Searches and reads from the floppy diskette.</p> <p>[Contents] When reading a new pattern data, in other words, when the pattern data is being read while the ready lamp is off, the pattern data is searched and read only from the floppy diskette. After a pattern data has once been read from the disk, the data is saved in the internal memory. And the pattern is sewn with the data from the internal memory while the ready lamp is on.</p> <p>[Caution] The work may take long, as it takes relatively long time in reading data from the diskette.</p>						
	2) ENABLE	<p>The pattern is first read from the internal memory. (Factory installed condition)</p> <p>[Contents] When a new pattern data is read, it is first searched from the internal memory. If the data does not exist in the internal memory, it is searched and read from the floppy disk.</p> <p>[Contents] If you want to exit from the current sewing work and move to the programming status to program new pattern, you can store your new pattern in the same pattern number as the one before on the floppy disc. However, internal memory will still retain the previous pattern shapes, thus the previous pattern will be called and you might think that your new programmed pattern is not stored properly. Refer to 2~3 "Check and delete pattern number" to delete pattern number stored in internal memory. Please keep in mind that it is most desirable to use a different number to store your new patterns to prevent such mix-up with the previous patterns.</p>						
<table border="1"> <thead> <tr> <th>Floppy Diskette</th><th>Memory</th><th>About the Processes</th></tr> </thead> <tbody> <tr> <td> No. 003  No. 003  </td><td> No. 003  ↓ No. 003  </td><td> <p>There is star pattern No. 003 in the floppy diskette.</p> <p>When the pattern is read, the data is copied and saved into the internal memory. And the pattern is sewn with the data read from the internal memory.</p> <p>In the programming mode, a circle pattern is written and saved as No. 003.</p> <p>When pattern No. 003 is read from the internal memory, the star pattern which had already existed before the circle pattern, is called. As the star pattern is sewn, it seems as though the circle pattern has not been saved in floppy disk.</p> </td></tr> </tbody> </table>			Floppy Diskette	Memory	About the Processes	No. 003  No. 003 	No. 003  ↓ No. 003 	<p>There is star pattern No. 003 in the floppy diskette.</p> <p>When the pattern is read, the data is copied and saved into the internal memory. And the pattern is sewn with the data read from the internal memory.</p> <p>In the programming mode, a circle pattern is written and saved as No. 003.</p> <p>When pattern No. 003 is read from the internal memory, the star pattern which had already existed before the circle pattern, is called. As the star pattern is sewn, it seems as though the circle pattern has not been saved in floppy disk.</p>
Floppy Diskette	Memory	About the Processes						
No. 003  No. 003 	No. 003  ↓ No. 003 	<p>There is star pattern No. 003 in the floppy diskette.</p> <p>When the pattern is read, the data is copied and saved into the internal memory. And the pattern is sewn with the data read from the internal memory.</p> <p>In the programming mode, a circle pattern is written and saved as No. 003.</p> <p>When pattern No. 003 is read from the internal memory, the star pattern which had already existed before the circle pattern, is called. As the star pattern is sewn, it seems as though the circle pattern has not been saved in floppy disk.</p>						

Function No. : 063		Function Name : Setting the magnifying/demagnifying mode
063. Scale Mode		It is to select and set the magnifying/demagnifying mode.
Setting Value	1) DISABLE	The Magnifying/demagnifying function is not used.
		[Contents] The machine uses the pattern data in the programmed size. As the magnifying/demagnifying function is not selected, the X scale , Y scale keys are not operated. Adjust the "XS" and "YS" indicated on the screen to 100%
	2) STITCH_LEN	It is to set the magnifying/demagnifying mode using the stitch length. (Factory installed condition)
		[Contents] While the number of stitches are the same, the length of the stitches along the X and Y axis are adjusted according to the magnifying/demagnifying rate. Set the rate within the feed plate transfer limit.
	3) STITCH_NUM	It is to set the magnifying/demagnifying mode using the number of stitches.
	* It is not applied (It is going to apply later)	[Contents] While the length of stitches are the same, the number of stitches are adjusted along the X and Y axis. Set the rate within the feed plate transfer limit.
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Magnifying/demagnifying according to stitch length</p>  </div> <div style="text-align: center;">  <p>Magnifying/demagnifying according to number of stitches</p>  </div> </div>		


Function No. : 064		Function Name : Number of chain sewings
064. Chain Number		It is to set the sewing mode and number of patterns to chain sew.
Setting Value	0~16	It is to set the number of patterns to chain sew. (Factory installed condition : 0)
		<p>[Contents] When the number is set as "0", one pattern is repeated and the screen indicates "NOR_SEW". When set as other than "0", it is set for chain sewing. This function is used to sew several patterns in certain amount of numbers. The mode is indicated as "CHN_XX" on the screen.</p>
<div> <div>Number set as 2</div> <div>  </div> </div> <div> <div>Number set as 3</div> <div>  </div> </div>		

Function No. : 065		Function Name : Transferring chain numbers
065. Chain Select		It is to set the mode of stopping one pattern and transferring to the next pattern.
Setting Value	1) MANUAL	The pattern is read and transferred manually.
		<p>[Contents] While chain sewing, the machine stops when the pattern is stopped. Press the ENTER key to read and sew the next pattern.</p>
	2) AUTO	The next pattern is read and transferred automatically.(Factory Installed Condition)
		<p>[Contents] When a pattern is stopped during chain sewing, the machine stops and the next pattern is automatically read. Sewing can be started by controlling the foot plate switch.</p>
	3) EXTERNAL	The next pattern is read and transferred by an external signal.
		<p>[Contents] After the machine stops when a pattern is stopped during chain sewing, there must be a signal from outside to read the next pattern.</p>

Function No. : 066		Function Name : Set the clamp when the chain is used.
066. Chain Clamp		When the chain function is used, the clamp up/down can be set.
Setting Value	1)DISABLE	The clamp down setting is unused (default).
		[Contents] In case where three patterns are used consecutively, when the first pattern work is finished, the second pattern is automatically called, and the clamp ascends. Therefore, after the pattern work, the clamp ascends.
	2)ENABLE	The clamp down setting is used.
		[Contents] In case where three patterns are used consecutively, when the first pattern work is finished, the second pattern is automatically called, and the clamp descends. When the second pattern work is finished, the third pattern is automatically called, and the clamp descends. After the last third pattern work is finished and the machine returns to the first pattern, the clamp ascends.

Function No. : 067		Function Name : Number of stitches to decelerate before ending work
067. Decel Stitch		It is to set the stitch number of when to decelerate before ending the work.
Setting Value	2~16 Stitch	It is to set the number of stitches when the machine should decelerate. (Factory installed condition : SPS/A/B-1306, 1507, 1310, 1811, 5030 : 2 SPS/A/B-2516 : 5 SPS/C-Series : 4)
		[Contents] It is to set the number of stitches when the machine should start decelerating before ending the operation.

Function No. : 068		Function Name : Decelerating speed before ending work
068. Decel SPM		It is to set the speed the machine should decelerate before ending the work.
Setting Value	200~500spm	It is to set the speed to decelerate before ending the work. (Factory installed condition : "400", SPS/C-Series : Factory installed condition "200")
		[Contents] The speed must be decelerated before ending the work. The decelerating speed is set here.

Function No. : 069		Function Name : Thread trimming delayed time
069. Trim Delay		It is to set the delayed time before the wiper is operated after the thread is trimmed.
Setting Value	52~1020ms	It is to set the delayed time after thread trimming. (Factory installed condition : "72")
		[Contents] It is to set the delayed time of the wiper operation after the thread has been cut.
 <p>[The ending Process of Sewing]</p>		


Function No. : 070		Function Name : The selection of the low pressure detecting device
070. Low Pressure		With machines using air pressure, it is selected whether to use the low pressure detecting device or not.
Setting Value	1) DISABLE	Low pressure detecting device is not used. (Factory installed condition)
		[Contents] With machines using air pressure, it is ignored when the pressure of the compressor goes below the principle limit.
	2) ENABLE	The low pressure detecting device is used. (Except for 1306, 1507, 1310, they will have default values.)
		[Contents] If the pressure of compressure is below regulations, in case pneumatic kinds, the error is marked on the screen to inform users.

Function No. : 071		Function Name : Feed plate control			
071. FF Number		The operation control of the feed plate is set as shown in the table below.			
		<p>[Contents] The feed plate and operation orders are set according to what kind of machine you have. Set the control order for paused pattern data operations and pedal control of the upper feed plate.</p> <p>[Caution] When the 'pause during operation' code appears, set the upper feed plate control at Function Number 061, "Feed Plate Control When Paused" first.</p>			
Item DEFAULT		Upper Reed Plates	Level 2 strokes	Upper feed plate controls for pause	Upper feed plate control with pedal
Setting Value	0	Single body feed plate	×	Feed plate raised and stopped	
	1	Single body feed plate	○	Feed plate raised and stopped	
	2	Two part feed plate	×	Both parts raised and stopped	
	3	Two part feed plate	×	Left side raised and stopped only	
	4	Two part feed plate	×	Right side raised and stopped only	
	5	Two part feed plate	○	Both parts raised and stopped	
	6	Two part feed plate	○	Left side raised and stopped only	
	7	Two part feed plate	○	Right side raised and stopped only	
	8	Two part feed plate	○	Both parts raised and stopped	Right feed plate lowered first
	9	Two part feed plate	○	Left side raised and stopped only	Right feed plate lowered first
	10	Two part feed plate	○	Both parts raised and stopped	Left feed plate lowered first
	11	Two part feed plate	○	Right side raised and stopped only	Left feed plate lowered first
	12	Two part feed plate	×	Both parts raised and stopped	Right feed plate lowered first
	13	Unused			
	· ·	Unused			
· ·	Unused				
31	Unused				
[Caution] Among the items of level 2 strokes, the stroke can be used when indicated.					

Function No. : 072		Function Name : Upper feed plate control when paused
072. FF PauseCntl		When a pause code occurs, it is to set the operation condition of the upper feed plate.
Setting Value	1) CLOSE	It keeps the upper feed plate in the lowered position.
		[Contents] When the operations is paused, the upper feed plates are all kept in the lowered position. In this case, the upper feed plates can be controlled with the pedal.
	2) OPEN	It keeps the upper feed plate in the raised position.
		[Contents] When paused during operation, the upper feed plates are all kept in the raised position. In this case, the upper feed plates can be controlled with the pedal.
	3) FF_NUMBER	Follow the instructions in 060 : <u>"Upper Feed Plate Control When Paused"</u> (Factory installed condition)
		[Contents] Follow the instructions in 060 : <u>"Upper Feed Plate Control When Paused"</u>

Function No. : 073		Function Name : Whether to use thread tension adjusting plate after thread trimming.
073. Trim Hold En		Define whether to use thread tension adjusting plate after thread trimming.
Setting Value	1) DISABLE	Do not use thread tension adjusting plate after thread trimming.
		[Contents]
	2) ENABLE	Use thread tension adjusting plate after thread trimming. (Factory Default)
		[Contents]

Function No. : 074		Function Name : Upper feed plate control
074. Upper Clamp En		Define whether to use upper feed plate.
Setting Value	1) DISABLE	Sewing will be allowed when the upper feed plate is opened.
		[Contents] In either case of opening or closing the upper feed plate, press the left switch on the stepping stand to start sewing.
	2) ENABLE	Sewing will not be allowed when the upper feed plate is opened. (Factory Default)
		[Contents] Only in case of closing the upper feed plate, press the left switch on the stepping stand to start sewing.

Function No. : 075		Function Name : Back/Forth jump stitches
075. ConKey3 Num		User can define stitch value to move. 1~100[Stitch]
Setting Value	1	[Contents] To confirm the pattern with the back/forth stitch function, the user can set the stitch value to reduce the time to retrieve stitches.
		 <p>ConKey3 Num = 1 [Before Setting-Up] ConKey3 Num = 3 [After Setting-Up]</p>

Function No. : 076		Function Name : Setting-up reference point for zooming
076. Scale Refer		On sewing mode, the user can zoom design based on machine origin, second origin, sewing starting point and user-defined reference point.
Setting Value	1) MACHINE__ORG	Zooming based on the machine origin (Factory Default)
		[Contents] Scaling up/down based on the current machine origin.
	2) SECOND__ORG	Zooming based on the second origin set by user.
		[Contents] Scaling up/down based on the second origin set by user at any location.
	3) SEWING__STRT	Zooming based on the reference on the sewing starting point
		[Contents] Zooming based on the first stitch of any pattern design.
	4) REFER__PNT	Zooming based on th reference point defined by user at any location.
		[Contents] Zooming based on the reference point defined by user at program code No.058 of <Function Code>.

Function No. : 077		Function Name : Palette signal check
077. Palette Chk		If there would be sensor attached on the upper feed plate, define whether to user the signal check.
Setting Value	1) DISABLE	No signal checking (Factory Default)
		[Contents]
	2) ENABLE	Signal checking
		[Contents]

Function No. : 078		Function Name : Sewing limit set-up
078. Sewing Limit		Designed to ensure the user to increase the mechanical sewing limit of the machine as desired SPS/C-Series can not be used.
Setting Value	1) DISABLE	Not in use (When shipped out from the factory)
		[Contents] The sewing limit cannot be expanded. Use the sewing limit as defined by type.
	2) ENABLE	In use
		[Contents] The user can expand the sewing limit. [Caution] On condition that sewing limit is changed in accordance with mechanically expanded limit. Otherwise, the machine can be damaged.

Function No. : 079		Function Name : X-axis forward direction sewing limit set-up
079. XPLUS Limit		The user can increase the X-axis forward direction as desired.
Setting Value	1 ~ 250mm	Set the size of X-axis forward direction as desired. (At the time of the factory shipping, machines are set in line with their sewing limit by type) Ex: 13mm for 1306 type
		[Contents] The user can expand the size of sewing limit in the program. [Caution] The feeding axis must be changed in line with the size of sewing limit where mechanical feeding is possible. If the user increases the set-up value in the program and begins feeding, the machine can be severely damaged.

Function No. : 080		Function Name : X-axis reverse direction sewing limit set-up
080. XMINUS Limit		The user can increase the X-axis reverse direction of the sewing limit
Setting Value	-1 ~ -250mm	Set the size of X-axis reverse direction as desired. (At the time of the factory shipping, machines are set in line with their sewing limit by type) Ex: -13mm for 1306 type
		[Contents] The user can expand the size of sewing limit in the program. [Caution] The feeding axis must be changed in line with the size of sewing limit where mechanical feeding is possible. If the user increases the set-up value in the program and begins feeding, the machine can be severely damaged.

Function No. : 081		Function Name : Y-axis forward direction sewing limit set-up
081. YPLUS Limit		The user can increase the Y-axis forward direction of the sewing limit
Setting Value	1 ~ 250mm	Set the size of Y-axis forward direction as desired. (At the time of the factory shipping, machines are set in line with their sewing limit by type) Ex: 6mm for 1306 type
		[Contents] The user can expand the size of sewing limit in the program. [Caution] The feeding axis must be changed in line with the size of sewing limit where mechanical feeding is possible. If the user increases the set-up value in the program and begins feeding, the machine can be severely damaged.

Function No. : 082		Function Name : Y-axis reverse direction sewing limit set-up
082. YMINUS Limit		The user can increase the Y-axis reverse direction of the sewing limit
Setting Value	-1 ~ -250mm	Set the size of Y-axis reverse direction as desired. (At the time of the factory shipping, machines are set in line with their sewing limit by type) Ex: -6mm for 1306 type
		[Contents] The user can expand the size of sewing limit in the program. [Caution] The feeding axis must be changed in line with the size of sewing limit where mechanical feeding is possible. If the user increases the set-up value in the program and begins feeding, the machine can be severely damaged.

Function No. : 083		Function Name : Quick origin search motion selection for 1811
083. FFOrigin 1811		As for SPS-1811 machines, origin search motion is performed due to reverse devices. However, if there is no reverse device, search motion takes place very slowly. This quick origin search motion function ensures fast origin search and feeding back to the starting point of sewing.
Setting Value	1) DISABLE	Quick origin search motion is not in use (at the factory)
		[Contents] Generally, search is done on overall sewing limit before implementation of origin motion and feeding back to the starting point of sewing.
	2) ENABLE	Quick origin search motion is in use.
		[Contents] No search done on overall sewing limit. Starts with origin motion right away and feeding back to the starting point of sewing.


Function No. : 084		Function Name: Upper-Lower Shaft Origin Search Motion Setting after finishing sewing [SPS/C- Series]
084. HOOKORG MODE		To set the function of upper-lower shaft origin search motion after finishing sewing.
Setting Value	1) JOB__SETUP	Not in use.
		[Contents] Do not apply the function of upper-lower shaft origin search motion.
	2) JOB__READY	In Use (at the factory)
		[Contents] Use the function of upper-lower shaft origin search motion. Unlike the existing pattern machines, upper shaft and lower shaft are separated and operated independently in case of SPS/C-Series. Therefore, this function allows setting origin search motion mode to set right time of upper-lower shaft hook time.

Function No. : 085		Function Name: Up-Down Setting Function of Machine Head [SPS/C-Series]
085. HEAD En/Dis		To set ascending of Machine Head after finishing sewing.
Setting Value	1) HEAD__DOWN	Not in use
		[Contents] Do not apply the ascending of machine head after finishing sewing.
	2) HEAD__UP	In Use (at the factory)
		[Contents] Apply the ascending of machine head after finishing sewing. Unlike the existing pattern machines, machine head can ascend and descend in case of SPS/C-Series. Therefore, if the head ascending is necessary for a user after finishing sewing, use the ascending function.
	3) JUMP__HEADUP	[Contents] Always let the head lifted when it is in the jump motion.

Function No. : 086		Function Name: Setting of reverse rotation after trimming [SPS/B/C-Series]
086. RevAfterTrim		The function is to set the reverse rotation after trimming.
Setting Value	1) DISABLE	Disabled (Default)
		[Contents] This disables the function of reserve rotation after trimming.
	2) ENABLE	In use
		[Contents] This enables the function of reverse rotation after trimming. With SPS/C-Series, reverse rotation can be made after trimming unlike other existing pattern machines. Therefore, for very thick sewing materials, during the jump motion after trimming, the needle may be interfered by the sewing materials or the clamp. In this case, user can avoid interruption by enabling the reverse rotation function.
	3) END__SEW	To be activated after the last trimming is conducted.
		[Contents] After the last trimming of sewing, the reverse rotation function shall be applied.

Function No. : 087		Function Name: Set reverse rotation angles after trimming [SPS/B/C-Series]
087. ReverseAngle		The function is to set reverse rotation angles during reverse rotation operation of machine.
Setting Value	1° ~ 40°	It is available to set reverse rotation angles. (Factory installed condition: "15°")
		[Contents] It is possible to set reverse rotation angle. The reverse rotation angle, set when reverse rotation after trimming mentioned in Function No.: 76 is set at ENABLE, will be applied.

Function No. : 088		Function name: Oil control (SPS/C/S-Series)
088. Oil Control		Set up a time for hook lubrication after trimming.
Setting Value	0° ~ 10°	Set up oil control time (Set-up value at the factory: "4")
		[Contents] This function is designed to supply oil to the hook after trimming for a set period of time, using pneumatic pressure. The unit of programmed set-up value is 25ms, and the set-up value at the time of the factory release is 4, or 0.1 seconds (25*4=100ms). Set the value at "0" when the function is not used.

Function No. : 089		Function name: Oil spray cycle off-time setting (C-Series model)
089. OilOffTime		It sets the oil spray cycle off-time.
Setting Value	00~50[ms]	The off-time of oil spraying cycle can be set (default value: 5).
		<p>[Contents] To prevent dust and thread scraps from sticking to the hook, oil is sprayed into the hook. The spraying frequency is set at "091. Oil Control."</p>  <p>The diagram illustrates a square wave signal. The high portion of the signal is labeled "091. Oil Control On Time" set value, and the low portion is labeled "092. Oil Off Time" set value. The total period of one cycle is 50ms.</p>

Function No. : 090		Function Name: Save Type Setting
090. Save Type		It determines the place of saving design patterns.
Setting Value	1) SAVE FDD	Save in FDD (Default value)
		[Contents] Save patterns in FDD.
	2) SAVE FLASH	Save in Flash Memory
		[Contents] When FDD has errors or there is no FDD, design patterns can be conveniently saved in Flash Memory.

Function No. : 091		Function Name: When opening a design, the design internally memorized can be deleted.
091. DsgnOpnCtrl		This function is to set whether other designs will be deleted when a new design is opened.
Setting Value	1)SAVE	Design Saving in Flash Memory (default)
		[Contents] When a design is opened from a floppy diskette or CF Card, save the designs opened from Flash Memory. If other designs need to be opened continuously, they could be saved in Flash Memory and it might cause memory save shortage. Therefore it would be better to save up to 16 designs (100kbyte per design).
	2) DELETE	Deleting Designs from Flash Memory
		[Contents] When designs are opened from Flash Memory, the designs will be deleted consecutively one by one. Therefore, whenever designs are opened from Flash Memory continuously, the current design will remain saved, while other designs are deleted.

Function No. : 092		Function Name: Setting the Safety Mode
092. Safety Mode		This is a function to offer safety to users.
Setting Value	1) DISABLE	Not in use (at the time of the factory release)
		[Contents] The safety mode has not been set.
	2) ENABLE	Used.
		[Contents] When the function is set, if the sewing machine is stopped because of emergency stop, thread sensing or pause code, the sewing machine remains stalled even when the pedal start switch or the clamp up/down switch is pressed or when any OP box keys are entered. To cancel the safety mode, press "EXE" on the left bottom of the OP Box. When the "EXE" key is pressed, the sewing machine can be operated again.

Function No. : 093		Function Name: Jump Speed Setting [Applied to SPS/C-Series only]
093. Jump Speed		This function is to set the jump speed.
Setting Value	1) SLOW__SPEED	It sets the slowest jump speed.
		[Contents]
	2) MIDDLE__SPEED	It sets the medium jump speed (default).
		[Contents]
	3) FAST__SPEED	It sets the highest jump speed.
		[Contents] To shorten the working hours, set the highest jump speed. It could save plenty of time.

Function No. : 094		Function Name: Design Auto Call Setting [Possible when SPS/C-Series I/O Board is used]
094. Auto Call		This function is to set the design auto call.
Setting Value	1) DISABLE	The design auto call is disabled (default).
		[Contents] When the function is disabled, it is same as the Nor__Sew mode.
	2) ENABLE	The design auto call is enabled.
		[Contents] The designs from 900 to 914 can be automatically called by using the external sensor input mixture.

Function No. : 095		Function Name: Sewing Ready Setting Upon Design Auto Call [Possible when SPS/C-Series I/O Board is used]
095. Auto Ready		This function is to set whether the sewing ready function is used upon the design auto call.
Setting Value	1) DISABLE	The function is disabled (default).
		[Contents] When the function is disabled, the sewing ready is not conducted when the design auto call is made by the external sensor. The design number only is automatically changed.
	2) ENABLE	The sewing ready is enabled.
		[Contents] When this function is set, the sewing preparation is automatically conducted upon the design auto call.

Function No. : 096		Function Name: External Control Signal Use Setting [Possible when SPS/C-Series I/O Board is used]
096. Attatch Set		This function is to use the external input signals to use Sewing Start, Emergency Switch, Clamp and Enter Key.
Setting Value	1) DISABLE	The function is disabled (default).
		[Contents] When the function is disabled, it is same as the previous usage.
	2) ENABLE	The function is enabled.
		[Contents] When the function is enabled, it is possible to use the external input signals to use Sewing Start, Emergency Switch, Clamp Up/Down, and Enter key.

Function No. : 097		Function Name: Design Call Sensor Time Setting [Possible when SPS/C-Series I/O Board is used]
097. AutoCall TM		This function is to set the time of the design auto call sensor (SEN_0~SEN_3). * Sensor connection method may differ by model types.
Setting Value	10	10 [Unit 100ms] (default)
		[Contents] The sensing time between the first sensor and the next sensor can be set. The basic unit is 100ms. When "10" is set at the parameter, it means 1000ms or 1 second. This function is aimed to set the time difference between the sensing acts of different sensors to ensure accurate sensing.

Function No. : 098		Function Name: Upper thread holder setting (C-Series AIR BAG model)
098. ThHold En/Dis		It sets whether to make the upper thread holder hold the needle thread after trimming.
Setting Value	1) DISABLE	The upper thread holder function is not used.
		[Contents] After trimming, the needle thread is not held.
	2) ENABLE	The upper thread holder function is used.
		[Contents] After trimming, the upper thread holder holds the needle thread for the time set at "110. ThreadHoleTm."

Function No. : 099		Function Name: Upper thread holding time setting (C-Series AIR BAG model)
099. ThreadHoldTm		Set the needle thread holding time by the upper thread holder after trimming.
Setting Value	0~5	The upper thread holder's holding time is set. (Default: 1[sec])
		[Contents] The function prevents the remaining thread on the needle from being sown to the sewing materials or being entangled after trimming, affecting the sewing quality negatively. In general, when 1ms is set, the thread is released after one stitching.

Function No. : 100		Function Name: Clamp sensor setting
100. Clamp Sensor		The left, right sensors detect the proper attachment of the clamp. If more than one sensor fails to detect the clamp, the machine does not start operating. This function is applied to the removable clamp [for Air bag model].
Setting Value	1) DISABLE	The clamp sensor is not used.
		[Contents] Without sensor's clamp detection, forced sewing can be conducted.
	2) ENABLE	The clamp sensor is used.
		[Contents] When either one of the left and right sensors fails to detect the clamp, sewing cannot be performed.

Function No. : 101		Function Name: Airbag mode setting
101. Cassette Type		If the clamp is removable (Cassette type), set the airbag mode.
Setting Value	1) DISABLE	The airbag mode is not used.
		[Contents] Regular clamp, not removable clamp (Cassette Type), is used.
	2) ENABLE	The airbag mode is used.
		[Contents] Removable clamp (Cassette type) is used.

Function No. : 102		Function Name: Program mode lock
102. Program Lock		This function locks the program mode of the main menu.
Setting Value	1) DISABLE	Disabled (Default)
		[Contents] When the function is disabled, the usage of program mode is as same as before.
	2) ENABLE	In use
		[Contents] When the function is enabled, it is impossible to enter the program mode.

Function No. : 103		Function Name: Semi-auto removal of lower feed plate(SPS-3020, 5030, 5034)
103. Low Feed Set		When sewing is completed, the lower feed plate is automatically removed.
Setting Value	1) DISABLE	Disabled (Default)
		[Contents] When the function is disabled, the usage of program mode is as same as before.
	2) ENABLE	In use
		[Contents] When the function is enabled, the lower feed plate is automatically removed.

Function No. : 104		Function Name: Basic clamp position setting
104. Clmp Ref POS		This function sets the basic position of the clamp.
Setting Value	1) Ref__UP	Disabled (Default)
		[Contents] When the function is disabled, the usage of program mode is as same as before.
	2) Ref__DOWN	In use
		[Contents] For use, the clamp's pneumatic lines A and B shall be exchanged before connection.

Function No. : 105		Function Name: Set up the positions to stop the needle bar
105. UpStop Pos		The function to set up the positions to stop the needle bar is to stop the needle bar at the positions of the established values when the motor stops. (It is applied only for the Direct Models.)
Setting Value	0° ~360°	It is available to set up the values within a range of 0° ~360°. (Factory installed condition: 0°. However, value of SPS/C-Series is originally set at 97°, upon shipment.)
		[Contents] The angles of the needle bar positions shall be changed as follows. It will show the change of the angle values when turning the hand pulley counterclockwise. The current angle values will be set up at the changed position by pressing the ENTER key. However, value of SPS/C-Series is originally set at 97°, upon shipment, because main shaft motor is installed at the 90° changed position due to the rise of HEAD.

















1) Function No. Related to Pattern Programming

(Function numbers might be different depending on machine type.)

NO.	Function	Contents
000	Trimming	Addition of trimming code.
001	2nd origin	Set of the 2nd origin.
002	Temporary suspension	Temporary suspension in a particular point.
003	One turn of sewing machine	Processing without sewing.
004	JUMP	Feed needle bar without sewing.
005	Point sewing	User inputs every stitch to create the sewing data.
006	Linear/Curving line sewing	Use straight line/curve to create the sewing data.
007	Linear sewing	Use Straight line to create the sewing data.
008	Spline sewing	use curve to create the sewing data.
009	Arc sewing	use arc to create the sewing data.
010	Circle sewing	Use circle to create the sewing data.
011	Change of jump speed	
012	Change of stitching speed	Use when changing embroidery speed within one work pattern.
013	Partial Sewing Stitch Width Change	Change stitch width by selecting a fixed part of sewing shape.
014	Pattern data reading from floppy diskette	Read the stored pattern from floppy diskette.
015	Pattern data writing to floppy diskette	Store the programmed pattern into floppy diskette.
016	Floppy diskette formatting	Format the floppy diskette.
017	Information indication of present pattern data	Number of stitches, Speed, Backlash, X-magnification, Y-magnification, Tracing, R-Pattern NO. W-Pattern No.
018	Coordinates setting	Absolute coordinate system/relative coordinate system.
019	Linear zig-zag sewing	Use straight line to create the zigzag sewing data.
020	Spline zig-zag sewing	Use curve to create the zigzag sewing data.
021	Arc zig-zag sewing	Use arc to create the zigzag sewing data.
022	Circle zig-zag sewing	Use circle to create the zigzag sewing data.
023	Linea offset sewing	Set the distance based on straight line to create the offset sewing data.
024	Spline offset sewing	Set the distance based on curve to create the offset sewing data.
025	Arc offset sewing	Set the distance based on arc to create the offset sewing data.
026	Circle offset sewing	Set the distance based on circle to create the offset sewing data.
027	Linear double sewing	Create the same sewing data as that created by straight line.
028	Spline double sewing	Create the same sewing data as that created by curve.
029	Arc double sewing	Create the same sewing data as that created by arc.
030	Circle double sewing	Create the same sewing data as that created by circle.
031	Linear double reverse sewing	Set the offset based on straight line to create the same type of sewing data.
032	Spline double reverse sewing	Set the offset based on curve to create the same type of sewing data.

NO.	Function	Contents
033	Arc double reverse sewing	Set the offset based on arc to create the same type of sewing data.
034	Circle double reverse sewing	Set the offset based on circle to create the same type of sewing data.
035	Linear reverse sewing	Create the opposite sewing data of the straight line data.
036	Spline reverse sewing	Create the opposite sewing data of curve data.
037	Arc reverse sewing	Create the opposite sewing data of arc data.
038	Circle reverse sewing	Create the opposite sewing data of circle data.
039	Partial Pattern Data Delete Function	Delete by selecting one from created pattern shapes.
040	Addition of automatic back-tack	Automatic back tacking.
041	Condensed Sewing Stitch Adding	It is the function to prevent stitches from being untangled by making stitch width condensed in sewing start part and sewing end part of pattern data.
042	Addition of overlap stitch	Additionally proceed sewing as many numbers of stitches as the user wants.
043	X-axis Symmetrical Data Addition	Add pattern data selected on the basis of X-axis.
044	Y-axis Symmetrical Data Addition	Add pattern data selected on the basis of Y-axis.
045	Point Symmetrical Data Addition	Add by making symmetric pattern data on the basis of end point of pattern data.
046	Partial Movement of Pattern Data	Move part of pattern to different location among the sewing shape.
047	Copying Function of Pattern Data to Specific Location	Set a fixed part of pattern shape and copy to desired location.
048	Deletion of pattern data	Delete sewing data on any part of pattern.
049	Partial Pattern Data Delete Function	Delete one of the generated pattern data shapes selectively (For example: Jump, Line, Curve, Arc, Circle).
050	Change/Saving Function of Maximum Pattern Sewing Speed and Extension/Reduction Rate	Set up maximum sewing speed and extension/reduction rate by pattern.
051	One Stitch Movement Function	It uses when correcting the location of one stitch in the formed sewing shape.
052	A Fixed Number of Stitch Delete Function	Delete 1-99 stitch in the pattern data shape after the start point to delete at present.
053	Change/Saving Function of Pattern Data Start Point	Change and save pattern data start point already set up when punching.
054	Change/Saving Function of Pattern 2nd Original Point	Change the already setup 2nd original point to new 2nd original point and save it.
055	Setting-up automatic thread trimmer	Delete stitch or pattern to automatically insert thread trimmer code.
056	Setting-up user-defined reference point for zooming	Scaling up/down based on the reference point set on any pattern.
057	Output Port Setting Function [Applicable when the SPS/C-Series board is attached]	The function is that a user can program devices that are set to certain places when punching.
058	Input port user setting function[Applicable when the SPS/C-Series board is attached]	The function can program devices set at arbitrary positions when conducting punching.
059	Time Delay Setting Function when using output port [Applicable when the SPS/C-Series board is attached]	The function is that a user can program applicable time delay when using output port.
063	Third thread adjusting device setting [Applicable when the SPS/C-Series board is attached]	These functions are programmable when the 3rd thread adjusting device is attached.

2) Pattern chart (Function numbers might be different depending on machine type.)

	Linear sewing	Spline sewing	Arc sewing	Circle sewing
Basic Sewing	NO. : 007 Name : Linear sewing 	No. : 008 Name : Spline sewing 	NO. : 009 Name : Arc sewing 	No. : 010 Name : Circle sewing 
Zig-Zag Sewing	No. : 019 Name : Linear zig-zag sewing 	No. : 020 Name : Spline zig-zag sewing 	No. : 021 Name : Arc zig-zag sewing 	No. : 022 Name : Circle zig-zag sewing 
Double Sewing	No. : 027 Name : Linear double sewing 	No. : 028 Name : Spline double sewing 	No. : 029 Name : Arc double sewing 	No. : 030 Name : Circle double sewing 
Reverse Sewing	No. : 035 Name : Linear reverse sewing 	No. : 036 Name : Spline reverse sewing 	No. : 037 Name : Arc reverse sewing 	No. : 038 Name : Circle reverse sewing 

3) Parameter Number Related to General sewing

(Parameter numbers can be different depending on machine type.)

NO.	Function name	Contents	Explanation and factory-installed setting value	Unit
000	Manual moving		★ Transfer of the feed plate by using direction keys	0/1
		1) DISABLE	1) Disable	
		2) ENABLE	2) Enable	
001	Starting position 2nd origin by manual moving	1) PTRN_STRT_POS	1) Moving the sewing starting position by using direction keys	0/1
		2) SECND_ORG	2) Setting to the 2nd origin by using direction keys	
002	Returning to the origin 1 after completing work		★ Returning to the origin 1 after completing work	0/1
		1) DISABLE	1) It does not return	
		2) ENABLE	2) It returns	
003	Returning when limit error happens		★ If it reaches transfer limit of the feed plate, it returns	0/1
		1) DISABLE	1) It does not return to the origin of machine	
		2) ENABLE	2) It returns to the origin of machine	
004	Returning method of starting point	1) SHORTEST	1) Returning through the shortest route	0~2
		2) ORG_TO_STRT	2) After returning to the original point, return to the starting point	
		3) REV_ORG_STRT	3) After returning to the origin point by tracing the pattern shape back	
005	Counting method of the lower thread counter	1) UP_COUNT	1) Counting by increasing the sewing completion number	0~3
		2) DN_COUNT	2) Counting by lowering the sewing completion number	
		3) DESIGN_UP	3) Counting by increasing the sewing completion number by design	
		4) DESIGN_DN	4) Counting by lowering the sewing completion number by design	
006	Mark of product counter	1) DISABLE	1) No use	0/1
		2) ENABLE	2) Use	
007	Time for pattern counter	1) JOB_SETUP	1) Before completion for sewing preparation	0/1
		2) JOB_READY	2) After completion for sewing preparation	
008	Trimming in emergency stop during the operation	1) AUTO_TRIM	1) Performing the automatic trimming	0/1
		2) MANU_TRIM	2) Performing the manual trimming	
009	Main shaft speed acceleration setting	1) SLOW_STRT0	A/B-Series 200→400→600→800→1000	1spm
			C-Series 200→200→400→800→1200→1600→1800→2000	
		2) SLOW_STRT1	A/B-Series 300→500→700→900→1200	
			C-Series 200→200→400→800→1000→1200→1400→1600	
		3) SLOW_STRT2	A/B-Series 400→500→800→1000→1200	
			C-Series 200→200→200→400→600→800→1000→1200	
		4) SLOW_STRT3	A/B-Series 500→600→900→1100→1300	
			C-Series 200→200→400→400→600→800→1200→1400	
		5) SLOW_STRT4	A/B-Series 500→500→500→800→1000	
			C-Series 200→400→400→600→800→1200→1600→1800	
		6) SLOW_STRT5	A/B-Series 600→600→600→800→1200	
			C-Series 200→400→400→600→800→1200→1600→2000	
		7) USER_STRT	User define	
010	1 st needle speed setting	200ms	Set the speed for the 1 st needle. 2~25[100ms]	1[100ms]
011	2 nd needle speed setting	200ms	Set the speed for the 2 nd needle. 2~25[100ms]	1[100ms]
012	3 rd needle speed setting	400ms	Set the speed for the 3 rd needle. 2~25[100ms]	1[100ms]
013	4 th needle speed setting	600ms	Set the speed for the 4 th needle. 2~25[100ms]	1[100ms]

NO.	Function name	Contents	Explanation and factory-installed setting value	Unit
014	5 th needle speed setting	800ms	Set the speed for the 5 th needle. 2~25[100ms]	1[100ms]
015	6 th needle speed setting	1000ms	Set the speed for the 6 th needle. 2~25[100ms]	1[100ms]
016	7 th needle speed setting	1200ms	Set the speed for the 7 th needle. 2~25[100ms]	1[100ms]
017	8 th needle speed setting	1400ms	Set the speed for the 8 th needle.	1[100ms]
018	9 th needle speed setting	1600ms	Set the speed for the 9 th needle. 2~25[100ms]	1[100ms]
019	10 th needle speed setting	1800ms	Set the speed for the 10 th needle. 2~25[100ms]	1[100ms]
020	Limit to maximum sewing speed	1) 2500spm/3.0mm(for 1306)		0~4
		2) 2000spm/3.0mm		
		3) 1700spm/3.0mm		
		4) 1300spm/3.0mm		
021	Transfer starting angle of the feed plate	50 [DEGREE]	Setting it to fit the thickness of sewing materials : 0~100°	1
022	Operating situation of the feed plate when finishing work	1) STRT__OPEN	1) Opening after returning to the starting point	0/1
		2) STRT__HOLD	2) Keeping the closing state even after returning to the starting position(Lifting by pedal)	
		3) OPEN__STRT	3) Returning to the starting position in fliting state	
		4) OPEN__STRT1	4) Return to start point in condition of 1 step rise	
		5) OPEN__STRT2	5) Return to start point in condition of 2 step rise	
023	Keep the close of the feed plate	1) DISABLE	1) It does not always keep descending	0/1
		2) ENABLE	2) It always keep descending	
024	Signal treatment of pedal 1	1) LATCH		0/1
		2) FLIP		
025	Signal treatment of pedal 2	1) LATCH		0/1
		2) FLIP		
026	Operation state of presser foot	1) ALWAYS__DN	Prohibiting the operation(Keeping the downward suspension all the time)	0/1
		2) SEW__DN	Keeping the downward suspension during sewing	
		3) TRIAL__DN	Keeping the downward suspension When a stitch proceeding /reversing	
027	Lowering timing of presser foot	1) WITH__STRT	Descending whit the main shaft turn at the same time	0/1
		2) WITH__FEED	Descending whit the feeding at the same time	
028	Wiper operation	1) ALWAYS__OFF	Operation prohibition	0~2
		2) ELEC__TYPE	Electronic type wiper	
		3) AIR__TYPE	Air type wiper	
029	Position of wiper operation	1) BET__NEDL__PF	1) Operating between a needle and middle presser foot	0/1
		2) BELW__PF	2) Operation below middle presser foot	
030	Thread broken sensor mode	1) DISABLE	1) No use	0/1
		2) ENABLE	2) Use	
031	Detected no. of broken stitches when starting sewing	5[STITCH], (SPS-5050/8050 : 10)	0~15 Stitches	1
032	Detected no. of broken stitches during the normal sewing	3[STITCH], (SPS-5050/8050 : 5)	0~15 Stitches	1
033	Trimming mode	1) DISABLE	No use	0/1
		2) ENABLE	Use	
034	Time of 1st-step jog speed	400[ms]	1~99×100ms	100
035	Time of 2nd-step jog speed	1000[ms]	1~99×100ms	100
036	Time of 3sd-step jog speed	2000[ms]	1~99×100ms	100
037	1st-step key-continued pressing time	400[ms]	1~99×100ms	100
038	2nd-step key-continued pressing time	100[ms]	1~99×100ms	100
039	3rd-step key-continued pressing time	3000[ms]	1~99×100ms	100

NO.	Function name	Contents	Explanation and factory-installed setting value	Unit
040	Operating time of elec' type wiper	52[ms]	0~1020ms	4
041	Returning time of elec' type wiper	100[ms]	0~1020ms (Waiting time for next operation)	4
042	Operating time of air type wiper	100[ms]	0~1020ms	4
043	Returning time of air type wiper	100[ms]	0~1020ms (Waiting time for next operation)	4
044	Waiting time descending completion of presser foot	152[ms]	0~1020ms	4
045	Waiting time ascending completion of presser foot	152[ms]	0~1020ms	4
046	Presser Full On Time	200[ms]	0~1020ms	4
047	Feeding plate Full On Time	200[ms]	0~1020ms	4
048	Trimming Full On Time	200[ms]	0~1020ms	4
049	Loosening thread Full On Time	200[ms]	0~1020ms	4
050	Wiper Full On Time	200[ms]	0~1020ms	4
051	Left feed plate Full On Time	200[ms]	0~1020ms	4
052	2 step stroke Full On Time	200[ms]	0~1020ms	4
053	Inverting device Full On Time	200[ms]	0~1020ms	4
054	Presser foot Duty	80%, (SPS-1306/SPS-1507/1310 : 33)	33~40%	1
055	Feeding plate Duty	80%, (SPS-1306/SPS-1507/1310 : 43)	40~48%	1
056	Trimming Duty	50%	30~80%	10
057	Loosening thread Duty	50%	30~80%	10
058	Wiper Duty	50%	30~80%	10
059	Left feed plate Duty	80%	30~80%	10
060	2 step stroke Duty	80%	30~80%	10
061	Inverting device Duty	80%	30~80%	10
062	Reading order when number of same pattern data exist in memory		★ The reading order when the same pattern data numbers exist in the internal memory	0/1
		1) DISABLE	1) Read first from a floppy disk	
		2) ENABLE	2) Read first from a internal memory	
063	Extension/Reduction mode Stitch-NUM: It is not applied (It is going to apply later)		★ It settles the way of reduction and extension for pattern	0~2
		1) DISABLE	Extension and reduction are impossible	
		2) STITCH_LEN	Extension and reduction by a stitch width	
		3) STITCH_NUM	Extension and reduction by a number of stitch	
064	Number to be performed chain stitch	0	0~16 0:General sewing, Over 1: Chain sewing	1
065	Change of chain number	1) MANUAL	Automatic change	0~2
		2) AUTO	Manual change by enter key	
		3) EXTERNAL	Change by outward input	
066	Clamp Setting for Chain Sewing	1) DISABLE	Disabled (default)	
		2) ENABLE	Enabled	
067	Reduction stitch before work completion	2[STITCH], (SPS-5050/8050 : 4, SPS-2211/2516 : 5)	Change to 2~16	1
068	Reduction speed before work completion	400[spm] SPS/C-Series : 200[spm]	200~500spm	100
069	Thread trimming delayed time	72[ms]	52~1020[ms]	4
070	Whether to use the function to detect fall of pressure	1) DISABLE(for 1306)	1) Do not use pressure reduction sensor.	
		2) ENABLE	2) Use pressure reduction sensor.	
071	Feed control	0	0~31 See "Parameter description related to general embroidery".	1
072	In case of temporary stop, control Pan feed plate		In case of meeting temporary stop code while embroidering, control top feed plate	
		1) CLOSE	Put down the top feed plate	
		2) OPEN	Hold up the top feed plate	
		3) FF	Control the top feed plate according to Article 060	
073	Thread tension adjusting after thread trimming.	1) DISABLE	Do not use thread tension adjusting plate after thread trimming.	0/1
		2) ENABLE	Use thread tension adjusting plate after thread trimming.	

NO.	Function name	Contents	Explanation and factory-installed setting value	Unit
074	Upper feed plate control	1) DISABLE	Sewing will be allowed whether the upper feed plate is opened or closed.	0/1
		2) ENABLE	Sewing will not be allowed when the upper feed plate is opened.	
075	Back/forth jump stitches	1	User can define stitch value to move. 1~100 [Stitch]	0/1
076	Setting-up reference point for zooming	1) MACHINE_ORG	Zooming based on the machine origin.	0~3
		2) SECOND_ORG	Zooming based on the second origin set by user.	
		3) SEWING_STRT	Zooming based on sewing starting point.	
		4) REFER_PNT	Zooming based on the reference point defined by user at any location.	
077	Palette signal check	1) DISABLE	Do not use signal on the upper feed plate sensor.	
		2) ENABLE	Use signal on the upper feed plate sensor.	
078	Sewing limit set-up	1) DISABLE	Not used (at the factory)	
		2) ENABLE	Used	
079	X-axis forward direction sewing limit set-up	13(mm) (For 1306)	Sets the size of X-axis forward direction as desired (1mm~250mm)	1
080	X-axis reverse direction sewing limit set-up	-13(mm) (For 1306)	Sets the size of X-axis backward direction as desired (-1mm~-250mm)	1
081	Y-axis forward direction sewing limit set-up	6(mm) (For 1306)	Sets the size of Y-axis forward direction as desired (1mm~250mm)	1
082	Y-axis reverse direction sewing limit set-up	-6(mm) (For 1306)	Sets the size of Y-axis backward direction as desired (-1mm~-250mm)	1
083	Quick origin search motion for 1811	1) DISABLE	Quick origin search motion not used	
		2) ENABLE	Quick origin search motion used	
084	Upper-lower shaft origin search motion after finishing sewing Setting [SPS/C-Series]	1) JOB_SETUP	Do not use upper-lower shaft origin search motion after finishing sewing	
		2) JOB_READY	Do use upper-lower shaft origin search motion after finishing sewing	
085	Machine Head Up-Down Setting Function [SPS/C-series]	1) HEAD_DOWN	Do not use the ascending of machine head after finishing sewing.	
		2) HEAD_UP	Do use the ascending of machine head after finishing sewing.	
		3) JUMP_HEADUP	Use the head lift function when it is in the jump motion.	
086	Reverse rotation setting after trimming	1) DISABLE	1) Disabled	0~2
		2) ENABLE	2) Enabled	
		3) END_SEW	3) To be activated after the last trimming is performed	
087	Reverse Rotation Angle after Trimming Setting Function	15°	Reverse Rotation Angle after Trimming Setting (1~40°)	1°
088	Oil control [SPS/C-Series]	4[ms]	Set the hook lubrication time after trimming (0°~10°)	1
089	Oil spray off-time cycle setting	5	This function sets the oil spray off-time cycle. (00~50[sec])	1[sec]
090	Designate the place of saving pattern designs	1) SAVE_FDD	Save in FDD (Default value)	
		2) SAVE_FLASH	Save in Flash Memory	
091	Deleting Flash Memory Designs When New Designs Are Opened	1) SAVE	Enabled (default)	
		2) DELETE	Disabled	
092	Setting the Safety Mode	1) DISABLE	Not used (at the factory)	
		2) ENABLE	Used	
093	Jump Speed Setting	1) SLOW_SPEED	Lowest Jump Speed	
		2) MIDDLE_SPEED	Medium Jump Speed	
		3) FAST_SPEED	Highest Jump Speed	
094	Design Auto Call Setting	1) DISABLE	This sets the design auto call function.	
		2) ENABLE		
095	Sewing Ready Function Setting Upon Design Auto Call	1) DISABLE	This sets whether the machine becomes ready for sewing, when designs are automatically called.	
		2) ENABLE		
096	External Control Signal Use Setting	1) DISABLE	This sets whether the external input signals are used to activate Sewing Start, Emergency Switch, Clamp, and Enter key.	
		2) ENABLE		
097	Design Call Sensing Time Setting	10	This sets the sensing time for the design auto call sensors (SEN_0~SEN_3).	1 [100ms]

NO.	Function name	Contents	Explanation and factory-installed setting value	Unit
098	Upper thread holder setting (C-Series AIR BAG model)	1) DISABLE	The upper thread holder function is not used.	
		2) ENABLE	The upper thread holder function is used.	
099	Upper thread holder time setting	1	It sets the time of holding the remaining needle thread after trimming by the upper thread holder.(0~5)	500[ms]
100	Clamp sensor setting (C-Series AIR BAG model)	1) DISABLE	The clamp sensor is disabled.	
		2) ENABLE	The clamp sensor is enabled.	
101	Airbag mode setting	1) DISABLE	The regular clamp is used.	
		2) ENABLE	The removable (Cassette type) clamp is used.	
102	Program mode lock	1) DISABLE	1) Disabled	0/1
		2) ENABLE	2) Enabled	
103	Semi-automatic removal of lower feed plate	1) DISABLE	1) Disabled	0/1
		2) ENABLE	2) Enabled	
104	Setting of basic clamp position	1) Ref__UP	1) Disabled	0/1
		2) Ref__DN	2) Enabled	
105	Setting of the needle bar stop position	0° (In case of SPS/C-series, 97°)	When the motor is stopped, the needle bar is positioned and stopped at the set value (0~360°)	1°


4) Error List

No.	Err List	Message	Meaning
1	Err 1	Main Motor Err!	Error occurs in main motor
2	Err 2	Synchro Err!	Error occurs in synchronizer
3	Err 3	Pattern Not Found!	Related pattern is not available on the diskette
4	Err 4	FDD Empty	Floppy disk drive is empty
5	Err 5	Disk-Read Err!	Machine can't read a diskette
6	Err 6	Disk-Write Err!	Machine can't write any data on the diskette
7	Err 7	Disk-Format Err!	A diskette is not formatted
8	Err 8	Disk-Full!	Diskette is full
9	Err 9	Scale Over!	Error occurs in enlargement and reduction
10	Err 10	Too Many Stitch !	It exceeds maximum number of stitches
11	Err 11	Reset Counter !	Counter should be reset
12	Err 12	Combination Not Completed!	Design combination is not completed
13	Err 13	Needle Position Err!	Needle bar is not in the proper position
14	Err 14	Limit Over!	it exceeds X-Y limit
15	Err 15	Calculation Err!	Calculation error occurs inside
16	Err 16	The Data Bad!	Pattern data is damaged
17	Err 17	Emergency Stop!	Emergency stop switch is pressed during the operation
18	Err 18	Thread Broken!	Thread is broken
19	Err 19	X-Y Error!	X-Y transferring is not performed
20	Err 20	System Program not Found	Program that you want to update does not exist in the diskette
21	Err 21	Internal Memory Err!	Internal operation error occurs
22	Err 22	Write Protected!	Diskette is write protected
23	Err 23	Insufficient Internal Memory	Internal memory is insufficient
24	Err 24	Low Pressure!	When air pressure is weak in case of pneumatic type
25	Err 25	Drag-Limit Over!	When it gets out of the sewing area after moving a stitch during editing stitch.
26	Err 26	Low-Feed-Plate\n Open!	When the clamp on the lower feed plate is raised.(It is applied only for 5030)
27	Err 27	Palette Open!	When the clamp cover on the lower feed plate is opened. (It is applied only for 5030)
28	Err 28	Emergency Sw\n Not Released!	In case that the Emergency Switch is pressed when Power On.
29	Err 29	Start Sw\n Not Released!	In case that the Start Switch is pressed when Power On.
30	Err 30	Right Sw\n Not Released!	In case that the Right Switch is pressed when Power On.
31	Err 31	Left Sw\n Not Released!	In case that the Left Switch is pressed when Power On.
32	Err 32	TwoStage Sw\n Not Released!	In case that the TwoStage Switch is pressed when Power On.
33	Err 33	Ser. Com. Err!	Abnormalities on the communication between the main shaft and the I/O board.
34	Err 34	Main Motor Err! Dismatch! 999!	The main shaft motor type is not appropriate.

No.	Err List	Message	Meaning
35	Err 35	Over Current Over tem 133!	Cutoff of IPM overcurrent to the main shaft board IPM
36	Err 36	Over Current Abnormal 131!	Motor overcurrent and connector abnormality
37	Err 37	Over Load Err! 129!	Motor overload error
38	Err 38	EncoderRET Err! 128!	No encoder RST signal
39	Err 39	EncoderAB Err! 127	Inconsistency between encoder RST direction and AB direction
40	Err 40	Sybchro! Con.Inserted! 60!	Accessing the location detector while the power is on
41	Err 41	Synchro! Con.Pulled Out! 61!	Removing the location detector while the power is off
42	Err 42	Reverse! Comm. Error! 126!	Mismatch in direction between the motor's rotor magnet and the stator current coil
43	Err 43	EEPROM! Access Error! EEPR!	ROM access error
44	Err 44	Ser.Com.Err! Motor Info Err!	Motor type communication error
45	Err 45	Unknown Err!	Unknown error
46	Err 46	Unknown Err!	Unknown error
47	Err 47	Hook Origin Error!	Failure to set the lower shaft origin
48	Err 48	Hook Motor Err. Push EXIT Key, Or Power Off/On!	Problem found at the lower shaft motor (for SPS/C-Series only)
49	Err 49	Y Motor Err. Push EXIT Key, Or Power Off/On!	Problem found at the Y-shaft motor (for SPS/C-Series only)
50	Err 50	X Motor Err. Push EXIT Key, Or Power Off/On!	Problem found at the X-shaft motor (for SPS/C-Series only)
51	Err 51	Timer Err. Push Power S/W Or Power Off/On!	Problem detected at the timer signal (for SPS/C-Series only)
52	Err 52	Main Origin Error!	Main shaft communication problem during the initial upper/lower shaft origin motion (for SPS/C-Series only)


5) SPS/A/B/C-Series block diagram

► SPS/B-1306 BLOCK DIAGRAM




► Input Voltage Type POWER DIAGRAM 1306


1Phase, 3Phase
Switch
difference



► SPS/A-1306 Series BLOCK DIAGRAM



► SPS/C-Series BLOCK DIAGRAM





BASIC MANUAL

SPS/A Series







- 1 Calling the pattern : Calling patterns from memory or floppy disks
- 2 Bobbin wind
- 3 Using the counter : Using the bottom thread counter and quantity control counter
- 4 Setting the extension and reduction
- 5 Chain sewing : Performing the chain sewing
- 6 Setting the parameter related to general sewing
- 7 Pattern programming : Generating the pattern that users want

* Reference

1. If the READY LAMP turns on or the upper feed plate is on the bottom, it can be impossible to use a specific key. In that case, operate the machine after pressing  key.
2. After pressing,  key, perform thread insertion.






1


Calling the pattern : Calling patterns from memory or floppy disks

  Input of pattern no. with digit keys  Calling the pattern 

2





Bobbin wind




  8  2  Starting by left pedal
Ending by right pedal 

Mode key  "3. BOBBIN WIND"

3







Using the counter : Using the bottom thread counter and quantity control counter



 Input of initial value with digit keys  Input of initial value with digit keys  Input of initial value of quantity control counter 

Input of initial value of bottom thread counter   

4







Setting the extension and reduction



 Input of setting value with digit keys   Y SCALE  Input of setting value with digit keys  


Rate for horizontal ext./red.  Rate for vertical ext./red. 

5


Chain sewing : Performing the chain sewing

 Input of number with digit keys   NO  Input of number with digit keys  

Selection of chain no.  Selection of pattern no. 


Repeat as much as the chain sewing number 

Setting the parameter related to general sewing



Parameter number related to general sewing									
pg	End/Dts	Manual Operation	End/Dts	054	PF	Duty	Presser foot duty		
000	Machine On/Off	Moving to start position of the 2nd origin by manual drive	001	055	FF <th>Duty</th> <th>Feed plate duty</th>	Duty	Feed plate duty		
001	Machine On/Off	Moving to start position of the 2nd origin by manual drive	002	056	TF <th>Duty</th> <th>Thread trimming duty</th>	Duty	Thread trimming duty		
002	Machine On/Off	Moving to start position of the 2nd origin by manual drive	003	057	TH <th>Duty</th> <th>Thread retaining duty</th>	Duty	Thread retaining duty		
003	Machine On/Off	Moving to start position of the 2nd origin by manual drive	004	058	TP <th>Duty</th> <th>Wiper duty</th>	Duty	Wiper duty		
004	Machine On/Off	Moving to start position of the 2nd origin by manual drive	005	059	FL <th>Duty</th> <th>Left feed plate duty</th>	Duty	Left feed plate duty		
005	Machine On/Off	Moving to start position of the 2nd origin by manual drive	006	060	TS <th>Duty</th> <th>2 step stroke duty</th>	Duty	2 step stroke duty		
006	Machine On/Off	Moving to start position of the 2nd origin by manual drive	007	061	TV <th>Duty</th> <th>Reversing device duty</th>	Duty	Reversing device duty		
007	Machine On/Off	Moving to start position of the 2nd origin by manual drive	008	062	PTPN <th>MODE</th> <th>Pattern data reading mode</th>	MODE	Pattern data reading mode		
008	Machine On/Off	Moving to start position of the 2nd origin by manual drive	009	063	Scale <th>MODE</th> <th>Setting the magnify/demagnifying mode</th>	MODE	Setting the magnify/demagnifying mode		
009	Machine On/Off	Moving to start position of the 2nd origin by manual drive	010	064	Chain <th>Number</th> <th>Number of chain numbers</th>	Number	Number of chain numbers		
010	Machine On/Off	Moving to start position of the 2nd origin by manual drive	011	065	Chain <th>Select</th> <th>Transferring chain numbers</th>	Select	Transferring chain numbers		
011	Machine On/Off	Moving to start position of the 2nd origin by manual drive	012	066	Chain <th>Clamp</th> <th>Set the clamp when the chain is used</th>	Clamp	Set the clamp when the chain is used		
012	Machine On/Off	Moving to start position of the 2nd origin by manual drive	013	067	Desel <th>Clamp</th> <th>Number of stitches to decelerate before ending work</th>	Clamp	Number of stitches to decelerate before ending work		
013	Machine On/Off	Moving to start position of the 2nd origin by manual drive	014	068	Trim <th>SPM</th> <th>Decelerating speed before ending work</th>	SPM	Decelerating speed before ending work		
014	Machine On/Off	Moving to start position of the 2nd origin by manual drive	015	069	Trim <th>Delay</th> <th>Thread trimming delayed time</th>	Delay	Thread trimming delayed time		
015	Machine On/Off	Moving to start position of the 2nd origin by manual drive	016	070	Low <th>Pressure</th> <th>Feed the plate of the low pressure detecting device</th>	Pressure	Feed the plate of the low pressure detecting device		
016	Machine On/Off	Moving to start position of the 2nd origin by manual drive	017	071	FF <th>Num</th> <th>Feed plate control</th>	Num	Feed plate control		
017	Machine On/Off	Moving to start position of the 2nd origin by manual drive	018	072	FF <th>PauseCtrl</th> <th>Upper feed plate control when paused</th>	PauseCtrl	Upper feed plate control when paused		
018	Machine On/Off	Moving to start position of the 2nd origin by manual drive	019	073	TH <th>Hold</th> <th>When to use thread tension adjusting plate after thread trimming</th>	Hold	When to use thread tension adjusting plate after thread trimming		
019	Machine On/Off	Moving to start position of the 2nd origin by manual drive	020	074	Upper <th>Clamp</th> <th>Back/forth jump stitches</th>	Clamp	Back/forth jump stitches		
020	Machine On/Off	Moving to start position of the 2nd origin by manual drive	021	075	Scale <th>Refer</th> <th>Setting reference point for zooming</th>	Refer	Setting reference point for zooming		
021	Machine On/Off	Moving to start position of the 2nd origin by manual drive	022	076	Palette <th>Chk</th> <th>Palette signal check</th>	Chk	Palette signal check		
022	Machine On/Off	Moving to start position of the 2nd origin by manual drive	023	077	Swing <th>Limit</th> <th>Sewing limit set-up</th>	Limit	Sewing limit set-up		
023	Machine On/Off	Moving to start position of the 2nd origin by manual drive	024	078	YPLUS <th>Limit</th> <th>X-axis forward direction swing limit set-up</th>	Limit	X-axis forward direction swing limit set-up		
024	Machine On/Off	Moving to start position of the 2nd origin by manual drive	025	080	YMINUS <th>Limit</th> <th>X-axis reverse direction swing limit set-up</th>	Limit	X-axis reverse direction swing limit set-up		
025	Machine On/Off	Moving to start position of the 2nd origin by manual drive	026	081	YPLUS <th>Limit</th> <th>X-axis forward direction swing limit set-up</th>	Limit	X-axis forward direction swing limit set-up		
026	Machine On/Off	Moving to start position of the 2nd origin by manual drive	027	082	YMINUS <th>Limit</th> <th>X-axis reverse direction swing limit set-up</th>	Limit	X-axis reverse direction swing limit set-up		
027	Machine On/Off	Moving to start position of the 2nd origin by manual drive	028	083	Quick <th>181</th> <th>Quick origin search motion selection for 181</th>	181	Quick origin search motion selection for 181		
028	Machine On/Off	Moving to start position of the 2nd origin by manual drive	029	084	HOOK/RC <th>MODE</th> <th>Quick origin search motion selection for 181</th>	MODE	Quick origin search motion selection for 181		
029	Machine On/Off	Moving to start position of the 2nd origin by manual drive	030	085	HEAD <th>End/Dts</th> <th>Up-Down Setting Function of Machine Head [SOS/C-Series]</th>	End/Dts	Up-Down Setting Function of Machine Head [SOS/C-Series]		
030	Machine On/Off	Moving to start position of the 2nd origin by manual drive	031	086	Reactive <th>Trim</th> <th>Set reverse rotation angles after trimming [SOS/B/C-Series]</th>	Trim	Set reverse rotation angles after trimming [SOS/B/C-Series]		
031	Machine On/Off	Moving to start position of the 2nd origin by manual drive	032	087	Reactive <th>Trim</th> <th>Set reverse rotation angles after trimming [SOS/B/C-Series]</th>	Trim	Set reverse rotation angles after trimming [SOS/B/C-Series]		
032	Machine On/Off	Moving to start position of the 2nd origin by manual drive	033	088	Oil <th>Control</th> <th>Oil spray cycle on/off-time setting (C-Series model)</th>	Control	Oil spray cycle on/off-time setting (C-Series model)		
033	Machine On/Off	Moving to start position of the 2nd origin by manual drive	034	089	Oil <th>Control</th> <th>Oil spray cycle on/off-time setting (C-Series model)</th>	Control	Oil spray cycle on/off-time setting (C-Series model)		
034	Machine On/Off	Moving to start position of the 2nd origin by manual drive	035	090	Save <th>Type</th> <th>Save Type Setting</th>	Type	Save Type Setting		
035	Machine On/Off	Moving to start position of the 2nd origin by manual drive	036	091	Save <th>Type</th> <th>Save Type Setting</th>	Type	Save Type Setting		
036	Machine On/Off	Moving to start position of the 2nd origin by manual drive	037	092	Save <th>Type</th> <th>Save Type Setting</th>	Type	Save Type Setting		
037	Machine On/Off	Moving to start position of the 2nd origin by manual drive	038	093	Save <th>Type</th> <th>Save Type Setting</th>	Type	Save Type Setting		
038	Machine On/Off	Moving to start position of the 2nd origin by manual drive	039	094	Auto <th>Ready</th> <th>Auto Ready</th>	Ready	Auto Ready		
039	Machine On/Off	Moving to start position of the 2nd origin by manual drive	040	095	Auto <th>Ready</th> <th>Auto Ready</th>	Ready	Auto Ready		
040	Machine On/Off	Moving to start position of the 2nd origin by manual drive	041	096	Auto <th>Ready</th> <th>Auto Ready</th>	Ready	Auto Ready		
041	Machine On/Off	Moving to start position of the 2nd origin by manual drive	042	097	Auto <th>Ready</th> <th>Auto Ready</th>	Ready	Auto Ready		
042	Machine On/Off	Moving to start position of the 2nd origin by manual drive	043	098	Auto <th>Ready</th> <th>Auto Ready</th>	Ready	Auto Ready		
043	Machine On/Off	Moving to start position of the 2nd origin by manual drive	044	099	ThreadEndTM <th></th> <th>Upper thread holder setting (Applied to SOS/C-Series only)</th>		Upper thread holder setting (Applied to SOS/C-Series only)		
044	Machine On/Off	Moving to start position of the 2nd origin by manual drive	045	100	ThreadEndTM <th></th> <th>Upper thread holder setting (C-Series AIR BAG model)</th>		Upper thread holder setting (C-Series AIR BAG model)		
045	Machine On/Off	Moving to start position of the 2nd origin by manual drive	046	101	ClampSensor <th></th> <th>Upper thread holding time setting (C-Series AIR BAG model)</th>		Upper thread holding time setting (C-Series AIR BAG model)		
046	Machine On/Off	Moving to start position of the 2nd origin by manual drive	047	102	ClampSensor <th></th> <th>Clamp sensor setting (C-Series AIR BAG model)</th>		Clamp sensor setting (C-Series AIR BAG model)		
047	Machine On/Off	Moving to start position of the 2nd origin by manual drive	048	103	Program <th>Lock</th> <th>Program mode lock</th>	Lock	Program mode lock		
048	Machine On/Off	Moving to start position of the 2nd origin by manual drive	049	104	Cmp <th>Per POS</th> <th>Semi-automatic removal of lower feed plate</th>	Per POS	Semi-automatic removal of lower feed plate		
049	Machine On/Off	Moving to start position of the 2nd origin by manual drive	050	105	upStop <th>Pos</th> <th>Set up the positions to stop the needle bar</th>	Pos	Set up the positions to stop the needle bar		
050	Machine On/Off	Moving to start position of the 2nd origin by manual drive	051						
051	Machine On/Off	Moving to start position of the 2nd origin by manual drive	052						
052	Machine On/Off	Moving to start position of the 2nd origin by manual drive	053						

Pattern programming : Generating the pattern that users want




Function number related to pattern programming		
0) TRIM	Trimming	
1) SEC-ORG	2nd origin	33) ARC DREV
2) PAUSE	Temporary suspension	34) CIRCLE DREV
3) EMPTY	One turn of sewing machine	35) LINE REV
4) JUMP	JUMP	36) CURVE REV
5) POINT	Point sewing	37) ARC REV
6) LINE/CURVE	Linear/Curving line sewing	38) CIRCLE REV
7) LINE	Linear sewing	39) PTRN DEL
8) CURVE	Spline sewing	40) BACK TACK
9) ARC	Arc sewing	41) CNDNS STI
10) CIRCLE	Circle sewing	42) OVLAP STI
11) JUMP SPD	Change of jump speed	43) SYMMETRY X
12) STI SPD	Change of stitching speed	44) SYMMETRY Y
13) STI WDT	Partial Sewing Stitch Width Change	45) SYMMETRY P
14) PTRN READ	Pattern data reading from floppy diskette	46) MOVE PTRN
15) PTRN WRITE	Pattern data writing to floppy diskette	47) COPY PTRN
16) FORMAT	Floppy diskette formatting	48) DEL PTRN
17) INFO DISP	Information indicating of present pattern data	49) REV SET
18) CORD SYS	Coordinates setting	50) SPD CHNG
19) LINE ZIG	Linear zig-zag sewing	51) STITCH DRAG
20) CURVE ZIG	Spline zig-zag sewing	52) STITCH DEL
21) ARC ZIG	Arc zig-zag sewing	53) MOV SEWSTRT
22) CIRCLE ZIG	Circle zig-zag sewing	54) MOV 2ndORG
23) LINE OFST	Linea offset sewing	55) Auto TRIM
24) CURVE OFST	Spline offset sewing	56) SCALE REFER
25) ARC OFST	Arc offset sewing	57) SET OP
26) CIRCLE OFST	Circle offset sewing	58) CHK IP
27) LINE DBL	Linear double sewing	59) TIME DELAY
28) CURVE DBL	Spline double sewing	
29) ARC DBL	Arc double sewing	
30) CIRCLE DBL	Circle double sewing	
31) LINE DREV	Linear double reverse sewing	60) SET TR3
32) CURVE DREV	Spline double reverse sewing	

7


EMERGENCY RECOVERY

1) Emergency Recovery When Problems Occur in Flash Memory

1-1) When the Flash Memory (D:\> Drive) is not recognized



1-2) When Pattern0.exe is deleted in Flash Memory (D:\> Drive)




2) User’s emergency self-restoration and operating program installation


Follow the order as below.




2-1) Flash Memory Formatting



2-2) Program Updating



2-3) Return to the initial program screen



SPECIAL FUNCTIONS

1) Auto Call Function

Description:

The function that a user can automatically call designs through the external input port can be added. In addition, the user can control the signals for Clamp, Emergency Switch, Enter Key, Sewing Start Pedal, and so on via the external input port.

This function is useful when the user desires it.

Therefore, since the specification is special, make sure to apply the function when there is a request only.

When using it, call for the assistance from Technical Assistant.

Take extra care to prevent the regular user from using this function.

This function is applicable to the machine types as below.

① Applicable Model

SPS/A/B - 1306, 1310, 1507, 1811, 2211, 2516,

SPS/A - 3020, 5030, 5034,

SPS/C - 5050, 8050

② Requirements for Application

In case of SPS/A/B-Series, the existing I/O board cannot be used since the number of external input ports is small. In this case, the I/O board of SPS/C-Series should be used.

In case of SPS/C-series, there is no need to change.

As such, when the special specifications are requested for SPS A/B series, make sure to replace its I/O board with the I/O Board of C-Series before release.

In some cases where the installation of SPS/C-Series' Operation Box is requested, the replacement can be conducted before release (To use the OP, lift Dip Switch 6 on the I/O board.)

③ Cautions for Application

The specification of the main shaft motor is FORTUNA-IV's main shaft motor. Previously, SANYO's main shaft motor was used. Therefore, the currently applied pattern's version is the integrated version which is applicable to both FORTUNA-IV and SANYO.

In order to use the two motors, the main shaft board's specification was changed to the integrated version.

If the user applies the Auto Call function in the prevision version, not the integrated version, he/she should replace the C-Series I/O board and ROM BIOS (not the integrated specifications).

When the integrated specification is applied, C-Series I/O Board and ROM BIOS(integrated version) need to be replaced.

In the event that the integrated specification version is applied when the Sanyo motor is used, replace the C-Series I/O Board, the main shaft board of the integrated board (apply the Jumper setting in line with the motor), and ROM BIOS of the integrated version.

④ Version Application

When using this function, the previous version ROM BIOS should be fully replaced.

(notified ROM BIOS versions by model)

To check out the version, see the version mark on ROM BIOS.

How to Use AUTO CALL (For SPS/A/B-Series)

Description : This is a function to call designs automatically. A total of 15 designs can be automatically called by using the four input sensors. It can be controlled by external inputs such as sewing start, emergency switch, clamp, and the enter key.

- In order to use the Auto Call function from SPS/A/B-Series, the existing I/O Board should be replaced with the I/O Board of SPS/C-Series. Otherwise, the function is unavailable.



The auto call cable is an optional item.
Please request the item when the function will be used.

1-1) Signal information related to input port connection

- ① External sensor's input signal list-up for design auto call

NO.	SEN_3	SEN_2	SEN_1	SEN_0	Design Number
1	0	0	0	1	900
2	0	0	1	0	901
3	0	0	1	1	902
4	0	1	0	0	903
5	0	1	0	1	904
6	0	1	1	0	905
7	0	1	1	1	906
8	1	0	0	0	907
9	1	0	0	1	908
10	1	0	1	0	909
11	1	0	1	1	910
12	1	1	0	0	911
13	1	1	0	1	912
14	1	1	1	0	913
15	1	1	1	1	914

※ For auto design call, an internal memory or a diskette must have the patterns from #900 to #906 saved.

- ② Definition and explanation of external input ports

Name	Input Port	Connector	Explanation
SEN_0	IP4.0	CN22	Sensor connection for auto call function (low active)
SEN_1	IP4.1	CN22	
SEN_2	IP4.2	CN22	
SEN_3	IP4.3	CN22	
Clamp	IP4.4	CN22	Clamp drive signal (low active)
Emergency S/W	IP4.5	CN22	Emergency stop switch signal (low active)
Sewing Start	IP4.6	CN22	Sewing start signal (low active)
Enter Key	IP4.7	CN22	Ready signal (low active)

③ Cables connected by user

Cable name	Product No.	Cable connecting position
(SPS/B, A-Series) Auto call function cable	CA-003043,00	CN22 on the I/O board
Adjacent sensor cable	CA-002857,00	SMR-03V-N of the auto call function cable

※ Connect the RA2611 connector of the auto call function cable to CN22 on the I/O board.

▶ See the 'Description on connector and jumper pin locations' below regarding the connector locations on the I/O board.


▶ See the cable specifications for cable connectors.

※ A total of 8 adjacent cables are used. Please request the desired number of adjacent sensor cables.

④ Cable signal input information


Signal name	Connector pin number (SMR-03V-N)	Description	Jumper pin for voltage change
SEN__0	1	+5V or +24V	BR1
	2	SEN__0	
	3	GND	
SEN__1	1	+5V or +24V	BR2
	2	SEN__1	
	3	GND	
SEN__2	1	+5V or +24V	BR3
	2	SEN__2	
	3	GND	
SEN__3	1	+5V or +24V	BR4
	2	SEN__3	
	3	GND	
CLAMP	1	+5V or +24V	BR5
	2	Clamp driving signal	
	3	GND	
EM-STOP	1	+5V or +24V	BR6
	2	Emergency stop signal	
	3	GND	
START	1	+5V or +24V	BR7
	2	Signal line for sewing start signal	
	3	GND	
ENTER	1	+5V or +24V	BR8
	2	Signal line for ready signal	
	3	GND	

⑤ Connector and jumper pin position



No.	Description	Remarks
①	Connector for signal input (CN 22)	Connecting the auto call function cable (connector: RA2611)
②	Jumper pin for changing signal input power	

⑥ Changing jumper for sensor input power change



- ▶ The input power supply to the sensor can be altered to +5V / +24V by changing the BR jumper at the upper left side of the I/O board.



The auto call function uses the adjacent sensor. Therefore connect the jumper pin to No. 2 and No. 3. (Jumper pins for change: BR1, BR2, BR3, BR4, BR5, BR6, BR7, BR8)
When changing the sensor specifications depending on the user needs, change the input power supply.

How to Use AUTO CALL (For SPS/C-5050,8050)

Description : This is a function to call designs automatically. A total of 15 designs can be automatically called by using the four input sensors. It can be controlled by external inputs such as sewing start, emergency switch, clamp, and the enter key.

► The description below is related to 5050 and 8050.



The auto call cable is an optional item.
Please request the item when the function will be used.

1-1) Signal information related to input port connection

① External sensor's input signal list-up for design auto call

NO.	SEN__2	SEN__1	SEN__0	Design Number
1	0	0	1	900
2	0	1	0	901
3	0	1	1	902
4	1	0	0	903
5	1	0	1	904
6	1	1	0	905
7	1	1	1	906

※ For design auto call, pattern numbers from 900 to 906 should be saved in the internal memory or diskette.

② Definition and description of external input ports

Signal name	Input port	Connector	Description
SEN__0	IP4.5	Sensor input connector	Sensor connection for auto call function (low active)
SEN__1	IP4.6		
SEN__2	IP4.7		
Clamp	IP3.4	CN16	Signal for clamp drive (low active)
Emergency S/W	IP3.5		Signal for emergency stop switch (low active)
Sewing Start	IP3.6		Signal for sewing start (low active)
Enter Key	IP3.7		Ready signal (low active)

③ Cables connected by user

Cable name	Product No.	Cable connecting location
(SPS/C-5050,8050) Auto call function cable	CA-003044,00	Connector on the rear PC box side for sensor input CN16 on the I/O board
Adjacent sensor cable	CA-002857,00	SMR-03V-N of the auto call function cable

※ Connect 1625-15Plug of the auto call function cable to the sensor input connector on the rear PC box.
Connect XHP-9 to CN16 on the I/O board.


- ▶ See 'Description on connector and jumper pin location' for the connector locations on the I/O board.
- ▶ See the cable specifications for cable connector.

※ A total of 7 adjacent sensor cables are used. Please request the desired number of the cables depending on user need.

④ Cable signal input information


Signal name	Connector pin number (SMR-03V-N)	Description	Jumper pin for voltage change
SEN__0	1	+5V or +24V	BR6
	2	SEN__0	
	3	GND	
SEN__1	1	+5V or +24V	BR7
	2	SEN__1	
	3	GND	
SEN__2	1	+5V or +24V	BR7
	2	SEN__2	
	3	GND	
CLAMP	1	+5V or +24V	BR8
	2	Clamp driving signal	
	3	GND	
EM-STOP	1	+5V or +24V	BR8
	2	Emergency stop signal	
	3	GND	
START	1	+5V or +24V	BR8
	2	Signal line for sewing start signal	
	3	GND	
ENTER	1	+5V or +24V	BR8
	2	Signal line for ready signal	
	3	GND	

⑤ Connector and jumper pin position



No.	Description	Remarks
①	Connector for sensor signal input	Connecting the auto call function cable (connector: 1625-15Plug)
②	Connector for signal input [CN16]	Connecting the auto call function cable (connector: XHP-9)
③	Jumper pin for changing sensor input power supply	

⑥ Changing jumper for sensor input power change



► The input power supply to the sensor can be altered to +5V / +24V by changing the BR jumper at the upper left side of the I/O board.

Caution

The auto call function uses the adjacent sensor. Therefore connect the jumper pin to No. 2 and No. 3. (Jumper pins for change: BR6, BR7, BR8)

When changing the sensor specifications depending on the user needs, change the input power supply.

1-2) Function description upon using the operating program

If the external input sensor signals explained above are properly connected, the user can automatically call the designs from #900 to #914 with the sensor signal, and it is possible to use Sewing Start, Clamp, Enter Key, and Emergency Switch.

To use the function, some parameter functions should be set in advance.

The following is how to set the functions.

A. On the initial screen, press **MODE**. On Main Menu, select Parameter Set.

Parameter should be set to use the auto design call function.

The relevant parameter setting is as follows:

097. Auto Call : Set the auto design call function.

098. Auto Ready : Set the auto ready function after calling a design.

099. Attach Set : Determine whether to use Sewing Start, Clamp, Enter Key, and Emergency Switch or not.

B. Select '097. Auto Call' and move the cursor to 'ENABLE'. Press ENTER.

C. Conduct the setting for 098 and 099 as above.

D. When the sewing returns to the initial mode, "NOR__SEW" is changed to "AUTCALL."

E. Use the external input sensor connected by the user.

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

```
< Parameter Set >
097.Auto Call
098.Auto Ready
099.Attach Set
```

```
097.Auto Call
1) DISABLE
2) ENABLE      <-
3) BARCDE
```

```
NO:001      AUTCALL
XS:100%
YS:100%     SP:2500
BC:014      PC:0058
```

2) Design auto call through handy barcode

The function enables automatic design call using the commercial barcode system, which provides various barcode specifications based on diverse formats. However, among the formats, only those with applicable specifications can be used.

There are various types of barcode reading system. As long as they are compatible, they can be used. If barcode types are different, they may not be recognized. Therefore, users are recommended to use the barcode systems provided by the company.

■ Barcode System Specifications

NO.	Item	Description
1	Scanning Method	Fixed or Handy Type
2	Communication Type	RS-232C
	Communication Speed (Baud Rate)	9600 bps
3	Barcode Type	CODE39 CODE93 CODE128
4	Barcode Command Details	0001~0999 (4 digits) - 000000000001~000000000999(12 digits)
5	Recommended Products	Metrologic MS5100 Eclipse Series

■ System Connection

The figure shows the system connection of Metrologic MS5100 Eclipse Series. The serial port of barcode is inserted into the serial port on the side of the OP Box.

The barcode label below is CODE39 and its barcode command is A003. A003 recognizes design number 003, and since up to three numerical digits can be recognized all the time, character information such as "A" is ignored in reading.

The production of barcode label requires dedicated software and a barcode label printer. They are commercial products, so that user can purchase them in the market. For more inquiries, please contact the sales team.



Before use, some parameters should be set up. The setting details are as follows:

(Except for the barcode setting function, it is same to the existing AutoCall function.)

- A. Press the MODE key on the initial screen and select Parameter Set on the Main Menu.
The following is related to setting parameters for design auto call.

The parameters below needed to be set.

097. Auto Call : Sets automatic design call using barcodes.

098. Auto Ready : Sets automatic sewing ready status after design call.

099. Attach Set : Sets enable or disable of sewing start, clamp, and enter key.

100. AutoCall TM : Sets the lapse time of input sensor upon design auto call.
(This function is meaningless in the barcode system.)

```
<< Main Menu >>
1. Parameter Set
2. Program
3. Bobbin Wind
```

```
<Parameter Set>
097.Auto Call
098.Auto Ready
099.Attach Set
```

- B. Select 097. Auto Call, and move the cursor to BARCODE. Press the enter key to save the value.

- C. Set 098, 099 depending on situations.

- D. When the sewing returns to the initial mode, user can check that "NOR__SEW" is changed to "BARCODE".

```
097.Auto Call
1) DISABLE
2) ENABLE
3) BAR CODE  <-
```

- E. If a barcode device is used and barcode labels are scanned, the design numbers are automatically converted. As such, designs can be automatically read.

Reference) When the barcode-based auto call function is used, if user uses the pedal and enter key manually as of in the regular sewing mode (NOR__SEW), the motions activated by the pedal and enter key might be a bit delayed.

```
NO : 001    BARCODE
XS : 100%
YS : 100%   SP:2500
BC : 014    PC:0058
```

Parameter save function

This function enables user to save user-defined parameter data in external storage devices (FDD) while using the pattern device.

The parameter data saved in external storage devices (FDD) can be used to replace the current parameter data all the time.



Caution

When using the parameter data saved in external storage device (FDD), the parameter data of the current device is replaced with the parameter data of external storage device (FDD).

1) Parameter Write

This is how to save changed parameters in line with user setting in external storage device.
The procedures are as follows:

- A. Press the **MODE** key on the initial screen and select Initialize on the main menu.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```

- B. Select No.3 **Ptrn Para.**

Then the Select Mode screen is displayed.
To write parameter data, select 0. Write.

```
<< Initialize >>
1. Para. Init
2. Sys. UpData
3. Ptrn Para
```

- C. Select 0 on the keypad.

- D. Ready LED blinks, and the device's data is saved in the external storage device (FDD).
Data is automatically saved in the set route as below:

```
<< Select Mode >>
Write(0)
Read(1)
To Exit(ESC)...
```

FDD route) A:\\SPS\\\\PARAM

2) Parameter Read

This is how to replace the revised parameter data in the pattern device with the parameter data saved in the external storage device. The procedures are as follows.

The procedures are as follows:

- A. Press the **MODE** key on the initial screen and select Initialize on the main menu.

```
<< Main Menu >>
0. Initialize
1. Parameter Set
2. Program
```

- B. Select No.3 **Ptrn Para**.

Then the Select Mode screen is displayed.
To read parameter data, select 1. Read.

```
<< Initialize >>
1. Para. Init
2. Sys. UpData
3. Ptrn Para
```

- C. Select No. 1 on the key pad.

```
<< Select Mode >>
Write(0)
Read(1)
To Exit(ESC)...
```

- D. Ready LED blinks, and the parameter data saved in the device is replaced with the parameter data saved in the external device (FDD).