




# Inverting Clamp Devices Mechanism ( SPS/A-1306 Series )




| REF<br>No. | Part no.                       | Part name                                       | Q'ty                 |
|------------|--------------------------------|-------------------------------------------------|----------------------|
| A-000      | 52A040S-306H                   | INVERTING CLAMP ASS'Y                           | <input type="text"/> |
| A-001      | 52A001S-306H<br>->CCP-BB009500 | BASE                                            | <input type="text"/> |
| A-002      | 52A002S-306H<br>->CCP-CB000100 | CRANK                                           | <input type="text"/> |
| A-003      | SC-0323-7900<br>->DSC-BJ004800 | NEEDLE BAR TURNING STAY BLOCK SCREW (1/8",N=40) | <input type="text"/> |
| A-004      | 11-017W-2700<br>->PWS-AA000500 | FLAT WASHER                                     | <input type="text"/> |
| A-005      | 52A005S-306H<br>->CCP-BA001500 | INVERTING CRANK BASE                            | <input type="text"/> |
| A-006      | SC-0524-2302<br>->DSC-BF022200 | FEED ADJUST GUIDE PLATE SCREW(1/8" N=44)        | <input type="text"/> |
| A-007      | 52A007S-306H<br>->DGR-AF001500 | INVERTING RACK                                  | <input type="text"/> |
| A-008      | 52A008S-306H<br>->CCP-BA001600 | INVERTING SUPPORT BASE                          | <input type="text"/> |
| A-009      | 52A009S-306H<br>->CCP-BB010100 | PRESSER PLATE BASE                              | <input type="text"/> |
| A-010      | 52A010S-306H<br>->CCP-BJ005300 | FEED FRAME (A)                                  | <input type="text"/> |
| A-011      | 52A011S-306H<br>->CCP-BJ005400 | FEED FRAME (B)                                  | <input type="text"/> |
| A-012      | SC-0525-5300<br>->DSC-BF000900 | MES DRIVING LINK SHAFT CAP SCREW(11/64" N=40)   | <input type="text"/> |
| A-013      | 10-020W-2700<br>->DWS-AA000600 | WASHER                                          | <input type="text"/> |
| A-014      | 52A014S-306H<br>->CCP-BB010200 | PRESSER PLATE GUIDE"A"                          | <input type="text"/> |
| A-015      | 52A015S-306H<br>->CCP-BB010300 | PRESSER PLATE GUIDE"B"                          | <input type="text"/> |
| A-016      | 10-057S-2077<br>->DSC-BF001400 | SCREW(9/64", N=40)                              | <input type="text"/> |
| A-017      | 52A017S-306H<br>->CCP-BB010000 | INVERTING CYLINDER BRACKET                      | <input type="text"/> |
| A-018      | SC-0548-7400<br>->DSC-BF000600 | DIAL PLATE SCREW (3/16",N=28)                   | <input type="text"/> |

|       |                                |                            |                          |
|-------|--------------------------------|----------------------------|--------------------------|
| A-019 | 52A019S-306H<br>->PPP-CA005900 | SYLINDER                   | <input type="checkbox"/> |
| A-020 | 09A029S-811H<br>->CCP-BM000900 | INVERTING CYLINDER KNUCKLE | <input type="checkbox"/> |
| A-021 | 09A030S-811H<br>->DSC-FK000100 | SCREW                      | <input type="checkbox"/> |
| A-022 | 49A003S-811H<br>->PPP-AA000100 | HOSE ELBOW                 | <input type="checkbox"/> |
| A-023 | 05A139S-811H<br>->PPP-AD001000 | HOSE @4 (YELLOW)           | <input type="checkbox"/> |



# Inverting Clamp Devices Mechanism ( SPS/A-1811 Series )




| REF No. | Part no.                       | Part name                         | Q'ty                 |
|---------|--------------------------------|-----------------------------------|----------------------|
| B-001   | 09A017S-811H<br>->CCP-CB000300 | INVERTING CRANK                   | <input type="text"/> |
| B-002   | 09A026S-811H<br>->DGR-AF001600 | INVERTING RACK                    | <input type="text"/> |
| B-003   | 09A021S-811H<br>->CCP-BJ006200 | INVERTING PRESSER PLATE"B"        | <input type="text"/> |
| B-004   | 09A011S-811H<br>->CCP-BJ005800 | INVERTING CLAMP SPACER            | <input type="text"/> |
| B-005   | 09A010S-811H<br>->CCP-BB010500 | INVERTING CLAMP                   | <input type="text"/> |
| B-006   | SC-0183-2700<br>->DSC-BF000700 | BASE FIXING SCREW(15/64" N=28)    | <input type="text"/> |
| B-007   | 22A043S-811H<br>->DSC-AA000500 | SCREW FOR FEED PLATE CLAMP B      | <input type="text"/> |
| B-008   | 06-102W-2350<br>->DWS-AA001500 | WASHER                            | <input type="text"/> |
| B-009   | SC-0508-1230<br>->DSC-CA001500 | PULLEY FIXING SCREW (15/64",N=28) | <input type="text"/> |
| B-010   | SN-0121-7400<br>->DSN-AA000700 | NUT(15/64" N=28)                  | <input type="text"/> |
| B-011   | 09A125S-811H<br>->CCP-LB000400 | COVER                             | <input type="text"/> |
| B-012   | SC-0158-3710<br>->DSC-BF010100 | SCREW FOR FACE PLATE (9/64",N=40) | <input type="text"/> |
| B-013   | 09A014S-811H<br>->DSC-BF019700 | SCREW                             | <input type="text"/> |
| B-014   | 52A008S-811H<br>->PBR-BA002500 | NEEDLE BEARLING (KT 7108N)        | <input type="text"/> |
| B-015   | 09A015S-811H<br>->PBR-BA002600 | NEEDLE BEARING                    | <input type="text"/> |
| B-016   | 09A116S-811H<br>->DWS-AA029500 | INVERTING CRANK WASHER            | <input type="text"/> |
| B-017   | 09A118S-811H<br>->CCP-BA001800 | INVERTING SUPPORT BASE"A"         | <input type="text"/> |
| B-018   | 09A119S-811H<br>->CCP-BA001900 | INVERTING SUPPORT BASE            | <input type="text"/> |

|       |                                |                                                         |                          |
|-------|--------------------------------|---------------------------------------------------------|--------------------------|
| B-019 | 01-017W-1600<br>->DWS-AA001100 | WASHER                                                  | <input type="checkbox"/> |
| B-020 | SC-0200-3800<br>->DSC-BH000500 | FEED ROCK SHAFT FIXING SCREW(11/64" N=40)               | <input type="checkbox"/> |
| B-021 | 09A020S-811H<br>->CCP-BJ006100 | Inverted platen                                         | <input type="checkbox"/> |
| B-022 | 09A021S-811H<br>->CCP-BJ006200 | INVERTING PRESSER PLATE"B"                              | <input type="checkbox"/> |
| B-023 | 09A022S-811H<br>->CCP-BJ006300 | Inverted platen                                         | <input type="checkbox"/> |
| B-024 | SC-0120-1230<br>->DSC-BA000100 | SCREW FOR OIL PUMP COVER(9/64",N=40)                    | <input type="checkbox"/> |
| B-025 | 09A023S-811H<br>->DSC-BB006200 | SCREW                                                   | <input type="checkbox"/> |
| B-026 | 09A029S-811H<br>->CCP-BM000900 | INVERTING CYLINDER KNUCKLE                              | <input type="checkbox"/> |
| B-027 | 09A030S-811H<br>->DSC-FK000100 | SCREW                                                   | <input type="checkbox"/> |
| B-028 | 09A027S-811H<br>->CCP-BB010600 | INVERTING CYLINDER BRACKET                              | <input type="checkbox"/> |
| B-029 | SC-0151-5050<br>->DSC-BA000800 | FIXING SCREW FOR CUTTING ADGE PRESSER IRON(15/64" N=28) | <input type="checkbox"/> |
| B-030 | 09A028S-811H<br>->PPP-CA006000 | INVERTING CYLINDER ASS'Y                                | <input type="checkbox"/> |
| B-031 | 49A003S-811H<br>->PPP-AA000100 | HOSE ELBOW                                              | <input type="checkbox"/> |
| B-032 | 05A039S-811H<br>->PPP-AD000100 | HOSE(@4)                                                | <input type="checkbox"/> |
| B-033 | 09A031S-811H<br>->CCP-BB010700 | FEED PLATE CLAMP                                        | <input type="checkbox"/> |
| B-034 | 22A043S-811H<br>->DSC-AA000500 | SCREW FOR FEED PLATE CLAMP B                            | <input type="checkbox"/> |
| B-035 | GP-013524-00                   | LOWER FEED PLATE(INVERTING)                             | <input type="checkbox"/> |
| B-036 | 09A037S-811H<br>->CGA-GK002700 | UPPER FEED PLATE                                        | <input type="checkbox"/> |
| B-037 | 09A032S-811H<br>->CCP-BB010800 | LABEL GUIDE(A)                                          | <input type="checkbox"/> |
| B-038 | 09A033S-811H<br>->CCP-BJ005900 | LABEL GUIDE(B)                                          | <input type="checkbox"/> |

|              |                                |                                                 |                                                                                     |
|--------------|--------------------------------|-------------------------------------------------|-------------------------------------------------------------------------------------|
| <b>B-039</b> | 09A034S-811H<br>->CCP-BJ006000 | LABEL GUIDE(C)                                  |  |
| <b>B-040</b> | 09A035S-811H<br>->CCP-MG000100 | LABEL GUIDE                                     |  |
| <b>B-041</b> | SC-0543-2302<br>->DSC-BJ000200 | TOP COVER PLATE HINGE FIXING SCREW(11/64" N=40) |  |
| <b>B-042</b> | 01-017W-1600<br>->DWS-AA001100 | WASHER                                          |  |



## Wiper & Preeser Foot Mechanism




| REF<br>No. | Part no.                       | Part name                                          | Q'ty                 |
|------------|--------------------------------|----------------------------------------------------|----------------------|
| C-001      | 11S036S-306H                   | WIPER ON/OFF SWITCH ASS'Y                          | <input type="text"/> |
| C-002      | 09A004S-811H<br>->CWP-LA000200 | WIPER COVER                                        | <input type="text"/> |
| C-003      | SC-0543-2302<br>->DSC-BJ000200 | TOP COVER PLATE HINGE FIXING SCREW(11/64" N=40)    | <input type="text"/> |
| C-003-01   | 01-017W-1600<br>->DWS-AA001100 | WASHER                                             | <input type="text"/> |
| C-004      | 09A005S-811H<br>->CWP-BB000200 | WIPER BASE                                         | <input type="text"/> |
| C-005      | SC-A174-4122<br>->DSC-BF001000 | SCREW(11/64" N=40)                                 | <input type="text"/> |
| C-006      | 09A001S-811H<br>->PSD-AB000100 | WIPER SOLENOID ASS'Y                               | <input type="text"/> |
| C-008      | 09A006S-811H<br>->CWP-CB000200 | WIPER CRANK                                        | <input type="text"/> |
| C-009      | 07S033S-306H<br>->PSC-AC000300 | SHUTTLE DRIVE SCREW                                | <input type="text"/> |
| C-010      | 06-146W-7400<br>->DWS-AA001200 | WASHER FOR FEED BAR SHAFT                          | <input type="text"/> |
| C-011      | 09A007S-811H<br>->CWP-CA000400 | ROD                                                | <input type="text"/> |
| C-012      | SC-000382-00<br>->DSC-FA001200 | SCREW FOR PRESSER FOOT LINK(C) 811H                | <input type="text"/> |
| C-012-01   | GP-007765-00<br>->DSC-FA001100 | STUD SCREW FOR WIPER 1254                          | <input type="text"/> |
| C-013      | 09A008S-811H<br>->CWP-CM000100 | PLATE                                              | <input type="text"/> |
| C-014      | 09A009S-811H<br>->CWP-BJ000200 | WIPER                                              | <input type="text"/> |
| C-015      | 40-004W-1600<br>->DWS-AA000500 | WASHER                                             | <input type="text"/> |
| C-016      | SC-0502-2302<br>->DSC-BJ001400 | UPPER COVER FIXING PLATE FIXING SCREW (9/64",N=40) | <input type="text"/> |
| C-017      | 52A020S-306H<br>->GP-019553-00 | EMERGENCY SWITCH(SRM20R11)                         | <input type="text"/> |
| C-018      | 09A003S-811H<br>->CGA-GC000200 | PRESSER FOOT                                       | <input type="text"/> |

|       |                                |                                  |                                                                                     |
|-------|--------------------------------|----------------------------------|-------------------------------------------------------------------------------------|
| C-019 | 20S075S-306H<br>->PWS-AA000200 | WASHER                           |  |
| C-020 | 09A036S-811H<br>->DSC-FA001000 | WIPER STOPPER STUD SCREW         |  |
| C-021 | 06-040R-106L<br>->CFA-FZ000200 | STOPPER RUBBER FOR REVERSE LEVER |  |



# Pneumatic Control Mechanism ( SP5/A-1306 Seires )



| REF No.  | Part no.                       | Part name                    | Q'ty                 |
|----------|--------------------------------|------------------------------|----------------------|
| D-000    | 1306-HS-23                     | PNEUMATIC ASS'Y A-1306-HS-23 | <input type="text"/> |
| D-001    | 49A001S-811H<br>->PPP-AB000200 | SPEED CONTROLLER             | <input type="text"/> |
| D-002    | 05A052S-811H<br>->PPP-AD000200 | URETHANE HOSE(@6)            | <input type="text"/> |
| D-003    | 52A026S-306H<br>->PPP-BD000200 | REGULATOR                    | <input type="text"/> |
| D-004    | 49A011S-811H<br>->PPP-AA000400 | TEE KQ2Y06-02S               | <input type="text"/> |
| D-005    | 49A014S-811H<br>->PPP-AA000300 | ELBOW UNION (KQ2L06-01S)     | <input type="text"/> |
| D-007    | 01S107S-306H<br>->PWS-AA000400 | WASHER(D=10,D'=5.3,T=1)      | <input type="text"/> |
| D-008    | 49A009S-811H<br>->PSN-AA000700 | NUT(M5*P0.8 L=3.5)           | <input type="text"/> |
| D-009    | 22A046S-306H<br>->PPP-BA000400 | SOLENOID VALVE SY3120-5LZ-M5 | <input type="text"/> |
| D-010    | 49A018S-811H<br>->PSC-DC000100 | SCREW(M4 L=35)               | <input type="text"/> |
| D-011    | 49A019S-811H<br>->PPP-BB000100 | MANIFOLD BLOCK SS5Y3-20-02   | <input type="text"/> |
| D-012    | 22A047S-811H                   | AIR TUBE LABEL               | <input type="text"/> |
| D-012-01 | 22A048S-811H<br>->CMB-LD007900 | AIR TUBE LABEL               | <input type="text"/> |
| D-013    | 22A049S-811H<br>->CMB-LD008000 | AIR TUBE LABEL               | <input type="text"/> |
| D-013-01 | 22A050S-811H<br>->CMB-LD008100 | AIR TUBE LABEL               | <input type="text"/> |
| D-014    | 49A015S-811H<br>->PPP-AA000200 | HOSE NIPPLE M-5H-4           | <input type="text"/> |
| D-015    | 49A020S-811H<br>->PPP-BC000100 | SILENCER ASS-01              | <input type="text"/> |