

SIRUBA
PARTS LIST

Series
HF008

Parts Group
HA


Subclass / Remark


Page

1/2

Date


2013/08/13






SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HB		1/2
				Date
				2012/08/25

(FOR 2.3 NEEDLE USE)



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HB		2/2
				Date
				2012/08/25


(FOR 4 NEEDLE USE)




A + B = HB02-A
 HA HB

HB02-A


SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HC		1/1
				Date
				2012/08/25




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HD		1/2
				Date
				2015/11/02




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HD		2/2
				Date
				2012/08/25




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HE		1/4
				Date
				2013/08/30



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HE		2/4
				Date
				2012/09/17



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HE		3/4
				Date
				2015/09/21




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HE		4/4
				Date
				2012/08/25

Exploded view diagram of the HF008 HE assembly. The diagram shows various components labeled with part numbers and assembly letters (A, B, C, D, E). Key sub-assemblies are highlighted with dashed boxes: HE27-C, HE27-E, HE38-E, HE38-C, HE13P-E, HE06Q-E, HE22R, HE21Q, HE22Q, HE07C-C, HE07C, and HE20D-E. Components include brackets, pins, rollers, and structural parts. Assembly letters A through E indicate the sequence of assembly steps.


SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HF		1/1
				Date
				2013/12/16

1 2 3 4 5

SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HJ		1/1
				Date
				2012/08/25




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HK		1/2
				Date
				2012/08/25




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HK		2/2
				Date
				2012/08/25


HK01-A




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HL		1/1
				Date
				2012/08/25

















SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HN		1/2
				Date
				2015/11/06




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HN		2/2
				Date
				2015/11/06




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HY		1/2
				Date
				2012/08/27
A	KY02F-A 油 罐	KY03 油 壺	KY04 漏 斗	KY23(6/7mm) 內六角開口板手
				
	KY09 開口板手	MY09 六角板手	MY08 六角板手	MY10 六角板手
				
B	MY12 六角板手	KY11 六角板手	KY14 內六角螺絲起子	KY17 一字起子
				
	KY18 鑷 子	KY20D 腳踏板	KT14 濾油器	KY201 工具袋
				
C	KY21-1 鉤 子	KZ03 乾燥劑	HY04 零件圖	HY02 使用說明書
				
	MY21 鍊條			
				
D				
E				

SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	HF008	HY		2/2
				Date
				2012/10/29



SIRUBA TABLE CUT - OUT	Series	Item Code	Subclass Remark	Mounting
	HF008	HF008-T3		Fully-submerged
				Date
				2012/11/08




SIRUBA
TABLE
CUT - OUT

Series
HF008

Item Code
HF008-T4

Subclass Remark
For FBQ

Mounting
Semi-submerged
Date
2012/11/08



單位 / UNIT : mm
所有尺寸公差 / TOLERANCE : ±2
長度 (L) : 1070 / 重量 (W) : 11.5kg ± 5%
長度 (L) : 1200 / 重量 (W) : 12.5kg ± 5%