

Bottom Hemming Automat

JTR-MF7923/BHA Series

PARTS LIST



No.JTR000
MF7923BHA-SP

HOW TO MAKE USE OF THIS PARTS LIST

1. Explanation of codes

- 1) "*" mark means this part is consumption part.
- 2) "#01 " refer to "Note" explanation at bottom of page.
- 3) "☆" means this part is replaced from Juki Original part to Jtron Original part.

2. Codes on the "Qty" column


- Each numeral indicates the number of parts required.
- "0.1" and "2.5" indicate the length (in meters) of the respective parts.

3. Parentheses mean that the corresponding part is a subpart that constructs an assembly part.

4. Dotted lines on the Figures indicate assembly parts.


CONTENTS

1. CHASSIS GROUP	1
2. STACKING CHASSIS GROUP	3
3. STACKING HOLDER PROFILE GROUP	5
4. TENSION CONTROL UNIT WITH STEP MOTOR	7
5. TENSION CONTROL UNIT	9
6. ROLLER GROUP	11
7. KNIFE GROUP	13
8. ATTACHMENT GROUP	15
9. FABRIC TRANSPORT GROUP	17
10.ADDITIONAL SENSING GROUP	19
11.THREAD STAND	21
12.OPERATING PANEL	22
13.FABRIC TRANSPORT GUARD	24
14.KNIFE GROUP COMPLETE ASSEMBLY	26
15. ELECTRICAL PANEL GROUP	28
16.ACCESSORY (equipment-related accessories)	30




Note	Parts No.	Description	Qty
	BH-7923-01-001	CHASIS FRAME GROUP	1
	SP-0300000-01	EDGE CONNECTION	28
	SP-0200000-01	NUT WITH SPRING	89
	VD-6061602-TP	SCREW	84
	BH-7923-01-005	UPPER TABLE CHASSIS CONNECTION ATTACHMENT	8
	BH-7923-01-006	WHEEL CONNECTION ATTACHMENT	2
	SP-0200000-04	NUT WITH SPRING	8
	VD-6081602-TP	SCREW	8
	BH-7923-01-009	FOOT CONNECTION ATTACHMENT	4
	HR-1000000-02	STABILIZING BASE	4
	HR-1400000-01	WHEEL	4
	BH-7923-01-012	WHEEL CONNECTION BRACKET 02	2
	VD-6062002-TM	SCREW	4
	BH-7923-01-014	SWITCH CONNECTION SHEET	1
	BH-7923-01-015	REAR COVER	1
	BH-7923-01-016	TRASH BIN COVER	1
	BH-7923-01-017	SMBDN COVER	1
	BH-7923-01-018	FRONT COVER	1
	BH-7923-01-019	PEDAL COVER	1
	BH-7923-01-020	TABLE	1
	BH-7923-01-021	HEAD STABILIZING SOLE	1
	BH-7923-01-022	STABILIZING SCREW	4
	BH-7923-01-023	PEDAL CONNECTION BRACKET	4
	BH-7923-01-024	SENSOR CONNECTION EDGE BAND	1
	BH-7923-01-025	STACKING AIR & CURRENT CONNECTION EDGE BAND	1
	PL-ASD125-10	WASHER	6
	HR-1800001-01-01	PEDAL	1
	HR-1800001-01-02	CONNECTION SWITCH	1
	HR-1800001-01-03	CONNECTION PIPE	4
	HR-1800001-01-04	STACKING AIR EDGE BAND AND ELECTRIC EDGE BAND	1
	HR-1800001-01-05	EFKA PEDAL	1
	HR-0900000-01	JUNTURE	1
	BH-7923-01-033	PROFILE COVER	1
	BH-7923-01-034	HEAD STABILIZER 1	4
	BH-7923-01-035	HEAD STABILIZER 2	1
	BH-7923-01-036	HEAD STABILIZER 3	1
	EL-0400000-02	SWITCH	1
	VD-6042002-TP	SCREW	1
	HR-1100000-01	HINGE	3
	HR-1700000-01	LOCK	3
	PN-0100000-02	REGULATOR	4
	PN-0100000-03	CONDITIONER	9
	EL-0600000-08	SENSOR	8
	VD-6041002-TP	SCREW	16
	PL-0430800-KM	NUT	2
	VD-6102502-TM	PEDAL	1
	VD-6051202-TP	SCREW	9
	VD-1061602-TM	SCREW	8
	VD-1051202-TM	SCREW	16
	SM-6120000-SM	NUT	2

2. STACKING CHASSIS GROUP




No.	Note	Parts No.	Description	Qty
1		BH-7923-02-001	STACKING CHASSIS GROUP	1
2		VD-6061602-TM	SCREW	26
3		VD-6081602-TM	SCREW	82
4		SP-0200000-05	NUT WITH SPRING	27
5		LR-35120550-C	LINEAR RAIL	1
6		BH-7923-02-001	UPPER TABLE	1
7		BH-7923-02-002	MOVING TABLE	1
8		BH-7923-02-007	L CONNECTION BRACKET	8
9		SP-0200000-07	NUT WITH SPRING	87
10		SP-0300000-02	PROFILE STABILIZING EDGE BAND	20
11		BH-7923-02-008	T CONNECTION	2
12		BH-7923-02-010	STACKING ARM STABILIZING BLOCK	1
13		BH-7923-02-011	STACKING ARM MOVEMENT SHAFT	1
14		BH-7923-02-009	STACKING T CONNECTION	2
15		BH-7923-02-013	STACKING CONNECTION BLOCK	1
16		BH-7923-02-014	CYLINDER PIN	1
17		BH-7923-02-015	FABRIC HOLDER BAND	1
18		PL-0841600-KM	WASHER	2
19		VD-6061202-TP	SCREW	1
20		VD-6052002-TP	SCREW	1
21		VD-6083502-TP	SCREW	2
22		VD-6082002-TP	SCREW	2
23		BH-7923-02-012	STACKING ARM CONNECTION YOKE	1
24		BH-7923-02-003	STACKING ARM	1
25		BH-7923-02-017	PISTON TABLE CONNECTION EDGE BAND	1
26		RL-0100000-04	BEARING	2
27		PN-0400000-04	CYLINDER	2
28		PN-0500000-05	SHANK	1
29		LA-01000000-C	LINEER GUIDEWAY	1
30		HR-0200000-01	STABILIZING SCREW	2
31		SP-0200000-04	NUT WITH SPRING	2
32		PN-0600000-16	AIR ELBOW	4
33		SM-6200000-SM	NUT	2
34		VD-1063002-TM	SCREW	4
35		PN-0500000-07	CYLINDER FORK CONNECTION	1
36		BH-7923-01-007	FOOT CONNECTION ATTACHMENT	4
37		HR-1000000-02	STABILIZING BASE	4
38		PN-0800000-03	DOUBLE VALVE PLATE	1
39		PN-0300000-03	VALVE	2
40		LA-01000000-C	LINEAR GUIDEWAY	1
41		LR-35120550-C	LINEAR RAIL	1
42		SP-0200000-05	NUT WITH SPRING	

3. STACKING HOLDER PROFILE GROUP




No.	Note	Parts No.	Description	Qty
1		BH-7923-03-001	STACKING HOLDER PROFILE GROUP	1
2		SP-03000000-01	EDGE CONNECTION	1
3		SP-02000000-01	NUT WITH SPRING	1
4		VD-6061602-TM	SCREW	1
5		BH-7923-03-002	FABRIC HOLDER	2
6		BH-7923-03-003	FABRIC HOLDER BRACKET	2
7		PL-ASD125-6	WASHER	1
8		BH-7923-01-025	PROFILE CAP	4
9		VD-6062502-TP	SCREW	1

4. TENSION CONTROL UNIT WITH STEP MOTOR




No.	Note	Parts No.	Description	Qty
1		BH-7923-04-001	STRECHING GROUP CONNECTION PLATE	1
2		EL-0100000-05	STEP MOTOR	1
3		BH-7923-04-003	STEP MOTOR CONNECTION BRACKET	1
4		BH-7923-04-004	INFINITE SHAFT BASE	1
5		BH-7923-04-005	TRANSPORT GROUP BRAKET	1
6		RL-0100200-05	BEARING	1
7		SC-01120586-01	BALL SCREW SHAFT	1
8		SF-0112000-03	NUT BLOCK	1
9		SF-0100000-01	BALL SCREW NUT	1
10		HR-0912000-01	COUPLING	1
11		VD-6042502-TP	SCREW	4
12		VD-6041602-TP	SCREW	2
13		VD-ASI4762-4 16	SCREW	16
14		VD-6042002-TP	SCREW	5
15		LR-15120550-A	LINEAR RAIL	2
16		VD-6052002-TP	SCREW	8
17		VD-6031602-TP	SCREW	20
18		VD-6043502-TP-20	SCREW	8
19		VD-6061602-TP	SCREW	1
20		LA-0200000-0A	LINEAR GUIDEWAY	3
21		VD-6051602-TP	SCREW	4
22		LR-15120250-A	LINEAR RAIL	1
23		BH-7923-04-023	PISTON CONNECTION ATTACHMENT	1
24		BH-7923-04-024	PISTON CONNECTION SHAFT	1
25		PN-0600000-29	AIR CYLINDER	1
26		PN-0600000-25	SPHERICAL SHANK	1
27		PN-0600000-30	ELBOW	2
28		SG-0390602-K0	RETAINING RING	1
29		VD-6082002-TP	SCREW	4
30		PL-0841600-KM	WASHER	4
31		SP-0200000-04	NUT WITH SPRING	4
32		VD-8050802-TP	SET SCREW	2
33		HR-0200000-02	BAKALITE ARM	1

5. TENSION CONTROL UNIT




No.	Note	Parts No.	Description	Qty
26		EL-0100000-05	STEPPING MOTOR	1
27		VD-6051202-TP	SCREW	4
28		BH-7923-05-028	STRECHING LOWER ARM CONNECTION	1
29		BH-7923-05-029	STRECHING ARM MIDDLE CONNECTION	1
30		BH-7923-05-030	STRECHING ARM UPPER CONNECTION	1
31		BH-7923-05-031	STEP MOTOR BLOCK	1
32		BH-7923-05-032	FABRIC OPENNING UNIT SHAFT	1
33		BH-7923-05-033	BLOCK CAP	1
34		VD-6061202-TP	SCREW	4
35		VD-6041202-TP	SCREW	4
36		VD-8051002-TP	SET SCREW	2
37		PL-0841600-KM	NUT	1
38		VD-6081602-TP	SCREW	1
39		PN-0600000-28	AIR REDUCING ADJUSTMENT	1
40		BH-7923-05-040	STEP MOTOR TRANSMITTING SHAFT	1
41		BH-7923-05-041	REAR ARM ALUMINUM ROLLER	1
42		BH-7923-05-042	FABRIC OPENNING ROLER	1
43		VD-6042502-TP	SCREW	4
44		HR-1900000-01	ORING	3
45		RL-0100100-04	BEARING	2
46		TK-061208220-A	GEAR	1
47		TK-061220220-A	GEAR	1
48		TZ-0600126-0A	TRIGGER BELT	1
49		BH-7923-05-049	FABRIC OPENNING AIR PIPE	3
50		BH-7923-05-050	FABRIC OPENNING BRACKET	1
51		VD-6041602-TP	SCREW	1
52		VD-8041002-TP	SET SCREW	4
53		VD-6031202-TP	SCREW	4
54		SG-1782002-K0	EXTERNAL RETANING RING	1

6. ROLLER GROUP




No.	Note	Parts No.	Description	Qty
1		BH-7923-06-001	ROLLER	1
2		VD-6041202-TP	SCREW	3
3		BH-7923-06-003	PISTON MOVEMENT CONNECTION	1
4		PN-0600000-41	AIR CYLINDER	1
5		VD-3041602-TP	SCREW	3
6		VD-3031002-TP	SCREW	2
7		BH-7923-06-007	PIN WITH SCREW	2
8		BH-7923-06-008	ROLLER BLOCK	1
9		BH-7923-06-009	ROLLER CONNECTION ARM	1
10		BH-7923-06-010	NUT	1
11		RL-0100000-09	BEARING	1
12		BH-7923-06-012	ROLLER ARM CONNECTION SHAFT	1
13		BH-7923-06-013	ROLLER ARM CONNECTION GUARD	1
14		RL-0100000-08	BEARING	3
15		PN-0600000-26	ELBOW	2
16		BH-7923-06-016	MOTOR CONNECTION BRACKET 01	1
17		BH-7923-06-017	MOTOR CONNECTION BRACKET 02	1
18		BH-7923-06-018	MOTOR CONNECTION BRACKET 03	1
19		BH-7923-06-019	TRIGGER UPPER GEAR	1
20		EL-0100000-05	STEP MOTOR	1
21		VD-6042002-TP	SCREW	4
22		BH-7923-06-022	TRIGGER BELT	1
23		RL-0100000-06	BEARING	1
24		BH-7923-06-024	PISTON CONNECTION SCREW	1
25		BH-7923-06-025	ROLLER GUARD SHEET	1
26		VD-6051202-TP	SCREW	8
27		PL-0531000-KM	WASHER	8
28		BH-7923-06-028	TRIGGER GEAR	1
29		SG-0390602-K0	RETAINING RING	1
30		BH-7923-06-030	BEARING STABILIZING SCREW	1

7. KNIFE GROUP




No.	Note	Parts No.	Description	Qty
1		BH-7923-07-001	KNIFE TRANSMITTING FRAME	1
2		BH-7923-07-002	KNIFE BLOCK	1
3		BH-7923-07-003	LEFT BUSHING	2
4		BH-7923-07-004	RIGHT BUSHING	1
5		BH-7923-07-005	KNIFE SHAFT	1
6		BH-7923-07-006	KNIFE ARM ECCENTRIC	1
7		VD-6041202-TP	SCREW	4
8		BH-7923-07-008	KNIFE COVER FRAME	1
9		VD-1031202-TM	SCREW	2
10		RL-0100000-02	BEARING	3
11		RL-0100000-03	BEARING	2
12		RL-0100000-06	BEARING	1
13		BH-7923-07-013	KNIFE SHAFT MOVEMENT ARM	1
14		13461207	ADJUST PIN	1
15		VD-6041002-TP	SCREW	1
16		BH-7923-07-016	KNIFE MOTOR TRANSMITTING ARM	1
17		BH-7923-07-017	STABILIZING RING	2
18		BH-7923-07-018	SHAFT	1
19		NM6050001SP	NUT M5	1
20		WP0550800SP	WASHER 5.5X10X0.8	1
21		BH-7923-07-021	KNIFE MOTOR ARM SET	1 SET
22		BH-7923-07-022	KNIFE GROUP COMPLETE SET	1 SET
23		BH-7923-07-023	AIR CONNECTION SHEET	1
24		BH-7923-05-050	AIR PIPE STABILIZER	1
25		VD-6031002-TP	SCREW	1
26		BH-7923-07-026	AIR PIPE	1
27		70001880	SUCTION PIPE SET TOP	1
28		BH-7923-07-028	SPRING	1
29		VD-8040802-TP	SET SCREW	2

8. ATTACHMENT GROUP




No.	Note	Parts No.	Description	Qty
1		VD-6030602-TP	SCREW	5
2		PL-0320500-KM	WASHER	5
3		BH-7923-08-003	FABRIC SEPARATER	1
4		70001890	SIDE COVER	1
5		BH-7923-08-005	PISTON CONNECTION COVER	1
6		PN-0400000-24	SQUARE CYLINDER	1
7		BH-7923-08-007	FABRIC SEPARATING BRACKET	1
8		VD-6041002-TP	SCREW	2
9		PN-0600000-25	PNEUMATIC ELBOW	2

9. FABRIC TRANSPORT GROUP





No.	Note	Parts No.	Description	Qty
1		BH-7923-09-001	FRONT FABRIC OPENNER ROLLER	1
2		BH-7923-09-002	TRANSPORT GEAR	20
3		BH-7923-09-003	TRANSPORT GEAR PIN	20
4		BH-7923-09-004	FABRIC OPENNER FIXED SHAFT	1
5		VD-6032502-TP-18	SCREW	6
6		EL-0600000-09	PHOTOCELL	3
7		BH-7923-09-007	PHOTOCELL CONNECTION BRACKET	3
8		VD-1031002-TM	SCREW	3
9		BH-7923-09-009	PHOTOCELL CONNECTION BRACKET SHAFT	3
10		BH-7923-09-010	FRONT STRECHING KIT	1
11		VD-8050802-TP	SET SCREW	3
12		RL-0100000-04	BEARING	4
13		BH-7923-09-013	PHOTOCELL CONNECTION ARM	1
14		VD-6041202-TP	SCREW	1
15		BH-7923-05-050	AIR PIPE STABILIZER	2
16		BH-7923-09-016	BLOWING PIPE	1
17		VD-6041002-TP	SCREW	3
18		PL-0430800-KM	WASHER	1
19		VD-8031002-TP	SET SCREW	1
20		VD-6082502-TP	SCREW	2
21		BH-7923-09-021	UPPER BLOWING PIPE	1
22		BH-7923-09-022	UPPER BLOWING CONNECTION ARM	1
23		BH-7923-09-023	FRONT ARM SQUEEZING BRACKET	1
24		VD-6083002-TP	SCREW	1
25		VD-6052502-TP	SCREW	4
26		PL-0531000-KM	WASHER	4
27		BH-7923-09-027	RAIL CONNECTION BLOCK	1
28		BH-7923-09-028	RAIL CONNECTION BLOCK CAP	1
29		VD-6052002-TP	SCREW	4
30		BH-7923-09-030	FRONT ARM STABILIZING PIPE	1
31		LR-20120350-B	LINEAR RAIL	1
32		LA-0200000-0B	LINEAR GUIDEWAY	1
33		VD-6051202-TP	SCREW	4
34		TZ-0100200-07	TRIGGER BELT	1
35		TK-1320636-11	TRIGGER GEAR	1
36		TK-0220615-10	TRIGGER GEAR	1
37		VD-6041602-TP	SCREW	8
38		EL-0100000-05	STEP MOTOR	2
39		TK-1222022-10	TRIGGER GEAR	1
40		TK-1220822-10	TRIGGER GEAR	1
41		TZ-0700165-10	TRIGGER BELT	1
42		VD-6082002-TP	SCREW	4
43		BH-7923-09-043	FRONT FRAME BLOCK	1
44		VD-8041002-TP	SET SCREW	2
45		BH-7923-09-045	UPPER AIR OPPENNIG CONNECTION	1
47		BH-7923-09-047	FRONT ROLLER SET	1
48		BH-7923-09-048	SENSOR HOLDER SET	1
53		RL-0100000-01	BEARING	1
54		BH-7923-09-054	VORM	1
55		BH-7923-09-055	GUIDEWAY CONNECTION BLOCK	1

10. ADDITIONAL SENSING GROUP




No.	Note	Parts No.	Description	Qty
1		BH-7923-10-001	SENSOR EXTERNAL BLOCK	1
2		BH-7923-10-002	SENSOR INTERNAL BLOCK	1
3		VD-8030802-TP	SET SCREW	1
4		BH-7923-10-004	SENSOR MOVEMENT ARM SHAFT	1
5		RL-0100000-06	BEARING	3
6		BH-7923-10-006	SENSOR MOVEMENT ARM SET	1
7		VD-6031202-TP	SCREW	1
8		VD-6041002-TP	SCREW	2
9		SG-0390602-K0	RETAINING RING	1
10		PN-0600000-35	PISTON	1
11		EL-0600000-08	PROBE SENSOR	1
12		SM-6030000-SM	NUT	2
13		BH-7923-10-013	STABILIZING YOKE	1
14		BH-7923-10-014	SPRING	1
15		VD-8030502-TP	SET SCREW	1
16		VD-1030802-TM	SCREW	1
17		VD-3031002-TP	SCREW	1
18		BH-7923-10-018	SENSOR DETECTION SHEET	1
19		VD-6032002-TP	SCREW	2
20		BH-7923-10-020	SENSOR GUARD SHEET	1
21		VD-6030802-TP	SCREW	2
22		PN-0600000-25	PNEUMATIC ELBOW	2
23		BH-7923-10-023	ADDITIONAL DETECTION ROLLER	1

11. THREAD STAND




No.	Note	Parts No.	Description	Qty
1		40106591	3 THREAD STAND	1
2		40106591	5 THREAD STAND	1
3		BH-7923-11-003	THREAD BREAKAGE SENSOR	8
4		BH-7923-11-004	SENSOR CABLE	8

12. OPERATING PANEL




No.	Note	Parts No.	Description	Qty
1		BH-7923-12-001	PANEL COVER	1
2		BH-7923-12-002	PANEL REAR COVER	1
3		PL-0430800-KM	WASHER	6
4		EL-0300000-03	TOUCH SCREEN	1
5		VD-6041002-TP	SCREW	6
6		BH-7923-12-006	PANEL CONNECTION SHAFT	1
7		BH-7923-12-007	PANEL CONNECTION BASE	1
8		SM-6050000-SM	NUT	1
9		BH-7923-12-009	PANEL CONNECTION YOKE	1
10		BH-7923-12-010	PANEL CONNECTION BLOCK	1
11		PL-0531000-KM	WASHER	1
12		VD-6052502-TP	PANEL CONNECTION SCREW	1
13		PL-0841600-KM	WASHER	1
14		SM-6080000-SM	NUT	1
15		VD-8030602-TP	SET SCREW	2
16		VD-1042501-TR	SCREW	3

13. FABRIC TRANSPORT GUARD




No.	Note	Parts No.	Description	Qty
1		BH-7923-13-001	UPPER BLOCK COVER	1
2		VD-6030802-TP	SCREW	3
3		BH-7923-13-003	FRONT FABRIC GUIDE	2
4		BH-7923-13-004	FABRIC INTERNAL GUIDE	1
5		BH-7923-13-005	FABRIC UPPER GUIDE	2
6		VD-6041002-TP	SCREW	2
7		VD-6032002-TP	SCREW	2
8		VD-6031602-TP	SCREW	1
9		BH-7923-13-009	FABRIC REAR GUIDE	2
10		VD-6031002-TP	SCREW	1
11		BH-7923-13-011	FABRIC HOLDER MOVEMENT SHAFT	1
12		BH-7923-13-012	FABRIC HOLDING SHEET	1
13		BH-7923-10-013	SPRING	1
14		VD-6030602-TP	SCREW	1
15		BH-7923-13-015	SPRING PRESSER PLATE	1
16		BH-7923-13-016	FABRIC HOLDER BLOCK	1
17		VD-6031202-TP	SCREW	1
18		VD-3030802-TP	SCREW	1
19		PN-04000000-23	CYLINDER	1
20		PN-06000000-25	PNEUMATIC ELBOW	1
21		SG-0390602-K0	RETAINING RING	2
22		RL-01000000-06	BEARING	2
23		VD-6042002-TP	SCREW	2
24		BH-7923-13-024	FABRIC GUIDE MOVEMENT ARM	1
25		BH-7923-13-025	LOWER STABILIZING GUARD	1

14. KNIFE GROUP COMPLETE ASSEMBLY




No.	Note	Parts No.	Description	Qty
1		BH-7923-07-022	KNIFE GROUP COMPLETE ASSEMBLY	1
2		BH-7923-18-002	BELT GUARD COVER	1
3		TZ-0700216-12	TRIGGER BELT	1
4		PL-0430800-KM	WASHER	2
5		TK-0221030-15	LOWER TRIGGER GEAR	1
6		TK-0220815-15	UPPER TRIGGER HANDWHEEL	1
7		BH-7923-18-007	SERVO MOTOR FRAME CONNECTION	1
8		BH-7923-18-008	MOTOR STABILIZING FRAME	1
9		EL-0500000-02	SERVO MOTOR	1
10		VD-3041002-TP	SCREW	2
11		VD-6041202-TP	SCREW	4

15. ELECTRICAL PANEL GROUP



No.	Note	Parts No.	Description	Qty
1		EL-3600000-01	PLC	1
2		EL-3600000-02	DRIVER	1
3		EL-3600000-03	SERVO MOTOR POWER CABLE	1
4		EL-3600000-04	ENCODER CABLE	1
5		EL-3600000-05	COMMUNICATION CABLE	1
6		EL-3600000-06	AIR RELAY	16
7		EL-3600000-07	MOTOR CABLE	1
8		EL-3600000-08	SENSOR CABLE	1
9		EL-3600000-09	220V PLC RELAY	1
10		EL-3600000-10	24V PLC RELAY	1
11		EL-3600000-11	GROUND PLC RELAY	1
12		EL-3600000-12	FAN	2
13		EL-3600000-13	POWER SOURCE 24V	1
14		EL-3600000-14	POWER SOURCE 48V	2
15		EL-3600000-15	220V SOCKET	1
16		EL-3600000-16	CIRCUIT BREAKER	2
17		EL-3600000-17	PLC RELAY	4
18		EL-3600000-18	TENSION DRIVE	1
19		EL-3600000-19	ROLLER DRIVE	1
20		EL-3600000-20	REAR MOTOR DRIVE	1
21		EL-3600000-21	FRONT ENGINE DRIVE	1
22		EL-3600000-22	EDGE CONTROL DRIVE	1
23		BH7923-15-023	CABLE CANNEL	2
24		BH7923-15-024	PANEL SHEET	1
25		BH7923-15-025	CABLE CANNEL	2
26		BH7923-15-026	CABLE CANNEL	2
27		BH7923-15-027	ELECTRICAL PANEL	1

16. ACCESSORY



No.	Note	Parts No.	Description	Qty
1		BH-7923-18-001	FABRIC GUARD	1
2		BH-7923-18-002	FABRIC GUARD	1

Company Name : JUKI SINGAPORE PTE LTD.
ADD : 20 BENDEMEER ROAD,#04-12 BS BENDEMEER CENTRE SINGAPRE 339914
PHONE : (65) 6553-4388
HTTP : <http://www.juki.com.sg>
E-Mail : we.sgp-sales@ml.juki.com

Company Name : JUKI Machinery Vietnam Company Ltd
ADD : 153 HOA LAN STR.,WARD 2, PHU NHUAN DIST., HO CHI MINH CITY, VIETNAM
PHONE : (84) 28-35178833
FAX : (84) 28-35178318
E-Mail : sales@jukimv.com

Company Name : JUKI Machinery Bangladesh Ltd
ADD : NATORE TOWER(5TH FLOOR) PLOT#32-D & 32-E, ROAD#2, SECOR#03 ,UTTARA MODEL TOWN, DHAKA, BANGLADESH
PHONE : (880)2-48954731
FAX : (880)2-48954733
E-Mail : vl.mbl-info@ml.juki.com

Company Name : JUKI India Private Limited
ADD : GAOUND AND 1ST FLOOR, NO.1090/I, 18TH CROSS ROAD,3RD SECTOR, HSR LAYOUT BANGALORE-560 102, KARNATAKA STATE, INDIA
PHONE : (91)80-4251-1900
FAX : (91)80-4251-1999
HTTP : <http://jukiindia.com>
E-Mail : jukiblr@jukiindia.com

Company Name : JUKI CENTRAL EUROPE
ADD : UL. POLECZKI 21(PLATAN PARK C) 02-822 WARSAW, POLAND
PHONE : (48)22-545-0400
FAX : (48)22-545-0411
HTTP : <http://jukieurope.com>

Company Name : JUKI America INC
ADD : 8500 NW 17TH STREET, SUITE 100, DORAL, FL 33126-1035, U.S.A.
PHONE : (1)305-594-0059
HTTP : <https://juki.com>

Company Name : JUKI MIDDLE EAST (JUKI SINGAPORE PTE. LTD. UAE BRANCH)
ADD : OFFICE NO, 2511. BLOCK A JAFZA 1, PO BOX 18031, JEBEL ALI, DUBAI UAE
PHONE : (971)4-8833228
FAX : (971)4-8833230
HTTP : <http://www.juki.com.sg>

Company Name : JUKI (China) CO LTD.
ADD : ROOM 901-903, HAILIANG BUILDING, NO.22, LANE 118 ZHONGJIANG ROAD, PUTUO DISTRICT SHANGHAI, CHINA, 200062
PHONE : 8621-6236-8888
HTTP : <http://www.jukichina.com>

**JUKI CORPORATION**

SEWING MACHINERY & SYSTEMS BUSINESS UNIT

2-11-1, Tsurumaki, Tama-shi, Tokyo 206-8551, Japan

Phone: (81) 42-357-2211

