


# 工業用縫紉機

## INDUSTRIAL SEWING MACHINE

### 335 筒型綜合送料厚用縫紉機

零件冊  
PARTS LIST



※ 規格  
SPECIFICATIONS


※ 針號  
NEEDLE SYSTEM: DP x 17 # 11-23

※ 最高縫速  
SEWING SPEED: MA x .2200s.p.m.


※ 最大縫距  
STITCH LENGTH: MA x .6.5 MM

本機適用於中、厚物，皮或合成皮之包縫；如皮包、皮鞋、運動鞋及一般皮製品等。



THIS MACHINE IS SUITABLE FOR SEWING MEDIUM/HEAVY THICKNESS LEATHER OR FABRIC PRODUCTS SUCH AS: HANDBAG, LEATHER SHOES SPORTING SHOES, AND GENERAL LEATHER PRODUCTS.




|       |         |                        |
|-------|---------|------------------------|
| 1     | 面板蓋     | FACE PLATE             |
| 1-1   | 螺絲      | FASTENING SCREW        |
| 2     | 天秤蓋     | LIBRA COVER            |
| 3     | 導綫架 (上) | THREAD GUIDE UPPER     |
| 3-1   | 一字螺絲    | FASTENING SCREW        |
| 4     | 下導綫架    | THREAD GUIDE           |
| 4-1   | 螺絲      | FASTENING SCREW        |
| 5     | 上蓋板     | ARM COVER UPPER        |
| 5-1   | 螺絲      | FASTENING SCREW        |
| 6     | 前蓋板     | ARM COVER FRONT        |
| 7     | 綫柱      | TENSION COMPLETE SET   |
| 7-1   | 螺母      | NUT                    |
| 8     | 鬆綫銷     | TENSION RELEASE PIN    |
| 9     | 沙拉組     | TENSION COMPLETE       |
| 9-14  | 吊綫彈簧    | SUSPENSION WIRE SPRING |
| 9-18  | 拉綫簧調整板  | ADJUSTMENT BOARD       |
| 10    | 鉸鏈      | HINGE                  |
| 10-1  | 內六角螺釘   | FASTENING SCREW        |
| 10-2  | 彈簧      | SPRING                 |
| 11    | 螺絲      | FASTENING SCREW        |
| 11-1  | 墊片      | CUSHION                |
| 11-2  | 螺母      | NUT                    |
| 12    | 掛鈎      | LINK                   |
| 12-1  | 掛鈎螺絲    | FASTENING SCREW        |
| 13    | 蝶形螺釘    | FASTENING SCREW        |
| A     | 機頭      | GEAR END               |
| B     | 下座      | DOWN BASE              |
| C     | 四角底座    | FOUR MAO BASE          |
| D     | 油槽      | TANK                   |
| E     | 針棒座擋塊   | BLOCKING BOARD         |
| E-1   | 螺釘      | BOLT                   |
| 102-2 | 螺母      | NUT                    |







|      |        |                                |
|------|--------|--------------------------------|
| 14   | 油棉     | WICK                           |
| 15   | 天秤銷    | LIBRA TIP                      |
| 15-1 | 螺絲     | SCREW                          |
| 16   | 天秤     | THREAD TAKE-UP LIBRA           |
| 17   | 針棒驅動銷  | NEEDLE BAR LINK HINGE STUD     |
| 18   | 針棒拉杆   | NEEDLE BAR STUD                |
| 18-1 | 一字螺絲   | FASTENING SCREW                |
| 19   | 天秤驅動器  | TAKE-UP SLEEVE FULCRUM STUD    |
| 20   | 針棒曲柄   | FLEX HANDLE                    |
| 21   | 滑塊座    | SLIDE BLOCK                    |
| 21-1 | 螺絲     | FASTENING SCREW                |
| 21-2 | 螺絲     | FASTENING SCREW                |
| 22   | 連接螺絲   | FASTENING SCREW                |
| 23   | 導座     | LEAD SEAT                      |
| 23-1 | 螺絲     | FASTENING SCREW                |
| 24   | 固定環    | COLLAR                         |
| 25   | 針柱滑塊板  | NEEDLE BAR GUIDE PLATE         |
| 26   | 針棒搖動臺軸 | NEEDLE BAR FRAME               |
| 26-1 | 螺絲     | FASTENING SCREW                |
| 27   | 針棒搖動臺  | NEEDLE BAR FRAME               |
| 27-1 | 針柱座固定栓 | NEEDLE BAR FRAME STOP          |
| 27-2 | 止付     | CENTER SCREW                   |
| 27-3 | 止付     | CENTER SCREW                   |
| 28   | 針棒     | NEEDLE BAR                     |
| 28-1 | 針柱座套管  | NEEDLE COLUMN BASE SLEEVE PIPE |
| 29   | 鴿子圈    | SPRING                         |
| 29-2 | 螺絲     | FASTENING SCREW                |
| 901  | 大釜     | HOOK                           |




|      |        |                                        |
|------|--------|----------------------------------------|
| 30   | 曲柄     | FLEX HANDLE                            |
| 30-1 | 螺絲     | FASTENING SCREW                        |
| 30-2 | 螺絲     | FASTENING SCREW                        |
| 30-3 | 緊定螺絲   | FASTENING SCREW                        |
| 30-4 | 螺絲     | SCREW                                  |
| 31   | 上軸前套   | UP SHAFT FRONT BUSHING                 |
| 31-1 | 油塞     | FELT                                   |
| 31-2 | 油棉     | WICK                                   |
| 32   | 上軸中套   | FELT                                   |
| 33   | 上軸套環   | BEVEL GEAR CASING CAP COLLAR           |
| 33-1 | 螺絲     | FASTENING SCREW                        |
| 34   | 上軸後套   | ARM SHAFT BUSHING BACK COVER           |
| 35   | 上軸     | ARM SHAFT                              |
| 36   | 針棒座滑塊  | SLIDE BLOCK                            |
| 37   | 搖動軸前曲銷 | BENDED PIN IN FRONT OF WAVING THE AXLE |
| 37-1 | 斜梢     | OBLIQUE TIP                            |
| 37-2 | 搖動滑塊銷  | WAVE AND SLIP ONE PIN                  |
| 38   | 針棒搖動軸  | THE NEEDLE WAVES THE AXLE EXCELLENTLY  |
| 39   | 搖架軸緊圈  | SET COLLAR                             |
| 39-1 | 螺絲     | FASTENING SCREW                        |
| 40   | 皮帶輪    | BALANCE WHEEL                          |
| 40-1 | 緊定螺絲   | FASTENING SCREW                        |
| 41   | 螺絲     | FASTENING SCREW                        |





|        |        |                                         |
|--------|--------|-----------------------------------------|
| 42     | 齒輪盒（左） | BEVEL GEAR CASING COMPLETE              |
| 42 - 1 | 螺絲     | SCREW                                   |
| 43     | 齒輪盒（右） | BEVEL GEAR CASING COMPLETE              |
| 44     | 上軸齒輪   | GEAR SET                                |
| 44 - 1 | 緊定螺絲   | FASTENING SCREW                         |
| 45     | 豎軸上齒輪  | GEAR SET                                |
| 46     | 大釜軸    | HOOK DRIVING SHAFT                      |
| 47     | 下軸齒輪   | GEAR SET                                |
| 47 - 1 | 螺絲     | SCREW                                   |
| 48     | 豎軸下齒輪  | GEAR SET                                |
| 49     | 大釜軸前套筒 | FRONT SLEEVE FOR HOOK SHAFT             |
| 50     | 下軸套環   | DOWN SHAFT COLLAR                       |
| 50 - 1 | 緊定螺絲   | FASTENING SCREW                         |
| 51     | 大釜軸支座  | HOOK SHAFT BASE                         |
| 51 - 1 | 螺絲     | FASTENING SCREW                         |
| 52     | 下軸套環   | DOWN SHAFT COLLAR                       |
| 53     | 下軸後親套  | KISS COVER AFTER PUTTING THE AXLE       |
| 54     | 下齒輪盒   | BEVEL GEAR CASING UNDER                 |
| 54 - 1 | 螺絲     | SCREW                                   |
| 57     | 豎軸上套筒  | BEVEL GEAR SHAFT BUSHING VERTICAL UPPER |
| 58     | 豎軸     | BEVEL GEAR SHAFT VERTICAL               |
| 60     | 豎軸下套筒  | BEVEL GEAR SHAFT BUSHING VERTICAL UPPER |




|      |        |                      |
|------|--------|----------------------|
| 61   | 滾條固定組  | GAUGE PLATE SET      |
| 61-1 | 喇叭座螺母  | NUT                  |
| 61-2 | 布架杆    | FABRIC SUPPORT POLE  |
| 61-3 | 螺絲     | SCREW                |
| 61-4 | 床介     | FIXTURE BOARD        |
| 61-5 | 螺絲     | SCREW                |
| 61-6 | 壓簧墊片   | CUSHION              |
| 61-7 | 彈簧     | SPRING               |
| 61-8 | 螺絲     | SCREW                |
| 61-9 | 布架板    | FABRIC SUPPORT PLATE |
| 62-1 | 螺絲     | FASTENING SCREW      |
| 62A  | 喇叭型針板  | NEEDLE PLATE         |
| 62B  | 平面型針板  | NEEDLE PLATE         |
| 63-1 | 一字螺絲   | FASTENING SCREW      |
| 63A  | 喇叭型牙齒  | TUBAEFORM TOOTH      |
| 63B  | 平面型牙齒  | PLANEFORM TOOTH      |
| 64   | 送料搖杆   | FEEDING ROCKER       |
| 64-1 | 墊片     | CUSHION              |
| 64-2 | 送料臺軸螺栓 | BOLT                 |
| 65   | 送料臺軸   | FEEDING PLATE SHAFT  |
| 65-1 | 螺絲     | FASTENING SCREW      |
| 66   | 大斧蓋    | HOOK COVER           |
| 67   | 針護架    | NEEDLE EGIS SUPPORT  |
| 67-1 | 螺絲     | SCREW                |
| 68   | 針板座    | NEEDLE BORAD BASE    |
| 68-1 | 螺絲     | SCREW                |
| 69   | 送料滑塊   | FEEDING SLIDE VALVE  |
| 70   | 滑塊基座   | SLIDE VALVE BASE     |
| 71   | 送料驅動臂  | FEEDING DRIVER       |
| 71-1 | 螺絲     | FASTENING SCREW      |
| 71-2 | 一字螺絲   | FASTENING SCREW      |







|      |          |                                    |
|------|----------|------------------------------------|
| 72   | 送料偏心凸輪   | PARTIAL FEEDING CAM                |
| 73   | 驅動連杆     | DRIVER ROD                         |
| 73-1 | 驅動連杆螺絲   | SCREW FOR DRIVER ROD               |
| 74   | 針棒搖動臺後曲柄 | BACK FLEX HANDLE                   |
| 74-1 | 內六角螺釘    | FASTENING SCREW                    |
| 75   | 針棒搖動連杆   | CONNECTION POLE                    |
| 75-1 | 螺絲       | FASTENING SCREW                    |
| 76   | 曲軸銷      | FLEX SHAFT END                     |
| 77   | 滑套       | SLIPPERY SET                       |
| 78   | 叉形連接杆    | FORK CONNECTION POLE               |
| 79   | 送料連接銷    | FEEDING CONNECTION END             |
| 79-1 | 墊片       | CUSHION                            |
| 79-2 | 螺母       | FASTENING SCREW                    |
| 80   | 搖動曲杆     | FLEX POLE                          |
| 81   | 水平送料軸    | FEEDING SHAFT                      |
| 82   | 送料調節彈簧   | SPRING FOR FEEDING CONTROL         |
| 83   | 彈簧基座     | SPRING BASE                        |
| 84   | 滑套座      | SLIPPERY SET BASE                  |
| 84-1 | 拉簧螺釘     | EXTENSION SPRING SCREW             |
| 84-2 | 內六角螺釘    | FASTENING SCREW                    |
| 85   | 送料調節親套   | COVER                              |
| 86   | 針距調節座    | CONTROL BASE FOR NEEDLE DISTANCE   |
| 86-1 | 送料調節彈簧   | SPRING FOR FEEDING CONTROL         |
| 86-2 | 螺絲       | FASTENING SCREW                    |
| 87   | 調節刻度板    | SCALE PLATE                        |
| 88   | 送料調節導套   | LEAD SET FOR FEEDING CONTROL       |
| 89   | 滑套軸      | SLIPPERY SHAFT                     |
| 90   | 差動調節軸    | CONTROL SHAFT                      |
| 91   | 針距調節把手   | HANDLE CONTROL FOR NEEDLE DISTANCE |
| 92   | 彈簧       | SPRING                             |
| 94   | 螺母       | NUT                                |
| 95   | 螺絲       | SCREW                              |



|       |           |                                                 |
|-------|-----------|-------------------------------------------------|
| 96    | 調壓力螺釘     | BOLT FOR TENSION CONTROL                        |
| 97    | 調整螺帽      | SCREW CAP                                       |
| 98    | 彈簧墊       | SPRING TRAY                                     |
| 99    | 壓棒套管      | PRESS ROD SLEEVE PIPE                           |
| 99-1  | 螺釘        | BOLT                                            |
| 100   | 壓棒彈簧 (扁)  | PRESS ROD SPRING (FLAT)                         |
| 101   | 扁擔吊架 (組件) | SHOULDER POLE STAND (PACKAGE)                   |
| 101-1 | 螺絲        | FASTENING SCREW FOR                             |
| 102   | 壓棒拉基      | PRESSER BAR GUIDE COLLAR                        |
| 102-1 | 連接螺栓      | CONNECTION BOLT                                 |
| 102-2 | 螺母        | NUT                                             |
| 103   | 壓腳提升把手    | LIFTING HANDLE                                  |
| 103-1 | 提升把手梢     | LIFTING HANDLE END                              |
| 104   | 壓棒        | PRESSER BAR                                     |
| 104-1 | 壓棒螺絲      | SCREW                                           |
| 105   | 彈簧壓杆      | SPRING PRESSER POLE                             |
| 106   | 彈簧        | SPRING                                          |
| 107A  | 喇叭型外壓腳    | OUTER PRESSER FOOT                              |
| 107B  | 平面型外壓腳    | FLAT PRESSER FOOT                               |
| 108   | 墊片        | WASHER                                          |
| 109   | 上送料驅動杆    | UP FEEDING POLE DRIVER                          |
| 110   | 上送料連接螺栓   | CONNECTION BOLT FOR UP FEEDING                  |
| 111   | 設定搖臂心     | ROCKER ARM                                      |
| 112   | 上送料搖臂     | UP FEEDING ROCKER ARM                           |
| 112-1 | 內六角螺釘     | FASTENING SCREW                                 |
| 113   | 蝶形螺母      | FASTENING SCREW                                 |
| 114   | 上送料軸偏心輪   | PARTIAL WHEEL                                   |
| 114-1 | 螺絲        | SCREW                                           |
| 115   | 上送料親套     | BUSHING                                         |
| 117   | 上送料軸      | UP FEEDING SHAFT                                |
| 118   | 上送料搖杆     | UP FEEDING ROCKER                               |
| 119   | 上送料連杆     | UP FEEDING CONNECTING ROD                       |
| 119-1 | 螺絲        | FASTENING SCREW                                 |
| 120   | 三角搖臂      | TRIANGULAR ROCKER ARM                           |
| 121   | 上送料系搖動連杆  | SHAKING CONNECTION ROD                          |
| 122   | 上送壓棒銷     | PRESS POLE TIP                                  |
| 123   | 連接導柱      | CONNECTION GUIDE POST                           |
| 124   | 滾子        | ROLLER                                          |
| 125   | 上送壓棒導座    | PRESS POLE LEADING BASE                         |
| 126   | 上送壓腳軸     | PRESS SHAFT                                     |
| 127-1 | 螺絲        | SCREW                                           |
| 127A  | 喇叭形內壓腳    | ESCORT THE FOOT IN THE SHAPE OF THE LOUDSPEAKER |
| 127B  | 內壓腳       | PRESS THE FOOT INSIDE                           |
| 128   | 托架定位板     | FIXTURE BOARD                                   |
| 128-1 | 螺絲        | SCREW                                           |
| 129   | 定位滑塊      | FIXTURE SLIP                                    |
| 129-1 | 螺絲        | FASTENING SCREW                                 |




|         |      |                             |
|---------|------|-----------------------------|
| 130     | 杠杆銷軸 | LEVER PIVOT                 |
| 131     | 扭簧   | SPRING                      |
| 132     | 短杠杆  | SHORT LEVER                 |
| 133     | 杠杆連杆 | CONNECTING ROD OF THE LEVER |
| 133 - 1 | 杠杆螺絲 | LEVER SCREW                 |
| 134     | 後箱蓋  | BACK CASE LID               |
| 134 - 1 | 螺絲   | SCREW                       |
| 134 - 2 | 螺母   | NUT                         |
| 134 - 3 | 螺絲   | SCREW                       |
| 136     | 長杠杆  | LONG LEVER                  |
| 137     | 吊鉤   | CLIVER                      |
| 137 - 1 | 螺絲   | FASTENING SCREW             |
| 138     | 導銷座  | GUIDE SEAT                  |
| 138 - 1 | 螺絲   | SCREW                       |
| 139     | 栓銷銷座 | BOLT PIN SEAT               |
| 140     | 栓銷彈簧 | BOLT PIN SPRING             |
| 141     | 栓銷   | BOLT PIN                    |
| 142     | 頂銷滑板 | SLIPPY BOARD                |
| 143     | 搖板   | SHAKING BOARD               |
| 143 - 1 | 搖板螺絲 | SCREW                       |
| 143 - 2 | 搖板彈片 | SHRAPNEL                    |




|     |     |                         |
|-----|-----|-------------------------|
| 144 | 大起子 | BIG OPENER              |
| 145 | 中起子 | MIDDLE OPENER           |
| 146 | 小起子 | SMALL OPENER            |
| 147 | 梭心  | SHUTTLE                 |
| 148 | 車針  | NEEDLE                  |
| 149 | 防塵罩 | DUSTPROOF COVER         |
| 150 | 零件盒 | ACCESSORY BOX           |
| 151 | 油壺  | DIL BOAT                |
| 152 | 打綫器 | FEEDING LINE IMPL EMENT |
| 153 | 鐵鞋  | IRON SHOE               |


154



155



156




157




|     |       |                               |
|-----|-------|-------------------------------|
| 154 | L型二綫架 | LINE TWO SHELF OF THE MODEL L |
| 155 | 綫盤    | THREAD TRAY                   |
| 156 | 橡皮墊   | RUBBER CUSHION                |
| 157 | 鏈條鏈鉤  | CHAIN& CHAIN HOOK             |

# 335-8B




|      |        |                                     |
|------|--------|-------------------------------------|
| 1    | 針板     | NEEDLE PLATE                        |
| 2    | 螺絲     | SCREW                               |
| 3    | 針板座固定片 | FIXTURE PIECE FOR NEEDLE PLATE BASE |
| 3-1  | 螺絲     | SCREW                               |
| 4-A  | 護蓋小    | SMALL EGIS COVER                    |
| 4-B  | 護蓋大    | BIG EGIS COVER                      |
| 5    | 凸輪     | CONVEXITY WHEEL                     |
| 6    | 連杆     | CONNECTION POLE                     |
| 7    | 油棉     | WICK                                |
| 8    | 彈簧     | SPRING                              |
| 9    | 針板座    | NEEDLE PLATE BASE                   |
| 10   | 大釜護片   | EGIS PIECE FOR HOOK                 |
| 11   | 螺絲     | SCREW                               |
| 33-1 | 螺絲     | SCREW                               |
| 51-1 | 螺絲     | SCREW                               |

# 335-8B



# 335-8BL



|                |       |                                   |
|----------------|-------|-----------------------------------|
| 1-1            | 螺絲    | SCREW                             |
| 10-1           | 螺絲    | SCREW                             |
| 12             | 短送料軸  | SHORT FEEDING SHAFT               |
| 13             | 下軸套管  | DOWN SHAFT BUSHING                |
| 14             | 送料拉杆  | FEEDING DRAWING POLE              |
| 15             | 螺絲    | SCREW                             |
| 16             | 連杆銷   | CONNECTION POLE TIP               |
| 17             | 扣環    | BUCKLE RING                       |
| 18             | 送金    | FEEDING TOOTH                     |
| 19             | 螺絲    | SCREW                             |
| 20             | 送金座   | FEEDING TOOTH BASE                |
| 21             | 送料牙架  | FEEDING SUPPORT                   |
| 22             | 牙架固定片 | FIXTURE PIECE FOR FEEDING SUPPORT |
| 23             | 螺絲    | SCREW                             |
| 24             | 固定環   | COLLAR                            |
| 25             | 搖動曲柄  | FLEX HANDLE                       |
| 26             | 曲柄銷   | FLEX TIP                          |
| 27             | 彈簧螺絲  | SCREW                             |
| 28             | 調整螺母  | NUT                               |
| 29             | 倒針把手  | HANDLE                            |
| 30             | 彈簧    | SPRING                            |
| 31             | 鋼珠    | STEEL BALL                        |
| 32             | 防沙板   | PREVENTION BOARD                  |
| 33             | 固定架   | FIXTURE SUPPORT                   |
| 39-1           | 螺絲    | SCREW                             |
| <b>335-8BL</b> |       |                                   |
| 1              | 針板    | NEEDLE PLATE                      |
| 2              | 送料板   | FEEDING PLATE                     |
| 3              | 針板座   | NEEDLE PLATE BASE                 |
| 4              | 後部    | BACK PART                         |