

PARTS LIST

TFHX-II

Table of Contents

● TFHX-II GENERAL VIEW	
● TFHX-II FRAMING.....	DH-1
● TFHX-II TABLE.....	DH-2
● TFHX-II MAIN SHAFT DRIVE SYSTEM.....	DH-3
● TFHX-II ROTARY HOOK BASE 1.....	DH-4-1
● TFHX-II ROTARY HOOK BASE 2.....	DH-4-2
● TFHX-II COLOR CHANGE SYSTEM.....	DH-5
● TFHX-II ARM 1.....	DH-6-1
● TFHX-II ARM 2.....	DH-6-2
● TFHX-II ARM 3.....	DH-6-3
● TFHX-II NEEDLE BAR CASE 1.....	DH-7-1
● TFHX-II NEEDLE BAR CASE 2.....	DH-7-2
● TFHX-II FRONT COVER.....	DH-8
● TFHX-II UPPER THREAD HOLDER SET.....	DH-9
● TFHX-II CAM DRIVE SYSTEM SET.....	DH-10
● TFHX-II X-AXIS DRIVE SYSTEM	DH-11
● TFHX-II Y-AXIS DRIVE SYSTEM A (FOR 4-HEAD M/C).....	DH-12a
● TFHX-II Y-AXIS DRIVE SYSTEM B (FOR 6-HEAD M/C, 8-HEAD M/C).....	DH-12b
● TFHX-II AUXILIARY DRIVE SYSTEM A (FOR 6-HEAD M/C).....	DH-13a
● TFHX-II AUXILIARY DRIVE SYSTEM B (FOR 8-HEAD M/C).....	DH-13b
● TFHX-II ROTARY-TYPE TENSION BASE.....	DH-14
● TFHX-II THREAD STAND A.....	DH-15a
● TFHX-II THREAD STAND B (FOR 15-NEEDLE M/C).....	DH-15b
● TFHX-II UNDER THREAD WINDER.....	DH-16
● TFHX-II WOODEN FRAME HOLDER.....	DH-17
● TFHX-II BORDER FRAME (OPTION).....	DH-18
● TFHX-II ELECTRICAL PARTS.....	DH-19
● TFHX-II LCD OPERATION PANEL (OPTION).....	DH-20

Part Nos. of screws, nuts, washers etc. are listed at the end of volume.

[Explanation of Marks #'s and *'s at End of Part No.]


- ◆ Please specify, in the following manner, your machine model, manufacturing number and embroidery space when you order us with the parts having **** at the end of the part No.:


Ex.	TFHX-II908	(450×360)S	No.01234
	[Model]	[Emb. Space]	[Mfg. No.]

- ◆ Please specify the number of needles on your machine's head in your parts order by changing the marks ##### into one of the 4-digit numbers below:

Ex.	The part Number, EF012345####	
	4-digit Numbers	Machine Type
	0300.....	3-needle machine
	0600.....	6-needle machine
	0900.....	9-needle machine
	1200.....	12-needle machine
	1500.....	15-needle machine

TFHX-II GENERAL VIEW






TFHX-II FRAMING

DH-1

Ref.No.	Description	Part No.	Remark
1	Integral Stand	DH0801S0****	
2	Stand Base	JE0807000000	
3	Stand Base Side Cover	CX08H1000000	
4	Vibration-preventive Base	EF08100A0000	
5	Caster	BP540SBAU650	
6	TAJIMA Brand Name Plate	CL0830000000	
7	Stand Side Cover	JE0814000000	
8	Right-end Box Cover	CC0811000000	
9	Left-end Box Cover	DH0812000000	
10	Bobbin Stand Base	PX0101000000	
11	Bobbin Stand Stud	EF0122000000	
12	Controller Pipe	CC0834000000	
12	Controller Pipe	RD0809010000	For 15-Needle M/C
13	Cross Joint	RD0806000000	
14	Operation Panel Attaching Arm	EG01040A0000	
15	Cushion Rubber	EC0829010000	
16	Panel Base	RD0802000000	For LCD Spec. M/C
17	Base Cover	RD0805000000	For LCD Spec. M/C
18	Model Name Plate	DH081600****	
19	Grommet	PB003300EB00	
20	Wiring Cover A	JE0815A2****	
21	Wiring Cover B	JE0815B1****	
22	Wiring Cover Stud	LH0835000000	
23	Fluorescent Lamp	ED7402000000	Option
24	Fluorescent Lamp	ED7402A00000	Option
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II TABLE

DH-2

Ref.No.	Description	Part No.	Remark
1	Table	DH080200****	
2	Joint Table Lid	DH081300****	
3	Countersunk Head Wood Screw	ZZ110312SD00	3.1P*12
4	Table Side Cover L	JE0819L00000	
5	Table Side Cover R	JE0819R00000	
6	Y-axis Motor Cover	CC0832000000	
7	Lid Support Stud	EFZ807100000	
8	Table Lid Holder Felt	EFZ807200000	
9	Encoder Table Lid	ED0814000000	
10	ATH Cover	PX0809000000	
11	No.1 Table Support	PX1001050000	
12	Round Head Wood Screw	ZZ410420CC00	4.5P*20
13	Table Support Spacer	DX1005000000	
14	Table Support Spacer	MX1099000000	
15	No.2 Table Support	PX1002050000	
16	Table Support Stud	EF1001010000	
17	No.5 Table Support	PX1005000000	
18	No.6 Table Support	PX1006000000	
19	Table Support C L	CX08F1LA0000	
20	Table Support C R	CX08F1RA0000	
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II MAIN SHAFT DRIVE SYSTEM

DH-3

Ref.No.	Description	Part No.	Remark
1	Main Shaft Motor	CX6204010000	
2	Pulley No.3 A	CX0169000000	For 4-Head M/C
2	Pulley No.3 A	CX0170000000	For 6-Head M/C, 8-Head M/C
3	Tension Roller	CX0112030000	For 6-Head M/C, 8-Head M/C
3	Tension Roller	CX0166000000	For 6-Head M/C, 8-Head M/C
4	Ball Bearing	BP6000ZZ0000	
5	Tension Pin B	CX0161000000	For 4-Head M/C
5	Tension Pin	DL0109000000	For 6-Head M/C, 8-Head M/C
6	E-ring	BPE700000000	
7	Timing Belt	BP150S5M1000	For 4-Head M/C
7	Timing Belt	BP200S5M1000	For 6-Head M/C
7	Timing Belt	BP200S5M1125	For 8-Head M/C
8	Pulley No.4 A	CX0163B00000	For 4-Head M/C
8	Pulley No.4 A	CX0163010000	For 6-Head M/C
8	Pulley No.4 A	JE0823000000	For 8-Head M/C
9	15mm Dia. Bearing Case Collar	EG0111000000	
10	Bearing Case	CX0160000000	
11	Graduated Spacer	CX0104000000	
12	Angle Indicator Plate	ED0170000000	
13	Angle Pointer	CX0168000000	For 4-Head M/C
13	Angle Pointer	DL0110000000	For 6-Head M/C, 8-Head M/C
14	Driven Shaft B	CX0223B00000	For 4-Head M/C
14	Driven Shaft D	CX0223D00000	For 6-Head M/C, 8-Head M/C
15	Gear Box	CX02160A0000	
15	Gear Box	CXC2160A0000	For Jumbo Rotary Hook
16	22mm Dia. Spacer A	CX0896A00000	0.1mm Thick
16	22mm Dia. Spacer B	CX0896B00000	0.3mm Thick
16	22mm Dia. Spacer C	CX0896C00000	1.0mm Thick
17	No.1 Gear	CX0213000000	
18	15mm Dia. Bearing Collar	EG0227000000	
19	Ball Bearing	BP6003ZZ0000	
20	No.2 Gear B	CX0214B00000	Iron Gear
20	No.2 Gear	CX0214000000	Plastic Gear Option
21	Washer	BPTW10200000	
22	Fixing Collar	CX0207000000	
23	Gear Shaft	CX0210000000	
24	Fixing Washer	CX0202000000	
25	Shaft Cover A	PX0810000000	For 4-Head M/C
25	Shaft Cover A	DX0103000000	For 6-Head M/C, 8-Head M/C
26	Shaft Cover B	JE0825000650	For 6-Head 500P M/C
26	Shaft Cover B	PX0811000801	For 8-Head M/C
27	Cover Bracket A	CX08G0000601	
28	Cover Bracket	CX08240A0000	
29			
30			
31			
32			
33			
34			
35			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ROTARY HOOK BASE 1

DH-4-1

Ref.No.	Description	Part No.	Remark
1	Rotary Hook Base A	FX0201AC0000	
1	Rotary Hook Base A	FXC201AC0000	For Jumbo Rotary Hook
2	Rotary Hook Base B	FX0201BC0000	
2	Rotary Hook Base B	FXC201BC0000	For Jumbo Rotary Hook
3	Rotary Encoder	EF6600A00000	
4	Rotary Hook Base Stud	FX0225000000	
5	Ball Bearing	BP6003ZZ0000	
6	15mm Dia. Bearing Collar	EG0227000000	
7	Spiral Bevel Gear A	EF0203000001	
8	Spiral Bevel Gear B	EF0204000001	
9	Spiral Bevel Gear A	EF0203B00000	Iron Gear: Can be used with Plastic Spiral Bevel Gear B as a set
10	Spiral Bevel Gear B	EF0204040000	Plastic Gear
11	Rotary Hook Shaft Spacer	EF0211000000	
12	Rotary Hook Shaft Bushing	EF0206000000	
12	Rotary Hook Shaft Bushing	EFC206010000	For Jumbo Rotary Hook
13	Rotary Hook Shaft	EF0205010000	
14	7.94mm Dia. Collar	EF0209000000	
15	Rotary Hook	ME0505E2****	
15	Rotary Hook	MEC505E2****	For Jumbo Rotary Hook
16	Rotary Hook Set Screw	ME0506000000	
17	Bobbin Case	ME050300****	
17	Bobbin Case	MEC503000DBM	For Jumbo Rotary Hook
18	Bobbin	ME050402****	
18	Bobbin	MEC504010DBM	For Jumbo Rotary Hook
19	Rotary Hook Support	EF021000****	
19	Rotary Hook Support	EFC210000000	For Jumbo Rotary Hook
20	Needle Plate	FX020200****	
21	Round Countersunk Head Screw	EG0228000000	
22	Top Lid	EG0221010000	
23	Rotary Hook Shaft Drive Shaft	PX081500****	
24	Rotary Hook Shaft Drive Shaft A	DH0201A0****	
25	N-Coupling	BPN150150000	
26	Rotary Hook Shaft Drive Shaft B	DH0201B0****	
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ROTARY HOOK BASE 2

DH-4-2

Ref.No.	Description	Part No.	Remark
1	Knife Base	FX0203000000	
2	Adjusting Liner	FX0209000000	0.1mm Thick
3	Adjusting Liner	FX0210000000	0.05mm Thick
4	Hexagon Socket Head Cap Screw	EG0219000000	
5	Movable Knife	FX0227000000	
6	Knife Drive Shaft	EG0205040000	
7	Fixed Knife	FX0228000000	
8	Under Thread Presser	FX0229000000	
9	Bushing	EG0211000000	
10	Knife Drive Arm	AT0205000000	
11	Knife Connecting Lever	AT0207000000	
11	Connecting Plate	GS0206000000	For the last Head
12	Connecting Lever Pin	AT0206000000	
13	Connecting Stud	AT0208000000	
14	Connecting Shaft Holder	FX0208000000	
15	Sensor Bracket A	FX0218000000	
16	Proximity Switch	PB001300KN00	
17	Searching Block	FX0217000000	
18	Thread Trimming Shaft	PX081600****	
19	Thread Trimming Shaft A	DH0202A0****	
20	M6 Joint	EF0827010000	
21	Thread Trimming Shaft B	DH0202B0****	
22	Solenoid Base	EG0214000000	
23	Solenoid	AT6806D10000	
24	Solenoid Cover	EG02100A0000	
25	Solenoid Pin	EG0252000000	
26	Compressed Spring	EG0218000000	
27	E-ring	BPE400000000	
28	Needle Bar O-Ring	EF0621000000	
29	Connecting Rod	EG0251000000	
30	Stepped Pin	EG0215000000	
31	Connecting Lever Pin	EG0217000000	
32	Picker Connecting Stud	EG0212000000	
33	Wide Picker	EG0213000000	
34	Eccentric Stopper	EG0220000000	
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II COLOR CHANGE SYSTEM

DH-5

Ref.No.	Description	Part No.	Remark
1	Potentiometer	PB000100RV00	
2	Sensor Base	CX0401000000	
3	Positioning Collar	CX0402000000	
4	Change Bearing Case	CX04070A0000	
5	Flanged DU Bushing	BPMB120620FD	
6	Positioning Spacer	CX0404010000	
7	Change Cover	CX04100A0000	
8	Color Change Cover A	CX0417010000	
9	Change Cover Stud	CX0414000000	
10	Change Cam	CX0406000000	
11	Pulse (Stepping) Motor	RD6401S00000	
12	Manual Connecting Shaft	CX0403000000	
13	Motor Attaching Plate	CX04090A0000	
14	Sensor Arm	CC0504000001	
15	Color Change Cam Shaft	CX0413000000	
16	Color Change Gear B	CX0412000000	
17	Color Change Motor Bracket	CC0505000000	
18	Sensor Arm	CC0504000000	
19	Color Change Gear A	CX0411000000	
20	Manual Connecting Shaft	CX0416000000	
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ARM 1

DH-6-1

Ref.No.	Description	Part No.	Remark
1	Arm	CL0579010000	For the 1st head
1	Arm	FN0501010000	
2	Arm Top Cover	CC0503000000	
2	Arm Top Cover	FN05030A0000	For 6-Head M/C, 8-Head M/C
3	Sensor Arm	CC0504B00000	
3	Sensor Arm	FN0504010000	For 6-Head M/C, 8-Head M/C
4	Case Linear	FX056600####	
5	Reinforcing Plate	FX056900####	
6	Take-up Lever Guide Rail	CL059200****	Note:
7	Arm Front Cover L	FN0522L2####	
8	Arm Front Cover R	FX0568RA####	
9	Upper Thread Locking Solenoid	FG6801000000	
10	O-Ring	BPS7000000000	
11	E-ring	BPE4000000000	
12	O-Ring	BPSS01800000	
13	E-ring	BPE0150000000	
14	Contact Point Lever	FN0524000000	
15	Return Spring	FN0526000000	
16	Spring Holder Collar	FN0525000000	
17	Drive Lever	FN0527000000	
18	Arm Guide Plate	FN0528000000	
19	Positioning Plate	FX0526000000	
20	Hexagon Socket Head Cap Screw	EG0219000000	
21	Arm Side Cover A	JX0509000000	
22	Seal Packing	FX0553200000	
23	Arm Side Cover B	FX0554AB0000	
24	Jump Motor Base	JX0510000000	
25	Pulse (Stepping) Motor	RX6402000000	
26	Jump Lever	MX0502000000	
27	Roller Pin E	JX0502S00000	
28	Jump Lever Return Spring	MX0503020000	
29	Cushion	AT0404000000	
30	Cushion Pin	AT0405000000	
31	Clutch Motor Lever	JX0506000000	
32	Clutch Pin	JX0507000000	
33	Clutch Base	JX0505000000	
34	Clutch Lever	JX0503000000	
35	Lever Fixing Screw	JX0504000000	
36	Eccentric Stopper	EG0220000000	
37			
38			Note: When ordering this part, please also specify
39			for which head (the 1st head, the last head or
40			other than these heads) it is used.
41			
42			
43			
44			
45			
46			
47			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ARM 2

DH-6-2

Ref.No.	Description	Part No.	Remark
1	Needle Bar Reciprocator Set	UN25009300NR	
2	Jump Spring	FX0516000000	
3	Spring Cradle	FX0564000000	
4	Needle Bar Reciprocator	FX0515010000	
5	Needle Bar Reciprocator Spacer	EF0554000000	
6	Reciprocator Slide Block	FX0565020000	
7	Needle Bar Drive Shaft Bushing	CX0506010000	
8	Stopper Base	FX0519000000	
9	No.5 Pin Set	UN2505900000	
10	No.5 Pin	JX0508000000	
11	Wick B	EF0557000000	
12	Connecting Rod Washer	EF0555010000	0.5mm Thick
12	Connecting Rod Washer	EF0555010040	0.4mm Thick
12	Connecting Rod Washer	EF0555010030	0.3mm Thick
13	Needle Bar Felt Packing	LE0537200000	
14	Presser Foot Reciprocator	FN0521000000	
15	Cushion Bracket	FX0521000000	
16	No.3 Pin Set	UN2505101000	
17	No.3 Pin	EF0511010000	
18	Needle Bar Drive Shaft Set	UN2501102000	
19	Needle Bar Drive Shaft	FX0522030000	
20	Needle Bar Drive Shaft Wick	EG0536000000	
21	Balancer Spring	FN0506000000	
22	Spring Collar	FN0507000000	
23	Bearing Case Collar	ME0555000000	
24	Needle Bar Drive Shaft Felt	FX0524000000	
25	Take-up Lever Drive Lever Pin Set	CL0572S10000	
26	Take-up Lever Drive Lever Pin	CL0572010000	
27	Wick B	EG0544000000	
28	Take-up Lever Drive Lever A Set	CL0573S00000	
29	Take-up Lever Drive Lever B	CL0574010000	
30	Roller Pin	CL0577000000	
31	8mm Dia. Roller	CL0578010000	
32	8mm Dia. Collar	EF0418000000	
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ARM 3

DH-6-3

Ref.No.	Description	Part No.	Remark
1	Needle Bar Cam Tightening Collar	EF0508000000	
2	Bearing Case	EF0502010000	
3	Ball Bearing	BP6004ZZ0000	
4	Needle Bar Drive Cam Set	UN250100B0NR	
5	Needle Bar Drive Cam	FX0502000000	
6	Needle Cage	BPK384188X01	
7	Connecting Rod	EF0505010000	
8	Take-up Lever Cam Base	CL0576000000	
9	Take-up Lever Drive Cam	FX0570000000	
9	Take-up Lever Drive Cam	FN0502000000	For Jumbo Rotary Hook
10	Cam Washer	EF0522000000	
11	Cam Washer A	EF0522A00000	
12	Cam Spacer	MX0505020000	
13	Presser Foot Cam	MX0508030000	
14	Presser Foot Cam Boss	MXJ509010000	
15	Needle Bar Drive Lever Set	EG0527000000	
16	No.2 Pin Set	UN2505300000	
17	No.2 Pin	EG0528000000	
18	Wick A	EG0543000000	
19	8mm Dia. Collar	EF0418000000	
20	No.1 Pin Set	UN2505601000	
21	No.1 Pin	FX0506010000	
22	Wick A	EF0556000000	
23	No.3 Pin Set	UN2505101000	
24	No.3 Pin	EF0511010000	
25	Wick B	EF0557000000	
26	Needle Bar Drive Connecting Rod	EF0513000000	
27	Drive Lever	MX0510020000	
28	No.1 Drive Shaft Set	UN2505501000	
29	No.1 Drive Shaft	FX0504010000	
30	Wick C	EF0558000000	
31	8mm Dia. Collar	MX0507000000	
32	Cam Follower	BPCFS4000000	
33	Eccentric Pin	MX0511010000	
34	Needle Bar Drive Shaft	PX081400****	
35	Needle Bar Drive Shaft A	DH0822A0****	
36	N-Coupling	BPN150150000	
37	Needle Bar Drive Shaft B	DH0822B0****	
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II NEEDLE BAR CASE 1

DH-7-1

Ref.No.	Description	Part No.	Remark
1	Needle Bar Case Set	UN260122####	When placing an order, please also specify for which head (the 1st head or other heads) you need.
1	Needle Bar Case Set	UN260121####	For Jumbo Hook. When placing an order, please also specify for which head (the 1st head or other heads) you need.
2	Needle Bar Case	CC060100####	For the 1st Head
2	Needle Bar Case	FN060100####	
3	Holder Spring Set Screw	EF0620000000	
4	Needle Bar	FX0632000000	
5	Needle Bar Holder Spring	EF0618030000	
6	Spring Shoe Washer	EF0619000000	
7	Felt Packing	EF062300####	
8	Cushion Rubber B	EF062700####	
9	Cushion Ring F	FX0616010000	
10	Cushion Ring E	FX0615000000	
11	Upper Dead Point Stopper	EF0617010000	
12	Flat Fillister Head Screw	EF0647000000	
13	Needle Bar Connecting Stud	CX0606010000	
14	Presser Foot Spring Holder	FX0618010000	
15	Presser Foot Spring D	FX0619D10000	
16	Presser Foot Connecting Stud	FX0621010000	
17	Presser Foot Set	FX0620S00000	
18	Presser Foot	FX0620100000	
19	Presser Foot Bushing	EF0613220000	
20	Presser Foot Set Screw	FX0622000000	
21	Cushion Ring A	EF0642020000	
22	Needle Clamp	C90029020000	
23	Needle Set Screw	EF0615000000	
24	Needle	EF06405Z1110	DB K5Z1 #11
25	Take-up Lever Positioning Bushing	EF0606000000	
26	Take-up Lever Shaft	EF060200####	
26	Take-up Lever Shaft	FX0602001200	For 12-Needle M/C
26	Take-up Lever Shaft	ED0F16000000	For 15-Needle M/C
27	Roller Type Take-up Lever Set	FX0645S00000	
27	Roller Type Take-up Lever Set	CL0611S20000	For Jumbo Rotary Hook
28	Take-up Lever	FX0645000000	
28	Take-up Lever	FX0603020000	For Jumbo Rotary Hook
29	Thread Guide	MX0521010000	
30	Take-up Lever Boss	CL0611010000	
31	Take-up Lever Adjusting Bushing	EF0605000000	
32	Needle Bar Guide Rail	FN062101####	
33	Rail Guide	FN062300####	
34	Case Rail, Lower	FX061200####	
34	Case Rail, Lower	ED0F15000000	For 15-Needle M/C
35	Parallel Pin	BPH70416L000	
36	Color Change Bracket L	FX0640L00000	
37	Color Change Bracket R	FX0640R00000	
38	Pin No.714	CD0E16000000	
39	Slide Shaft	CX066000****	
40	Slide Shaft A	DH0601A0****	
41	M6 Joint	EF0827010000	
42	Slide Shaft B	DH0601B0****	
43			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II NEEDLE BAR CASE 2

DH-7-2

Ref.No.	Description	Part No.	Remark
1	Top Cover Set	UN260140####	
2	Top Cover	FN064100####	
3	Top Cover Attaching Screw	CX0675000000	
4	Thread Take-up Spring Attaching Base Set	UN260131####	
5	Thread Take-up Spring Attaching Base	FN063100####	
6	Retracting Lever Set	FN0639000000	
7	Push Spring	FN0638000000	
8	Knurled Screw	FN0640000000	
9	Tension Collar	FN0636000000	
10	Thread Take-up Spring	FN0637000000	
11	Stroke Adjuster A	FN0634000000	
12	5 mm Dia. Shaft	FN063300####	
13	Stroke Adjuster B	FN0635000000	
14	Roller-type Large Thread Holder Set	FN063201####	
15	Needle Roller	FN0642000000	
16	Thread Guide	MX0521010000	
17	Face Plate	FN062202####	
18	Upper Thread Locking Device	UN260200####	
19	Holder Base	FN062803####	
20	Lock Shaft	FN0624010000	
21	Lock Spring	FN0625010000	
22	Presser Fixture	FN0626020000	
23	Nut Cap	FN0619000000	
24	Thread Presser Base Set	UN680033####	
25	Thread Holder Bracket	AT0323000000	
26	Thread Suspender Disk	EF0637000000	
27	Thread Suspender Spring	EF0639000000	
28	Thread Suspender Spring Presser	EF0638000000	
29	Thread Suspender Attaching Screw	AT2311000000	
30	Thread Presser Base (with Tape)	UN680172####	
31	Thread Presser Base	AT032400####	
32	Velcro	AT030500####	
32	Velcro	FX0631201200	For 12-Needle M/C
32	Velcro	ED0F20001500	For 15-Needle M/C
33	Thread Presser Lid (with Tape)	UN680182####	
34	Thread Presser Lid	AT032500####	
35	Thread Presser Spacer	AT0304000000	
36	Change Roller Base	CX069100####	
37	Cam Roller Pin Set	EF0519S00000	
38	Space Block A	CX0677010000	
39	Space Block B	CX0678010000	
40			
41			
42			
43			
44			
45			
46			
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II FRONT COVER

DH-8

Ref.No.	Description	Part No.	Remark
1	Front Cover A	CX0666AB****	For 4-Head M/C
2	Cover Attaching Bracket L	CX0686L00000	
3	Cover Attaching Bracket R	CX0686R00000	
4	Connecting Plate	CX0690000000	For 4-Head M/C
5	Top Cover	CX08B70A****	
5	Top Cover	JE08290008A1	For 8-Head M/C
6	Front Cover A	CX068900****	
7	Start/Stop Switch Label	PB002501SP00	
8	Front Cover D	CX0666DB****	For 4-Head M/C
8	Front Cover B	BX08090B****	For 6-Head M/C, 8-Head M/C
9	Cover Attaching Bracket E	BX0812E00000	
10	Cover Attaching Bracket F	BX0812F00000	
11	Start Switch Base	BX080803****	
12	Retaining Washer	BX0811000000	
13	Cord Clamp	BX0810000000	
14	Cylinder Head Switch Assembly	SC5807000000	
15	Start Switch	SC5803000000	
16	Stop Switch	SC5806000000	
17	Front Cover D	CX0692D0****	For 4-Head M/C
17	Front Cover D	CX0693D0****	For 6-Head M/C, 8-Head M/C
18	Front Cover E	CX067601****	For 4-Head M/C
18	Front Cover J	EN08690C****	For 6-Head M/C, 8-Head M/C
19	Cover Plate Spring	FX0805010000	
20	Stop Switch Base	EN089000****	
21	Push-button Switch	PB0019D0SP00	
22	Push-button Switch Emergency Stop Plate	PB0019C0SP00	
23	Front Cover E	CX0692E0****	For 4-Head M/C
23	Front Cover E	CX0693E0****	For 6-Head M/C, 8-Head M/C
24	Cover Attaching Bracket L	CX0695L00000	
25	Cover Attaching Bracket R	CX0695R00000	
26	Front Cover B	MX08160C****	For 6-Head M/C, 8-Head M/C
27	Cover Attaching Bracket L	FX0637L00000	
28	Cover Attaching Bracket R	FX0637R00000	
29	Front Cover B	CX0693B0****	
30	Cover Attaching Bracket	CX0687000000	
31	Cover Attaching Bracket C	FX0641C00000	
32	Arm L Cover	JX0856000000	For 4-Head M/C
32	Arm L Cover	JX0855000000	For 6-Head M/C, 8-Head M/C
33	L Cover Stud	CX0808010000	
34	Cover Bracket	CX08240A0000	
35	Arm R Cover	CX08M9020000	
35	Arm R Cover	CX08M3000000	For 6-Head M/C, 8-Head M/C
36	Cover Bracket A	CX08G0010000	
37			
38			
39			
40			
41			
42			
43			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II UPPER THREAD HOLDER SET

DH-9

Ref.No.	Description	Part No.	Remark
1	Assembly Base Set	UN68024000FG	
2	Assembly Base	AT0333000000	
3	Base Lid A	AT0332000000	
4	Upper Thread Hook A	AT1303030000	
5	Special Nut	AT0307200000	
6	Arm Connecting Rod	MX0519000000	
7	Lever Connecting Pin	AT0309000000	
8	Upper Thread Hook Lever	MX0517000000	
9	Upper Thread Hook Return Spring	JE0501000000	
10	Spring Holder Collar	MX0523000000	
11	Pulse Motor Base	AT0330000000	
12	Pulse (Stepping) Motor	RX6402000000	
13	Eccentric Stopper	EG0220000000	
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II CAM DRIVE SYSTEM SET

DH-10

Ref.No.	Description	Part No.	Remark
1	ATH Attaching Base	SFC2010C00000	
2	22mm Dia. Spacer A	CX0896A00000	0.1mm Thick
2	22mm Dia. Spacer B	CX0896B00000	0.3mm Thick
2	22mm Dia. Spacer C	CX0896C00000	1.0mm Thick
3	Thread Trimming Solenoid	AT6805B00000	
4	Solenoid Bracket	SF0207010000	
5	Solenoid Lever	AS0103000000	
6	Roller Shaft A Set	SP0101000000	
7	Take-up Lever Positioning Bushing	EF0606000000	
8	Washer	BPTW08150000	
9	Drive Lever Shaft	SF0209000000	
10	Drive Lever Pin	SF0210000000	
11	Driven Lever	SF0205000000	
12	Cam Lever	SF0204000000	
12	Cam Lever	SFC2040000000	For Jumbo Rotary Hook
13	No.1 Roller Pin Set	CHW105S000000	
14	O-Ring	BPP8000000000	
15	Connecting Rod	SF0206000000	
16	Connecting Rod Pin	SF0212000000	
17	Connecting Stud	SF0203000000	
18	E-ring	BPE4000000000	
19	Positioning Collar	SF0214000000	
20	O-Ring	BPP6000000000	
21	Thread Trimming Shaft Holder	SF0208000000	
22	Case Bearing	BPCSA0602M00	
23	Thread Trimming Cam	SF0202010000	
24	Cam Split Collar	SF0211000000	
25	15mm Dia. Collar	CE0110000000	
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II X-AXIS DRIVE SYSTEM

DH-11

Ref.No.	Description	Part No.	Remark
1	Z-spec. Frame	CC070100****	
2	Z-spec. Frame Felt	CX0722020000	
3	Steel Plate A	CX03B900****	When ordering this part, please also inform us of the total length.
4	L-shaped Stay A	CX07B9000000	
5	L-shaped Stay B L	CX07F5L00000	
6	L-shaped Stay B R	CX07F5R00000	
7	Bushing Plate	CC0755000000	
8	Cord Bushing	PB000200BU00	
9	Traverse Linear Way	BPLWL15C****	
10	Linear Spacer	CX07B1000000	
11	Joint Plate AL	CX07C8L00000	
12	Joint Plate AR	CX07C8R10000	
13	Joint Plate B	CX07F6000000	
14	Joint Plate L	CX07K3L0****	
15	Joint Plate R	CX07K3R0****	
16	Joint Plate	CC075100****	
17	Joint Plate	JE0724000000	For 6-Head 500P M/C
17	Joint Plate	CX07K4000636	for 8-Head M/C
18	X-axis Spacer	CX0761000000	
19	X-axis Belt Catcher F	CX07J8F00000	
20	X-axis Belt Catcher G	CX07J8G00000	
21	X-axis Belt Catcher H	CX07J8H00000	
22	X-axis Timing Belt	BP025MA5****	
23	X-axis Belt Catcher J	CX07J8J00000	
24	X-axis Belt Catcher K	CX07J8K00000	
25	Tension Pulley	CX07K2000000	
26	Needle Bearing	BPHK10100000	
27	Washer	BPTW10200000	
28	X-axis Pin	CX07K1010000	
29	Idler Bracket L	CX07J9L00000	
30	Idler Bracket R	CX07J9R00000	
31	Reinforcing Plate	JE0725000000	
32	Pulse (Stepping) Motor	CX6407010000	
33	Motor Spacer	CX07J4000000	
34	86 mm Dia. Motor Plate L	CX07J3L10000	
35	86 mm Dia. Motor Plate R	CX07J3R10000	
36	Z-spec. Frame Pulley	CX07J6000000	
37	Ball Bearing	BPBC616ZZ000	
38	Auxiliary Plate Support	CX07J5010000	
39	Bearing Case Base R	CX07J7R00000	
40	Bearing Case Base L	CX07J7L00000	
41	X Origin Detecting Plate	CC0754000000	
42	Proximity Switch	PB001300KN00	
43	X Origin Detecting Plate A	CC0764A00000	
44	Origin Search Attaching Plate	CC0763000000	
45	Z-spec. Frame Cover	CC070200****	
45	Z-spec. Frame Cover	JE070200****	For 6-Head 500P M/C, 8-Head M/C
46	Traverse Scale	CX07A3000000	
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II Y-AXIS DRIVE SYSTEM A (FOR 4-HEAD M/C)_{DH-12a}

Ref.No.	Description	Part No.	Remark
1	Y-axis Frame L	CX07D1L000000	
2	Y-axis Frame R	DH0705R0****	
3	Frame Bracket A	CX08E50A0000	
4	Frame Bracket B	CX08E60A0000	
5	Traverse Linear Way	BPLWL15C2R58	
6	Y-axis Belt Catcher	CX0705010000	
7	Y-axis Stack Plate	CX07C0000000	
8	Z-spec. Frame Stay	CX07F4000000	
9	Y-axis Sensor Bracket	CC0762000001	
10	Y-axis Origin Adjusting Plate	CC0765000000	
11	Proximity Switch	PB001300KN00	
12	Frame Cover C	CX07H6000000	
13	Y-axis Tension Bearing Case	CX07C5000000	
14	No.1 Pulley	CX0715010000	
15	Needle Bearing	BPHK10100000	
16	Washer	BPTW10200000	
17	Tension Shaft	CX07C1000000	
18	Y-axis Timing Belt	BP015MA50261	
19	Frame Cover B	CX07B8000000	
20	Ball Bearing	BP6002ZZ0000	
21	Fixing Collar	CX0712000000	
22	No.3 Pulley	CX0109010000	
23	Y-axis Shaft (For Pulley)	CX07C3000000	
24	Y-axis Joint	CX07C4000000	
25	Y-axis Shaft	CX07C2000401	
26	Split Joint	CX0784000000	
27	Pulse (Stepping) Motor	CX6404010000	
28	Y-axis Motor Base	PX0703000000	
29	Pulse Motor Spacer	PX0704000000	
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II Y-AXIS DRIVE SYSTEM B (FOR 6-, 8-HEAD M/C) DH-12b

Ref.No.	Description	Part No.	Remark
1	Y-axis Frame L	PX0701000000	
1	Y-axis Frame L	DH0705L00000	for 8-Head M/C
2	Y-axis Frame R	DH0705R0****	
3	Frame Bracket A	CX08E50A0000	
4	Frame Bracket B	CX08E60A0000	
5	Traverse Linear Way	BPLWL15C2R58	
6	Y-axis Belt Catcher	CX07H7010000	
7	Y-axis Stack Plate	CX07H8010000	
8	Y-axis Belt Presser	CX07D6000000	
9	Z-spec. Frame Stay L	CX07F7L00000	
10	Z-spec. Frame Stay R	CX07F7R00000	
11	Y-axis Sensor Bracket	CC0762000000	
12	Y-axis Origin Adjusting Plate	CC0765000000	
13	Proximity Switch	PB001300KN00	
14	Frame Cover C	CX07H6000000	
15	Y-axis Tension Bearing Case	CX07J0000000	
16	No.1 Pulley	CX07H4010000	
17	Needle Bearing	BPHK10100000	
18	Washer	BPTW10200000	
19	Tension Shaft	CX07H9000000	
20	Y-axis Timing Belt	BP025MA50261	
21	Frame Cover B	CX07B8000000	
22	Ball Bearing	BP6002ZZ0000	
23	Fixing Collar	CX0712000000	
24	No.3 Pulley	CX07H3010000	
25	Y-axis Shaft (For Pulley)	CX07C3000000	
26	Y-axis Joint	CX07C4000000	
27	Y-axis Shaft R	CX07H2R0****	
28	Split Joint	CX0784000000	
29	Pulse (Stepping) Motor	CX6404010000	
30	Y-axis Motor Plate	CX07G6000000	
31	Y-axis Shaft L	CX07H2L0****	
32	Y-axis Shaft R	DH0707R0****	
33	N-Coupling	BPN150150000	
34	Y-axis Motor Plate	JE0706000000	
35	Pulse (Stepping) Motor	DX6402010000	
36	Y-axis Shaft L	DH0707L0****	
37	Driver Shaft Vibration Stopper	CC0825000000	
38	Round Head Wood Screw	ZZ410420CC00	4.5P*20
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II AUXILIARY DRIVE SYSTEM A (FOR 6-HEAD M/C) *DH-13a*

Ref.No.	Description	Part No.	Remark
1	Bearing Case Plate A	CX07G5000000	
2	Bearing Unit	BPUFL0020000	
3	Needle Bar Cam Tightening Collar	EF0508000000	
4	Wire-drive Pulley	CX07J2000000	
5	Base Cover	CX07G8000000	
6	Auxiliary Drive Base	CX07H0010000	
7	Slide Rail	BP330LMM2205	
8	Slide Rail Cover	CX07G9000000	
9	Connector	CX07G7000000	
10	Stopper Plate	CX07D7000601	
11	Wire Catcher Plate	CX07G2000000	
12	Auxiliary Drive Wire	CX07G4000000	
13	Wire Pulley	CX07E1000601	
14	Bearing	BP0608ZZ0000	
15	Bearing Washer	CX07D5000601	
16	Pulley Shaft	CX07G0000000	
17	Wire Cover	CX07G3000000	
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II AUXILIARY DRIVE SYSTEM B (FOR 8-HEAD M/C) *DH-13b*

Ref.No.	Description	Part No.	Remark
1	Base	DH0708000000	
2	Bearing Case Plate A	CX07G5000000	
3	Bearing Unit	BPUFL0020000	
4	Auxiliary Drive Pulley	JE0713000000	
5	Auxiliary Drive Base	CC0709000000	
6	Traverse Linear Way	BPLWL15C2R24	
7	Auxiliary Drive Stay	JE0711000000	
8	Connector	JE0710000000	
9	Stopper Plate	JE0718000000	
10	Auxiliary Drive Stack Plate A	JE0720000000	
11	Auxiliary Drive Stack Plate B	JE0721000000	
12	Belt Catcher Plate	JE0719000000	
13	Timing Belt	BP025MA50316	
14	Shaft Holder Bracket A	JE0716000000	
15	No.1 Pulley	CX07H4010000	
16	Washer	BPTW10200000	
17	Pulley Shaft	JE0714000000	
18	E-ring	BPE700000000	
19	Idler Pulley	JE0715000000	
20	Shaft Holder Bracket B	JE0717000000	
21	Slide Rail Cover	CC0722000000	
22	Base Lid	JE0723000000	
23	Belt Cover	CC0712000000	
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ROTARY-TYPE TENSION BASE

DH-14

Ref.No.	Description	Part No.	Remark
1	Rotary-type Tension Base Set	UN230120****	When ordering this part, please also specify for which head (the 1st head or other heads) it is used.
2	Tension Base	FN091901####	
3	Rotary Tension Disk	FN0901010000	
4	Slit Disk Shaft	FN0904010000	
5	Rotary Base	FN0916010000	
6	Rotary Disk Slit Plate	FG7210000000	
7	Thread Guide Pin B	FN0906000000	
8	Guide Pin Roller	FN0907000000	
9	First Tension Thread Spring Screw	FN0922000000	
10	Spring Hook	EF0910000000	
11	First Tension Spring	LG0960010000	
12	First Tension Disk	FN0921000000	
13	First Tension Stud	FN0903000000	
14	Thread Guide Pin A	FN0905000000	
15	Upper Thread Presser Base	FN0924000000	
16	Truss Head Tapping Screw	ZZ010306SD00	3P*6
17	Shaft Holder	FN0923000000	
18	Countersunk Tapping Screw	ZZ110310SD00	3P*10
19	Thread Holding Felt	FN093000####	
20	Upper Thread Presser Shaft	ED0L1800####	
21	Spring Pin	BPSP01560000	1.5P*6
22	Upper Thread Guide	FN090901####	
23	Countersunk Tapping Screw	ZZ110308SD00	3P*8
24	Thread Guide Plate	FN091501####	
25	Sleeve	EC0912000000	
26	Thread Presser Spring	EC0908000000	
27	Thread Presser	EC0909010000	
28	Tension Base Lamp Cover	ED0K17000000	
29	Tension Base Card (PC Board)	RX7201000000	
30	Tension Base Cover	CC091800####	For the 1st Head
30	Tension Base Cover	FN091800####	
31	Thread Breakage Sensor Rail	FN091000####	
32	Thread Breakage Sensor Base	FN0911000000	
33	TC Sensor Card	FG7204000000	
34	Slit Disk Guard A	FN091200####	
35	Slit Disk Guard B	FN091300####	
36	Tension Base Support L	FN0917L00000	
37	Tension Base Support R	FN0917R00000	
38	Cable Cover	FN091403####	
39	Base Joint	CX06010B####	
40	Tension Base Cord Cover A	CX0668AA####	
40	Tension Base Cord Cover B	CC060600####	For 6-Head M/C, 8-Head M/C
41	Tension Base Cord Cover B	CX0668BA####	
41	Tension Base Cord Cover A	CC060500####	For 6-Head M/C, 8-Head M/C
42	Tension Base Cord Cover C	CX0668CA####	
42	Tension Base Cord Cover C	CC060700####	For 6-Head M/C, 8-Head M/C
43	Harness Guard Bushing	MX0833010000	
44			
45			
46			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II THREAD STAND A

DH-15a

Ref.No.	Description	Part No.	Remark
1	Thread Stand Plate	CX08M801****	
2	Thread Stand Plate Stay A	CX08H8010000	
3	Thread Stand Cushion	CX08H7000000	
4	Thread Stand Stud	EF0939010000	
5	Thread Stand Felt	EF0940000000	
6	Thread Stand Shaft B	EF0937B10000	
6	Thread Stand Shaft	JE0828000000	For 8-Head M/C
7	Thread Course	JE082700****	
8	Thread Guide A	EF0942A00000	White
8	Thread Guide B	EF0942B00000	Red
9	No.1 Tension Set	UN150501C000	
10	No.1 Thread Tension Spring Screw	FN0922000000	
11	Spring Hook	EF0910000000	
12	No.1 Tension Spring	LG0960010000	
13	No.1 Tension Disk	LG0920010000	
14	No.1 Tension Stud	FN0903000000	
15	No.1 Tension Thread Course	ED0L14010000	
16	Spiral Tube	EC0906000003	
17	Tube Joint	ED0L11000000	
18	Tube Presser Pipe	ED0L12000000	
19	Fluorescent Lamp	CX740100****	
20	Fluorescent Lamp Stand Pipe	CX7402000000	
21	Fluorescent Lamp Pipe Support	EF0813000000	
22	Fluorescent Lamp Thread Stand Stay A	CX08N0A10000	
23	Thread Stand Plate Spacer A	CX08N1A10000	
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II THREAD STAND B (FOR 15-NEEDLE M/C)_{DH-15b}

Ref.No.	Description	Part No.	Remark
1	Thread Stand Plate, Front	CX08M8A0****	
2	Thread Stand Plate, Rear	CX08M8B0****	
3	Thread Stand Plate Base	ED0L07A000000	
4	Thread Stand Plate Spacer	ED08490000000	
5	Thread Stand Stud	EF09390100000	
6	Thread Stand Felt	EF09400000000	
7	Thread Stand Shaft B	ED0860A000000	
7	Thread Stand Shaft	ED0L080000000	For 8-Head M/C
8	Thread Course	CX08G601****	
9	Thread Guide A	EF0942A000000	White
9	Thread Guide B	EF0942B000000	Red
10	No.1 Tension Set	UN150501C000	
11	No.1 Thread Tension Spring Screw	FN09220000000	
12	Spring Hook	EF09100000000	
13	No.1 Tension Spring	LG09600100000	
14	No.1 Tension Disk	LG09200100000	
15	No.1 Tension Stud	FN09030000000	
16	No.1 Tension Thread Course	ED0L140100000	
17	Spiral Tube	EC09060000002	
18	Tube Joint	ED0L110000000	
19	Tube Presser Pipe	ED0L120000000	
20	Fluorescent Lamp	CX740100****	Option
21	Fluorescent Lamp Stand Pipe	CX74020000000	Option
22	Fluorescent Lamp Pipe Support	EF08130000000	Option
23	Fluorescent Lamp Attaching Collar	CX08N70000000	Option
24	Fluorescent Lamp Attaching Base	CX08N60000000	Option
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II UNDER THREAD WINDER

DH-16

Ref.No.	Description	Part No.	Remark
1	Under Thread Winder Base Set	CX1115SB0000	
1	Under Thread Winder Base Set	CX1116S10000	For 6-Head M/C, 8-Head M/C
2	Under Thread Winder Base	CX1115000000	
2	Under Thread Winder Base	CX1116010000	For 6-Head M/C, 8-Head M/C
3	Thread Winder Arm	CX1115500000	
4	Spacer		16P*8.5P*0.8t
5	E-ring		E-6 Black-coated
6	Thread Winder Shaft	CX1115300000	
7	Spacer		10P*6.5P*0.5t
8	Rubber Ring	CX1115100000	
9	Thread Winder Wheel	CX1115200000	
10	Thread Winder Plate Spring	CX1115700000	
11	Pan Head Screw		11/64*40*8
12	Thread Winder Arm Spring	CX1115900000	
13	Thread Winder Cam Shaft	CX1115600000	
14	Bobbin Presser	CX1115400000	
15	Pan Head Screw		9/64*40*5.5
16	Thread Winder Cam Shaft Spring	CX1115800000	
17	E-ring		E-5 Black-coated
18	Thread Suspender Disk	EF0637000000	
19	Thread Suspender Spring	EF0639000000	
20	Thread Suspender Spring Presser	EF0638000000	
21	Thread Suspender Attaching Screw	AT2311000000	
22	Bobbin Winder Pulley	CX1102010000	
23	Thread Guide Stay	CX11010A0000	For 4-Head M/C, 6-Head M/C
24	Adjusting Screw	EF09090A0000	
25	Spring Hook	EF0910000000	
26	Under Thread Winding Coil Spring	CX1103000000	
27	Thread Course Tension Disk	EF0913000000	
28	Felt Packing	EF0904000000	
29	Thread Course Tension Stud	EF0914000000	
30	Thread Course Thread Guide	EF0912000000	
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II WOODEN FRAME HOLDER

DH-17

Ref.No.	Description	Part No.	Remark
1	Wooden Frame Holder Set	JE0391S0****	
2	Wooden Frame Holder L	JE0391L0****	
3	Wooden Frame Holder R	JE0391R0****	
4	Frame Holder Reinforcing Angle	JE0392000000	
5	Countersunk Head Wood Screw	ZZ110312SD00	3P*12
6	Magnet Case A	OFA2001S0000	
7	Spacer C	CX0319000000	
8	Magnet Case B	OFA2002S0000	
9	Spacer D	CX0320000000	
10	Middle Sash L	JE0393L0****	
11	Middle Sash R	JE0393R0****	
12	Slide Support	CX0318000000	
13	Frame Set Screw B Set	WH0A10S10000	
14	Frame Set Screw B	WH0A10010000	
15	Set Screw Spacer A	WH0A12000000	
16	Tie Plate B	CX03B6000000	
17	Tie Plate D	CX0321000000	
18	Tie Plate F	JE0396000000	
19	Border Frame Spacer AL	CX0395L00000	
20	Border Frame Spacer AR	CX0395R00000	
21	Border Frame Spacer C	CX03B4000000	
22	Frame Holder Spacer A	JE0394000000	
23	Positioning Washer	CX0397000000	
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II BORDER FRAME (OPTION)

DH-18

Ref.No.	Description	Part No.	Remark
1	Border Frame	CX03C000****	For 4-Head M/C
1	Border Frame	CX039800****	For 6-Head M/C
1	Border Frame	JE031100****	For 8-Head M/C
2	Border Frame Felt	CX0386000000	
3	Border Frame Clip	MX0320D0****	For X-direction Use
3	Border Frame Clip	MX0320E0****	For Y-direction Use
4	Border Frame Spacer AL	CX0395L00000	
5	Border Frame Spacer AR	CX0395R00000	
6	Border Frame Spacer C	CX03B4000000	
7	Frame Set Screw B Set	WH0A10S10000	
8	Frame Set Screw B	WH0A10020000	
9	Set Screw Spacer A	WH0A12000000	
10	Positioning Washer	CX0397000000	
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)




TFHX-II ELECTRICAL PARTS

DH-19

Ref.No.	Description	Part No.	Remark
1	Power Supply Driver Box	JX5600010000	
2	Mother Board	JX5603000000	
3	Driver CPU Card	JX5602010000	
4	Driver Card (PC Board)	HX5602A10000	
5	5V Power Supply	PB0032A1PW00	
6	24V Power Supply	PB0025A1PW00	
7	Fan	PB001100BF00	
8	Fan	PB001800BF00	
9	Clamp Filter	PB000500FM00	
10	Power Supply Box Stand	HX0811020000	
11	Electrical Component Parts Base	CX08J2100000	
12	Inverter	PB000301AD00	
13	Line Noise Filter	PB0015A0FM00	For 3-phase Spec. M/C
14	Brake Resistor	PB001600RA00	
15	Noise Filter	PB000900FM00	For 3-phase Spec. M/C
16	Noise Filter	PB000800FM00	For Single-phase Spec. M/C
17	Surge Protector	PB001500RS00	
18	Surge Protector	PB001400RS00	For 3-phase Spec. M/C
19	Terminal Base	PB001400TB00	
20	Terminal Base	PB001500TB00	
21	Circuit Protector	PB002800KA00	For 3-phase Spec. M/C
21	Circuit Protector	PB002700KA00	For Single-phase Spec. M/C
22	Switch Guard	CX08J1510000	
23	Breaker Lock	CX08J1700000	For 3-phase Spec. M/C
23	Breaker Lock	CX08J1800000	For Single-phase Spec. M/C
24	Switch Guard Plate	CX08J2400000	For 3-phase Spec. M/C
24	Switch Guard Plate	CX08J2300000	For Single-phase Spec. M/C
25	Harness Holder	JX0809000000	
26	Electrical Parts Cover	CX08J2200000	
27	Controller	JX5100A30000	
28	FIP (Indicator Assembly)	PB001100LP00	
29	CPU-B Card	MX5101A90000	
30	Switch Card	MX5102000000	
31	Memory-B Card	JX5101000000	
32	Floppy Disk Drive	PB001000RE00	
33	Joint Card (PC Board)	EC6103A00000	
34	I/F Card A	HX6102030000	
35	Card Stud	CX0853010000	
36	Head Card	JX6101010000	
37	Truss Head Tapping Screw	ZZ010308SD00	3P*8
38	Card Attaching Base	CL0896000000	
39	Fluorescent Lamp Transformer Unit	PA6012010000	For 220 - 240V Spec. M/C with Fluorescent Lamp
40	Separate Transformer UnitX8	PA6016010000	For 4-Head M/C
40	Separate Transformer UnitX9	PA6018010000	For 6-Head M/C, 8-Head M/C
41			
42			
43			
44			
45			
46			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)



TFHX-II LCD OPERATION PANEL (OPTION)

DH-20

Ref.No.	Description	Part No.	Remark
1	Controller	RX5100000000	
2	12.1-inch TFT Color LCD	PB001800LP00	
3	12.1-inch Touch Panel	RX5105000000	
4	12.1-inch Touch Panel Protection Sheet	RX5110000000	
5	Frame Travel Switch Card	RX5107000000	
6	Switch Lever	RX0810000000	
7	Speaker	RX5106000000	
8	Floppy Disk Drive	PB001100RE00	
9	CPU-C Card	RX5111000000	
10	RISC Card	RX5104000000	
11	Backlight Inverter	PB001900LP00	
12	Touch Panel Cable Extension Card	RX5108000000	
13	Regulator Card	RX5109000000	
14	Jog Remote-controller	RX5101000000	
15	Jog Remote-controller Card	RX5102000000	
16	Jog Remote-controller Harness	RX5103000000	
17	Jog Remote-controller Pocket	PB0001A0NB00	
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			

Note: As for parts with marks # or *, please follow our instructions on Table of Contents in your parts order.

(EE07)

No.	Part No.	Remark	No.	Part No.	Remark
A	Flat Fillister Head Screw		B18	SS6203200TD0	M3*20
A1	SM15015430CN	1/8*44*3	B19	SS6203200TN0	M3*20
A2	SM15015450CN	1/8*44*5	B20	SS6203250TN0	M3*25
A3	SM15015455CN	1/8*44*5.5	B21	SS6204050TD0	M4*5
A4	SM15015460CN	1/8*44*6	B22	SS6204050TN0	M4*5
A5	SM16515530CN	9/64*40*3	B23	SS6204060TN0	M4*6
A6	SM14020540CN	9/64*40*4	B24	SS6204080TD0	M4*8
A7	SM16516540SA	9/64*40*4	B25	SS6204080TN0	M4*8
A8	SM17010540CN	9/64*40*4	B26	SS6204100TD0	M4*10
A9	SM1E515550CN	9/64*40*5	B27	SS6204100TN0	M4*10
A10	SM14020560CN	9/64*40*6	B28	SS6204120TD0	M4*12
A11	SM15525560CN	9/64*40*6	B29	SS6204120TN0	M4*12
A12	SM15526570CN	9/64*40*7	B30	SS6204150TN0	M4*15
A13	SM15020580CN	9/64*40*8	B31	SS6204180TN0	M4*18
A14	SM15530580CN	9/64*40*8	B32	SS6204200TD0	M4*20
A15	SM16025580CN	9/64*40*8	B33	SS6204200TN0	M4*20
A16	SM150205A0CN	9/64*40*10	B34	SS6204250TN0	M4*25
A17	SM150205C0CN	9/64*40*12	B35	SS6204250TN1	M4*25
A18	SM150205F0CN	9/64*40*15	B36	SS6204300TN0	M4*30
A19	SM15422643TN	11/64*40*4.3	B37	SS6204350TN0	M4*35
A20	SM17017670CN	11/64*40*7	B38	SS6204400TN0	M4*40
A21	SM1C035675CN	11/64*40*7.5	B39	SS6204450TN0	M4*45
A22	SM10825690SH	11/64*40*9	B40	SS6205060TN0	M5*6
A23	SM146266B5CN	11/64*40*11.5	B41	SS6205080TD0	M5*8
A24	SM172316C0CN	11/64*40*12	B42	SS6205080TN0	M5*8
A25	SS6003080SC0	M3*8	B43	SS6205100TD0	M5*10
A26	SS6003080SD0	M3*8	B44	SS6205100TN0	M5*10
A27	SS6003100CC0	M3*10	B45	SS6205100TP0	M5*10
A28	SS6004100SC0	M4*10	B46	SS6205120TN0	M5*12
			B47	SS6205140TN0	M5*14
			B48	SS6205150MZ0	M5*15
			B49	SS6205150TD0	M5*15
B	Hexagon Socket Head Cap Screw		B50	SS6205150TN0	M5*15
B1	SS6202080TD0	M2*8	B51	SS6205160TN0	M5*16
B2	SS6202100TD0	M2*10	B52	SS6205180TN0	M5*18
B3	SS6276050TN0	M2.6*5	B53	SS6205200TD0	M5*20
B4	SS6203030TN0	M3*3	B54	SS6205200TN0	M5*20
B5	SS6203040TN0	M3*4	B55	SS6205220TN0	M5*22
B6	SS6203050TN0	M3*5	B56	SS6205230TN0	M5*23
B7	SS6203060TD0	M3*6	B57	SS6205250TN0	M5*25
B8	SS6203060TN0	M3*6	B58	SS6205300TN0	M5*30
B9	SS6203080TD0	M3*8	B59	SS6205350TN0	M5*35
B10	SS6203080TN0	M3*8	B60	SS6205350TN1	M5*35
B11	SS6203100TD0	M3*10	B61	SS6205400TN0	M5*40
B12	SS6203100TN0	M3*10	B62	SS6205450TN0	M5*45
B13	SS6203120TN0	M3*12	B63	SS6205500TN0	M5*50
B14	SS6203150TD0	M3*15	B64	SS6205500TN1	M5*50
B15	SS6203150TN0	M3*15	B65	SS6205550TN0	M5*55
B16	SS6203160TN0	M3*16	B66	SS6205600TN0	M5*60
B17	SS6203180TN0	M3*18	B67	SS6205600TN1	M5*60

B.C.D.E

No.	Part No.	Remark	No.	Part No.	Remark
B	Hexagon Socket Head	Cap Screw	C7	SS9306150SC0	M6*15
B68	SS6206080TN0	M6*8	C8	SS9306450SD0	M6*45
B69	SS6206090TN0	M6*9	C9	SS9306500SC0	M6*50
B70	SS6206100TN0	M6*10	C10	SS9306500SD0	M6*50
B71	SS6206120TN0	M6*12	C11	SS9306550SD0	M6*55
B72	SS6206150TN0	M6*15	C12	SS9306650SD0	M6*65
B73	SS6206180TN0	M6*18	C13	SS9306750SC0	M6*75
B74	SS6206200TN0	M6*20	C14	SS9308150TN0	M8*15
B75	SS6206250TN0	M6*25	C15	SS9308180TN0	M8*18
B76	SS6206300TN0	M6*30	C16	SS9310300TN0	M10*30
B77	SS6206350TN0	M6*35	C17	SS9310350SC0	M10*35
B78	SS6206400TN0	M6*40	C18	SS9310350TN0	M10*35
B79	SS6206450TN0	M6*45	C19	SS9310400SC1	M10*40
B80	SS6206450TN1	M6*45	C20	SS9312500TN0	M12*50
B81	SS6206500TN1	M6*50			
B82	SS6206650TN0	M6*65			
B83	SS6506750TN1	M6*75			
B84	SS6206800TN1	M6*80	D	Round Fillister Head Screw	
B85	SS6206A00TN0	M6*100	D1	SM66514540CL	9/64*40*4
B86	SS6208120TN0	M8*12	D2	SM66015550CL	9/64*40*5
B87	SS6208150TN0	M8*15	D3	SM66015550CN	9/64*40*5
B88	SS6208150TP0	M8*15	D4	SM67018550CN	9/64*40*5
B89	SS6208200TN0	M8*20	D5	SM67020550CN	9/64*40*5
B90	SS6208250TN0	M8*25	D6	SM66015560CL	9/64*40*6
B91	SS6208300TN0	M8*30	D7	SM66015560CN	9/64*40*6
B92	SS6208350TN0	M8*35	D8	SM67020560CL	9/64*40*6
B93	SS6208400TN0	M8*40	D9	SM67020560CN	9/64*40*6
B94	SS6208400TN1	M8*40	D10	SM65817568CN	9/64*40*6.8
B95	SS6208450TN0	M8*45	D11	SM67020580CL	9/64*40*8
B96	SS6208450TN1	M8*45	D12	SM67020580CN	9/64*40*8
B97	SS6208500TN0	M8*50	D13	SM660255A0CN	9/64*40*10
B98	SS6208600TN0	M8*60	D14	SM670205C0CN	9/64*40*12
B99	SS6208700TN0	M8*70	D15	SM67015660CN	11/64*40*6
B100	SS6210200TN0	M10*20	D16	SM67530665CN	11/64*40*6.5
B101	SS6210250TN0	M10*25	D17	SM675306A5CN	11/64*40*10.5
B102	SS6210300TN0	M10*30	D18	SM675306C0CN	11/64*40*12
B103	SS6210350TN0	M10*35	D19	SM675256F0CN	11/64*40*15
B104	SS6210400TN0	M10*40	D20	SM69065CQ5CN	9/32*28*24.5
B105	SS6212300TN0	M12*30	D21	SS7003050SD0	M3*5
B106	SS6212350TN0	M12*35			
			E	Pan Head Screw	
C	Hexagon Bolt		E1	SS4164014MZ0	M1.4*1.4
C1	SS9303060SD0	M3*6	E2	SS4102030MZ0	M2*3
C2	SS9304080SD0	M4*8	E3	SS4102040MZ0	M2*4
C3	SS9305100SD0	M5*10	E4	SS4102080MZ0	M2*8
C4	SS9305150SC0	M5*15	E5	SS4175030MZ0	M2.5*3
C5	SS9305150SD0	M5*15	E6	SS4175040MZ0	M2.5*4
C6	SS9305200SD0	M5*20	E7	SS4175050MZ0	M2.5*5

No.	Part No.	Remark	No.	Part No.	Remark
E	Pan Head Screw		E57	SS4105500SD1	M5*50
E8	SS4175080MZ0	M2.5*8	E58	SS4105600SD1	M5*60
E9	SS4175130MZ0	M2.5*13			
E10	SS4175130SD0	M2.5*13			
E11	SS4103030MZ0	M3*3			
E12	SS4103030SD0	M3*3	F	Countersunk Head Screw	
E13	SS4103040CD0	M3*4	F1	SMA55005A0CN	9/64*40*10
E14	SS4103040MZ0	M3*4	F2	SMB7000680CN	11/64*40*8
E15	SS4103040SD0	M3*4	F3	SS1102060SD0	M2*6
E16	SS4103050MZ0	M3*5	F4	SS1103040MZ0	M3*4
E17	SS4103050SD0	M3*5	F5	SS1103040SD0	M3*4
E18	SS4103060MZ0	M3*6	F6	SS1103050MZ0	M3*5
E19	SS4103060SA0	M3*6	F7	SS1103050SD0	M3*5
E20	SS4103060SD0	M3*6	F8	SS1003060SD0	M3*6
E21	SS4103080MZ0	M3*8	F9	SS1103060MZ0	M3*6
E22	SS4103080SA0	M3*8	F10	SS1103060SD0	M3*6
E23	SS4103080SD0	M3*8	F11	SS1103070SD0	M3*7
E24	SS4103100SC1	M3*10	F12	SS1003080SD0	M3*8
E25	SS4103100SD0	M3*10	F13	SS1103080MZ0	M3*8
E26	SS4103110SC1	M3*11	F14	SS1103080SC0	M3*8
E27	SS4103120MZ0	M3*12	F15	SS1103080SD0	M3*8
E28	SS4103120SD0	M3*12	F16	SS1103080SN0	M3*8
E29	SS4103140SA0	M3*14	F17	SS1103100SD0	M3*10
E30	SS4103140SD0	M3*14	F18	SS1103120MZ0	M3*12
E31	SS4103150SD0	M3*15	F19	SS1103120SD0	M3*12
E32	SS4103160SD0	M3*16	F20	SS1103150MZ0	M3*15
E33	SS4103200SD0	M3*20	F21	SS1103160SD0	M3*16
E34	SS4103400SD1	M3*40	F22	SS1104050SD0	M4*5
E35	SS4103500SD1	M3*50	F23	SS1104060MZ0	M4*6
E36	SS4104040SD0	M4*4	F24	SS1104060SD0	M4*6
E37	SS4104050SD0	M4*5	F25	SS1104080MZ0	M4*8
E38	SS4104060MZ0	M4*6	F26	SS1104080SD0	M4*8
E39	SS4104060SD0	M4*6	F27	SS1104100MZ0	M4*10
E40	SS4104080SD0	M4*8	F28	SS1104100SD0	M4*10
E41	SS4104100SD0	M4*10	F29	SS1104120SD0	M4*12
E42	SS4104120SD0	M4*12	F30	SS1104140SD0	M4*14
E43	SS4104150SD0	M4*15	F31	SS1104150SD0	M4*15
E44	SS4104180SD0	M4*18	F32	SS1104200SD0	M4*20
E45	SS4104300SD0	M4*30	F33	SS1104220SD0	M4*22
E46	SS4104500SD0	M4*50	F34	SS1104250SD0	M4*25
E47	SS4104600SD1	M4*60	F35	SS1105060SD0	M5*6
E48	SS4105060SD0	M5*6	F36	SS1105080SD0	M5*8
E49	SS4105070SD0	M5*7	F37	SS1105100MZ0	M5*10
E50	SS4105080SD0	M5*8	F38	SS1105100SD0	M5*10
E51	SS4105100MZ0	M5*10	F39	SS1105120SD0	M5*12
E52	SS4105100SD0	M5*10	F40	SS1105150SD0	M5*15
E53	SS4105120SD0	M5*12	F41	SS1105300SD0	M5*30
E54	SS4105300SD1	M5*12	F42	SS1105350SD0	M5*35
E55	SS4105150SD0	M5*15	F43	SS1105400SD0	M5*40
E56	SS4105450SD1	M5*45	F44	SS1106150SC0	M6*15

F.G.H.J.K

No.	Part No.	Remark	No.	Part No.	Remark
F	Countersunk Head Screw		H30	SS0104065SD0	M4*6.5
F45	SS1106150SD0	M6*15	H31	SS0104080MZ0	M4*8
F46	SS1106350SD0	M6*35	H32	SS0104080SD0	M4*8
F47	SS1108120SD0	M8*12	H33	SS0104080MZ2	M4*8
F48	SS1108700TN0	M8*70	H34	SS0104100MZ0	M4*10
			H35	SS0104100SD0	M4*10
			H36	SS0104120SD0	M4*12
			H37	SS0104150SD0	M4*15
G	Round Countersunk Head Screw		H38	SS0104200SD0	M4*20
G1	SMC5000460CL	1/8*44*6	H39	SS0105050SD0	M5*5
G2	SMC5000530CL	9/64*40*3	H40	SS0105060SD0	M5*6
G3	SMC5000535CL	9/64*40*3.5	H41	SS0105065SD0	M5*6.5
G4	SMC5000540CL	9/64*40*4	H42	SS0105070SD0	M5*7
G5	SMC5000560CL	9/64*40*6	H43	SS0105080MZ0	M5*8
G6	SMC5000570CL	9/64*40*7	H44	SS0105080SD0	M5*8
G7	SMC5000595CL	9/64*40*9.5	H45	SS0105100MZ0	M5*10
G8	SMC50005C0CL	9/64*40*12	H46	SS0105100SD0	M5*10
			H47	SS0105120MZ0	M5*12
			H48	SS0105120SD0	M5*12
			H49	SS0105150SD0	M5*15
H	Truss Head Screw		H50	SS0105200SD0	M5*20
H1	SMF6016470CL	1/8*44*7	H51	SS0105250SD0	M5*25
H2	SMF8020530CL	9/64*40*3.5	H52	SS0105300SD0	M5*30
H3	SMF8020540CL	9/64*40*4	H53	SS0105350SD0	M5*35
H4	SME9510540CM	9/64*40*4	H54	SS0106080SD0	M6*8
H5	SMF8020560CL	9/64*40*6	H55	SS0106100SD0	M6*10
H6	SMF8020580CL	9/64*40*8	H56	SS0106220SD0	M6*22
H7	SS0175030MZ0	M2.5*3	H57	SS0106250SD0	M6*25
H8	SS0175030SD0	M2.5*3	H58	SS0106350SD0	M6*35
H9	SS0175040MZ0	M2.5*4	H59	SS0106400SD0	M6*40
H10	SS0175040SA0	M2.5*4			
H11	SS0175040SD0	M2.5*4			
H12	SS0103030MZ0	M3*3			
H13	SS0103030SD0	M3*3	J	Round Head Screw	
H14	SS0103040SD0	M3*4	J1	SS3102030MZ0	M2*3
H15	SS0103050MZ0	M3*5	J2	SS3103080SD0	M3*8
H16	SS0103050SD0	M3*5	J3	SS3103080SE0	M3*8
H17	SS0103060MZ0	M3*6	J4	SS3103100MZ0	M3*10
H18	SS0103060SD0	M3*6			
H19	SS0103060SA0	M3*6			
H20	SS0103080SD0	M3*8			
H21	SS0103080SA0	M3*8	K	Slotted Set Screw	
H22	SS0103100MZ0	M3*10	K1	SMK0000435CN	1/8*44*3.5
H23	SS0103100SD0	M3*10	K2	SMK0000560CN	9/64*40*6
H24	SS0103200SD0	M3*20	K3	SMK0000625CN	11/64*40*2.5
H25	SS0104040MZ0	M4*4	K4	SMK0000635CN	11/64*40*3.5
H26	SS0104050MZ0	M4*5	K5	SMK0000640CN	11/64*40*4
H27	SS0104050SD0	M4*5	K6	SMK0000650CN	11/64*40*5
H28	SS0104060MZ0	M4*6	K7	SMK0000A50CN	15/64*28*5
H29	SS0104060SD0	M4*6	K8	SMK0000AA0CN	15/64*28*10

K.L.M.N.P

No.	Part No.	Remark	No.	Part No.	Remark
K	Slotted Set Screw		L37	SS8208100TN0	M8*10
K9	SMK0000AF0CN	15/64*28*15	L38	SS8208150TN0	M8*15
K10	SMK0000AH0CN	15/64*28*17			
K11	SMK0000B40CN	1/4*40*4			
K12	SMK0000B45CN	1/4*40*4.5			
K13	SMK0000B50CN	1/4*40*5	M	Hexagon Socket Head Button Screw	
K14	SMK0000B60CN	1/4*40*6	M1	SS3203050SC0	M3*5
K15	SMK0000B80CN	1/4*40*8	M2	SS3204060SC0	M4*6
K16	SMK0000CC0CN	9/32*28*12	M3	SS3204080SC0	M4*8
K17	SS8005060TN0	M5*6	M4	SS3204080SD0	M4*8
			M5	SS3205100SC0	M5*10
			M6	SS3205100SD0	M5*10
L	Hexagon Socket Head Set Screw				
L1	SMJ0000425CN	1/8*44*2.5			
L2	SMJ0000430CN	1/8*44*3	N	Screw with Washer	
L3	SMJ0000690CN	11/64*28*9	N1	SSA003080000	M3*8
L4	SMJ0000640CN	11/64*40*4	N2	SSA003150000	M3*15
L5	SMJ0000660CN	11/64*40*6	N3	SSA003160000	M3*16
L6	SMJ0000680CN	11/64*40*8	N4	SSA003180000	M3*18
L7	SMJ0000A40CN	15/64*28*4	N5	SSA004080000	M4*8
L8	SMJ0000A90CN	15/64*28*9	N6	SSA004100000	M4*10
L9	SS8275030TN0	M2.5*3	N7	SSA004550000	M4*55
L10	SS8203020TN0	M3*2	N8	SSA005100000	M5*10
L11	SS8203030TN0	M3*3	N9	SSA005120000	M5*12
L12	SS8203040TN0	M3*4	N10	SSA005140000	M5*14
L13	SS8203050TN0	M3*5	N11	SSA005180000	M5*18
L14	SS8203060TN0	M3*6			
L15	SS8203080TN0	M3*8			
L16	SS8204030TN0	M4*3			
L17	SS8204040TN0	M4*4	P	Nut	
L18	SS8204050TN0	M4*5	P1	SMN046030CN0	1/8*44*6*3
L19	SS8204060TN0	M4*6	P2	SMN056020CL0	9/64*40*6*2
L20	SS8204060TN1	M4*6	P3	SMN056030CN0	9/64*40*6*3
L21	SS8204080TN0	M4*8	P4	SMN066020CN0	11/64*40*6*2
L22	SS8204100TN0	M4*10	P5	SMN066030CN0	11/64*40*6*3
L23	SS8204120TN0	M4*12	P6	SMN067030CN0	11/64*40*7*3
L24	SS8205040TN0	M5*4	P7	SMN167030CN0	11/64*40*7*3
L25	SS8205050TN0	M5*5	P8	SSN166XA0000	M1.6 Type 1
L26	SS8205060TN0	M5*6	P9	SSN002SD0000	M2 Type 1
L27	SS8205080TN0	M5*8	P10	SSN073SD0000	M2.3 Type 1
L28	SS8205100TN0	M5*10	P11	SSN075MZ0000	M2.5 Type 1
L29	SS8205120TN0	M5*12	P12	SSN003MZ0000	M3 Type 1
L30	SS8205150TN0	M5*15	P13	SSN003SC0000	M3 Type 1
L31	SS8206050TN0	M6*5	P14	SSN003SD0000	M3 Type 1
L32	SS8206060TN0	M6*6	P15	SSN403SD0000	M3 Thumbscrew Type 2
L33	SS8206080TN0	M6*8	P16	SSN203SC0000	M3 Type 3
L34	SS8206100TN0	M6*10	P17	SSN203SD0000	M3 Type 3
L35	SS8206180TN0	M6*18	P18	SSN285SC0000	M3.5 Type 3
L36	SS8208080TN0	M8*8	P19	SSN004SC0000	M4 Type 1

P.R

No.	Part No.	Remark	No.	Part No.	Remark
P	Nut		R22	WSP05A008SD0	Plain M5*10*0.8t
P20	SSN004SD0000	M4 Type 1	R23	WSP05C008MZ0	Plain M5*12*0.8t
P21	SSN204SC0000	M4 Type 3	R24	WSP05C008SC0	Plain M5*12*0.8t
P22	SSN204SD0000	M4 Type 3	R25	WSP05C008SD0	Plain M5*12*0.8t
P23	SSN005SC0000	M5 Type 1	R26	WSP06D010SC0	Plain M6*13*1.0t
P24	SSN005SD0000	M5 Type 1	R27	WSP06D010SD0	Plain M6*13*1.0t
P25	SSN205SC0000	M5 Type 3	R28	WSP06G010SC0	Plain M6*16*1.0t
P26	SSN205SD0000	M5 Type 3	R29	WSP08G012SD0	Plain M8*16*1.2t
P27	SSN605SD0000	M5 Cap Screw	R30	WSP08J016SC0	Plain M8*18*1.6t
P28	SSN006SC0000	M6 Type 1	R31	WSP08J016SD0	Plain M8*18*1.6t
P29	SSN006SC1000	M6 Type 1(Left)	R32	WSP08J032SC0	Plain M8*18*3.2t
P30	SSN006SD0000	M6 Type 1	R33	WSP08N032SC0	Plain M8*22*3.2t
P31	SSN006SD1000	M6 Type 1(Left)	R34	WSP10S032SC0	Plain M10*26*3.2t
P32	SSN206SC0000	M6 Type 3	R35	WSP12L520SC0	Plain M12*20.5*2t
P33	SSN008SC0000	M8 Type 1	R36	WSS020000KD0	Spring M2
P34	SSN008SD0000	M8 Type 1	R37	WSS760000KC0	Spring M2.6
P35	SSN208SC0000	M8 Type 3	R38	WSS030000KC0	Spring M3
P36	SSN208SD0000	M8 Type 3	R39	WSS030000KD0	Spring M3
P37	SSN010SC0000	M10 Type 1	R40	WSS850000KC0	Spring M3.5
P38	SSN710CD0000	M10 with Flange	R41	WSS040000KC0	Spring M4
P39	SSN710SC0000	M10 with Flange	R42	WSS040000KD0	Spring M4
P40	SSN012SC0000	M12 Type 1	R43	WSS050000KC0	Spring M5
P41	SSN212SC0000	M12 Type 3	R44	WSS050000KD0	Spring M5
P42	SSN216SC0000	M16 Type 3	R45	WSS050000MZ0	Spring M5
P43	SSN020SC0000	M20 Type 1	R46	WSS060000KC0	Spring M6
			R47	WSS060000KD0	Spring M6
			R48	WSS080000KC0	spring M8
			R49	WSS080000KD0	spring M8
R	Washer		R50	WSS100000KC0	Spring M10
R1	WSP640303MZ0	Plain M1.4*3*0.3t	R51	WSS120000KC0	Spring M12
R2	WSP023505XZ0	Plain M2*3.5*0.5t	R52	WSW04B003TP0	Wave M4
R3	WSP765005XB0	Plain M2.6*5*0.5t	R53	WSW05B003TN0	Wave M5
R4	WSP767505XB0	Plain M2.6*7.5*0.5t	R54	WSW06A503TN0	Wave M6
R5	WSP036003XZ0	Plain M3*6*0.3t	R55	WSL048505TP0	With teeth M4
R6	WSP036005SC0	Plain M3*6*0.5t	R56	WSL05A006TP0	With teeth M5
R7	WSP037005SD0	Plain M3*7*0.5t	R57	WSN080000SC0	Slant M8
R8	WSP038003SD0	Plain M3*8*0.3t	R58	WSC048005SC0	Disk Spring M4
R9	WSP038005MZ0	Plain M3*8*0.5t			
R10	WSP038005SC0	Plain M3*8*0.5t			
R11	WSP038005SD0	Plain M3*8*0.5t			
R12	WSP038100SD0	Plain M3*8*1t			
R13	WSP048005SC0	Plain M4*8*0.5t			
R14	WSP048005SD0	Plain M4*8*0.5t			
R15	WSP048008SC0	Plain M4*8*0.8t			
R16	WSP048008SD0	Plain M4*8*0.8t			
R17	WSP04A008MZ0	Plain M4*10*0.8t			
R18	WSP04A008SC0	Plain M4*10*0.8t			
R19	WSP04A008SD0	Plain M4*10*0.8t			
R20	WSP04C010SC0	Plain M4*12*1t			
R21	WSP05A008SC0	Plain M5*10*0.8t			

1st Edition (2001.07) July, 2001

■ **Manufactured by:**
Tokai Industrial Sewing Machine Co., Ltd.

NO.1800, Ushiyama-cho, Kasugai, Aichi-pre., 486-0901, Japan
Telephone:568-33-1161 Fax:568-33-1191

■ **Distributed by:**
Tajima Industries Ltd.

19-22, Shirakabe, 3-chome, Higashi-ku, Nagoya, 461-0011, Japan
Telephone:52-932-3444 Fax:52-932-2457

■ **Authorized Distributor:**

--