

ENGLISH

**SC-921
INSTRUCTION MANUAL**



CONTENTS

I . SPECIFICATIONS	1
II . SET-UP	1
1. Installing to the table	1
2. Installing the control panel	2
3. Connecting the cords	3
4. Attaching the connecting rod	11
5. Setting procedure of the machine head	12
6. Adjusting the machine head (direct-drive motor type sewing machine only)	13
III . FOR THE OPERATOR	14
1. Operating procedure of the sewing machine.....	14
2. Operation panel (CP-18).....	15
3. Operating procedure of the sewing pattern	16
(1) Reverse feed stitching pattern	16
(2) Overlapped stitching pattern	17
4. One-touch setting	18
5. Production support function	19
6. Setting of functions of SC-921	22
7. Function setting list.....	23
8. Detailed explanation of selection of functions	27
9. Automatic compensation of neutral point of the pedal sensor	37
10. Selection of the pedal specifications.....	37
11. Setting of the auto lifter function	38
12. Selecting procedure of the key-lock function	39
13. Connection of the pedal of standing-work machine	39
14. External input / output connector	40
15. Connection of the material end sensor	41
16. Initialization of the setting data	42
IV . MAINTENANCE	42
1. Removing the rear cover.....	42
2. Replacing the fuse	43
3. Error codes.....	44


I . SPECIFICATIONS

Supply voltage	Single phase 100 to 120V	3-phase 200 to 240V	Single phase 220 to 240V
Frequency	50Hz/60Hz	50Hz/60Hz	50Hz/60Hz
Operating environment	Temperature : 0 to 40°C Humidity : 90% or less	Temperature : 0 to 40°C Humidity : 90% or less	Temperature : 0 to 40°C Humidity : 90% or less
Input	450VA	450VA	450VA

* The electric power is a reference value for the model equipped with the LH-3568A machine head.
It differs by the selected machine head.

II . SET-UP

SC-921 control box




SC-921 is a discrete control box and can be used with the DD (direct-drive) system sewing machine head.

Install the control box on the table according to the instructions given below.

1. Installing to the table

* The instructions apply to the case the control box is installed on the table of the MF-7800D.
To use any other machine head, install the control box on the table referring to the Instruction Manual for the main body of the relevant sewing machine.




- 1) Install control box ② and sensor bracket ③ on the table with fitting bolt asm. ① supplied with the unit as accessories. At this time, insert supplied nuts and washers as shown in the figure so that the control box and sensor bracket are securely fixed.
- 2) Install the control box (or the one equipped with a small sized motor unit) on the table. Then, install the sewing machine head on the table. (Refer to the Instruction Manual for the sewing machine.)
- 3) Install the mounting plate on the CP-18 panel with four tapping screws ④ supplied with the unit. At this time, take care not to allow the cable to be caught under the mounting bracket. (To install the CP-18 on the table, install it as shown in Fig. A.)
- 4) Install CP-18 panel ⑤ and sensor bracket ③ on the table with wood screws ⑥.

2. Installing the control panel




WARNING :

To protect against possible personal injury due to abrupt start of the machine, be sure to start the following work after turning the power off and a lapse of 5 minutes or more.



- 1) Remove side plate setscrews ❶ from the side plate.



- 2) Install control panel ❷ on the machine head using screws ❺, flat washers ❸ and rubber seat ❹ supplied with the control panel as the accessories.

(Caution) 1. DDL-9000B (Not provided with AK) is given as an example of installing procedure.

2. Screw to install the panel changes according to the machine head used. Refer to Table 1 and confirm the kind of screw.

< The relation between the respective machine heads and the positions of installing hole of the bracket are as described in the table. >




Table 1

	Installing hole	Screw	
DDL-9000B	❶ - ❺	(Provided with AK) M5 X 14	Side plate setscrew
		(Not provided with AK) M5 X 12	
LH-3500A	❷ - ❺	M5 X 14	Side plate setscrew
DLN-9010	❷ - ❺	3/16-28 L=12	Screw supplied with panel as accessories
DDL-8700 series	❸ - ❺	3/16-28 L=12	Screw supplied with panel as accessories
DDL-5500 series *1	❸ - ❺	3/16-28 L=12	Screw supplied with panel as accessories
LZ-2280 series *1	❸ - ❺	11/64-40 L=7.8	Screws supplied with machine head

1 For the DDL-5556 and LZ-228, the machine head is supplied with an auxiliary bracket for mounting the control panel as an accessory. Be sure to install the bracket while referring to the instruction manual for the machine head.

(Caution) 1. Screws to be used for installing the panel differ with the machine head, i.e., screws supplied with the panel as accessories and the side plate setscrews. Select appropriate screws/setscrews referring to Table 1.

2. If the screw type is not correct, the tapped hole can be collapsed.

3. If you want to install the panel on the DDL-8700, be aware that the method to install it on the machine head differs depending on whether or not the machine head is provided with the AK device.
Machine head with the AK device: Install the panel on the head bracket supplied with the AK.

(The auxiliary bracket should be fixed with the side plate setscrews.)

Machine head without the AK device: Remove the side plate setscrews and install the panel on the side plate using the screws supplied with panel as accessories.

4. If you want to use the panel with the machine head for heavy-weight materials, install it referring to the "Supplementary Instructions" for the machine head.


3. Connecting the cords




WARNING :

- To prevent personal injury caused by abrupt start of the sewing machine, carry out the work after turning OFF the power switch and a lapse of 5 minutes or more.
- To prevent damage of device caused by maloperation and wrong specifications, be sure to connect all the corresponding connectors to the specified places.
- To prevent personal injury caused by maloperation, be sure to lock the connector with lock.
- As for the details of handling respective devices, read carefully the Instruction Manuals supplied with the devices before handling the devices.


Following connectors are prepared on the SC-921. Connect the connectors coming from the machine head to the corresponding places so as to fit the devices mounted on the machine head.




- | | | | |
|--------|--|--------|---|
| ① CN30 | Motor signal connector | ⑥ CN42 | Thread trimming safety switch |
| ② CN38 | Operation panel: Various kinds of sewing can be programmed. (For details of the operation panel other than CP-18, refer to the Instruction Manual for the panel to be used.) | ⑦ CN39 | Standing machine pedal : JUKI standard PK70, etc. Sewing machine can be controlled with external signals. |
| ③ CN33 | Synchronizer : It detects the needle bar position. | ⑧ CN55 | +24 V external power source |
| ④ CN37 | Presser foot lifting solenoid (Only for the automatic presser foot lifter type) | ⑨ CN57 | Simplified production control counter input |
| ⑤ CN48 | Safety switch (standard) : When tilting the sewing machine without turning the power OFF, the operation of the sewing machine is prohibited so as to protect against danger. OPTION switch: Input function can be changed by changing over the internal function with this switch. | ⑩ CN36 | Machine head solenoid: Provided with solenoids for thread trimming, reverse feed stitching, one-touch type reverse feed switch. |
| | | ⑪ CN54 | Material end detection sensor, etc. |
| | | ⑫ CN51 | Optional function/device input/output. |
| | | ⑬ CN56 | Optional function/device output (solenoid valve output). |
| | | ⑭ CN34 | Pedal sensor: The pedal sensor supplied with the SC-921 is to be connected to this connector to operate the sewing machine. |



- 1) Pass cords **1** of the thread trimming solenoid, reverse-stitching solenoid, etc. and the cord from the motor through hole **A** in the table to route them down under the machine table.



- 2) Loosen screw **B** in cover **2** with a screwdriver to open the cover.




- 3) Connect 14P code **3** coming from the machine head to connector **6** (CN36).
- 4) Insert 3P cord **9** coming from the machine head into connector **10** (CN42).
- 5) When the optional AK device is attached, connect 2P connector **4** coming from the AK device to connector **7** (CN37).

6) Connect connector **5** coming from the motor to connector **8** (CN30) on the circuit board.

7) Insert pedal sensor cable **11** into connector **12** (CN34).

- (Caution)**
1. When using the AK device, set whether to use the AK device after confirming how to select the auto-lifter function. (Refer to “[III-11. Setting of the auto lifter function](#)” p. 38.)
 2. Be sure to securely insert the respective connectors after checking the inserting directions since all connectors have the inserting directions. (When using a type with lock, insert the connectors until they go to the lock.) The sewing machine is not actuated unless the connectors are inserted properly. In addition, not only the problem of error warning or the like occurs, but also the sewing machine and the control box are damaged.


[Connecting the connector for the operation panel]



The connector for the operation panel is provided. Paying attention to the orientation of the connector **13**, connect it to connector (CN38) **14** located on the circuit board. After connecting, securely lock the connector.


- (Caution)** Be sure to turn OFF the power before connecting the connector.

[Connection of the pedal of standing-work machine]



Connect the connector of PK70 ⑮ to connector ⑯ (CN39 : 12P) of SC-921 .


(Caution) Be sure to turn OFF the power before connecting the connector.




6) After inserting the connector, put all cords together with cable clip band ⑰ located on the side of the box.

(Caution) 1. Fix the cord clamp and the cable clip band following the attaching procedure.
2. When removing the connector, remove it from the wire saddle and remove it while pressing the hook of the cable clip band.


How to fix cable clip band ⑰



How to remove cable clip band




Pushing the hook portion, push the band to remove it.




7) Close cover ② and fix the cover by tightening screw ⑮ with a screwdriver.

(Caution) Take care not to allow the cord to be caught under cover ②.




- 8) Connect connector 4P 18 to connector 19 located on the side of the box.
- 9) Connect motor output cord 20 of the power switch to connector 21.

[For CE specifications only]



Connect motor output cord 22 to connector 23 located on the side of the box.



Installing power switch

Connect power supply cord to the power switch.

[CE specifications]


Single phase 230V : Power supply cords : Brown, Blue, and green/yellow (ground wire)

[Changing over the voltage between 100 V and 200 V]




WARNING :

To prevent personal injuries caused by electric shock hazards or abrupt start of the sewing machine, carry out the work after turning OFF the power switch and a lapse of 5 minutes or more. To prevent accidents caused by unaccustomed work or electric shock, request the electric expert or engineer of our dealers when adjusting the electrical components.




* The illustration below shows the PWR-T PCB. The type of PCB differs by destination.

A




Wiring for the single-phase 100 V


Be sure to connect the wire between 1 and 2. If it is connected between 1-3 or 2-3, the sewing machine will be inoperative.




B



Wiring for the 3-phase 200 V




C



Wiring for the single-phase 200 V

Be sure to connect the wire between 1 and 2. If it is connected between 1-3 or 2-3, the sewing machine will be inoperative.



By making the following two changes, the SC-921 can be used with three different power supplies, i.e., single-phase 100 - 120 V, single-phase 200 to 240 V and 3-phase 200 to 240 V.

* Only the control box which uses PWR-T PCB can be changed.

① Replacement of the power cords

② Changing-round of connector ① on the PWR PCB

- 1) Turn OFF the power with the power switch after checking that the sewing machine has stopped.
- 2) Draw out the power cord from the power receptacle after checking that the power switch has been turned OFF. Then wait for 5 minutes or more.
- 3) Loosen the screws which are used to secure the rear lid of the control box cover. Carefully open the rear cover.

4) Changing procedure of the power voltage

(Caution) If the supply power changing is carried out in a wrong manner, the control box can break. Be extremely careful when taking the supply voltage changing procedure.

A. To change over the supply voltage from 200 - 240 V to 100 - 120 V


- Change the power cord with the JUKI genuine cord with the part number (M90355800A0). Change the earth cord with the one with the part number (M90345800A0).
- Change over supply voltage changeover connector ① mounted on the PWR PCB with the connector for 100 V.
- Connect the crimp style terminal of AC input cord to the power plug as shown in the figure A.

B,C. To change over the supply voltage from 100 - 120 V to 200 - 240 V

- Change the power cord with the JUKI genuine cord with the part number (M90175800A0).
- Change over supply voltage changeover connector ① mounted on the PWR PCB with the connector for 200 V.
- Connect the crimp contact of the AC input cord to the power plug as illustrated in Fig. B for the 3-phase power supply or as illustrated in Fig. C for the single-phase one.

5) Before closing the rear lid of the cover, ascertain again that the relevant parts have been correctly changed without fail.


6) Close the rear lid while pressing it, taking care not to allow the wiring to be caught between the rear lid of the cover and the main body of the control box. Then, secure the lid with the screws.




Locking section

(Caution) Be sure to remove the connector while holding its locking section with your fingers. Be extremely careful not to pull the connector forcibly.

[In case of using the power switch for LA]



Connect motor output cord 22 to connector 23 located on the side of the box.



Installing power switch

Connect power supply cord to the power switch.


[JUS specifications]

3-phase 220 V : Power supply cords : black, white, red and green/yellow (ground wire)


Single phase 120V : Power supply cords : black, white, and green/yellow (ground wire)

When the metallic conduit is used, be sure to change over the power cord section following the steps of procedure described below.


(Caution) Be sure to carry out this procedure before installing the control box on the machine table.




- 1) Place the control box with its frame side down on the machine table as illustrated in the sketch.
- 2) Loosen screw B in underside cover A to open the cover.




- 3) Change over the cord shown in the red-line circle following the steps of procedure described below.




- 4) Remove two screws **C** to remove clamping plate **D** from the main body of the control box.




- 5) Remove connector **E** while holding its locking section **F** with your fingers.




- 6) Turn connector **G** to remove the cord locking section.




- 7) Loosen nut **H** to remove the connector from clamping plate **D**.




- 8) Put locknut **I** on the power cord and draw out the cord **J** from inside clamping plate **D**.



- 9) Install clamping plate **D** back to the control box.
 10) Pass power cord **J** through conduit **K**.
 11) Fix conduit **K** with locknuts **I** with clamping plate **D** placed between the locknuts.



- 12) Close underside cover **A** and secure the cover with screw **B**.



10) Make sure that the power switch is turned OFF and insert power supply cord coming from the power switch into the power plug socket.


- (Caution)**
1. Top end of power supply cord varies in accordance with destination or supply voltage. Check again the supply voltage and the voltage designated on the control box when installing the switch.
 2. Be sure to prepare power plug ②4 conformed to the safety standard.
 3. Be sure to connect the ground wire (green / yellow).

4. Attaching the connecting rod



WARNING :


To protect against possible personal injury due to abrupt start of the machine, be sure to start the following work after turning the power off and a lapse of 5 minutes or more.




- 1) Fix connecting rod ① to installing hole ③ of pedal lever ② with nut ③.
- 2) Installing connecting rod ① to installing hole ① will lengthen the pedal depressing stroke, and the pedal operation at a medium speed will be easier.



5. Setting procedure of the machine head

(Caution) For the operation panel other than CP-18, refer to the Instruction Manual for the operation panel to be used for the setting procedure of the machine head.






- 1) Refer to "III-6. Setting for functions of SC-921" p.22, and call the function setting No. 95.



- 2) The type of machine head can be selected by pressing  switch 5 ( switch 6).


* Refer to the "List of machine heads" on the separate sheet or the Instruction Manual for the machine head of your sewing machine for the type of the machine head.




- 3) After selecting the type of machine head, by pressing  switch 3 ( switch 4), the step proceeds to 96 or 94, and the display automatically changes to the contents of the setting corresponding with the type of machine head.

6. Adjusting the machine head (direct-drive motor type sewing machine only)


- (Caution) 1. When the slip between the marker dot on the handwheel and the concave of the cover is excessive after thread trimming, adjust the angle of the machine head by the operation below.
2. It is not necessary to adjust the machine head the part of which is connected to CN33.
(Refer to “II-3. Connecting the cords” p. 3.)




- 1) Simultaneously pressing switch , turn ON the power switch.
- 2) is displayed (A) in the indicator and the mode is changed over to the adjustment mode.



- 3) Turn the pulley of the machine head by hand until the main-shaft reference signal is detected. At this time, the degree of an angle from the main-shaft reference signal is displayed on the indicator (B).
(The value is the reference value.)




- 4) In this state, align marker dot 7 on the pulley with recess 8 on the pulley cover.



- 5) Press switch 6 to finish the adjustment work. (The value is the reference value.)

III. FOR THE OPERATOR

1. Operating procedure of the sewing machine




1) Press ON button ❶ of the power switch to turn ON the power.

(Caution) If the power indication LED does not light up even when turning ON the power switch, immediately turn OFF the power switch and check the voltage.

In addition, in such a case as this, return ON the power switch when 2 to 3 minutes or more have passed after turning OFF the power switch.

2) When the needle bar is not in UP position, it automatically turns to the UP position.

(Caution) When turning ON the power for the first time, there is the case where the timing is slightly retarded to perform the initialization work. When turning ON the power, the needle bar moves. Do not put your hands or things under the needle.




3) When depressing front part ❸ of the pedal, the sewing machine rotates at the number of revolutions in accordance with the depressing amount. When the pedal is returned to the neutral position, the sewing machine stops.

4) When lightly depressing back part ❹ of the pedal, the presser goes up. (PFL type only)


5) When strongly depressing back part ❺ of the pedal, thread trimming is performed.

	PFL	KFL
Presser foot operation by pedal	Enabled	Disabled
Pedal depressing depth for thread trimming	Deep	Shallow




6) For some types of the sewing machine heads, it is possible to program various sewing patterns, using the operation panel, such as the reverse feed stitching at sewing start and that at sewing end. For the CP-18 ❹, refer to **"III-3. Operating procedure of sewing patterns" p.16** for details. For the operation panel other than the CP-18 ❹, refer to the individual Instruction Manual for the operation panel to be used.

(The figure given illustrates the case of the DDL-9000B.)











7) For some types of the sewing machine heads, reverse feed is performed by pressing touch-back switch ❷. (The figure given illustrates the case of the DDL-9000B.)



8) When sewing is completed, press OFF button ❷ of the power switch to turn OFF the power switch after confirming that the sewing machine has stopped.

2. Operation panel (CP-18)



- ①  switch : Used for changing over effective/ineffective of the reverse feed stitching pattern.
- ②  switch : Used for changing over effective/ineffective of the overlapped stitching pattern.
- ③  switch : Used for confirming the contents of setting and for changing over effective/ineffective of the reverse feed stitching at sewing start.
- ④  switch : Used for selecting the process (A, B, C, D) the number of stitches for which is to be changed.
* The selected process flashes on and off.
- ⑤  switch : Used for changing the content of the selected display (flashing section) and for changing over effective/ineffective of the reverse stitch at sewing end.
- ⑥  switch : Used for changing the content of the selected display (flashing section).
- ⑦  switch : Used for calling the production support function (by keeping the switch held pressed for two seconds).

Indicators ① and ② : Various pieces of information are displayed.

LED ③ : Lights up when the reverse feed stitching pattern is effective.

LED ④ : Lights up when the overlapped stitching pattern is effective.


LED ⑤ : Lights up when the production support function is displayed.

3. Operating procedure of the sewing pattern

- (Caution) 1. For the operation panel other than CP-18, refer to the Instruction Manual for the operation panel to be used.
2. For some machine heads, reverse-stitching pattern cannot be used.

(1) Reverse feed stitching pattern

Reverse feed stitching at sewing start and reverse feed stitching at sewing end can be separately programmed.



[Setting procedure of the reverse feed stitching]

- 1) Effective/ineffective of the reverse feed stitching pattern can be changed over by pressing switch ①.

When the reverse feed stitching pattern is rendered effective, LED ③ lights up, the number of stitches of the reverse feed stitching at sewing start is displayed on ①, and the number of stitches of the reverse feed stitching at sewing end is displayed on indicator ②.


Select a process (A, B, C or D) the number of stitches for which is to be changed by using ABCD switch ④.

The number which is flashing on and off represents the process which is being set.

Change the number of stitches for the selected process by using \ominus switch ⑤ and \oplus switch ⑥.

Press \hookleftarrow switch ③ to confirm the change you have made. (The number of stitches that can be set is 0 to 15.)

- (Caution) The sewing machine cannot perform sewing when the display of the number of stitches for a process is flashing on and off.




- 2) When the number of reverse feed stitches display is not flashing on and off, every press on \hookleftarrow switch ③ changes over the reverse feed stitching mode from the "reverse feed stitching at sewing start," "double reverse feed stitching at sewing start" and "no reverse feed stitching at sewing start."

In addition, every time \ominus switch ⑤ is pressed, the reverse feed stitching feature changes over from the reverse feed stitching at sewing end to the double reverse stitch at sewing end, then to no reverse feed stitching at sewing end, in turn.

(2) Overlapped stitching pattern

Overlapped stitching pattern can be programmed.



A : Number of stitches of normal stitching setting

0 to 15 stitches

B : Number of stitches of reverse stitching setting

0 to 15 stitches


C : Number of stitches of normal stitching setting

0 to 15 stitches

D : Number of times of repetition

0 to 9 times

(Caution) When process D is set to 5 times, the sewing is repeated as A → B → C → B → C.



[Setting procedure of the overlapped stitching]

- 1) Effective/ineffective of the overlapped stitching pattern can be changed over by pressing switch ②.

When the overlapped stitching pattern is rendered effective, LED ① lights up.

- 2) Select a process (A, B, C or D) the number of stitches for which is to be changed by using switch ④.

The number which is flashing on and off represents the process which is being set.

- 3) Change the number of stitches for the selected process by using minus switch ⑤ and plus switch ⑥.

- 4) Press switch ③ to confirm the change you have made.


(The sewing machine does not run unless the setting has been confirmed by pressing switch ③.)

(Caution) The overlapped stitching pattern is carried out under automatic operation mode. Once the pedal is depressed, the sewing machine will automatically perform sewing of the number of overlapped stitches.

4. One-touch setting

A part of function setting items can be easily changed in the normal sewing state.

(Caution) For the setting of functions other than those covered in this part, refer to "III-6. Setting of functions of SC-921" p.22.



[One-touch setting procedure]

- 1) Keep **i** switch ⑦ held pressed for one second to place the panel in the function setting mode.
- 2) Change over the item to be set by using **←** switch ③ or **→** switch ④. Then, the set value can be changed by using **−** switch ⑤ and **+** switch ⑥.
- 3) To return to the normal sewing state, press **i** switch ⑦.

(Caution) The setting is confirmed by pressing **i** switch ⑦.

① Thread trimming function (**f r n**)

o f f : Thread trimming operation is not performed (solenoid output prohibition: Thread trimmer, wiper)

o n : Thread trimming operation is effective.

② Wiper function (**h p**)

o f f : Wiper does not operate after thread trimming

o n : Wiper operates after thread trimming

③ One-shot automatic stitching function (**h o f**)

o f f : One-shot automatic stitching function is ineffective. **o n** : One-shot automatic stitching is effective.

(Caution) This function is rendered effective when the material end sensor function is set. It is not possible to prohibit the one-shot operation during overlapped sewing operation. The number of revolution is the value which is set for setting No. 38.

④ Setting of the max. speed of stitch (**s p d**)

The highest speed of stitch of the machine head is set. The upper limit of the set value differs with the type of machine head to which the SC is connected.

Setting range : 150 - Max. value [sti/min]

⑤ Material end sensor function (**e d**)

o f f : Material end sensor function is ineffective.

o n : Once the material end is detected, the sewing machine stops running after having sewn the number of stitches set with ⑦ (**e d s f**).

* This function is rendered effective when the material edge sensor is set up..

⑥ Thread trimming function by material end sensor (**e d f r**)

o f f : Automatic thread trimming function after the detection of material end is ineffective.

o n : Once the material end is detected, the sewing machine performs thread trimming after having sewn the number of stitches set with ⑦ (**e d s f**).

* This function is rendered effective when the material edge sensor is set up..

⑦ Number of stitches for material end sensor (**e d s f**)

The number of stitches to be sewn from the detection of material end to the stop of the sewing machine

Number of stitches that can be set: 0 to 19 (stitches)

(Caution) If the number of stitches specified is inadequate, the sewing machine can fail to stop within the preset number of stitches depending on the number of revolutions of the sewing machine.

5. Production support function

The production support function consists of three different functions (six different modes) such as the production volume management function, operation measuring function and bobbin counter function. Each of them has its own production support effect. Select the appropriate function (mode) as required.

■ Production volume management function

Target No. of pcs. display mode [F100]

Target/actual No. of pcs difference display mode [F200]

The target number of pieces, actual number of pieces and the difference between the target and actual number of pieces along with the operation time are displayed to notify the operators of a delay and advance in real time. Sewing machine operators are allowed to engage sewing while constantly checking his/her work pace. This helps raise target awareness, thereby increasing productivity. In addition, a delay in work can be found at an early stage to enable early detection of problems and early implementation of corrective measures.

■ Operation measuring function

Sewing machine availability rate display mode [F300]

Pitch time display mode [F400]

Average number of revolutions display mode [F500]


Sewing machine availability status is automatically measured and displayed on the control panel. The data obtained can be used as basic data to perform process analyses, line arrangement and equipment efficiency checkup.

■ Bobbin counter function

Bobbin counter display mode

In order to change bobbins before the current bobbin runs out of thread, the time for replacing the bobbin is notified.

[To use the production support mode]



(Caution) Modes F100 to F500 have been factory-set in the OFF state at the time of delivery.

The mode state is changed over to ON/OFF according to the setting of the bobbin thread counter function (function setting No. 6).

Keep **i** switch 7 held pressed (one second) in the normal sewing state to call the one-touch setting screen.

Then, press **A/B** switch 1 or **A/B/C/D** switch 2 to set each production support mode in ON/OFF state to call the one-touch setting screen.


Press **←** switch 3 or **A/B/C/D** switch 4 to select the mode to be set in the ON/OFF state.



ON/OFF of the display can be changed over by pressing **−** switch 5 or **+** switch 6.



To return to the normal sewing state, press **i** switch 7.




Sewing can be performed with the production support data displayed on the control panel.

[Basic operation of the production support modes]





- 1) When **i** switch 7 is pressed in the normal sewing state, LED E lights up to enter the production support mode.
- 2) Production support function can be changed over by pressing  switch 3 or  switch 4.

- 3) Data attached marked with (*1) in Table 1 "Indicator A" can be changed by means of  switch 5 and  switch 6.

- 4) When you keep  switch 6 held pressed for two seconds, indicator B and LED E flash on and off. While they are flashing on and off, data marked with (*2) in Table 1 "Display under modes" can be changed by pressing  switch 5 and  switch 6.

When you press **i** switch 7, the value marked with (*2) is confirmed and indicator B and LED E stop flashing on and off. Not that value marked with (*1) is automatically reset by changing the value marked with (*2).

- 5) The value with a sharp mark (*3) in Table 1 "Display of modes" can be changed only immediately after resetting by using  switch 5 and  switch 6.
- 6) Refer to the table "Mode resetting operation," for the resetting procedure of data.
- 7) To return to the normal sewing state, press **i** switch 7.

Data to be displayed under the respective modes are as described in the table below.

Table 1: Display of modes







Mode name	Indicator A	Indicator B	Indicator B (when  switch 5 is pressed)
Target No. of pcs. display mode [F100]	Actual number of pieces (Unit : piece) (*1)	Target number of pieces (Unit : piece) (*2)	-
Target/actual No. of pcs. difference display mode [F200]	Difference between target number of pieces and actual number of pieces (d : piece) (*1)	Target pitch time (Unit : 100 msec) (*2)	-
Sewing machine availability rate display mode [F300]	oP-r	Sewing machine availability rate in the previous sewing (Unit : %)	Display of average availability rate of sewing machine (Unit : %)
Pitch time display mode [F400]	Pi-T	Pitch time in the previous sewing (Unit : 1sec)	Display of average pitch time (Unit : 100 msec)
Average number of revolutions display mode [F500]	ASPd	Average number of revolutions in the previous sewing (Unit : sti/min)	Display of average number of revolutions (Unit : sti/min)
Bobbin counter display mode	bbn	Bobbin counter value (*3)	-



Table 2: Mode resetting operation



Mode name	 Switch ⑤ (held pressed for 2 seconds)	 Switch ⑤ (held pressed for 4 seconds)
Target No. of pcs. display mode [F100]	Resets the actual number of pieces Resets the difference between target number of pieces and actual number of pieces	-
Target/actual No. of pcs. difference display mode [F200]	Resets the actual number of pieces Resets the difference between target number of pieces and actual number of pieces	-
Sewing machine availability rate display mode [F300]	Resets average availability rate of sewing machine	Resets average availability rate of sewing machine. Resets average pitch time. Resets average number of revolutions of sewing machine.
Pitch time display mode [F400]	Resets average pitch time	Resets average availability rate of sewing machine. Resets average pitch time. Resets average number of revolutions of sewing machine.
Average number of revolutions display mode [F500]	Resets average number of revolutions of sewing machine.	Resets average availability rate of sewing machine. Resets average pitch time. Resets average number of revolutions of sewing machine.
Bobbin counter display mode	Resets the bobbin counter value (Note that only the bobbin counter is immediately reset by pressing  switch ⑤.)	-



[Detailed setting of production volume management function [F101], [F102]]



When  switch ⑦ is held pressed (for three seconds) under the target No. of pcs. display mode [F100] or the target/actual No. of pcs. difference display mode [F200], the detailed setting of the production volume management function can be carried out.

The setting state of the number of times of thread trimming [F101] and that of the target achievement buzzer [F102] can be changed over by pressing  switch ③ or  switch ④.




The number of times of thread trimming for sewing one piece of garment can be set by pressing  switch ⑤ or  switch ⑥ in the setting state of the number of times of thread trimming [F101].

It is possible to set whether the buzzer sounds or not when the actual number of pieces has reached the target volume by pressing  switch ⑤ or  switch ⑥ in the setting state of the target achievement buzzer [F102].

6. Setting of functions of SC-921

Functions can be selected and specified.

(Caution) For the function setting procedure of any operation panel other than CP-18, refer to the Instruction Manual for the operation panel to be used.



* The content of setting of the setting No. returns to the initial value by pressing \ominus switch 5 and \oplus switch 6 simultaneously.

3) After completion of the changing procedure, press \leftarrow switch 3 or ABCD switch 4 to confirm the updated value.

(Caution) If the power is turned OFF before carrying out this procedure, the changed content is not updated. When \leftarrow switch 3 is pressed, the display on the panel changes to the previous setting No. When ABCD switch 4 is pressed, the display on the panel changes to the subsequent setting No. After completion of the operation, the machine is returned to the normal sewing state by turning OFF the power and re-turning it ON.

1) Turn ON the power with info switch 7 held pressed.

(The item which has been changed during the previous work is displayed.)

* If the screen display does not change, re-carry out operation described in step 1).

(Caution) Be sure to re-turn ON the power switch when one or more seconds have passed after turning it OFF. If the power switch is re-turned ON immediately after turning it OFF, the sewing machine may fail to operate normally. In such a case, be sure to turn ON the power switch again properly.

2) To move the setting No. forward, press ABCD switch 4. To move the setting No. backward, press \leftarrow switch 3.

(Caution) If the setting No. is moved forward (or backward), the previous (or subsequent) content of the setting is confirmed. Be careful when the content of a setting is changed (when the \ominus / \oplus switch is touched).

Example) Changing the maximum number of revolutions (setting No. 96)

Press \leftarrow switch 3 or ABCD switch 4 to call setting No. "96."

The current set value is displayed on indicator B.

Press \ominus switch 5 to change the setting to "2500."

7. Function setting list

No	Item	Description	Setting range	Indication of function setting	Ref. page
1	Soft start function	The number of stitches to be sewn at a low speed when the soft-start function is used at the start of sewing. 0 : The function is not selected. 1 to 9 : The number of stitches to be sewn under the soft-start mode.	0 to 9 (Stitches)	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
2	Material end sensor function	Material end sensor function (to be used only with CP-18). 0 : Material end detection function is not operative. 1 : After detecting material end, the specified number of stitches (No. 4) will be sewn, and the sewing machine will stop.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="2"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
3	Thread trimming function by material end sensor	Thread trimming function by material end sensor (to be used only with CP-18). 0 : Automatic thread trimming function after detection of material end is not operative. 1 : After detecting material end, the specified number of stitches (No. 4) will be sewn, and the sewing machine will stop and perform automatic thread trimming.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="3"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
4	Number of stitches for material end sensor	Number of stitches for material end sensor (to be used only with CP-18). Number of stitches from detection of material end to stop of the sewing machine.	0 to 19 (Stitches)	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="4"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="5"/>	27
5	Flicker reducing function	Flicker reducing function 0 : Flicker reducing function is not operative. 1 : Flicker reducing function is effective	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="5"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
6	Bobbin thread counting function	Bobbin thread counting function 0 : Bobbin thread counting function is not operative. 1 : Bobbin thread counting function is operative.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="6"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/>	27
7	Unit of bobbin thread counting down	Unit of bobbin thread counting down 0 : 1 Count/10 stitches 1 : 1 Count/15 stitches 2 : 1 Count/20 stitches 3 : 1 Count/thread trimming	0 to 3	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="7"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	
8	Number of rotation of reverse feed stitching	Sewing speed of reverse feed stitching	150 to 3,000 (sti/min)	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="8"/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="9"/> <input type="text" value="0"/> <input type="text" value="0"/>	
9	Thread trimming prohibiting function	Thread trimming prohibiting function (to be used only with CP-18). 0 : Thread trimming is effective. 1 : Thread trimming is prohibited. (Output of solenoid is prohibited. : Thread trimmer and wiper)	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="9"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
10	Setting of needle bar stop position when the sewing machine stops.	Position of needle bar is specified when the sewing machine stops. 0: The needle bar stops at its lower position. 1: The needle bar stops at its upper position.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="0"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	27
11	Operation confirmation sound for operation panel	Operation confirmation sound for operation panel 0 : Operation confirmation sound is not generated 1 : Operation confirmation sound is generated.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="1"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/>	27
12	Optical switch function selection	Switching of function of optional switch. Refer to "III-8. Detailed explanation of selection of functions" p. 27		<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value=""/> <input type="text" value="o"/> <input type="text" value="P"/> <input type="text" value="T"/> <input type="text" value=""/>	28
13	Function of prohibiting start of the sewing machine by bobbin thread counter	Function of prohibiting start of the sewing machine by bobbin thread counting 0 : When counting is out (-1 or less) Function of prohibiting start of the sewing machine is not operative. 1 : When counting is out (-1 or less) Function of prohibiting start of the sewing machine after thread trimming is operative. 2 : When counting is out (-1 or less), the sewing machine stops once. Function of prohibiting start of the sewing machine after thread trimming is operative.	0 to 2	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	
14	Sewing counter	Counting function of sewing (number of completion of process) 0 : Sewing counter function is not operative. 1 : Sewing counter function is operative. (Every time thread trimming is performed) 2 : With the sewing counting switch input function	0 to 2	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="4"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/>	31
15	Thread wiping function after thread trimming	Thread wiping operation after thread trimming is specified. 0 : Thread wiping is not carried out after thread trimming 1 : Thread wiping is carried out after thread trimming	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/> <input type="text" value="5"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="1"/>	
21	Function of automatic presser foot lifting at pedal's neutral position	Function of lifting presser foot when the pedal is in neutral position. 0 : Function of neutral automatic presser lifting is not operative. 1 : Selection of function of neutral presser lifting.	0/1	<input type="text" value=""/> <input type="text" value=""/> <input type="text" value="2"/> <input type="text" value="1"/> <input type="text" value=""/> <input type="text" value=""/> <input type="text" value="0"/>	31


* Do not change the set values with asterisk (*) mark as they are functions for maintenance. If the standard set value set at the time of delivery is changed, it is in danger of causing the machine to be broken or the performance to be deteriorated. If it is necessary to change the set value, please purchase the Engineer's Manual and follow the instructions.

No	Item	Description	Setting range	Indication of function setting	Ref. page									
22	Needle up/down correction switch changeover function	Function of the needle up/down correction switch is changed over. 0 : Needle up/down compensation 1 : One stitch compensation	0/1	<table><tr><td></td><td></td><td>2</td><td>2</td><td></td><td></td><td>0</td></tr></table>			2	2			0	31		
		2	2			0								
25	Thread trimming operation after turning the handwheel by han	Thread trimming operation after moving the needle away from its upper or lower position by turning the handwheel by hand is specified. 0 : Thread trimming operation is carried out after turning the handwheel by hand 1 : Thread trimming operation is not carried out after turning the handwheel by hand	0/1	<table><tr><td></td><td></td><td>2</td><td>5</td><td></td><td></td><td>1</td></tr></table>			2	5			1			
		2	5			1								
29	Setting of one-touch type reverse feed solenoid pull-in time	This function sets the suction time of initial motion of back-tack solenoid. 50 ms to 500 ms	50 to 500 (ms)	<table><tr><td></td><td></td><td>2</td><td>9</td><td></td><td>7</td><td>0</td></tr></table>			2	9		7	0	31		
		2	9		7	0								
30	Function of reverse feed stitching on the way	Function of reverse feed stitching on the way 0 : Normal one-touch type reverse feed stitching function 1 : Function of reverse feed stitching on the way is operative.	0/1	<table><tr><td></td><td></td><td>3</td><td>0</td><td></td><td></td><td>0</td></tr></table>			3	0			0	32		
		3	0			0								
31	Number of stitches of reverse feed stitching on the way	Number of stitches of reverse feed stitching on the way.	0 to 19 (Stitches)	<table><tr><td></td><td></td><td>3</td><td>1</td><td></td><td></td><td>4</td></tr></table>			3	1			4	32		
		3	1			4								
32	Effective condition of reverse feed stitching on the way when the sewing machine is stopping.	Effective condition of reverse feed stitching on the way 0 : Function is not operative when the sewing machine stops. 1 : Function is operative when the sewing machine stops.	0/1	<table><tr><td></td><td></td><td>3</td><td>2</td><td></td><td></td><td>0</td></tr></table>			3	2			0	32		
		3	2			0								
33	Thread trimming function by reverse feed stitching on the way	Thread trimming function by reverse feed stitching on the way 0 : Automatic thread trimming function after completion of reverse feed stitching on the way is not operative. 1 : Automatic thread trimming after completion of reverse feed stitching on the way is performed.	0/1	<table><tr><td></td><td></td><td>3</td><td>3</td><td></td><td></td><td>0</td></tr></table>			3	3			0	32		
		3	3			0								
35	Number of rotation at a low speed	Lowest speed by pedal (The MAX value differs by machine head.)	150 to MAX (sti/min)	<table><tr><td></td><td></td><td>3</td><td>5</td><td></td><td>2</td><td>0</td><td>0</td></tr></table>			3	5		2	0	0		
		3	5		2	0	0							
36	Number of rotation of thread trimming	Thread trimming speed (The MAX value differs by machine head.)	100 to MAX (sti/min)	<table><tr><td></td><td></td><td>3</td><td>6</td><td></td><td>2</td><td>1</td><td>0</td></tr></table>			3	6		2	1	0		
		3	6		2	1	0							
37	Number of rotation of soft-start	Sewing speed at the start of sewing (soft-start) (The MAX value differs by machine head.)	100 to MAX (sti/min)	<table><tr><td></td><td></td><td>3</td><td>7</td><td></td><td>8</td><td>0</td><td>0</td></tr></table>			3	7		8	0	0	27	
		3	7		8	0	0							
38	One-shot speed	One-shot speed (The max. value depends on the number of rotation of the sewing machine head.)	150 to MAX (sti/min)	<table><tr><td></td><td></td><td>3</td><td>8</td><td></td><td>2</td><td>5</td><td>0</td><td>0</td></tr></table>			3	8		2	5	0	0	32
		3	8		2	5	0	0						
39	Pedal stroke at the start of rotation	Position where the sewing machine starts rotating from pedal neutral position (Pedal stroke)	10 to 50 (0.1 mm)	<table><tr><td></td><td></td><td>3</td><td>9</td><td></td><td></td><td>3</td><td>0</td></tr></table>			3	9			3	0		
		3	9			3	0							
40	Low speed section of pedal	Position where the sewing machine starts accelerating from pedal neutral position (Pedal stroke)	10 to 100 (0.1 mm)	<table><tr><td></td><td></td><td>4</td><td>0</td><td></td><td></td><td>6</td><td>0</td></tr></table>			4	0			6	0		
		4	0			6	0							
41	Starting position of lifting presser foot by pedal	Position where the cloth presser starts lifting from pedal neutral position (Pedal stroke)	− 60 to −10 (0.1mm)	<table><tr><td></td><td></td><td>4</td><td>1</td><td></td><td>−</td><td>2</td><td>1</td></tr></table>			4	1		−	2	1		
		4	1		−	2	1							
42	Starting position of lowering presser foot	Starting position of lowering presser foot Stroke from the neutral position	8 to 50 (0.1 mm)	<table><tr><td></td><td></td><td>4</td><td>2</td><td></td><td></td><td>1</td><td>0</td></tr></table>			4	2			1	0		
		4	2			1	0							
43	Pedal stroke 2 for starting thread trimming	Position 2 where the thread trimming starts from pedal neutral position (When the function of lifting presser foot by pedal is provided.) (Pedal stroke) (Effective only when Item No. 50 is set at 1.)	− 60 to −10 (0.1 mm)	<table><tr><td></td><td></td><td>4</td><td>3</td><td></td><td>−</td><td>5</td><td>1</td></tr></table>			4	3		−	5	1		
		4	3		−	5	1							
44	Pedal stroke for reaching the maximum number of rotation	Position where the sewing machine reaches its highest sewing speed from pedal neutral position (Pedal stroke)	10 to 150 (0.1 mm)	<table><tr><td></td><td></td><td>4</td><td>4</td><td></td><td>1</td><td>5</td><td>0</td></tr></table>			4	4		1	5	0		
		4	4		1	5	0							
45	Compensation of neutral point of the pedal	Compensation value of the pedal sensor	−15 to 15	<table><tr><td></td><td></td><td>4</td><td>5</td><td></td><td></td><td></td><td>0</td></tr></table>			4	5				0		
		4	5				0							
47	Auto-lifter selecting function	Limitation time of waiting for lifting solenoid type auto-lifter device	10 to 600 (second)	<table><tr><td></td><td></td><td>4</td><td>7</td><td></td><td></td><td>6</td><td>0</td></tr></table>			4	7			6	0	33	
		4	7			6	0							
48	Pedal stroke 1 for starting thread trimming	Position where thread trimming starts from pedal neutral position (Standard pedal) (Pedal stroke) (Effective only when Item No. 50 is set at 0.)	− 60 to − 10 (0.1 mm)	<table><tr><td></td><td></td><td>4</td><td>8</td><td></td><td>−</td><td>3</td><td>5</td></tr></table>			4	8		−	3	5		
		4	8		−	3	5							
49	Lowering time of presser foot	Sets the time required until the lowering of the presser foot is completed after a depress on the pedal	0 to 500 (10 ms)	<table><tr><td></td><td></td><td>4</td><td>9</td><td></td><td>1</td><td>4</td><td>0</td></tr></table>			4	9		1	4	0	35	
		4	9		1	4	0							

* Do not change the set values with asterisk (*) mark as they are functions for maintenance. If the standard set value set at the time of delivery is changed, it is in danger of causing the machine to be broken or the performance to be deteriorated. If it is necessary to change the set value, please purchase the Engineer's Manual and follow the instructions.

No	Item	Description	Setting range	Indication of function setting	Ref. page								
50	Pedal specification	Type of pedal sensor is selected. 0 : KFL 1 : PFL Refer to “ III-10. Selection of the pedal specifications ” p. 37.	0/1	<table><tr><td></td><td></td><td>5</td><td>0</td><td></td><td></td><td>1</td></tr></table>			5	0			1		
		5	0			1							
51	Compensation of solenoid-on timing of reverse feed stitching at the start of sewing	Compensation of starting the solenoid for reverse feed stitching when reverse feed stitching at the start of sewing is performed.	− 36 to 36 (10°)	<table><tr><td></td><td></td><td>5</td><td>1</td><td></td><td></td><td>1</td><td>0</td></tr></table>			5	1			1	0	33
		5	1			1	0						
52	Compensation of solenoid-off timing of reverse feed stitching at the start of sewing	Compensation of releasing the solenoid for reverse feed stitching when reverse feed stitching at the start of sewing is performed.	− 36 to 36 (10°)	<table><tr><td></td><td></td><td>5</td><td>2</td><td></td><td></td><td>1</td><td>6</td></tr></table>			5	2			1	6	33
		5	2			1	6						
53	Compensation of solenoid-off timing of reverse feed stitching at the end of sewing	Compensation of releasing the solenoid for reverse feed stitching when reverse feed stitching at the end of sewing is performed.	− 36 to 36 (10°)	<table><tr><td></td><td></td><td>5</td><td>3</td><td></td><td></td><td>1</td><td>8</td></tr></table>			5	3			1	8	33
		5	3			1	8						
55	Foot lift after thread trimming	Function of lifting presser foot at the time of (after) thread trimming 0 : Not provided with the function of automatic lifting of work-clamp after thread trimming 1 : Provided with the function of lifting presser foot automatically after thread trimming	0/1	<table><tr><td></td><td></td><td>5</td><td>5</td><td></td><td></td><td>1</td></tr></table>			5	5			1	34	
		5	5			1							
56	Reverse revolution to lift the needle after thread trimming	Function of reverse revolution to lift the needle at the time of (after) thread trimming 0 : Not provided with the function of reverse revolution to lift the needle after thread trimming 1 : Provided with the function of reverse revolution to lift the needle after thread trimming	0/1	<table><tr><td></td><td></td><td>5</td><td>6</td><td></td><td></td><td>0</td></tr></table>			5	6			0	34	
		5	6			0							
58	Function of holding predetermined upper/lower position of the needle bar	Function of holding predetermined upper/lower position of the needle bar 0 : Not provided with the function of holding predetermined upper/lower position of the needle bar 1 : Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is weak.) 2 : Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is medium.) 3 : Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is strong.)	0 to 3	<table><tr><td></td><td></td><td>5</td><td>8</td><td></td><td></td><td>0</td></tr></table>			5	8			0	34	
		5	8			0							
59	Function of Auto/ Manual change-over of reverse feed stitching at the start of sewing	This function can specify the sewing speed of reverse feed stitching at the start of sewing. 0 : The speed will depend on the manual operation by pedal, etc. 1 : The speed will depend on the specified reverse feed stitching speed (No. 8).	0/1	<table><tr><td></td><td></td><td>5</td><td>9</td><td></td><td></td><td>1</td></tr></table>			5	9			1	34	
		5	9			1							
60	Function of stop immediately after reverse feed stitching at the start of sewing	Function at the time of completion of reverse feed stitching at the start of sewing 0 : Not provided with the function of temporary stop of the sewing machine at the time of completion of reverse feed stitching at the start of sewing 1 : Provided with the function of temporary stop of the sewing machine at the time of completion of reverse feed stitching at the start of sewing.	0/1	<table><tr><td></td><td></td><td>6</td><td>0</td><td></td><td></td><td>0</td></tr></table>			6	0			0	34	
		6	0			0							
64	Change-over speed of condensation stitch or EBT (end back tack)	Initial speed when starting condensation stitch or EBT	0 to 250 (sti/min)	<table><tr><td></td><td></td><td>6</td><td>4</td><td></td><td>1</td><td>8</td><td>0</td></tr></table>			6	4		1	8	0	
		6	4		1	8	0						
70	Function of soft-down of presser foot	Presser foot is slowly lowered. 0 : Presser foot is rapidly lowered. 1 : Presser foot is slowly lowered.	0/1	<table><tr><td></td><td></td><td>7</td><td>0</td><td></td><td></td><td>0</td></tr></table>			7	0			0	35	
		7	0			0							
71	Double reverse feed stitching function	Effective/ineffective of double reverse feed stitching is changed over. (to be used only with CP-18) 0 : Ineffective 1 : Effective	0/1	<table><tr><td></td><td></td><td>7</td><td>1</td><td></td><td></td><td>1</td></tr></table>			7	1			1		
		7	1			1							
72	Sewing machine startup selecting function	Current limit at the startup of sewing machine is specified. 0 : Normal (Current limit is applied during startup) 1 : Rapid (Current limit is not applied during startup)	0/1	<table><tr><td></td><td></td><td>7</td><td>2</td><td></td><td></td><td>0</td></tr></table>			7	2			0		
		7	2			0							
73	Retry function	This function is used when needle cannot pierce materials . 0 : Normal 1 : Retry function is provided.	0/1	<table><tr><td></td><td></td><td>7</td><td>3</td><td></td><td></td><td>1</td></tr></table>			7	3			1	35	
		7	3			1							
74	With/without thread trimmer for MF	With/without thread trimmer for MF is selected. 0 : Not provided with the tread trimmer 1 : Provided with the thread trimmer	0/1	<table><tr><td></td><td></td><td>7</td><td>4</td><td></td><td></td><td>1</td></tr></table>			7	4			1		
		7	4			1							
76	One-shot function	One-shot operation up to the material end is specified. (to be used only with CP-18) 0 : One-shot operation is not performed. 1 : One-shot operation is performed.	0/1	<table><tr><td></td><td></td><td>7</td><td>6</td><td></td><td></td><td>0</td></tr></table>			7	6			0	27	
		7	6			0							
84	Initial motion suction time of presser foot lifting solenoid	Suction motion time of presser foot lifting solenoid	50 to 500 (ms)	<table><tr><td></td><td></td><td>8</td><td>4</td><td></td><td>2</td><td>5</td><td>0</td></tr></table>			8	4		2	5	0	35
		8	4		2	5	0						

* Do not change the set values with asterisk (*) mark as they are functions for maintenance. If the standard set value set at the time of delivery is changed, it is in danger of causing the machine to be broken or the performance to be deteriorated. If it is necessary to change the set value, please purchase the Engineer's Manual and follow the instructions.

No	Item	Description	Setting range	Indication of function setting	Ref. page
87	Function of pedal curve selection	Pedal curve is selected. (Improving pedal inching operation) 	0/1/2	<div> <div></div> <div></div> <div>8</div> <div>7</div> <div></div> <div></div> <div>0</div> </div>	35
90	Initial motion up stop function	Automatic UP stop function is set immediately after turning ON the power. 0 : off 1 : on	0/1	<div> <div></div> <div></div> <div>9</div> <div>0</div> <div></div> <div></div> <div>1</div> </div>	36
91	Function of prohibiting compensation operation after turning handwheel by hand	It is effective in combination with the machine head provided with tension release function. 0 : Tension release function is ineffective. 1 : Tension release function is effective.	0/1	<div> <div></div> <div></div> <div>9</div> <div>1</div> <div></div> <div></div> <div>1</div> </div>	
92	Function of reducing speed of reverse feed stitching at the start of sewing	Function to reduce speed at the time of completion of reverse feed stitching at the start of sewing. 0 : Speed is not reduced. 1 : Speed is reduced.	0/1	<div> <div></div> <div></div> <div>9</div> <div>2</div> <div></div> <div></div> <div>0</div> </div>	35
93	Function added to needle up/down compensating switch	Operation of needle up/down compensating switch is changed after turning ON the power or thread trimming. 0 : Normal (needle up/down compensating stitching only) 1 : One stitch compensating stitching is performed only when aforementioned changeover is made. (Upper stop → up-per stop)	0/1	<div> <div></div> <div></div> <div>9</div> <div>3</div> <div></div> <div></div> <div>0</div> </div>	36
94	Continuous + One-shot nonstop function	The function that does not stop the sewing machine by combining continuous stitching with one-shot stitching using the program sewing function which is available in the IP operation panel. 0 : Normal (The sewing machine stops when a step is completed.) 1 : The sewing machine does not stop when a step is completed and proceeds to next step.	0/1	<div> <div></div> <div></div> <div>9</div> <div>4</div> <div></div> <div></div> <div>0</div> </div>	36
95	Head selection function	Machine head to be used is selected. (When the machine head is changed, each setting item is changed to the initial value of the machine head.)		<div> <div></div> <div></div> <div>9</div> <div>5</div> <div>d</div> <div>L</div> <div>8</div> <div>7</div> </div>	
96	Max. number of rotation setting	Max. number of rotation of the sewing machine head can be set. (The MAX value differs by machine head.)	150 to MAX (sti/min)	<div> <div></div> <div></div> <div>9</div> <div>6</div> <div>4</div> <div>0</div> <div>0</div> <div>0</div> </div>	36
100	Number of stitches sewn before thread clamp works at the beginning of sewing	Sets the number of stitches to be sewn at the beginning of sewing before the thread clamp solenoid (CN36-7) starts operating 0: Thread clamp solenoid does not operate. 1-9: The number of stitches to be sewn before the thread clamp solenoid operates	0-9 (stitches)	<div> <div></div> <div>1</div> <div>0</div> <div>0</div> <div></div> <div></div> <div>0</div> </div>	
103	Needle cooler output OFF delay time	Delay time from the stop of sewing machine to the output OFF is specified using the needle cooler output function.	100 to 2000 ms	<div> <div></div> <div>1</div> <div>0</div> <div>3</div> <div></div> <div>5</div> <div>0</div> <div>0</div> </div>	
120	Main shaft reference angle compensation	Main shaft reference angle is compensated.	-60 to 60	<div> <div></div> <div>1</div> <div>2</div> <div>0</div> <div></div> <div></div> <div>0</div> </div>	36
121	Up position starting angle compensation	Angle to detect UP position starting is compensated.	-15 to 15	<div> <div></div> <div>1</div> <div>2</div> <div>1</div> <div></div> <div></div> <div>0</div> </div>	36
122	DOWN position starting angle compensation	Angle to detect DOWN position starting is compensated.	-15 to 15	<div> <div></div> <div>1</div> <div>2</div> <div>2</div> <div></div> <div></div> <div>0</div> </div>	36
124	Setting of energy-saving function during standby	Setting to reduce the power consumption while the sewing machine is in standby state 0: Energy-saving mode is ineffective 1: Energy-saving mode is effective	0/1	<div> <div></div> <div>1</div> <div>2</div> <div>4</div> <div></div> <div></div> <div>0</div> </div>	36

* Do not change the set values with asterisk (*) mark as they are functions for maintenance. If the standard set value set at the time of delivery is changed, it is in danger of causing the machine to be broken or the performance to be deteriorated. If it is necessary to change the set value, please purchase the Engineer's Manual and follow the instructions.

8. Detailed explanation of selection of functions

① Selection of the soft-start function (Function setting No. 1)

The needle thread may fail to interlace with the bobbin thread at the start of sewing when the stitching pitch (stitch length) is small or a thick needle is used. To solve such problem, this function (called "soft-start") is used to limit the sewing speed, thereby assuring successful formation of the starting stitches.

1 **0**

0 : The function is not selected.

1 to 9 : The number of stitches to be sewn under the soft-start mode.

The sewing speed limited by the soft-start function can be changed. (Function setting No. 37)

3 **7** **8** **0** **0**

Data setting range

100 to MAX sti/min <10 sti/min> (The MAX value differs by machine head.)

② Material end sensor function (Function setting No. 2 to 4, 76)

This function is possible when the material end sensor is attached.

For details, refer to "[III-15. Connection of the material and sensor](#)" p. 41 and the Instruction Manual for the material end sensor.

(Caution) This function is rendered effective only with the CP-18.

③ Flicker reducing function (Function setting No. 5)

The function reduces flickering of the hand lamp at the start of sewing.

5 **0**

0 : Flicker reducing function is ineffective

1 : Flicker reducing function is effective

(Caution) When the flicker reducing function is set at the "Flicker reducing function is effective," the startup speed of the sewing machine decreases.

④ Bobbin thread counting function (Function setting No. 6)

When the control panel is used, the function subtracts from the predetermined value and indicates the used amount of bobbin thread.

For the details, refer to the instruction manual for the control panel.

6 **1**

0 : Bobbin thread counting function is not operative.

1 : Bobbin thread counting function is operative.

(Caution) If "0" is set, the LCD indication on the control panel will go out and the bobbin thread counting function will be invalid.

⑤ Thread trimming prohibiting function (Function setting No. 9)

This function turns OFF thread trimming solenoid output and wiper solenoid output when thread trimming is actuated.

(Caution) This function is rendered effective only with the CP-18.

By this function, separate sewing material can be spliced and sewn without trimming thread.

9 **0**

0 : off Thread trimming is operative. (thread can be trimmed).

1 : on Thread trimming is inoperative. (thread can not be trimmed).

⑥ Setting of the needle bar stop position when the sewing machine stops (Function setting No. 10)

The position of the needle bar when the pedal is in its neutral position is specified.

1 **0** **0**

0 : Down The needle bar stops in the lowest position of its stroke.

1 : Up The needle bar stops in the highest position of its stroke.

(Caution) If the stop position of the needle bar is set to the highest position, the thread trimming action will be taken after the needle bar comes down once to the lowest position.

⑦ Panel operating sound (Function setting No. 11)


Whether the panel operation generates sound or not can be selected.

1 **1** **1**

0 : off Operation confirmation sound is not generated

1 : on Operation confirmation sound is generated.

⑧ Selection of the optional input/output function (Function setting No. 12)



1 2 o P T _

o P T _ _ E n d

i n _ _

o u T _

i 0 1 * * *

i 1 2

o 0 1 * * *

o 0 3

Select function setting No. 12 with the operating procedure of function setting procedures 1) through 3).

Select the items of "End", "in" and "ouT" with keys 5 and 6.

[When "in" is selected]

The input function setting connector indication number is shown on indicating section (A). Designate the indication number by means of key 3 or 4. Specify the function of the pin of the connector corresponding to the indication number by means of key 5 or 6.

Function code and abbreviation are displayed alternately on indicator (B). (For the relation between signal input No. and connector pin array, refer to the separate list.)

[When "ouT" is selected]

The output function setting connector indication number is shown on indicating section (A). Designate the indication number by means of key 3 or 4. Specify the function of the pin of the connector corresponding to the indication number by means of key 5 or 6.

Function code and abbreviation are displayed alternately on indicator (B). (Refer to the separate table for the relation between the signal output numbers and the connector pin configuration.)

* Example) To assign the thread trimming function to the input function setting connector indication number "i01" (CN36-4)

1 2 o P T _

o P T _ i n _ _

i 0 1 n o P

i 0 1 T S W

Lighting alternately

L _ _ 4

i 0 1 L _ _ 4

H _ _ 4

i 0 2 S F S W

o P T _ i n _ _

o P T _ _ E n d

1. Select function setting No. 12 with the operating procedure of function setting procedures 1) through 3).

2. Select the item of "in" with keys 5 and 6.

3. Select the port of the indication number "i01" by means of key 4.

4. Select the thread trimming function, "TSW" with keys 5 and 6.

5. Determine the thread trimming function, "TSW" with key 4.

6. Set ACTIVE of the signal with keys 5 and 6.

Set the display to "L" when the signal is "Low" and performing thread trimming, and set the display to "H" when the signal is "High" and performing thread trimming.

7. Determine the aforementioned function with key 4.

8. Finish the optional input with key 4.

9. Select the item of "End" with keys 5 and 6 to return to the function setting mode.

Input function list

Function code	Abbreviation	Function item	Remarks
0	noP	No function	(Standard setting)
1	HS	Needle up / down compensating stitching	Every time the switch is pressed, normal feed stitching by half stitch is performed. (Same operation as that of up / down compensating stitching switch on the panel.)
2	bHS	Back compensating stitching	Reverse feed stitching is performed at low speed while the switch is held pressing. (It is effective only when a constant-dimension sewing is selected.)
3	EbT	Function of canceling once reverse feed stitching at the end of sewing	By depressing the back part of the pedal after pressing the switch, operation of reverse feed stitching is canceled once.
4	TSW	Thread trimming function	This function is actuated as the thread trimming switch.
5	FL	Presser foot lifting function	This function is actuated as the foot lifter switch.
6	oHS	One stitch compensating stitching	Every time the switch is pressed, one stitch stitching operation is executed.
7	SEbT	Function of cancel of reverse feed stitching at start/end	By operating the optional switch, ineffective/effective can be alternately changed over.
8	PnFL	Presser lifting function when pedal is neutral	Every time the switch is pressed, the function whether automatically lifting the presser foot when the pedal is neutral or not can be selected.
9	Ed	Material edge sensor input	This function works as the input signal of material edge sensor.
10	LinH	Function of prohibiting depressing front part of pedal	Rotation by pedal is prohibited.
11	TinH	Function of prohibiting thread trimming output	Output of thread trimming is prohibited.
12	LSSW	Low speed command input	This function works as low speed switch for standing sewing machine.
13	HSSW	High speed command input	This function works as high speed switch for standing sewing machine.
14	USW	Needle lifting function	UP stop motion is performed when switch is pressed during DOWN stop.
15	bT	Reverse feed stitching switch input	Reverse feed stitching is output as long as the switch is held pressed.
16	SoFT	Soft start switch input	The speed of stitch is limited to the predetermined soft-start speed as long as the switch is held pressed.
17	oSSW	One-shot speed command switch input	This function works as one-shot speed command as long as the switch is pressed.
18	bKoS	Backward one-shot speed command switch input	Reverse feed stitching is performed in accordance with the one-shot speed command as long as the switch is held pressed.
19	SFSW	Safety switch input	Rotation is prohibited.
20	MES	Thread trimming safety switch input	It operates as an input signal of the thread trimmer safety switch.
21	AUbT	Automatic reverse feed stitching cancellation/addition switch	Every time the switch is pressed, reverse feed stitching at sewing start or reverse feed stitching at sewing end is cancelled or added.
22	CUnT	Sewing counter input	Every time the switch is pressed, the sewing counter value is increased.

Output function list

Function code	Abbreviation	Function item	Remarks
0	noP	No function	(Standard setting)
1	TrM	Thread trimming output	Output of thread trimming signal
2	WiP	Thread wiper output	Output of thread wiper signal
3	TL	Thread release output	Output of thread release signal
4	FL	Presser lifter output	Output of presser lifting signal
5	bT	Reverse feed stitching output	Output of reverse feed stitching signal
6	EbT	EBT cancel monitor output	State of one time cancel of reverse feed stitching at end function is output.
7	SEbT	Reverse feed stitching at start/end cancel monitor output	State of cancel of reverse feed stitching at start/end is output.
8	AUbT	Sewing start/end cancellation/addition monitor output	State of cancel or addition of automatic reverse feed stitching is output.
9	SSTA	Sewing machine stop state output	Sewing machine stop state is output.
10	Cool	Needle cooler output	Output for needle cooler
11	bUZ	Buzzer output	It is output when the bobbin counter set value has been exceeded, an error has occurred or the bobbin thread remaining amount is detected.
12	LSWo	Revolution command output	Revolution demanding command state is output.

Input function setting connectors

Connector No.	Pin No.	Display No.	Initial value of function setting
CN36	4	i01	noP (No function setting)
CN48	2	i02	SFSW (Safety switch input)
CN50	12	i03	SoFT (Soft-start speed limit input)
CN36	5	i04	bT (Reverse feed stitching switch input)
CN50	11	i05	LinH (Input of prohibition of depress on front part of pedal)
CN39	7	i06	TSW (Thread trimming switch input)
	11	i07	LSSW (Low-speed revolution switch input)
	9	i08	HSSW (High-speed revolution switch input)
	5	i09	FL (Presser foot lifting switch input)
CN57	1	i10	CUnT (Sewing counter input)
CN42	2	i11	noP (No function setting)
CN54	3	i12	noP (No function setting)
CN56	6	i13	noP (No function setting)
	7	i14	noP (No function setting)
	8	i15	noP (No function setting)
	9	i16	noP (No function setting)

Output function setting connector

Connector No.	Pin No.	Display No.	Initial value of function setting
CN50	7	o01	bT (Reverse feed stitching output)
	8	o02	TrM (Thread trimming output)
	9	o03	LSWo (Revolution request output)
CN56	2	o04	noP (No function setting)
	4	o05	noP (No function setting)
	6	o06	noP (No function setting)
	8	o07	noP (No function setting)
CN51	2	o08	noP (No function setting)
	3	o09	noP (No function setting)
	4	o10	noP (No function setting)
	5	o11	noP (No function setting)

⑨ **Sewing counting function (Function setting No. 14)**

The function counts up every time thread trimming is completed and counts the number of completion of the sewing process.

1 **4** **1**

0 : off Sewing counting function is inoperative.

1 : on Sewing counting function is operative. (Every time thread trimming is performed)

2 : on External sewing counter switch input.

(Caution) The sewing counter can only be operative when the CP-180 is used with the sewing machine.

The counter indication changes as shown below according to the combination of setting No. 6 and setting No. 14.

Setting No. 6	Setting No. 14	Counter
1	1	Bobbin counter
1	0	Bobbin counter
0	1	Sewing counter (only with CP-180)
0	0	Counter function is ineffective.

⑩ **Neutral automatic presser lifting function (with AK device only) (Function setting No. 21)**

This function can automatically lift the presser foot when the pedal is in the neutral position.

Automatic lifting time of the pedal depends on the automatic lifting time after thread trimming and when the presser foot is automatically lowered, it is automatically lifted at the second neutral position after it has come off the neutral position once.

2 **1** **0**

0 : off Function of neutral automatic presser lifting is not operative.

1 : on Selection of function of neutral automatic presser lifting

⑪ **Needle up/down switch function changeover function (Function setting No. 22)**

The needle up/down switch function can be changed over between the needle up/down compensation and one stitch compensation.

2 **2** **0**

0 : Needle up / down compensating stitching

1 : One stitch compensating stitching

⑫ **Setting of the suction time of the back-tack solenoid (Function setting No. 29)**

This function can change the suction time of the back-tack solenoid.

It is effective to decrease the value when the heat is high.

(Caution) When the value is excessively decreased, failure of motion or defective pitch will follow.

Be careful when changing the value.

2 **9** **7** **0**

Setting range : 50 to 500 ms <10 / ms>

⑬ Function of reverse feed stitching on the way (Function setting Nos. 30 to 33)

Functions of the limit of number of stitches and thread trimming command can be added to the touch back switch on the sewing machine head.

Function setting No. 30

3 **0** **0**

Function of reverse feed stitching on the way is selected.

0 : off Normal back-tack function

1 : on Function of reverse feed stitching on the way

Function setting No. 31

3 **1** **4**

Number of stitches performing reverse feed stitching is set.

Setting range

0 to 19 stitches

Function setting No. 32

3 **2** **0**

Effective condition of reverse feed stitching on the way

0 : off Inoperative when the sewing machine stops. (Reverse feed stitching on the way functions only when the sewing machine is running.)

1 : on Operative when the sewing machine stops.

(Reverse feed stitching on the way functions both when the sewing machine is running and stops.)

(Caution) Either condition is operative when the sewing machine is running.

Function setting No. 33

3 **3** **0**

Thread trimming is performed when reverse feed stitching on the way is completed.

0 : off Without thread trimming

1 : on Thread trimming is executed.

Application	Function setting			Output function
	No.30	No.32	No.33	
①	0	0 or 1	0 or 1	It works as normal touch-back switch.
②	1	0	0	When operating touch-back switch at the time of depressing front part of the pedal, reverse feed stitching as many as the number of stitches specified by the function setting No. 31 can be performed.
③	1	1	0	When operating touch-back switch at the time of either stop of the sewing machine or depressing front part of the pedal, reverse feed stitching as many as the number of stitches specified by the function setting No. 31 can be performed.
④	1	0	1	When operating touch-back switch at the time of depressing front part of the pedal, automatic thread trimming is performed after reverse feed stitching as many as the number of stitches specified by the function setting No. 31 has been performed.
⑤	1	1	1	When operating touch-back switch at the time of either stop of the sewing machine or depressing front part of the pedal, automatic thread trimming is performed after reverse feed stitching as many as the number of stitches specified by the function setting No. 31 has been performed.

Actions under each setting state

① Used as the normal reverse feed stitching touch-back switch.

② Used for reinforcing seam (press sewing) of the pleats. (It works only when the sewing machine is running.)

③ Used for reinforcing seam (press sewing) of the pleats.

(It works either when the sewing machine stops or when the sewing machine is running.)

④ Used as starting switch for reverse feed stitching at the sewing end.

(Used as the substitute for thread trimming by depressing back part of the pedal. It works only when the sewing machine is running. It is especially effective when the sewing machine is used as the standing-work machine.)

⑤ Used as starting switch for reverse feed stitching at the sewing end.

(Used as the substitute for thread trimming by depressing back part of the pedal. It works either when the sewing machine stops or when the sewing machine is running. It is especially effective when the sewing machine is used as the standing-work machine.)

⑭ Number of rotation of one-shot stitching (Function setting No. 38)

This function can set, by the pedal operation of one time, the sewing speed of one-shot stitching when the sewing machine continues stitching until completing the number of stitches specified or detecting the material end.

3 **8** **2** **5** **0** **0**

Setting range

150 to MAX. sti/min. <50 / sti/min>

(Caution) The max. number of rotation of one-shot stitching is limited by the model of the sewing machine head.

⑮ Holding time of lifting presser foot (Function setting No. 47)

This function automatically lowers the presser foot when the time set with the setting No. 47 has passed after lifting the presser foot.

When the pneumatic type presser foot lifter is selected, the holding time control of lifting presser foot is limitless regardless of the set value.

□□47□□60

Setting range

10 to 600 sec <10 / sec>

⑯ Compensation of timing of the solenoid for reverse feed stitching (Function setting No. 51 to 53)

When the normal and reverse feed stitches are not uniform under the automatic reverse feed stitching action, this function can change the ON / OFF timing of the solenoid for back tack and compensate the timing.

① Compensation of on-timing of solenoid for reverse feed stitching at the start of sewing (Function setting No. 51)


On-timing of solenoid for reverse feed stitching at the start of sewing can be compensated by the unit of angle.

□□51□□10

Adjusting range

− 36 to 36 <1 / 10°>

Set value	Compensation angle	Number of stitches of compensation
− 36	− 360 °	− 1
− 18	− 180 °	− 0.5
0	0 °	0
18	180 °	0.5
36	360 °	1



② Compensation of off-timing of solenoid for reverse feed stitching at the start of sewing (Function setting No. 52)


Off-timing of solenoid for reverse feed stitching at the start of sewing can be compensated by the unit of angle.

□□52□□16

Adjusting range

− 36 to 36 <1 / 10°>

Set value	Compensation angle	Number of stitches of compensation
− 36	− 360 °	− 1
− 18	− 180 °	− 0.5
0	0 °	0
18	180 °	0.5
36	360 °	1



③ Compensation of off-timing of solenoid for reverse feed stitching at the end of sewing (Function setting No. 53)


Off-timing of solenoid for reverse feed stitching at the end of sewing can be compensated by the unit of angle.

□□53□□18

Adjusting range

− 36 to 36 <1 / 10°>

Set value	Compensation angle	Number of stitches of compensation
− 36	− 360 °	− 1
− 18	− 180 °	− 0.5
0	0 °	0
18	180 °	0.5
36	360 °	1



⑰ Foot lift function after thread trimming (Function setting No. 55)

This function can automatically lift the presser foot after thread trimming. This function is effective only when it is used in combination with the AK device.

☐ ☐ ☐ **5** ☐ ☐ ☐ ☐ **1**

0 : off Function of automatically lifting the presser foot is not provided.
(Presser foot does not automatically go up after thread trimming.)

1 : on Function of automatically lifting the presser foot is provided.
(Presser foot automatically goes up after thread trimming.)

⑱ Reverse revolution to lift the needle after thread trimming (Function setting No. 56)

This function is used to make the sewing machine rotate in the reverse direction after thread trimming to lift the needle bar almost to highest position. Use this function when the needle appears under the presser foot and it is likely to make scratches on the sewing products of heavy-weight material or the like.

☐ ☐ ☐ **5** ☐ ☐ ☐ ☐ **6** ☐ ☐ ☐ ☐ **0**

0 : off Function of making the sewing machine rotate in the reverse direction to lift the needle after thread trimming is not provided.

1 : on Function of making the sewing machine rotate in the reverse direction to lift the needle after thread trimming is provided.

(Caution) The needle bar is raised, by rotating the machine in the reverse direction, almost to the highest dead point. This may result in slip-off of the needle thread. It is therefore necessary to adjust the length of thread remaining after thread trimming properly.

⑲ Function of holding predetermined upper / lower position of the needle bar (Function setting No. 58)

When the needle bar is in the upper position or in the lower position, this function holds the needle bar by applying a brake slightly.

☐ ☐ ☐ **5** ☐ ☐ ☐ ☐ ☐ **8** ☐ ☐ ☐ ☐ **0**

0 : off Not provided with the function of holding predetermined upper/lower position of the needle bar

1 : on Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is weak.)

2 : on Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is medium.)

3 : on Provided with the function of holding predetermined upper/lower position of the needle bar (holding force is strong.)

⑳ Change-over function of AUTO / Pedal for sewing speed of the reverse feed stitching at the start of sewing (Function setting No. 59)

This function selects whether the reverse feed stitching at the start of sewing is performed without a break at the speed set by the function setting No. 8 or the stitching is performed at the speed by the pedal operation.

☐ ☐ ☐ **5** ☐ ☐ ☐ ☐ ☐ ☐ **9** ☐ ☐ ☐ ☐ **1**

0 : Manual The speed is indicated by the pedal operation.

1 : Auto Automatic stitching at the specified speed

(Caution) 1. The max. sewing speed of the reverse feed stitching at the start of sewing is limited to the speed set by the function setting No. 8 regardless of the pedal.
2. When "0" is selected, stitches of reverse feed stitching may not match those of normal feed stitching.

㉑ Function of stop immediately after the reverse feed stitching at the start of sewing (Function setting No. 60)


This function temporarily stops the sewing machine even when keeping depressing the front part of the pedal at the time of completion of process of reverse feed stitching at the start of sewing.

It is used when sewing a short length by reverse feed stitching at the start of sewing.

☐ ☐ ☐ **6** ☐ ☐ ☐ ☐ ☐ ☐ **0** ☐ ☐ ☐ ☐ **0**

0 : Not provided with the function of temporary stop of the sewing machine immediately after the reverse feed stitching at the start of sewing

1 : Provided with the function of temporary stop of the sewing machine immediately after the reverse feed stitching at the start of sewing



②② Function of soft-down of presser foot (with AK device only) (Function setting Nos. 70 and 49)

This function can softly lower the presser foot.

This function can be used when it is necessary to decrease contact noise, cloth defect, or slippage of cloth at the time of lowering the presser foot.

Note : Change the time of function setting No. 49 together at the time of selecting the function of soft-down since the sufficient effect cannot be obtained unless the time of function setting No. 49 is set longer when lowering the presser foot by depressing the pedal.

□□49□□140

0 to 500 ms
10 ms/Step

□□70□□□□0

0 : Function of soft-down of presser foot is not operative. (Presser foot is rapidly lowered.)

1 : Selection of function of soft-down of presser foot

②③ Function of reducing speed of reverse feed stitching at the start of sewing (Function setting No. 92)

Function to reduce speed at the time of completion of reverse feed stitching at the start of sewing : Normal use depending on the pedal condition (Speed is accelerated to the highest without a break.)


This function is used when temporary stop is used properly. (Cuff and cuff attaching)

□□92□□□□0

0 : Speed is not reduced.

1 : Speed is reduced.

Temporary stop



②④ Retry function (Function setting No. 73)

When the retry function is used, if the sewing material is thick and not pierced with needle, this function makes the needle pierce in the material with ease.

□□73□□□□1

0 : Normal

1 : Retry function is provided.

②⑤ Presser foot lifting solenoid suction time setting (Function setting No. 84)

Suction time of presser foot lifting solenoid can be changed. When heating is great, it is effective to lessen the value.

(Caution) When the value is excessively small, malfunction will be caused. So, be careful when changing the value.

□□84□□250

Setting range : 50 to 500ms <10/ms>

②⑥ Function of pedal curve selection (Function setting No. 87)

This function can perform the selection of the curve of number of rotation of the sewing machine against the depressing amount of the pedal.


Change to this function when you feel that inching operation is hard or that pedal response is slow.

□□87□□□□0

0 : Number of rotation of the sewing machine in terms of the depressing amount of the pedal increases linearly.

1 : Reaction to intermediate speed in terms of the depressing amount of the pedal is delayed.

2 : Reaction to intermediate speed in terms of the depressing amount of the pedal is advanced.



②7 Initial motion UP stop position move function (Function setting No. 90)

Effective/ineffective of automatic return to UP stop position immediately after turning ON the power can be set.

9 0 1 0 : Ineffective
1 : Effective

②8 Function added to the needle up / down compensating switch (Function setting No. 93)

One stitch operation can be performed only when the needle up / down compensating switch is pressed at the time of upper stop immediately after turning ON the power switch or upper stop immediately after thread trimming.

9 3 0 0 : Normal (Only needle up / down compensating stitching operation)
1 : One stitch compensating stitching operation (upper stop → upper stop)
is performed only when aforementioned changeover is made.

②9 Continuous stitching + one shot stitching nonstop function (Function setting No. 94)

This function is used to proceed a step to the next one without stopping the sewing machine at the end of the step when performing sewing with the continuous sewing and one-shot sewing combined using the programming function of the operation panel IP.

9 4 0 0 : Normal (Stop when a step has completed.)
1 : The sewing machine proceeds to next step without stopping after a step has completed.

③0 Setting of max. number of rotation of the sewing machine head (Function setting No. 96)

This function can set the max. number of rotation of the sewing machine head you desire to use. Upper limit of the set value varies in accordance with the sewing machine head to be connected.

9 6 4 0 0 0 150 to Max. [sti/min] <50 / sti/min>

③1 Main shaft reference angle compensation (Function setting No. 120)

Main shaft reference angle is compensated

1 2 0 0 Setting range
– 60 to 60° <1 / °>

③2 UP position starting angle compensation (Function setting No. 121)

Angle to detect UP position starting is compensated.

1 2 1 0 Setting range
– 15 to 15° <1 / °>

③3 DOWN position starting angle compensation (Function setting No. 122)

Angle to detect DOWN position starting is compensated.

1 2 2 0 Setting range
– 15 to 15° <1 / °>


③4 Setting of energy saving function during standby (Function setting No. 124)


It is possible to reduce power consumption while the sewing machine is in standby state. It should be noted that the startup of the sewing machine may delay for a moment if this function is set.

1 2 4 0 0 : Energy-saving mode is ineffective.
1 : Energy-saving mode is effective.

9. Automatic compensation of neutral point of the pedal sensor

Whenever the pedal sensor, spring, etc. are replaced, be sure to perform following operation :



- 1) Pressing switch  ④, turn ON the power switch.
- 2) Compensated value is displayed on indicator ②.

(Caution) 1. At this time, the pedal sensor does not work properly if the pedal is depressed. Warning sound "blips" and the correct compensation value is not displayed.

2. If any display ("-0-" or "-8-") other than a numeric value appears on indicator ②, refer to the Engineer's Manual.

- 3) Turn OFF the power switch, and turn ON the power switch again to return to the normal mode.

(Caution) Be sure to re-turn ON the power switch when one or more seconds have passed after turning it OFF.


(If the ON-OFF operation is carried out faster than the above, the setting may not change normally.)

10. Selection of the pedal specifications

When the pedal sensor has been replaced, change the set value of function setting No. 50 according to the newly connected pedal specifications.

0 : KFL

1 : PFL



(Caution) Pedal sensor with two springs located at the back part of the pedal type is PFL, and that with one spring type is KFL. Set the pedal sensor to PFL when lifting the presser foot by depressing the back part of the pedal.


11. Setting of the auto lifter function



WARNING :

When the solenoid is used with the air drive setting, the solenoid may be burned out. So, do not mistake the setting.

When the auto-lifter device (AK) is attached, this function makes the function of auto-lifter work.



- 1) Turn ON the power switch with switch **5** held pressed.
- 2) "FL ON" is displayed on indicators **A** and **B** with a blip to make the auto lifter function effective.
- 3) Turn OFF the power switch, and turn ON the power switch again to return to the normal mode.
- 4) Repeat the operation 1) to 3), and LED display is turned to (FL OFF). Then, the function of auto-lifter does not work.

FL ON : Auto-lifter device becomes effective. Selection of the auto-lifter device of solenoid drive (+33V) or of air drive (+24V) can be performed with switch **6**.
(Changeover is performed to drive power +33V or +24V of CN37.)

Solenoid drive display (+33V)


Air drive display (+24V)

FL OFF : Auto-lifter function does not work. (Similarly, the presser foot is not automatically lifted when programmed stitching is completed.)

- (Caution)
1. To perform re-turning ON of the power, be sure to perform after the time of one second or more has passed.
(If ON / OFF operation of the power is performed quickly, setting may be not changed over well.)
 2. Auto-lifter is not actuated unless this function is properly selected.
 3. When "FL ON" is selected without installing the auto-lifter device, starting is momentarily delayed at the start of sewing. In addition, be sure to select "FL OFF" when the auto-lifter is not installed since the touch-back switch may not work.

12. Selecting procedure of the key-lock function


Setting of the number of stitches for a pattern can be prohibited by enabling the key lock function.



- 1) Turn ON the power switch with switch ⑤ and switch ⑥ held pressed.
- 2) "KEY LOCK" is displayed on indicators ① and ② with a blip to make the key-lock function effective.
- 3) The panel returns to the normal operation after displaying "KEY LOCK" on the indicators.

- 4) While the key lock function is effective, "KEY LOCK" is displayed on the indicators when turning the power ON.
- 5) When you carry out steps 1) to 3) in repetition, "KEY LOCK" is not displayed when turning the power ON and the key lock function is rendered ineffective.
 - KEY LOCK display when turning the power ON
 - Display appears: The key lock function is effective.
 - Display does not appear: The key lock function is ineffective.

13. Connection of the pedal of standing-work machine



- 1) Connect the connector of PK70 to connector ① (CN39 : 12P) of SC-921 .
- 2) Tighten the cord of PK70 together with other cords with cable clip band ② attached to the side of the box after passing it through the cable clamp.

(Caution) Be sure to turn OFF the power before connecting the connector.

14. External input / output connector

External input/output connector (CN50) ❶ which can take out the following signals that are convenient when installing counter or the like outside is prepared.

(Caution) When using the connector, note that the engineer who has the electrical knowledge has to work.




Table of assignment of connector and signal


CN50	Signal name	Input / output	Description	Electric spec.
1	+5V	-	Power source	
2	MA	Output	Rotation signal 360 pulses/rotation	DC5V
3	MB	Output	—	DC5V
4	UDET(N)	Output	"L" is output when needle bar is at LOW position.	DC5V
5	DDET(N)	Output	"L" is output when needle bar is at UP position.	DC5V
6	HS(N)	Output	Rotation signal 45 pulses/rotation	DC5V
7	BTD(N)	Output	"L" is output when the back-tack solenoid works.	DC5V
8	TRMD(N)	Output	"L" is output when the thread trimmer solenoid works.	DC5V
9	LSWO(P)	Output	Rotation request (pedal or the like) monitor signal	DC5V
10	S.STATE(N)	Output	"L" is output when the sewing machine is in the stop state.	DC5V
11	LSWINH(N)	Input	Rotation by pedal is prohibited while "L" signal is being inputted.	DC5V, -5mA
12	SOFT	Input	Rotation speed is limited to the soft-speed while "L" signal is being inputted.	DC5V, -5mA
13	SGND	-	0V	

JUKI genuine part No.

Connector : Part No. HK016510130

Pin contact : Part No. HK016540000

15. Connection of the material end sensor



Pin No.	Signal name	Remarks
1	+12V	Power supply is selected according to the sensor used.
2	+5V	
3	OPT_S	Sensor input is assigned to the material end sensor.
4	GND	

- 1) Connect the connector of material end sensor to connector ❶ (CN54 : 4P) of SC-921.
- 2) Tighten the cord of the material end sensor together with other cords with cable clip band ❷ attached to the side of the box after passing it through the cable clamp.
- 3) Assign CN54 to the material end sensor input referring to "III-8-⑧. Optional input/output function selection (function setting No. 12) p.28.
- 4) To use the material end sensor with the CP-18, set up the sensor functions on the control box through the function setting procedure. Selectable functions and the corresponding selection numbers are as follows:

- Material end sensor function (function setting No. 2)
The material end sensor is enabled.

☐ ☐ ☐ **2** ☐ ☐ ☐ **1**

0: Material end sensor is not used.

1: Material end sensor is enabled.

- Thread trimming function by means of the material end sensor (function setting No. 3)
The automatic thread trimmer is activated after the detection of the material end.

☐ ☐ ☐ **3** ☐ ☐ ☐ **1**

0: Automatic thread trimming is not carried out.

1: Automatic thread trimming is carried out.

- The number of stitches after the activation of the material end sensor (function setting No. 4)
The number of stitches to be sewn until the sewing machine stops after the material end sensor has detected the material end can be specified.

☐ ☐ ☐ **4** ☐ ☐ ☐ **5**

Data setting range: 0 - 19 <1/stitch>

- One-shot function (function setting No. 76)
The one-shot operation until the material end is detected can be set.

☐ ☐ **7** **6** ☐ ☐ ☐ **0**

0: One-shot operation is not carried out.


1: One-shot operation is carried out.

- (Caution)**
1. Be sure to turn OFF the power before connecting the connector.
 2. For the use of the material end sensor, refer to the Instruction Manual attached to the material end sensor.

JUKI genuine part number	Connector	HK042310040
	Pin connector	HK042340000

16. Initialization of the setting data

All contents of function setting of SC-921 can be returned to the standard set values.



- 1) Turn ON the POWER switch with all of switch 4, switch 5 and 6 held pressed.
- 2) "rS" is displayed on indicator (B) with a blip to start initialization.
- 3) The buzzer sounds after approximately one second (single sound three times, "peep", "peep", and "peep"), and the setting data returns to the standard setting value.

(Caution) Do not turn OFF the power on the way of initializing operation. Program of the main unit may be broken.

- 4) Turn OFF the power switch and turn ON the power switch after closing the front cover. The machine returns to the normal motion.

- (Caution)**
1. When you carry out the aforementioned operation, the neutral position correction value for the pedal sensor is also initialized. It is therefore necessary to carry out automatic correction of the pedal sensor neutral position before using the sewing machine. (Refer "[III-9. Automatic compensation of neutral point of the pedal sensor](#)" p. 37.)
 2. When you carry out the aforementioned operation, the machine-head adjustment values are also initialized. It is therefore necessary to carry out adjustment of the machine head before using the sewing machine. (Refer "[II-6. Adjusting the machine head](#)" p. 13.)
 3. Even when this operation is performed, the sewing data set by the operation panel cannot be initialized.


IV. MAINTENANCE

1. Removing the rear cover




WARNING :


To prevent personal injuries caused by electric shock hazards or abrupt start of the sewing machine, remove the cover after turning OFF the power switch and a lapse of 5 minutes or more. To prevent personal injuries, when a fuse has blown out, be sure to replace it with a new one with the same capacity after turning OFF the power switch and removing the cause of the blown-out of the fuse.



- 1) Press the OFF button of the power switch to turn OFF the power after confirming that the sewing machine has stopped.
- 2) Draw out the power cord coming from the power plug socket after confirming that the power switch is turned OFF. Perform the work of step 3) after confirming that the power has been cut and it has passed for 5 minutes or more.




3) Loosen setscrew **2** in cover **1**. Open cover **1**.



4) To close cover **1**, re-tighten setscrew **2** while paying attention to the orientation of cable clip band **3** mounted on the side face of the box.

2. Replacing the fuse

(Caution) The illustration below shows the PWR-T PCB. The type of PCB differs by destination.



- 1) Remove all the cables which are connected to the control box.
- 2) Remove the connecting rod.
- 3) Remove the control box from the table stand.
- 4) Holding the glass section of fuse **1**, remove the fuse.

(Caution) There is a risk of electrical shock when removing the fuse. Be sure to remove the fuse after LED **2** has totally gone out.

5) Be sure to use a fuse with the designated capacity.

1 : 3.15 A/250 V Time-lag fuse

(Power circuit protective fuse)

Part number: KF000000080

6) Install the control box on the table stand. (Refer to "[II-1. Installing to the table](#)" p. 1.)

7) Connect all the cables to the control box. (Refer to "[II-3. Connecting the cords](#)" p. 3.)


8) Fit the connecting rod back in place. (Refer to "[II-4. Attaching the connecting rod](#)" p. 11.)

3. Error codes

In case of the following, check again before you judge the case as trouble.

Phenomenon	Cause	Corrective measure
When tilting the sewing machine, the buzzer beeps and the sewing machine cannot be operated. Solenoids for thread trimming	When tilting the sewing machine without turning OFF the power switch, Action given on the left side is taken for safety sake.	Tilt the sewing machine after turning OFF the power.
Solenoids for thread trimming, reverse feed, wiper, etc. fail to work. Hand lamp does not light up.	When the fuse for solenoid power protection has blown out	Check the fuse for solenoid power protection.
Even when depressing the pedal immediately after turning ON the power, the sewing machine does not run. When depressing the pedal after depressing the back part of pedal once, the sewing machine runs.	Neutral position of the pedal has varied. (Neutral position may be shifted when changing spring pressure of the pedal or the like.)	Execute the automatic neutral correction function of the pedal sensor.
The sewing machine does not stop even when the pedal is returned to its neutral position.		
Stop position of the sewing machine varies (irregular).	When tightening the screw in the handwheel is forgotten at the time of adjustment of needle stop position.	Securely tighten the screw in the handwheel.
Presser foot does not go up even when auto-lifter device is attached.	Auto-lifter function is OFF.	Select "FL ON" by auto-lifter function selection.
	Pedal system is set to KFL system.	Change the jumper to PFL setting to lift the presser foot by depressing the back part of the pedal.
	Cord of auto-lifter device is not connected to connector (CN37).	Connect the cord properly.
Touch-back switch fails to work.	Presser foot is going up by auto-lifter device.	Operate the switch after the presser foot lowered.
	Auto-lifter device is not attached. However, auto-lifter function is ON.	Select "FL OFF" when auto-lifter device is not attached.
UP position move fails to work when all lamps on the panel light up.	The mode is in the function setting mode. The switch on the CTL p.c.b. is pressed by the bound cords and the aforementioned mode resulted.	Remove the under cover. Bundle the cables by routing them according to the normal routing method as described in the Instruction Manual.
Sewing machine fails to run.	Motor output cord (4P) is disconnected.	Connect the cord properly.
	Connector (CN30) of motor signal cord is disconnected.	Connect the cord properly.

In addition, there are the following error codes in this device. These error codes interlock (or limit function) and inform the problem so that the problem is not enlarged when any problem is discovered. When you request our service, please confirm the error codes.



[Checking procedure of the error code]

- 1) Turn ON the power switch with switch ① held pressed.
- 2) The latest error number is displayed on indicator ② with a blip.
- 3) Contents of previous errors can be checked by pressing switch ③ or switch ④.

(When the confirmation of the contents of previous error advanced to the last, the warning sound peeps in single tone two times.)

(Caution) When switch ③ is pressed, the previous error code of the currently displayed one is displayed. When switch ④ is pressed, the next error code of the currently displayed one is displayed.

Error code list

No.	Description of error detected	Cause of occurrence expected	Items to be checked
E000	Execution of data initialization (This is not the error.)	<ul style="list-style-type: none"> When the machine head is changed. When the initialization operation is executed. 	
E003	Disconnection of synchronizer connector	<ul style="list-style-type: none"> When position detection signal is not input from the sewing machine head synchronizer. 	<ul style="list-style-type: none"> Check the synchronizer connector (CN33) for loose connection and disconnection.
E004	Synchronizer lower position sensor failure	<ul style="list-style-type: none"> When the synchronizer has broken. 	<ul style="list-style-type: none"> Check whether the synchronizer cord has broken since the cord is caught in the machine head. Check the belt tension. Check the setting of the machine head. Check the setting of the motor pulley.
E005	Synchronizer upper position sensor failure	<ul style="list-style-type: none"> Belt is loose. Machine head is not proper. Motor pulley is not proper. 	
E007	Overload of motor	<ul style="list-style-type: none"> When the machine head is locked. When sewing extra-heavy material beyond the guarantee of the machine head. When the motor does not run. Motor or driver is broken. 	<ul style="list-style-type: none"> Check whether the thread has been entangled in the motor pulley. Check the motor output connector (4P) for loose connection and disconnection. Check whether there is any holdup when turning the motor by hand.
E011(*)	CompactFlash(TM), not yet inserted	<ul style="list-style-type: none"> CompactFlash(TM) is not yet inserted. 	<ul style="list-style-type: none"> Reset by resetting operation.
E012(*)	Read error	<ul style="list-style-type: none"> Data cannot be read out from CompactFlash(TM). 	<ul style="list-style-type: none"> Reset by resetting operation.
E013(*)	Write error	<ul style="list-style-type: none"> Data cannot be written on CompactFlash(TM). 	<ul style="list-style-type: none"> Reset by resetting operation.
E014(*)	Write protect	<ul style="list-style-type: none"> CompactFlash(TM) is in the write-protect state. 	<ul style="list-style-type: none"> Reset by resetting operation.
E015(*)	Format error	<ul style="list-style-type: none"> Formatting cannot be executed. 	<ul style="list-style-type: none"> Reset by resetting operation.
E016(*)	External media capacity exceeded	<ul style="list-style-type: none"> Capacity of CompactFlash(TM) is not enough. 	<ul style="list-style-type: none"> Reset by resetting operation.
E019(*)	File size exceeded	<ul style="list-style-type: none"> The file size exceeds the allowable limit. 	<ul style="list-style-type: none"> Reset by resetting operation.
E021(*)	Access error	<ul style="list-style-type: none"> File access fault. 	<ul style="list-style-type: none"> Reset by resetting operation.
E032(*)	File compatibility error	<ul style="list-style-type: none"> File is not compatible. 	<ul style="list-style-type: none"> Turn the power OFF.

* The error numbers marked with an asterisk (*) are displayed only when a fault takes place with the IP panel connected to the control box.

No.	Description of error detected	Cause of occurrence expected	Items to be checked
E053(*)	IP panel initialization executed (Not an error)	<ul style="list-style-type: none"> In the case the model code of the IP panel and that of the control box do not match. In the case the IP panel initialization is executed.. 	<ul style="list-style-type: none"> Turn the power OFF.
E070	Slip of belt	<ul style="list-style-type: none"> When the machine head is locked. Belt is loose. 	<ul style="list-style-type: none"> Check whether there is any holdup when turning the motor by hand. Check the belt tension.
E071	Disconnection of motor output connector	<ul style="list-style-type: none"> Disconnection of motor connector. 	<ul style="list-style-type: none"> Check the motor output connector for loose connection and disconnection.
E072	Overload of motor at the time of thread trimming motion	<ul style="list-style-type: none"> Same as E007. 	<ul style="list-style-type: none"> Same as E007.
E220	Grease-up warning	<ul style="list-style-type: none"> When the predetermined number of stitches has been reached. 	<ul style="list-style-type: none"> Replenish the specified places with grease and reset. (For the details, refer to the data of the machine head.)
E221	Grease-up error	<ul style="list-style-type: none"> When the predetermined number of stitches has been reached and the sewing is not possible. 	<ul style="list-style-type: none"> Replenish the specified places with grease and reset. (For the details, refer to the data of the machine head.)
E302	Fall detection switch failure (When the safety switch works)	<ul style="list-style-type: none"> When fall detection switch is input in the state that the power is turned ON. Thread trimming knife position is not correct. Machine-head tilt detector's connector has come off. 	<ul style="list-style-type: none"> Check whether the machine head is tilted without turning OFF the power switch (sewing machine operation is prohibited for safety sake). Check whether the fall detection switch cord is caught in the sewing machine or the like. Check whether the fall detection switch lever is caught in something. Check whether the contact of the tilt detection switch lever with the machine table is inadequate. (The table has a dent or the mounting location of the bed strut is too far.) Check the machine-head tilt detector's connector (CN48) for looseness and slip-off.
E303	Semicircular plate sensor error	<ul style="list-style-type: none"> Semicircular plate sensor signal cannot be detected. 	<ul style="list-style-type: none"> Check whether the machine head corresponds with the machine type setting. Check whether the motor encoder connector is disconnected.
E331	Tape cutter device sensors are turned ON simultaneously	<ul style="list-style-type: none"> Faulty operation of the tape cutter device. 	<ul style="list-style-type: none"> Check whether the tape cutter device is connected properly. Check whether the pneumatic pressure is adequate.
E332	Tape cutter device sensors are turned OFF simultaneously	<ul style="list-style-type: none"> Faulty assembly and adjustment of the tape cutter device. 	<ul style="list-style-type: none"> Check whether the tape cutter device is properly assembled.
E499	Data fault	<ul style="list-style-type: none"> The stored data have broken. 	<ul style="list-style-type: none"> Reset all data on the function setting to the default values referring to "Initializing the function setting data" in the Engineer's Manual.
E704	Data fault	<ul style="list-style-type: none"> The stored data have broken. 	<ul style="list-style-type: none"> Reset all data on the function setting to the default values referring to "Initializing the function setting data" in the Engineer's Manual.
E704(*)	System version mismatch		<ul style="list-style-type: none"> In the case the IP panel system version does not match the sewing machine head version, turn the power OFF. Match the IP panel system version with the sewing machine head version.
E730	Encoder failure	<ul style="list-style-type: none"> When the motor signal is not properly inputted. 	<ul style="list-style-type: none"> Check the motor signal connector (CN30) for loose connection and disconnection. Check whether the motor signal cord has broken since the cord is caught in the machine head.
E731	Motor hole sensor failure		<ul style="list-style-type: none"> Check whether the inserting direction of the motor encoder connector is wrong.

* The error numbers marked with an asterisk (*) are displayed only when a fault takes place with the IP panel connected to the control box.

No.	Description of error detected	Cause of occurrence expected	Items to be checked
E733	Inverse rotation of motor	<ul style="list-style-type: none"> This error occurs when the motor is running at 500 sti/min or more in the opposite direction of that of rotation indication during motor is running. 	<ul style="list-style-type: none"> Connection of the encoder of main shaft motor is wrong. Connection for the electric power of main shaft motor is wrong.
E799	Thread trimming operation time-out	<ul style="list-style-type: none"> The thread trimmer control operation is not completed within the predetermined time period. 	<ul style="list-style-type: none"> Check whether the function setting No. 95 (Head selection function) has been set correctly. Check whether the motor pulley diameter agrees with the setting. Check whether the belt has slackened.
E808	Solenoid short circuit	<ul style="list-style-type: none"> Solenoid power does not become normal voltage. 	<ul style="list-style-type: none"> Check whether the machine head cord is caught in the pulley cover or the like.
E809	Holding motion failure	<ul style="list-style-type: none"> Solenoid is not changed over to holding motion. 	<ul style="list-style-type: none"> Check whether the solenoid is abnormally heated. (CTL circuit board asm. Circuit is broken.)
E810	Solenoid current abnormality	<ul style="list-style-type: none"> Solenoid rare short-circuit. 	<ul style="list-style-type: none"> Solenoid resistance.
E811	Abnormal voltage	<ul style="list-style-type: none"> When voltage higher than guaranteed one is inputted. 200V has been inputted to SC-921 of 100V specifications. 220V is applied to 120V box. CE : 400V is applied to 230V box. When voltage lower than guaranteed one is inputted. 100V has been inputted to SC-921 of 200V specifications. 120V is applied to 220V box. Inner circuit is broken by the applied over-voltage. 	<ul style="list-style-type: none"> Check whether the applied power voltage is higher than the rated voltage + (plus) 10% or more. Check whether 100V/200V changeover connector is improperly set. In the aforementioned cases, POWER p.c.b is broken. Check whether the voltage is lower than the rated voltage - (minus) 10% or less. Check whether 100V/200V changeover connector is improperly set. Check whether fuse or regenerative resistance is broken.
E906	Operation panel transmission failure	<ul style="list-style-type: none"> Disconnection of operation panel cord. Operation panel has broken. 	<ul style="list-style-type: none"> Check the operation panel connector (CN38) for loose connection and disconnection. Check whether the operation panel cord has broken since the cord is caught in the machine head.
E920(*)	Faulty GA	<ul style="list-style-type: none"> Faulty gate array. 	<ul style="list-style-type: none"> Turn the power OFF.
E922	Main shaft uncontrollable	<ul style="list-style-type: none"> In the case the main shaft cannot be controlled. 	<ul style="list-style-type: none"> Turn the power OFF.
E924	Motor driver failure	<ul style="list-style-type: none"> Motor driver has broken. 	
E930	Faulty encoder	<ul style="list-style-type: none"> In the case a motor signal cannot be input correctly. 	<ul style="list-style-type: none"> Check the motor signal connector (CN30) for looseness and slip-off. Check whether the motor signal cord is caught in the machine head or has a break.
E931	Motor hole sensor failure		
E941(*)	Faulty GA	<ul style="list-style-type: none"> Faulty gate array. 	<ul style="list-style-type: none"> Turn the power OFF.
E942	Faulty EEPROM	<ul style="list-style-type: none"> Data cannot be written on the EEPROM. 	<ul style="list-style-type: none"> Turn the power OFF.

* The error numbers marked with an asterisk (*) are displayed only when a fault takes place with the IP panel connected to the control box.

